





SLC™ 8000 Advanced Console Manager User Guide

Part Number 900-704-R Revision J March 2018

Intellectual Property

© 2018 Lantronix, Inc. All rights reserved. No part of the contents of this publication may be transmitted or reproduced in any form or by any means without the written permission of Lantronix.

Lantronix and *Lantronix Spider* are registered trademarks of Lantronix, Inc. in the United States and other countries. *SLC and vSLM* are trademarks of Lantronix, Inc.

Patented: patents.lantronix.com; additional patents pending.

Windows and *Internet Explorer* are registered trademarks of Microsoft Corporation. *Firefox* is a registered trademark of the Mozilla Foundation. *Chrome* and *iGoogle* are trademarks of Google Inc. All other trademarks and trade names are the property of their respective holders.

Warranty

For details on the Lantronix warranty policy, please go to our web site at <u>http://www.lantronix.com/support/warranty</u>.

Contacts

Lantronix Corporate Headquarters

7535 Irvine Center Drive Suite100 Irvine, CA 92618, USA

Toll Free:800-526-8766Phone:949-453-3990Fax:949-453-3995

Technical Support

Online: www.lantronix.com/support

Sales Offices

For a current list of our domestic and international sales offices, go to the Lantronix web site at <u>www.lantronix.com/about/contact</u>.

GNU General Public License Notice

This product includes open source software, including software subject to the GNU General Public Licenses ("GPL"). Lantronix will provide a CD-ROM containing the source files subject to the GPL upon request by mail. To request a CD containing the source files, send a check payable to "Lantronix, Inc." for US \$50.00 (per product) to the address below. This nominal charge covers Lantronix' costs for duplication, media, and postage. Your request should identify the Lantronix product for which source code is desired, and the check must indicate "Open Source CD Request". Please allow 6-8 weeks for the CD to be shipped. For GPL source code requests or inquiries please contact write to Lantronix, Inc., Attn: Open Source Request, 7535 Irvine Center Drive, Irvine, CA 92618 USA. Any GPL Code made available is for informational purposes only and distributed "As is" with no support and/or warranty of any kind intended, implied, or provided.

Disclaimer & Revisions

All information contained herein is provided "AS IS." Lantronix undertakes no obligation to update the information in this publication. Lantronix does not make, and specifically disclaims, all warranties of any kind (express, implied or otherwise) regarding title, non-infringement, fitness, quality, accuracy, completeness, usefulness, suitability or performance of the information provided herein. Lantronix shall have no liability whatsoever to any user for any damages, losses and causes of action (whether in contract or in tort or otherwise) in connection with the user's access or usage of any of the information or content contained herein. The information and specifications contained in this document are subject to change without notice.

Operation of this equipment in a residential area is likely to cause interference, in which case the user, at his or her own expense, will be required to take whatever measures may be required to correct the interference.

Note: This equipment has been tested and found to comply with the limits for Class A digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with this User Guide, may cause interference to radio communications. Operation of this equipment in a residential area is likely to cause interference, in which case the user will be required to correct the interference at his own expense.

User Information

Class A Equipment (Broadcasting and communication equipments for office work)

Seller and user shall be noticed that this equipment is suitable for electromagnetic equipments for office work (Class A) and it can be used outside home.

Changes or modifications made to this device that are not explicitly approved by Lantronix will void the user's authority to operate this device.

声明 此为A级产品,在生活环境中,该产品可能会造成无线电干扰。在这种情况下,可能需要用户对其干扰采取切实可行的措施。

사용자안내문

기 종 별	사용자안내문
A 급 기기	이 기기는 업무용 (A 급) 전자파적합기기로서
(업무용방송통신기자재)	판매자 또는 사용자는 이 점을 주의하시기
	바라며 , 가정외의 지역에서 사용하는 것을
	목적으로 합니다.

Revision History

Date	Rev.	Comments
March 2014	А	Preliminary release.
October 2014	В	Initial document for firmware release 7.1.0.0.
June 2015	С	Updated for firmware release 7.2.0.0.
		Changes include new operating atmosphere information and warning language in Chinese and Korean. Software changes include additions in Telnet, SSH and TCP timeout directions, number of sessions message, idle timeout message, VBUS enabling, assert DTR, run web server, added mounted column information for NFS Mounts, masked CHAP secret and DOD CHAP secret fields, USB devices in diagnostics and addition of SSH bit option. SSL settings were removed so the SSLv2 protocol option is no longer available.
June 2016	D	Updated for firmware release 7.3.0.0.
January 2017	E	Updated power cord information.
June 2017	F	Updated for firmware release 7.4.0.0 and for new dual SFP transceiver port or dual Ethernet port capability options. Updated the following:
		 IPv6 Neighbor Table, Ethernet Bonding Status links, and IPv6 Forward Flag under Network Settings. IKE v2, x.509 Certificate, Certificate Authority/Certificate File fore Remote Peer, Certificate Authority/Certificate File/Key File for Local Peer, SA Lifetime, Remote and Dead Peer settings under Network VPN. Enable v1/v2c, Trap Version, Alarm Delay to SNMP, and Trap User Name, Password and Passphrase under SNMP Services. Added ability change and reset BootCount, BootDelay and BootLimit.
September 2017	G	Updated part number.
February 2018	Н	Updated for firmware release 7.5.0.0.
March 2018	J	Updated to include additional SLC hardware and new trap information for firmware release 7.5.0.0.

Table of Contents

Intellectual Property	2
Warranty	2
Contacts	2
GNU General Public License Notice	2
Disclaimer & Revisions	3
User Information	3
Revision History	4
List of Figures	14
List of Tables	18

1: About this Guide

Purpose and Audience	19
Summary of Chapters	19
Additional Documentation	20

2: Introduction

Features 21 21 Console Management Power 22 22 Hardware _____ System Features ______24 Protocols Supported _____25 Access Control _____25 Device Port Buffer _____25 _____ 25 Configuration Options Device Port and Console Port Interfaces 26 Network Connections _____29 Front Panel USB Ports ______30 Memory Card Port _______ 30 Internal Modem 31

3: Installation

What's in the Box	32
Customize an SLC 8000	33
Product Label	34
Technical Specifications	34
Physical Installation	36
Connecting to a Device Port	36
Modular Expansion for I/O Module Bays	38

32

19

Connecting to Network Ports	39
Connecting Terminals	39
AC Input	40
Modem Installation	41
Battery Replacement	44

4: Quick Setup

Recommendations	48
IP Address	48
Method #1 Using the Front Panel Display	49
Front Panel LCD Display and Keypads	49
Navigating	49
Entering the Settings	51
Restoring Factory Defaults	52
Method #2 Quick Setup on the Web Page	52
Network Settings	54
Date & Time Settings	54
Administrator Settings	54
Method #3 Quick Setup on the Command Line Interface	55
Next Step	58

5: Web and Command Line Interfaces

Web Manager	59
Logging in	61
Logging Out	61
Web Page Help	62
Command Line Interface	62
Logging In	62
Logging Out	62
Command Syntax	63
Command Line Help	63
Tips	63

6: Basic Parameters

Requirements	66
Network Port Settings	67
Ethernet Interfaces (Eth1 and Eth2)	70
Gateway	72
Hostname & Name Servers	73
DNS Servers	73
DHCP-Acquired DNS Servers	73
TCP Keepalive Parameters	73

Ethernet Counters	73
Network Commands	74
IP Filter	74
Viewing IP Filters	74
Mapping Rulesets	75
Enabling IP Filters	75
Configuring IP Filters	76
Rule Parameters	77
Updating an IP Filter	77
Deleting an IP Filter	78
IP Filter Commands	78
Routing	78
Dynamic Routing	78
Static Routing	79
Routing Commands	79
VPN	79
VPN Commands	84
Security	85
Performance Monitoring	87
Performance Monitoring - Add/Edit Probe	90
Performance Monitoring - Results	
Performance Monitoring Commands	96

7: Services

System Logging and Other Services	97
SSH/Telnet/Logging	98
System Logging	99
Audit Log	99
SMTP	99
SSH	100
Telnet	100
Web SSH/Web Telnet Settings	101
Phone Home	101
SSH Commands	101
Logging Commands	101
SNMP	102
v1/v2c Communities	104
Version 3	104
V3 User Read-Only	104
V3 User Read-Write	105
V3 User Trap	105
Services Commands	105
NFS and SMB/CIFS	105

SMB/CIFS Share	107
NFS and SMB/CIFS Commands	107
Secure Lantronix Network	108
Browser Issues	111
Secure Lantronix Network Commands	113
Date and Time	113
Date and Time Commands	115
Web Server	116
Admin Web Commands	118
Services - Web Sessions	118
Services - SSL Certificate	118
iGoogle Gadgets	121

8: Device Ports

Connection Methods	123
Permissions	123
I/O Modules	124
Device Status	125
Device Ports	126
Telnet/SSH/TCP in Port Numbers	127
DevicePort Global Commands	127
Device Ports - Settings	128
Device Port Settings	130
IP Settings	132
Data Settings	133
Hardware Signal Triggers	134
Modem Settings (Device Ports)	135
Modem Settings: Text Mode	136
Modem Settings: PPP Mode	136
Port Status and Counters	138
Device Ports - Power Management	138
Device Ports - RPMs - Add Device	140
Device Port - Sensorsoft Device	142
Device Port Commands	143
Device Commands	143
Interacting with a Device Port	143
Device Ports - Logging and Events	144
Local Logging	144
NFS File Logging	144
USB and SD Card Logging	145
Token/Data Detection	145
Syslog Logging	145
Token & Data Detection	146

ey S	Sec	lne	nce	es	_											
/ S	D	C	ar	d	Po	or	t									
p of	U:	SB	/SE) C	arc	d S	Sto	rag	е.							
ata	Se	ttin	gs	_												_
ode	em	Se	ttin	igs												
nce	d (Cor	ıso	ole l	Ма	na	age	r U	ser	G	uide	е				
1100	u	501	130		via	iia	ge	10	301	9	un					
	y S S of ita ode	y Sec SD of Us ta Se odem	y Seque SD C of USB/ ta Settin odem Se	y Sequence Sequence Sequence Sequence of USB/SE ta Settings odem Settin aced Consc	y Sequences Sequences SD Card of USB/SD C ta Settings odem Settings	y Sequences y Sequences SD Card P(of USB/SD Card ita Settings odem Settings odem Settings	SCP Client y Sequences SD Card Por of USB/SD Card S ta Settings odem Settings odem Settings	y Sequences y Sequences SD Card Port of USB/SD Card Stor ta Settings odem Settings odem Settings	SCP Client y Sequences /SD Card Port of USB/SD Card Storag ita Settings odem Settings odem Settings	y Sequences y Sequences SD Card Port of USB/SD Card Storage ta Settings odem Settings nced Console Manager User	y Sequences y Sequences of USB/SD Card Storage ta Settings odem Settings nced Console Manager User G	y Sequences y Sequences of USB/SD Card Storage ta Settings odem Settings odem Settings	y Sequences y Sequences of USB/SD Card Storage ta Settings odem Settings odem Settings	y Sequences y Sequences of USB/SD Card Storage ta Settings odem Settings nced Console Manager User Guide	SCP Client y Sequences y Sequences /SD Card Port of USB/SD Card Storage ita Settings odem Settings odem Settings inced Console Manager User Guide	SCP Client

Local Logging	148
Log Viewing Attributes	
NFS File Logging	
USB / SD Card Logging	
Syslog Logging	
Logging Commands	149
Console Port	
Console Port Commands	150
Internal Modem Settings	150
Setting Up Internal Modem Storage	150
Internal Modem Commands	154
Host Lists	154
Host Parameters	155
Host Parameters	156
Host List Commands	157
Scripts	157
Scripts	159
User Rights	160
CLI Commands	161
Batch Script Syntax	161
Interface Script Syntax	162
Primary Commands	163
Secondary Commands	165
Control Flow Commands	166
Sample Scripts	167
Batch Script—SLC CLI	169
Sites	172
Site Commands	174
Modem Dialing States	175
Dial In	175
Dial-back	175
Dial-on-demand	176
Dial-in & Dial-on-demand	176
Dial-back & Dial-on-demand	177
CBCP Server and CBCP Client	178
CBCP Server	178
CBCP Client	179
Key Sequences	179

__181 __185 __185

Text Mode 186 PPP Mode 187 IP Settings 188 Manage Files 188 USB Commands 189 SD Card Commands 189

10: Remote Power Managers

Devices - RPMs	190
RPMs - Add Device	193
RPMs - Manage Device	196
RPMs - Outlets	199
RPM Shutdown Procedure	200
Optimizing and Troubleshooting RPM Behavior	202
RPM Commands	203

11: Connections

ypical Setup Scenarios for the SLC Unit	204
Terminal Server	204
Remote Access Server	205
Reverse Terminal Server	205
Multiport Device Server	206
Console Server	206
Connection Configuration	207
Connection Commands	209

12: User Authentication

Authentication Commands	212
User Rights	212
Local and Remote User Settings	214
Adding, Editing or Deleting a User	215
Shortcut	219
Local Users Commands	219
Remote User Rights Commands	219
NIS	220
NIS Commands	223
LDAP	223
LDAP Commands	227
RADIUS	228
RADIUS Commands	231
User Attributes & Permissions from LDAP Schema or RADIUS VSA	231
Kerberos	232

204

210

Kerberos Commands	235
TACACS+	235
TACACS+ Groups	236
TACACS+ Commands	239
Groups	240
Group Commands	243
SSH Keys	243
Imported Keys	243
Exported Keys	243
Imported Keys (SSH In)	245
Host & Login for Import	245
Exported Keys (SSH Out)	245
Host and Login for Export	246
SSH Commands	248
Custom Menus	248
Custom User Menu Commands	251

13: Maintenance

Firmware & Configurations	252
Zero Touch Provisioning Configuration Restore	252
HTTPS Push Configuration Restore	253
Internal Temperature	255
Site Information	255
SLC Firmware	255
Boot Banks and Bootloader Settings	256
Load Firmware Via Options	257
Configuration Management	257
Manage Files	259
Administrative Commands	259
System Logs	260
System Log Commands	261
Audit Log	262
Audit Log Commands	263
Email Log	263
Logging Commands	263
Diagnostics	264
Diagnostic Commands	266
Status/Reports	267
View Report	267
Status Commands	268
Emailing Logs and Reports	269
Events	271
Events Commands	272

LCD/Keypad	273
Administrative LCD/Keypad Commands	274
Banners	275
Administrative Banner Commands	276
14: Application Examples	277
Telnet/SSH to a Remote Device	277
Dial-in (Text Mode) to a Remote Device	279
Local Serial Connection to Network Device via Telnet	280
15: Command Reference	282
Introduction to Commands	282
Command	282
Command Line Help	283
Tips	283
Administrative Commands	284
Audit Log Commands	298
Authentication Commands	298
Kerberos Commands	299
LDAP Commands	300
Local Users Commands	302
NIS Commands	306
RADIUS Commands	307
TACACS+ Commands	308
User Permissions Commands	309
Remote User Commands	310
CLI Commands	312
Description	312
Connection Commands	314
Console Port Commands	317
Custom User Menu Commands	317
Date and Time Commands	319
Device Commands	320
Device Port Commands	321
Diagnostic Commands	326
Events Commands	329
Group Commands	331
Host List Commands	331
Internal Modem Commands	333
IP Filter Commands	334
Logging Commands	335
Network Commands	337
NFS and SMB/CIFS Commands	341

Performance Monitoring Commands	343
Routing Commands	347
RPM Commands	347
SD Card Commands	350
Security Commands	350
Services Commands	351
Site Commands	352
SLC Network Commands	353
SSH Key Commands	354
Status Commands	356
System Log Commands	358
USB Access Commands	358
USB Device Commands	359
USB Storage Commands	359
USB Modem Commands	362
VPN Commands	363
Appendix A: Security Considerations	366
Security Practice	366
Factors Affecting Security	366

Appendix B: Safety Information

Safety Precautions	367
Fuse Caution Statement	367
Cover	367
Power Plug	367
Input Supply	368
Grounding	368
Rack	368
Port Connections	368

Appendix C: Adapters and Pinouts369Appendix D: Protocol Glossary372

Appendix E: Compliance Information	374
RoHS, REACH and WEEE Compliance Statement	375

List of Figures

Figure 2-1 SLC 8048 Unit (Front Side) - Part Number SLC 804812N-01-S	23
Figure 2-2 SLC 8048 Unit Samples (Back Side) - Part Number SLC80482201S	24
Figure 2-3 Three 16-Port USB I/O Modules Installed in Bays 1, 2, & 3 with Dual Ethernet Port _	27
Figure 2-4 One 16-Port USB I/O Module Installed in Bay 1 with Dual Ethernet Port	27
Figure 2-5 One 16 RJ-45 Serial Port I/O Module Installed in Bay1 & Two 15 USB I/O Module Installed Bays 2 & 3 with Dual SFP Port	27
Figure 2-6 SFP Port LEDs	28
Figure 2-8 Console Port (Front Side)	28
Figure 2-10 Dual Ethernet Network Connection	29
Figure 2-11 Inserting SFP Transceiver Module into the SFP Port	29
Figure 2-12 Dual USB Ports	30
Figure 2-13 Memory Card Port	30
Figure 2-14 Internal Modem Location	31
Figure 3-3 Product Label	34
Figure 3-7 Sample Device Port Connections (Back Side)	38
Figure 3-9 AC Power Input	40
Figure 4-2 Front Panel LCD Display and Five Button Keypad (Enter, Up, Down, Left, Right)	49
Figure 4-5 Quick Setup	53
Figure 4-6 Quick Setup Completed in Web Manager	55
Figure 4-7 Home	55
Figure 4-8 Beginning of Quick Setup Script	56
Figure 4-9 Quick Setup Completed in CLI	57
Figure 5-1 Web Page Layout	59
Figure 5-2 Sample Dashboards	60
Figure 6-1 Network > Network Settings	68
Figure 6-2 Network > Network Settings (SFP Model)	69
Figure 6-3 Network Settings > SFP NIC Information & Diagnostics	70
Figure 6-4 Network > IP Filter	74
Figure 6-5 Network > IP Filter Ruleset (Adding/Editing Rulesets)	76
Figure 6-6 Network > Routing	78
Figure 6-7 Network > VPN (1 of 2)	80
Figure 6-8 Network > VPN (2 of 2)	81
Figure 6-9 Network > Security	86
Figure 6-10 Network > Perf Monitoring	88
Figure 6-11 Performance Monitoring - Add/Edit Probe	90

Figure 6-13 Performance Monitoring - Operations	95
Figure 7-1 Services > SSH/Telnet/Logging	98
Figure 7-2 Services > SNMP	102
Figure 7-3 Services > NFS & SMB/CIFS	106
Figure 7-4 Services > Secure Lantronix Network	108
Figure 7-5 IP Address Login Page	109
Figure 7-6 SSH and Telnet Opening File Popups	109
Figure 7-7 SSH or Telnet CLI Session	110
Figure 7-8 Disabled Port Number Popup Window	111
Figure 7-9 Services > Secure Lantronix Network > Search Options	112
Figure 7-10 Services > Date & Time	114
Figure 7-11 Services > Web Server	116
Figure 7-12 Web Sessions	118
Figure 7-13 SSL Certificate	119
Figure 7-14 iGoogle Gadget Example	122
Figure 8-2 Devices > Device Status	125
Figure 8-3 Devices > Device Ports	126
Figure 8-4 Device Ports > Settings (1 of 2)	129
Figure 8-5 Device Ports > Settings (2 of 2)	130
Figure 8-7 Device Ports - Power Management	139
Figure 8-8 Device Ports > RPMs - Add Device	141
Figure 8-9 Devices > Device Ports > Sensorsoft	142
Figure 8-10 Sensorsoft Status	143
Figure 8-11 Devices > Device Ports - Logging & Events	146
Figure 8-12 Devices > Console Port	149
Figure 8-13 Devices > Internal Modem	151
Figure 8-14 Devices > Host Lists	154
Figure 8-15 View Host Lists	156
Figure 8-16 Devices > Scripts	158
Figure 8-17 Adding or Editing New Scripts	159
Figure 8-22 Devices > Sites	172
Figure 9-1 Devices > USB / SD Card	182
Figure 9-2 Devices > SD Card > Configure	182
Figure 9-3 Devices > USB > Configure	183
Figure 9-4 Devices > USB > Modem	184
Figure 9-5 Firmware and Configurations - Manage Files	188
Figure 10-1 Devices > RPMs	190
Figure 10-2 RPM Shutdown Order	191

Figure 10-3 RPM Notifications	192
Figure 10-4 RPM Raw Data Log	192
Figure 10-5 RPM Logs	193
Figure 10-6 RPM Environmental Log	193
Figure 10-7 Device Ports > RPMs - Add Device	194
Figure 10-8 RPMs - Managed Device	197
Figure 10-9 RPMs - Outlets	200
Figure 11-1 Terminal Server	205
Figure 11-2 Remote Access Server	205
Figure 11-3 Reverse Terminal Server	205
Figure 11-4 Multiport Device Server	206
Figure 11-5 Console Server	206
Figure 11-6 Devices > Connections	207
Figure 11-7 Current Connections	209
Figure 12-1 User Authentication > Authentication Methods	211
Figure 12-3 User Authentication > Local/Remote Users	214
Figure 12-4 User Authentication > Local/Remote User > Add/Edit User	216
Figure 12-5 User Authentication > NIS	220
Figure 12-6 User Authentication > LDAP	224
Figure 12-7 User Authentication > RADIUS	228
Figure 12-8 User Authentication > Kerberos	233
Figure 12-9 User Authentication > TACACS+	237
Figure 12-10 User Authentication > Groups	241
Figure 12-11 User Authentication > SSH Keys	244
Figure 12-12 Current Host Keys	247
Figure 12-13 User Authentication > Custom Menus	249
Figure 13-1 Maintenance > Firmware & Configurations	254
Figure 13-2 Network > Firmware/Config > Manage	259
Figure 13-3 Maintenance > System Logs	260
Figure 13-4 System Logs	261
Figure 13-5 Maintenance > Audit Log	262
Figure 13-6 Maintenance > Email Log	263
Figure 13-7 Maintenance > Diagnostics	264
Figure 13-8 Maintenance > Diagnostics	266
Figure 13-9 Maintenance > Status/Reports	267
Figure 13-10 Generated Status/Reports	268
Figure 13-11 Emailed Log or Report	269
Figure 13-12 About SLC	270

Figure 13-13 Maintenance > Events	271
Figure 13-14 Maintenance > LCD/Keypad	273
Figure 13-15 Maintenance > Banners	275
Figure 14-1 SLC - Console Manager Configuration	277
Figure 14-2 Remote User Connected to a SUN Server via the SLC unit	277
Figure 14-3 Dial-in (Text Mode) to a Remote Device	279
Figure 14-4 Local Serial Connection to Network Device via Telnet	280
Figure C-1 RJ45. Receptacle to DB25M DCE Adapter for the SLC unit (PN 200.2066A)	369
Figure C-2 RJ45 Receptacle to DB25F DCE Adapter for the SLC unit (PN 200.2067A)	370
Figure C-3 RJ45 Receptacle to DB9M DCE Adapter for the SLC unit (PN 200.2069A)	370
Figure C-4 RJ45 Receptacle to DB9F DCE Adapter for the SLC unit (PN 200.2070A)	371
Figure C-5 RJ45 Receptacle to DB25M DTE Adapter (PN 200.2073)	371

List of Tables

Table 2-7 Device (DCE Reversed & DTE) Port Pinout	28
Table 2-9 Console (DTE) Port Pinout	28
Table 3-1 What's in the Box	32
Table 3-2 Optional Accessories	33
Table 3-4 SLC Technical Specifications	34
Table 3-5 Console Port and Device Port - Reverse Pinout Disabled	37
Table 3-6 Device Port - Reverse Pinout Enabled (Default)	37
Table 3-8 Available I/O Module Configurations	39
Table 4-1 Methods of Assigning an IP Address	48
Table 4-3 LCD Arrow Keypad Actions	50
Table 4-4 Front Panel Setup Options with Associated Parameters	50
Table 5-3 SCS Commands	64
Table 5-4 CLI Keyboard Shortcuts	65
Table 6-12 Error Conditions	94
Table 8-1 Supported I/O Module Configurations	124
Table 8-6 Port Status and Counters	138
Table 8-18 Definitions	162
Table 8-19 Primary Commands	163
Table 8-20 Secondary Commands	165
Table 8-21 Control Flow Commands	166
Table 12-2 User Types and Rights	212
Table 15-1 Actions and Category Options	282

1: About this Guide

Purpose and Audience

This guide provides the information needed to install, configure, and use the Lantronix SLC[™] 8000 advanced console manager. The SLC unit is for IT professionals who must remotely and securely configure and administer servers, routers, switches, telephone equipment, or other devices equipped with a serial port for facilities that are typically remote branch offices or "distributed" IT locations.

Summary of Chapters

The remaining chapters in this guide include:

Chapter	Description
Chapter 2: Introduction	Describes the SLC 8000 models, their main features, and the protocols they support.
Chapter 3: Installation	Provides technical specifications; describes connection form factors and power supplies; provides instructions for installing the SLC 8000 advanced console manager in a rack.
Chapter 4: Quick Setup	Provides instructions for getting your SLC unit up and running and for configuring required settings.
Chapter 5: Web and Command Line Interfaces	Describes the web and command line interfaces available for configuring the SLC 8000 advanced console manager.
	The configuration chapters (6-12) provide detailed instructions for using the web interface and include equivalent command line interface commands.
Chapter 6: Basic Parameters	Provides instructions for configuring network ports, firewall and routing settings, and VPN.
Chapter 7: Services	Provides instructions for enabling and disabling system logging, SSH and Telnet logins, SNMP, SMTP, and the date and time.
Chapter 8: Device Ports	Provides instructions for configuring global device port settings, individual device port settings, and console port settings.
Chapter 9: USB/SD Card Port	Provides instructions for using the USB port.
Chapter 10: Remote Power Managers	Provides instructions for using RPMs.
Chapter 11: Connections	Provides instructions for configuring connections and viewing, updating, or disconnecting a connection.
Chapter 12: User Authentication	Provides instructions for enabling or disabling methods that authenticate users who attempt to log in via the web, SSH, Telnet, or the console port. Provides instructions for creating custom menus.
Chapter 13: Maintenance	Provides instructions for upgrading firmware, viewing system logs and diagnostics, generating reports, and defining events. Includes information about web pages and commands used to shut down and reboot the SLC 8000 advanced console manager.
Chapter 14: Application Examples	Shows how to set up and use the SLC unit in three different configurations.

Chapter (continued)	Description
Chapter 15: Command Reference	Lists and describes all of the commands available on the SLC command line interface
Appendix A: Security Considerations	Provides tips for enhancing SLC security.
Appendix B: Safety Information	Lists safety precautions for using the SLC 8000 advanced console manager.
Appendix C: Adapters and Pinouts	Includes adapter pinout diagrams.
Appendix D: Protocol Glossary	Lists the protocols supported by the SLC unit with brief descriptions.
Appendix E: Compliance Information	Provides information about the SLC 8000 advanced console manager's compliance with industry standards.

Additional Documentation

Visit the Lantronix Web site at <u>www.lantronix.com/support/documentation</u> for the latest documentation and the following additional documentation.

Document	Description
SLC 8000 Advanced Console Manager Quick Start Guide	Provides accessories and part number information, hardware installation instructions, directions to connect the SLC unit, and network IP configuration information.
SLC 8000 Advanced Console Manager Product Brief	Provides product overview information and specifications.

2: Introduction

The SLC 8000 advanced console manager enables IT system administrators to manage remote servers and IT infrastructure equipment securely over the Internet.

IT equipment can be configured, administered, and managed in a variety of ways, but most devices have one of two methods in common: via USB port and/or via an RS-232 serial port, sometimes called a console, auxiliary, or management port. These ports are often accessed directly by connecting a terminal or laptop to them, meaning that the administrator must be in the same physical location as the equipment. The SLC 8000 advanced console manager gives the administrator a way to access them remotely from anywhere there is a network or modem connection. The SLC 8000 unit can accommodate up to three I/O modules (16-port USB I/O module and/or 16-port RJ45 I/O module.)

Many types of equipment can be accessed and administered using console managers including:

- Servers: Unix, Linux, Windows, and others.
- Networking equipment: Routers, switches, storage networking.
- Telecom: PBX, voice switches.
- Other systems with serial interfaces: Heating/cooling systems, security/building access systems, UPS, medial devices.

The key benefits of using console managers:

- Saves money: Enables remote management and troubleshooting without sending a technician onsite. Reduces travel costs and downtime costs.
- Saves time: Provides instant access and reduces response time, improving efficiency.
- Simplifies access: Enables you to access equipment securely and remotely after hours and on weekends and holidays—without having to schedule visits or arrange for off-hour access.
- Protects assets: Security features provide encryption, authentication, authorization, and firewall features to protect your IT infrastructure while providing flexible remote access.

The SLC advanced console manager provides features such as convenient text menu systems, break-safe operation, port buffering (logging), remote authentication, and Secure Shell (SSH) access. Dial-up modem support ensures access when the network is not available.

Features

Console Management

• Up to 48 serial RJ45 RS-232 and/or USB type A ports for console connectivity

Note: USB ports are generally intended to connect directly to USB console ports. It is also possible to connect a USB to serial adapter to them to connect to serial console ports, if needed.

- Enables system administrators to remotely manage devices with serial and/or USB console ports, e.g., Linux, Unix, and recent versions of Windows servers, routers, telecom, and switches with RS-232C (now EIA-232) or USB compatible serial consoles in a 1U-tall rack space. All models have two Ethernet ports, called Eth1 and Eth2 in this document.
- Provides data logging, monitoring, and secure access control via the Internet

Power

- Universal AC power input (100-240V, 50/60 Hz) or 20-72 VDC power input hardware option
- Convection cooled, silent operation, low power consumption

Hardware

- SLC Chassis: The SLC 8000 advanced console manager has a 1U-tall (1.75 inch), selfcontained rack-mountable chassis.
- Three I/O Module Bays are available on the back of the SLC unit, and able to accomodate a combined total of 48 device ports depending on the number of I/O modules installed. See *Figure 2-2*. Configuration possibilities are listed below. See *Appendix C: Adapters and Pinouts on page 369* for more information on serial adapters and pin-outs, and also *Table 3-8 on page 39* which describes different I/O module configurations.
 - Up to three 16-port RJ45 I/O modules can be installed to provide a maximum of fortyeight serial RS-232C (EIA-232) device ports. The serial RJ45 ports match the RJ45 pinouts of the console ports of many popular devices found in a network environment, and where different can be converted using Lantronix adapters.
 - Up to three 16-port USB I/O modules can be installed to provide a maximum of fortyeight USB I/O device ports.
 - A combination of 16-port USB I/O modules and 16-port RJ45 I/O modules can be installed to provide up to forty-eight serial RJ45 ports and/or USB type A ports, according to the type and number of I/O modules installed on the back of the SLC unit.

Note: The SLC8008 ships with an 8-port serial module that must be installed in the first bay. This module is not available separately. See Table 3-8 on page 39 which describes different I/O module configurations.

- Network Interface on the back left side of the SLC unit can accommodate either a factoryinstalled:
 - Dual 10/100/1000 Base-T Ethernet port I/F card. Ethernet ports are referred to as Eth1 and Eth2 in the user interface and this user guide.
 - Dual SFP port I/F card to support 1 Gigabit-capable single or multi-mode fiber or copper SFP transceiver modules. Single and multi-mode SFP transceiver modules are referred to as F1 in the user interface and this user guide.

Notes:

- 1000 BASE-T SFP transceiver copper modules need to use RX_LOS signal within SFP interface pins for the indicator on Link Status LED. Not all vendor 1000 Base-T SFP modules provide this feature. Qualified copper SFP transceiver modules with this feature include the following: the Finisar 1000 Base-T Copper SFP Transceiver FCLF8250P2BTL and the Fiberstore Cisco SFP-GE-T Compatible 1000 Base-T SFP RJ-45 100m Transceiver.
- SFP transceiver modules are provided by users according to fiber mode and brand preferences. Network ports and the SFP port have LEDs to indicate link and activity status. If a single mode and a multi-mode are both installed the SLC 8000 unit, the device can be configured to utilize one mode at a time.

- Front Console Panel Ports (see Figure 2-1)
 - One serial console port (RJ45) for VT100 terminal or PC with emulation with LED for activity indicators
 - Two USB type A ports for use with flash drives or external USB modems
 - Optional internal modem
 - One Secure Digital (SD) memory card slot (SD card provided by the user)
 - One RJ11 modem port on the front panel

Note: Use of the RJ11 modem port requires installation of an optional modem card (Lantronix part number 56KINTMODEM-01) - see Modem Installation on page 41.

- LCD display and keypad
- 256 KB-per-port buffer memory for serial device ports
- Software reversible device port pinouts
- Either universal AC power input (100-240V, 50/60 Hz) or DC power input (20-72 VDC)

Note: For more detailed information, see Chapter 4: Quick Setup on page 48.







Note: Please contact Lantronix Technical Support to verify the compatibility of a specific transceiver as not all are compatible.



The SLC 8000 supports the use of single mode, multimode fiber optic and copper SFP transceiver modules in dual SFP port models. SFP modules are provided by the user.

The back of the SLC unit appearance and function will depend upon:

1) The type(s) of I/O modules installed in Bay 1, Bay 2 and Bay 3. See Table 3-8 on page 39.

2) The type of I/F card (dual Ethernet port or dual SFP port) installed. If a dual SFP port is installed, then the type of SFP transceiver module (single mode optic fiber, multi-mode optic fiber, or copper) inserted into the SFP port will also impact appearance and function.

System Features

The SLC 8000 firmware has the following basic capabilities:

- Software reversible device port pinouts (serial RJ45 ports only)
- Connects up to 48 RS-232 serial consoles or up to 48 USB consoles ٠
- Support use of simple straight-through cables for use with Cisco, Sun and other devices that use the "Cisco" RJ-45 serial pinouts
- 10/100/1000 Base-T Ethernet network compatibility or SFP ports to support single or multimode 1 Gigabit SFP transceiver modules
- Buffer logging to file
- Email and SNMP notification ٠
- ID/Password security, configurable access rights ٠
- Secure shell (SSH) security; supports numerous other security protocols ٠
- Network File System (NFS) and Common Internet File System (CIFS) support
- RAW TCP, Telnet or SSH to a serial port by IP address per port or by IP address and TCP port number
- Configurable user rights for local and remotely authenticated users
- Supports an external modem

- Simultaneous access on the same port "listen" and "direct" connect mode
- Remote power manager (RPM) control of UPS and PDU devices
- Local access through a dedicated front panel serial console port
- Web administration (using most browsers)

Protocols Supported

The SLC 8000 advanced console manager supports the TCP/IP network protocol as well as:

- SSH, Telnet, PPP, NFS, and CIFS for connections in and out of the SLC console manager
- SMTP for mail transfer
- DNS for text-to-IP address name resolution
- SNMP for remote monitoring and management
- SCP, FTP and SFTP for file transfers and firmware upgrades
- TFTP for firmware upgrades
- DHCP and BOOTP for IP address assignment
- HTTPS (SSL) for secure browser-based configuration
- NTP for time synchronization
- LDAP with Group support, NIS, RADIUS with VSA support, CHAP, PAP, Kerberos, TACACS+, and SecurID (via RADIUS) for user authentication
- Callback Control Protocol (CBCP)
- IPsec for VPN access

For brief descriptions of these protocols, see Appendix D: Protocol Glossary on page 372.

Access Control

The system administrator controls access to attached servers or devices by assigning access rights to up to 128 user profiles. Each user has an assigned ID, password, and access rights. Other user profile access options may include externally configured authentication methods such as Radius and LDAP.

Device Port Buffer

The SLC 8000 unit supports real-time data logging for each device port. The port can save the data log to a file, send an email notification of an issue, or take no action.

You can define the path for logged data on a port-by-port basis, configure file size and number of files per port for each logging event, and configure the device log to send an email alert message automatically to the appropriate parties indicating a particular error.

Configuration Options

You may use the backlit front-panel LCD display for initial setup and configuration and to view current network, console, and date/time settings, and get internal temperature status.

Both a web interface viewed through a standard browser and a command line interface (CLI) are available for configuring the SLC settings and monitoring performance.

Device Port and Console Port Interfaces

RS-232 RJ45 Interface

Device ports are located on the back of the SLC 8000 unit (please see *Figure 2-2*). The console port is located on the front of the SLC 8000 unit (please see *Figure 2-8*). All devices attached to the device ports and the console port must support the RS-232C (EIA-232) standard. For serial RJ45 device ports and the console port, RJ45 cabling (e.g., category 5 or 6 patch cabling) is used.

Serial RJ45 device ports for the SLC 8000 advanced console manager are reversed by default so that straight-through RJ45 patch cables may be used to connect to Cisco and Sun RJ45 serial console ports. If you are replacing an SLC with an SLC 8000 you can either switch the ports to the non-reversed pinout used by SLC units and use your original cables and adapters, or remove any rolled cables or adapters and replace them with straight-through RJ45 cables, e.g. Ethernet patch cables.

Note: RJ45 to DB9/DB25 adapters are available from Lantronix. For serial pinout information, see the Appendix C: Adapters and Pinouts on page 369.

Device ports and the console port support the following baud-rate options: 300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200 and 230400 baud.

USB Interface

The SLC unit can contain up to up to three I/O modules comprised of 16-port USB I/O module(s) and/or 16-port RJ45 I/O module(s) installed in the three module bays available from the back of the SLC 8000 unit. USB device ports can be used with a USB type A connector to serial adapter, if needed.

Figure 2-3 shows an SLC unit containing two 16-port RJ45 I/O modules installed in Bay 1 and Bay 2 for a total of 32 serial RJ45 device ports and one 16-port USB I/O module installed in Bay 3, for a total of 48 device ports. *Figure 2-4* shows an SLC unit containing three 16-port RJ45 I/O modules installed in Bay 1, Bay 2 and Bay 3 for a total of 48 serial RJ45 device ports.

Note: When installing I/O modules into an SLC 8000 (Figure 2-2), Bay 1, Bay 2, and Bay 3 must be populated in order. The 8-port RJ45 serial module is supported on Bay 1 only.

I/F Card Slot: Dual Small Form-Factor Pluggable (SFP) or Dual Ethernet Port

On the left back side of the SLC 8000 unit, a dual SFP port or dual Ethernet port I/F card can be installed. See *Figure 2-5*. If the dual SFP port is installed, copper or optic fiber 1 Gigabit SFP transceiver modules may be used. The SLC 8000 supports use of single and multi-mode SFPs.



Figure 2-3 Three 16-Port USB I/O Modules Installed in Bays 1, 2, & 3 with Dual Ethernet Port

Figure 2-4 One 16-Port USB I/O Module Installed in Bay 1 with Dual Ethernet Port



Figure 2-5 One 16 RJ-45 Serial Port I/O Module Installed in Bay1 & Two 15 USB I/O Module Installed Bays 2 & 3 with Dual SFP Port







Table 2-7 Device (DCE Reversed & DTE) Port Pinout

DCE Pin	DTE Pin	Description
8	1	RTS (output)
7	2	DTR (output)
6	3	TXD (output)
5	4	Ground
4	5	Ground
3	6	RXD (input)
2	7	DSR (input)
1	8	CTS (input)

Figure 2-8 Console Port (Front Side)



Table 2-9 Console (DTE) Port Pinout

DTE Pin	Description
1	RTS (output)
2	DTR (output)
3	TXD (output)
4	Ground
5	Ground
6	RXD (input)
7	DSR (input)
8	CTS (input)

Network Connections

The SLC 8000 network interfaces are 10/100/1000 Base-T Ethernet for use with a conventional Ethernet network as shown in *Figure 2-10*. Use standard RJ45-terminated cables, like Category 5 or 6 patch cable. CAT5E or better cables are recommended for 1000 Base Ethernet. Network parameters must be configured before the SLC console manager can be accessed over the network.

Note: One possible use for the two Ethernet ports is to have one port on a private, secure network and the other on a public, unsecured network. The SLC 8000 can also be equipped with a factory-installed NIC (Ethernet RJ45 or SFP ports). The NIC with SFP ports can support single/multi-mode fiber or copper SFP transceiver modules at 1 Gigabit speed.



Figure 2-10 Dual Ethernet Network Connection

Figure 2-11 Inserting SFP Transceiver Module into the SFP Port



Front Panel USB Ports

The SLC 8000 unit has two 2.0 USB ports (HS, FS, LS) on the front panel, as seen in *Figure 2-12*.





Memory Card Port

The SLC unit has a memory card port on the front panel of the unit which accepts SD cards.



Figure 2-13 Memory Card Port

Internal Modem

An internal modem can be installed in the SLC 8000 advanced console manager. See *Modem Installation on page 41* for instructions.



Figure 2-14 Internal Modem Location

3: Installation

This chapter provides a high-level procedure for installing the SLC advanced console manager followed by more detailed information about the SLC connections and power supplies.

Caution: To avoid physical and electrical hazards, please read Appendix A: Security Considerations on page 366 before installing the SLC 8000 advanced console manager.

What's in the Box

Table 3-1 lists all included components that come in the box and their corresponding part numbers.

Part Number	Component Description	
SLC 8000 Advan	ced Console Manager Models	
Part number depends on SLC model.*	SLC 8000 Advanced Console Manager	
	Note: *Please visit https://www.lantronix.com/products/lantronix-slc-8000/#tab-order to view available SLC models and configurations. See Customize an SLC 8000 on page 33.	
Cables		
200.2070A	RJ45 to DB9F Adapter	
200.0062	RJ45 to RJ45, Cat5, 6.6 ft (2 m)	
	Note: Not available with SFP fiber versions.	
500-153	RJ45 Loopback Plug	
North American Power Cords		
500-041-R	For AC Supply Models, USA & Canada: 110V AC Power Cord, 8 ft (2.43 m), RoHS.	
	<i>Note:</i> Power cords for other international regions are available and sold separately. See <i>Table 3-2.</i>	
083-152-R	For DC Supply Models, USA & Canada: the DC Installation Kit is included.	

Table 3-1 What's in the Box

Notes:

- Accessories that can be ordered separately are listed below in Table 3-2. Regional power cords are available as accessories.
- SLC 8000 single and dual AC supply variants ship with 110V North American AC power cord(s).
- * TAA Compliant models available, replace the "S" with "G" in the SKUs above, (e.g. SLC80321201G for 16-Port RS-232 (RJ45) Single AC Supply).

Part Number	Component Description		
International Power Cords:			
930-077-R	Power Cord, Israel, 250VAC 10A, 8FT, RoHS		
930-075-R	Power Cord, UK, 250VAC 10A, 8FT, RoHS		
930-074-R	Power Cord, European, 250VAC 10A, 8FT, RoHS		
User Swappable Modules			
FRRJ451601	16 Device Port RS-232 (RJ45) I/O Device Port Module		
FRUSB1601	16 Device Port USB I/O Device Port Module		
FR1ACPS01	100 to 240V AC Single Power Supply Module		
FR2ACPS01	100 to 240V AC Dual Power Supply Module		
FR2DCPS01	-20 to -72V DC Dual Power Supply Module		
Secondary Connectivity Accessories for SLC 8000			
56KINTMODEM-0156K v.92	Internal Modem for Dial-UP Out-of-Band Connection		
PXC2102H2-01-S	3.5G Cellular Out-of-Band Connectivity Intelligent Gateway		
	Note: Wireless data plan sold separately.		

Table 3-2 Optional Accessories

Verify and inspect the contents of the SLC package using the enclosed packing slip or the table above. If any item is missing or damaged, contact your place of purchase immediately.

Customize an SLC 8000

Build any combination up to 48 managed console ports by following these easy steps:

1. Pick a baseline configuration:



2. Add up to two modules:



- 3. Choose from Single AC, Dual AC or Dual DC power supply.
- 4. Choose from Ethernet Copper or SFP (Dual AC) variants.
- 5. Select secondary out-of-band options (PSTN modem, cellular gateway.)
- 6. Protect investment with various extended warranty and service options.

Product Label

The product label on the underside of the SLC 8000 advanced console manager contains the following information about each SLC unit:

- Part Number
- Product Revision
- Country of Manufacturing Origin
- Serial Number
- Manufacturing Date Code
- Bar Code



Figure 3-3 Product Label

Technical Specifications

Table 3-4	SLC	Technical	Specifications
-----------	-----	-----------	----------------

Component	Description
Serial Interface (Device)	 Up to 48 RJ45-type 8-conductor connectors as up to three16-port RJ45 I/O modules can be installed. These connectors have individually configurable standard and reversible pinouts, 8 or 16 ports per I/O module. Speed software selectable (300 to 230400 baud)
	Note: Serial RJ45 device ports for the SLC 8000 advanced console manager are reversed by default. Do not use rolled cables and adapters when replacing an SLC console manager with the SLC 8000 model.
USB 2.0 Interface (Device)	 Up to 48 USB type A (Host) as up to three 16-port USB I/O modules can be installed HS, FS, and LS Capable of providing VBUS 5V up to 100 mA per port, but not to exceed 600 mA total per 16-port USB I/O module. May be used with a USB-to-serial adapter to connect a serial device, if needed. Please contact Lantronix for the list of tested adapters. Caution: USB ports are designed for data traffic only. They are not designed for charging or powering devices. Over-current conditions on VBUS 5V may disrupt operations.

Component (continued)	Description
Serial Interface (Console)	 (1) RJ45-type 8-pin connector (DTE) Speed software selectable (300 to 230400 baud) LEDs: Green light ON indicates data transmission activities Yellow light ON indicates data receiving activities
Network Interface	 (2) 10/100/1000 Base-T RJ45 Ethernet with LED indicators: Green light ON indicates a link at 1000 Base-T. Green light OFF indicates a link at other speeds or no link. Yellow light ON indicates a link is established. Yellow light blinking indicates activity.
	 (2) SFP ports to support standard fiber or copper SFP transceiver modules (single or multi-mode) at speed 1 Gigabit. LED indicators: Green light ON indicates a link is established. Green light OFF indicates no link. Yellow light ON indicates no link activity. Yellow light blinking indicates activity.
Power Supply AC (single or dual)	 Universal AC power input: 100-240 VAC 50 or 60 Hz IEC 60320/C14
Power Supply DC (dual)	20V to 72V input
Power Consumption	 Less than 25W with 48 RS232 serial ports Less than 45W with 48 USB ports
Dimensions	1U, 1.75 in x 17.25 in x 12 in
Weight	 12.1 lbs with 48 serial ports 11.8 lbs with 48 USB ports
Temperature	 Operating: 0 to 50°C (32 to 122°F), 30 to 90% RH, non-condensing Storage: -20 to 80°C (-4 to 176°F), 10 to 90% RH, non-condensing
Relative Humidity	 Operating: 10% to 90% non-condensing; 40% to 60% recommended Storage: 10% to 90% non-condensing
Front USB Ports	 (2) ports, type A, host USB 2.0 (HS, FS, LS)
Memory Card	Single memory card slot supporting: SD SDHC
Optional Internal Modem	 300 bps to 56K bps data rate Upstream 48K bps, downstream 56K bps V.44 data compression (V92MB-U, V92HU) V.42 bis and MNP-5 data compression V.29 FastPOS support Caller ID type I and II for select countries Agency approvals: Transferable FCC68, CS03 and CTR21 certifications, IEC60601-1 (Medical Electronics) compliant, CE Marking, IEC60950 approved
Operating Atmosphere Caution: EQUIPMENT IS FOR INDOOR USE	 For use at altitudes no more than 2000 meters above sea level only. 仅适用于海拔 2000m 以下地区安全使用 For use in non-tropical conditions only.
ONLY!	仅适用于非热带气候条件下安全使用

Physical Installation

Install the SLC 8000 advanced console manager in an EIA-standard 19-inch rack (1U tall) or as a desktop unit. The SLC module uses convection cooling to dissipate excess heat.

To install the SLC 8000 advanced console manager in a rack:

1. Place the SLC unit in a 19-inch rack.

Warning: Do not to block the air vents on the sides of the SLC module. If you mount the SLC advanced console manager in an enclosed rack, we recommended that the rack have a ventilation fan to provide adequate airflow through the SLC unit.

- Connect the serial device(s) to the SLC unit ports. See the section, Connecting to a Device Port (on page 36).
- 3. Choose one of the following options:
 - To configure the SLC 8000 advanced console manager using the network, or to monitor serial devices on the network, connect at least one SLC network port to a network. See *Connecting to Network Ports (on page 39)*.
 - To configure the SLC unit using a dumb terminal or a computer with terminal emulation, connect the terminal or PC to the front panel SLC console port. See *Connecting Terminals (on page 39)*.
- 4. Connect the power cord, and apply power. See AC Input (on page 40).
- 5. Wait approximately one minute for the boot process to complete.

When the boot process ends, the SLC host name and the clock appear on the LCD display. Now you are ready to configure the network settings as described in *Chapter 4: Quick Setup*.

Connecting to a Device Port

You can connect almost any device that has a serial console port to a device port on the SLC 8000 unit for remote administration. The console port must support the RS-232C interface.

Note: Many servers must either have the serial port enabled as a console or the keyboard and mouse detached. Consult the server hardware and/or software documentation for more information.

To connect to a serial RJ45 device port:

- 1. Connect one end of the Cat 5 cable to the device port.
- 2. Connect the other end of the Cat 5 cable to an RJ45 serial console port or to other port types using a Lantronix serial console adapter.

Notes:

- See Device Port Commands to enable or disable reverse pinouts through the CLI.
- Table 3-5 and Table 3-6 provide additional information on reverse pinouts.
- See Appendix C: Adapters and Pinouts for information about Lantronix adapters.
- 3. Connect the adapter to the serial console port on the serial device as shown in *Figure* 3-7.
| Pin Number | Description |
|------------|--------------|
| 1 | RTS (output) |
| 2 | DTR (output) |
| 3 | TXD (output) |
| 4 | Ground |
| 5 | Ground |
| 6 | RXD (input) |
| 7 | DSR (input) |
| 8 | CTS (input) |

Table 3-5 Console Port and Device Port - Reverse Pinout Disabled

Table 3-6 Device Port - Reverse Pinout Enabled (Default)

Pin Number	Description
1	CTS (input)
2	DSR (input)
3	RXD (input)
4	Ground
5	Ground
6	TXD (output)
7	DTR (output)
8	RTS (output)

To connect to a USB device port:

- 1. Connect the USB type A connector of a USB cable to a device port.
- 2. Connect the other end of the USB cable to a USB console port.

Figure 3-7 shows a sample I/O module installation with two 16-port RJ45 I/O modules and one 16-port USB I/O module, and how the device ports correspond to the buttons on the *Dashboard*.



Figure 3-7 Sample Device Port Connections (Back Side)

Modular Expansion for I/O Module Bays

The SLC 8000 advanced console manager, which provides 3 separate bays, supports the flexibility to change the I/O module configuration by offering a 16-port module for expansion. When populating the bays, Bay 1, Bay 2 and Bay 3 must be populated in consecutive order. Bay 1 is the slot next to the Ethernet ports and Bay 3 is the slot beside the power supply module. See *Figure 3-7* and *Table 3-8*. When device ports are unused or unsupported, they do not appear in the *Dashboard*. See *Sample Dashboards*.

Note: See the SLC 8000 I/O Module Installation Guide for information on installing I/O modules.



Table 3-8 Available I/O Module Configurations

Note: The 8-port RJ45 serial module is supported on Bay 1 only. The available I/O module configurations in Table 3-8 are supported with either dual Gigabit Ethernet or dual SFP ports.

Connecting to Network Ports

The SLC network ports, 10/100/1000 Base-T Ethernet, allow remote access to the attached devices and the system administrative functions. Use a standard RJ45-terminated Category 5 cable to connect to the network port. A CAT5e or better cable is recommended for use with a 1000 Base-T Ethernet connection.

Note: One possible use for the two Ethernet ports is to have one port on a private, secure network, and the other on an unsecured network.

Connecting Terminals

The console port is for local access to the SLC 8000 advanced console manager and the attached devices. You may attach a dumb terminal or a computer with terminal emulation to the console port. The SLC console port uses RS-232C protocol and supports VT100 emulation. The default serial settings are 9600 baud, 8 bit data, No parity, 1 stop bit with no flow control.

To connect the console port to a terminal or computer with terminal emulation, Lantronix offers optional adapters that provide a connection between an RJ45 jack and a DB9 or DB25 connector. The console port is configured as DTE (non-reversed RJ45). See *Appendix C: Adapters and Pinouts on page 369* for more information.

To connect a terminal:

- 1. Attach the Lantronix adapter to your terminal (typically a PN 200.2066A adapter see *Figure C-1*) or your PC's serial port (use PN 200. adapter see *Figure C-4*).
- 2. Connect the Cat 5 cable to the adapter, and connect the other end to the SLC console port.
- 3. Turn on the terminal or start your computer's communication program (e.g., PuTTY or TeraTerm Pro).
- 4. Once the SLC 8000 advanced console manager is running, press **Enter** to establish connection. You should see the model name and a login prompt on your terminal. On a factory default SLC you may log in with the user name **sysadmin** and the password **PASS**.

AC Input

The power supply module for the SLC controller accepts AC input voltage of 100-240 VAC, 50/60 HZ. Rear-mounted IEC-type AC power connectors are provided for universal AC power input. (See *What's in the Box on page 32.*)

Warning: Disconnect all power supply modules before servicing to avoid electric shock.



Figure 3-9 AC Power Input

Modem Installation



- Caution: TO REDUCE THE RISK OF FIRE, USE ONLY NO. 26 AWG OR LARGER (e.g., 24 AWG) UL LISTED OR CSA CERTIFIED TELECOMMUNICATION LINE CORD.
- Attention: POUR RÉDUIRE LES RISQUES D'INCENDIE, UTILISER UNIQUEMENT DES CONDUCTEURS DE TÉLÉCOMMUNICATIONS 26 AWG AU DE SECTION SUPÉRLEURE.
- Warning: RISK OF ELECTRICAL SHOCKS; DISCONNECT ALL POWER AND PHONE LINES BEFORE SERVICING!



Caution: DEVICES INSIDE THE EQUIPMENT AND THE MODEM ARE ELECTROSTATIC -SENSITIVE; DO NOT HANDLE EXCEPT AT A STATIC FREE WORKPLACE.

MODEM PART NUMBER

Lantronix 56KINTMODEM-01

MODEM SERVICING INSTRUCTIONS

You will need a medium size Phillips screw driver.

- 1. Turn off power to the SLC 8000 advanced console manager.
- 2. Locate the battery modem door on the top of the SLC unit.

3. Carefully unscrew and lift the door off with the screw driver.



4. Take note of the orientation of the modem in the photograph so that you can install a new modem correctly with the same orientation.



5. If there is a modem replacement, carefully lift the old modem out of its socket.



6. Install the new modem with correct orientation.

7. Make sure to have correct pin alignment.



8. Press the modem down to make sure it sits down all the way in the socket.



- 9. Double-check the new modem placement to make sure it is done properly.
- 10. Place the battery/modem door back.
- 11. Carefully tighten the door screw.

Battery Replacement



Caution: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Attention: II Y A DANGER D'EXPLOSION S'IL Y A REMPLACEMENT INCORRECT DE LA BATTERIE. REMPLACER UNIQUEMENT AVEC UNE BATTERIE DU MÊME TYPE OU D'UN TYPE EQUIVALENT RECOMMANDÉ PAR LE CONSTRUCTEUR. METTRE AU REBUT LES BATTERIES USAGÉES CONFORMÉMENT AUX INSTRUCTIONS DU FABRICANT.



Caution: DEVICES INSIDE THE EQUIPMENT ARE ELECTROSTATIC -SENSITIVE; DO NOT HANDLE EXCEPT AT A STATIC FREE WORKPLACE.

Battery Part Numbers

Panasonic BR2032 or equivalent (button cell lithium, non-rechargeable.)

Caution: DO NOT USE BATTERY TYPE CR2032 SINCE IT HAS A LOWER OPERATING TEMPERATURE RANGE.

DISPOSAL OF USED BATTERIES (from battery data sheet)

- If not in a large quantity, button cell batteries contain so little Lithium that they do not qualify as reactive hazardous waste. These batteries are safe for disposal in the normal municipal waste stream.
- If in a large quantity, disposal of button cell batteries should be performed by permitted, professional firms knowledgeable in Federal, State and local hazardous waste transportation and disposal requirements.

Caution: RISK OF FIRE, EXPLOSION AND BURNS. DO NOT RECHARGE, CRUSH, HEAT ABOVE 212°F (100°C) OR INCINERATE.

Battery Replacement Instructions

Warning: RISK OF ELECTRICAL SHOCKS; DISCONNECT ALL POWER AND PHONE LINE BEFORE SERVICING!

You will need a medium size Phillips screw driver.

- 1. Turn off power to the SLC 8000 advanced console manager.
- 2. Locate the battery/modem door on the top of the SLC unit.
- 3. Carefully unscrew and lift the door off with the screw driver.



4. If there is a modem installed, note the orientation of the modem so that later you can install it back correctly.



5. If there is a modem installed, carefully lift the modem out of its socket.



6. Use fingers to lift the battery out of the socket.



Caution: DO NOT USE A METAL OBJECT TO PRY OUT THE BATTERY. IT MAY SHORT THE BATTERY AND DAMAGE THE BATTERY HOUSING.

7. Install the new battery with the (+) side up making sure the battery sits completely and securely in the housing.



- 8. Re-install the modem with correct orientation.
 - a. Make sure also to have correct pin alignment.

b. Press the modem down to make sure it sits down all the way in the socket.



- 9. Double-check the battery and modem placements to make sure they are done properly.
- 10. Place the battery/modem door back.
- 11. Carefully tighten the door screw.
- 12. If necessary, reprogram the SLC system date-time after installing a new battery.

4: Quick Setup

This chapter helps get the IP network port up and running quickly, so you can administer the SLC advanced console manager using your network.

Recommendations

To set up the network connections quickly, we suggest you do one of the following:

- Use the front panel LCD display and keypad buttons to configure the IP address, subnet mask, gateway address and DNS address(es), if applicable.
- Complete the quick setup (see Figure 4-5) on the web interface.
- SSH to the command line interface and follow the Quick Setup script on the command line interface.
- Connect to the console port and follow the Quick Setup script on the command line interface.

Note: The first time you power up the SLC unit, Eth1 tries to obtain its IP address via DHCP. If you have connected Eth1 to the network, and Eth1 is able to acquire an IP address, you can view this IP address on the LCD or by running the Lantronix DeviceInstaller[™] application. If Eth1 cannot acquire an IP address, you cannot use Telnet, SSH, or the web interface to run Quick Setup.

IP Address

Your SLC 8000 advanced console manager must have a unique IP address on your network. The system administrator generally provides the IP address and corresponding subnet mask and gateway. The IP address must be within a valid range and unique to your network. If a valid gateway address has not been assigned the IP address must be on the same subnet as workstations connecting to the SLC 8000 over the network.

The following table lists the options for assigning an IP address to your SLC unit.

Method	Description
DHCP	A DHCP server automatically assigns the IP address and network settings. The SLC 8000 advanced console manager is DHCP-enabled by default.
	With the Eth1 network port connected to the network, and the SLC unit powered up, Eth1 acquires an IP address, viewable on the LCD.
	At this point, you can use SSH to connect to the SLC console manager or use the web interface.
BOOTP	Non-dynamic predecessor to DHCP.
Front panel LCD display and keypads	You manually assign the IP address and other basic network, console, and date/time settings. If desired, you can restore the factory defaults.
Serial port login to command line interface	You assign an IP address and configure the SLC unit using a terminal or a PC running a terminal emulation program to the SLC serial console port connection.

Table 4-1 Methods of Assigning an IP Address

Method #1 Using the Front Panel Display

Before you begin, ensure that you have:

- Unique IP address that is valid on your network (unless automatically assigned)
- Subnet mask (unless automatically assigned)
- Gateway (unless automatically assigned)
- DNS settings (unless automatically assigned)
- Date, time, and time zone
- Console port settings: baud rate, data bits, stop bits, parity, and flow control

Make sure the SLC advanced console manager is plugged into power and turned on.

Front Panel LCD Display and Keypads

With the SLC unit powered up, you can use the front panel display and buttons to set up the basic parameters.

Figure 4-2 Front Panel LCD Display and Five Button Keypad (Enter, Up, Down, Left, Right)



The front panel display initially shows the hostname (abbreviated to 14 letters) and the date and time.

When you click the right-arrow button, the SLC network settings displays. Using the five buttons on the keypad, you can change the network, console port, and date/time settings and view the firmware release version. If desired, you can restore the factory defaults.

Note: Have your information handy as the display times out without accepting any unsaved changes if you take more than 30 seconds between entries.

Any changes made to the network, console port, and date/time settings take effect immediately.

Navigating

The front panel keypad has one **Enter** button (in the center) and four arrow buttons (up, left, right, and down). Press the arrow buttons to navigate from one option to another, or to increment or decrement a numerical entry of the selected option. Use the **Enter** button to select an option to change or to save your settings.

The following table lists the SLC navigation actions, buttons, and options.

Table 4-3	LCD Arrow	Keypad	Actions
-----------	-----------	--------	---------

Button	Action		
Right arrow	To move to the next option (e.g., from Network Settings to Console Settings)		
Left arrow	To return to the previous option		
Enter (center button)	To enter edit mode		
Up and down arrows Within edit mode, to increase or decrease a numerical entry			
Right or left arrows	Within edit mode, to move the cursor right or left		
Enter	To exit edit mode		
Up and down arrows	To scroll up or down the list of parameters within an option (e.g., from IP Address to Mask)		

Table 4-4 Front Panel Setup Options with Associated Parameters

	Current Time	Eth1 Network Settings	Console Port Settings	Date / Time Settings	Release	Internal Temp	User Strings	Location	Device Ports
Up/ Down Arrow	User ID & Current TIme	Eth1 IP Address	Baud Rate, Data Bits, Stop Bits, Parity, Flow Control	Time Zone	Firmware version and date code (display only)	Reading in Celsius & Fahrenheit	Displays configured user string(s), if any.	Indicates the Rack (RK), Row (RW) & Cluster (CW) Iocations.	Detects the connection state of each port: 0 =No DSR input signal detected on device port 1 =DSR input signal detected on device port
		Eth1 Subnet Mask	Data Bits	Date/Time	Restore Factory Defaults				
		Gateway	Stop Bits						
		DNS1	Parity						
		DNS2	Flow Control						
		DNS3							

Note: The individual screens listed from left to right in Table 4-4 can be enabled or disabled for display on the SLC LCD screen. The order of appearance of the screens, if enabled, along with the elected "Home Page" may vary on the LCD monitor according to configuration. The internal temperature, user strings, location and device ports LCD menus are disabled by default. See LCD/Keypad (on page 273) for instructions on enabling and disabling screens.

Left/Right Arrow

Entering the Settings

To enter setup information:

1. From the normal display (host name, date and time), press the right arrow button to display Network Settings. The IP address for Eth1 displays.

Note: If you have connected Eth1 to the network, and Eth1 is able to acquire an IP address through DHCP, this IP address displays, followed by the letter [D]. Otherwise, the IP address displays as all zeros (000.000.000).

- 2. Press the **Enter** button on the keypad to enter edit mode. A cursor displays below one character of the existing IP address setting.
- 3. To enter values:
 - Use the left or right arrow to move the cursor to the left or to the right position.
 - Use the up or down arrow to increment or decrement the numerical value.
- 4. When you have the IP address as you want it, press **Enter** to exit edit mode, and then press the down arrow button. The Subnet Mask parameter displays.

Note: You must edit the IP address and the Subnet Mask together for a valid IP address combination.

5. To save your entries for one or more parameters in the group, press the right arrow button. The Save Settings? Yes/No prompt displays.

Note: If the prompt does not display, make sure you are no longer in edit mode.

- 6. Use the left/right arrow buttons to select **Yes**, and press the **Enter** button.
- 7. Press the right arrow button to move to the next option, Console Settings.
- 8. Repeat steps 2-7 for each setting.
- 9. Press the right arrow button to move to the next option, **Date/Time Settings**, and click **Enter** to edit the time zone.
 - To enter a US time zone, use the up/down arrow buttons to scroll through the US time zones, and then press **Enter** to select the correct one.
 - To enter a time zone outside the US, press the left arrow button to move up to the top level of time zones. Press the up/down arrow button to scroll through the top level.

A time zone with a trailing slash (such as Africa/) has sub-time zones. Use the right arrow button to select the Africa time zones, and then the up/down arrows to scroll through them.

Press **Enter** to select the correct time zone. To move back to the top-level time zone at any time, press the left arrow.

- 10. To save your entries, press the right arrow button. The **Save Settings? Yes/No** prompt displays.
- *Note:* If the prompt does not display, make sure you are no longer in edit mode.
- 11. Use the left/right arrow buttons to select Yes, and press the Enter button.
- 12. To review the saved settings, press the up or down arrows to step through the current settings.

When you are done, the front panel returns to the clock display. The network port resets to the new settings, and you can connect to your IP network for further administration. You should be able to SSH to the SLC 8000 advanced console manager through your network connection, or access the Web interface through a Web browser.

Restoring Factory Defaults

To use the LCD display to restore factory default settings:

- 1. Press the right arrow button to move to the last option, Release.
- Use the down arrow to move to the Restore Factory Defaults option. A prompt for the 6-digit Restore Factory Defaults password displays.
- 3. Press Enter to enter edit mode.
- 4. Using the left and right arrows to move between digits and the up and down arrows to change digits, enter the password (the default password is 999999).

Notes: The Restore Factory Defaults password is only for the LCD. You can change it at the command line interface using the admin keypad password command. The front panel Factory Default password and sysadmin password should be recorded and stored in a secure place accessible by at least two authorized system administrators. Recovering an SLC if both of these passwords are unknown is cumbersome and time consuming.

- 5. Press **Enter** to exit edit mode. If the password is valid, a Save Settings? Yes/No prompt displays.
- 6. Select **Yes** and press **Enter**. When the process is complete, the SLC unit reboots.

Method #2 Quick Setup on the Web Page

After the unit has an IP address, you can use the *Quick Setup* page to configure the remaining network settings. This page displays the first time you log into the SLC 8000 advanced console manager only. Otherwise, the SLC *Home* page displays.

To complete the Quick Setup page:

- 1. Open a web browser (Firefox, Chrome or Internet Explorer web browsers with the latest browser updates).
- 2. In the URL field, type https:// followed by the IP address of your SLC console manager.

Note: The web server listens for requests on the unencrypted (HTTP) port (port 80) and redirects all requests to the encrypted (HTTPS) port (port 443).

3. Log in using sysadmin as the user name and PASS as the password. The first time you log in to the SLC unit, the *Quick Setup* page automatically displays.

Note: To open the Quick Setup page at another time, click the Quick Setup tab.

	Figure 4-5 Quic	k Setup	
Logout Host: slc4331 User: sysadmin	.C 8048	5 7 9 11 13 15 17 19 21 23 25 27 2 6 8 10 12 14 16 18 20 22 24 26 8 3 Configuration Image: Configuration (DP only) Image: Configuration	19 31 33 35 37 39 41 43 45 47 A 10 32 34 36 38 40 42 44 46 48 B Connected Device (DP only)
Network Services User Authe	ntication Devices Maintenance	Quick Setup	☆? 🕂 🗉
Quick Setup			
	Quick Setu	p	Help?
Weld	ome to the Lantronix SLC 8000 A	dvanced Console Manager	
Below are basic settings that If th	it is recommended you configure before u ese settings are OK, click the checkbox be	sing the Lantronix SLC 8000 Advance elow and select the Apply button.	ed Console Manager.
	Accept default Quick S	Setup settings	
Network Settings		The SLC has tw By default, both Eth1 ar	vo Ethernet ports, Eth1 and Eth2. Id Eth2 are configured for DHCP.
Obtain fr	om DHCP	Default Gateway:	
Eth1 Settings: Obtain fr	om BOOTP		
Specify:		Hostname:	slc4331
IP Address:		Not pri	e: The hostname will be used as the ompt in the Command Line Interface.
Subnet Mask:		Domain:	
Date & Time Settings		Administrator Settings	
Change Date/Time:		Т	he sysadmin user has complete
Date: May	▼ 20 ▼ 2016 ▼	1	The default password is 'PASS'.
Time: 08 ▼ : 3	3 🔻 pm 👻	Currenterier Deservored	
Time Zone: GMT		Sysaumin Password.	
		Retype Password:	
	Apply		

4. To accept the defaults, select the **Accept default Quick Setup settings** checkbox on the top portion of the page and click the **Apply** button at the bottom of the page. Otherwise, continue with step 5.

Note: Once you click the *Apply* button on the *Quick Setup* page, you can continue using the web interface to configure the SLC further.

5. Enter the following settings:

Network Settings

Note: Configurations with the same IP subnet on multiple interfaces (Ethernet or PPP) are not currently supported.

Network Setting	Description
Eth 1 Settings	 Obtain from DHCP: Acquires IP address, subnet mask, hostname and gateway from the DHCP server. (The DHCP server may not provide the hostname gateway, depending on its setup.) This is the default setting. If you select this option, skip to Gateway. Obtain from BOOTP: Lets a network node request configuration information from a BOOTP "server" node. If you select this option, skip to Gateway. Specify: Lets you manually assign a static IP address, generally provided by the system administrator.
IP Address (if specifying)	 Enter an IP address that is unique and valid on your network. There is no default. Enter all IP addresses in dot-quad notation. Do not use leading zeros in the fields for dot-quad numbers less than 100. For example, if your IP address is 172.19.201.28, do not enter 028 for the last segment octet.
	Note: Currently, the SLC 8000 advanced console manager does not support configurations with the same IP subnet on multiple interfaces (Ethernet or PPP).
Subnet Mask	If specifying an IP address, enter the subnet mask for the network on which the SLC unit resides. There is no default.
Default Gateway	The IP address of the router for this network. There is no default.
Hostname	The default host name is slcXXXX, where XXXX is the last 4 characters of the hardware address of Ethernet Port 1. There is a 64-character limit (contiguous characters, no spaces).
	<i>Note:</i> The host name becomes the prompt in the command line interface.
Domain	If desired, specify a domain name (for example, support.lantronix.com). The domain name is used for host name resolution within the SLC 8000 advanced console manager. For example, if abcd is specified for the SMTP server, and mydomain.com is specified for the domain, if abcd cannot be resolved, the SLC unit attempts to resolve abcd.mydomain.com for the SMTP server.

Date & Time Settings

Date & Time Setting	Description
Change Date/Time	Select the checkbox to manually enter the date and time at the SLC unit's location.
Date	From the drop-down lists, select the current month, day, and year.
Time	From the drop-down lists, select the current hour and minute.
Time Zone	From the drop-down list, select the appropriate time zone.

Administrator Settings

Administrator Setting	Description
Sysadmin Password	To change the password (e.g., from the default) enter a Sysadmin Password of up to 64 characters.
Retype Password	Re-enter the Sysadmin Password above in this field as a confirmation.

6. Click the **Apply** button to save your entries.

Logout Host: slc4331 User: sysadmin			8 LCD (U1 E1 1 3 U2 E2 2 4 Select port for ©	5 7 9 11 13 15 17 19 21 23 6 8 10 12 14 16 18 20 22 24 Configuration () WebSSH (DP	25 27 29 31 33 35 37 39 4 26 28 30 32 34 36 38 40 4 only) Connected Device (I 	1 43 45 47 A 2 44 46 48 B OP only)
Network	Services	User Authentication	Devices	Maintenance	Quick Setup	<u>ቆ</u>	? 🛱 🖻
Quick Se	tup						

Figure 4-6 Quick Setup Completed in Web Manager

Quick Setup configuration is complete.

You can now begin configuring and connecting Device Ports.

If Quick Setup has already been run the standard Home page will display.

	Figure 4-7 Home	
LOD SLC 8048 Logout Host: slc4331 User: sysadmin	U1 E1 1 3 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 35 37 39 41 SD U2 E2 2 4 6 8 10 12 14 16 18 20 22 24 26 28 30 32 34 36 38 40 42 Select port for © Configuration WebSSH (DP only) Connected Device (DP)	43 45 47 A 44 46 48 B P only)
Network Services User Authentication Devices	Maintenance Quick Setup	? 🗗 🗉
	Home	Help?

Welcome to the Lantronix SLC 8000 Advanced Console Manager



Method #3 Quick Setup on the Command Line Interface

If the SLC 8000 advanced console manager does not have an IP address, you can connect a dumb terminal or a PC running a terminal emulation program (VT100) to access the command line interface. (See *Connecting Terminals on page 39.*) If the unit has an IP address, you can use SSH or Telnet to connect to the SLC unit.

By default, Telnet is disabled and SSH is enabled. To enable Telnet, use the *Services* > *SSH/Telnet/Logging (on page 98)*.

To complete the command line interface Quick Setup script:

- 1. Do one of the following:
 - With a serial terminal connection, power up, and when the command line displays, press **Enter**.

- With a network connection, use an SSH client or Telnet program (if Telnet has been enabled) to connect to xx.xx.xx (the IP address in dot quad notation), and press **Enter**. You should be at the login prompt.
- 2. Enter sysadmin as the user name and press Enter.
- 3. Enter PASS as the password and press **Enter**. The first time you log in, the Quick Setup script runs automatically. Normally, the command prompt displays.

Figure 4-8 Beginning of Quick Setup Script

Welcome to the Lantronix SLC8000 Advanced Console Manager Model Number: SLC8032

Quick Setup will now step you through configuring a few basic settings.

The current settings are shown in brackets ('[]'). You can accept the current setting for each question by pressing <return>.

4. Enter the following information at the prompts:

Note: To accept a default or to skip an entry that is not required, press *Enter*.

CLI Quick Setup Settings	Description
Config Eth1	Select one of the following:
	 (1) obtain IP Address from DHCP: The unit will acquire the IP address, subnet mask, hostname, and gateway from the DHCP server. (The DHCP server may or may not provide the gateway and hostname, depending on its setup.) This is the default setting. (2) obtain IP Address from BOOTP: Permits a network node to request configuration information from a BOOTP "server" node. (3) static IP Address: Allows you to assign a static IP address manually. The IP address is generally provided by the system administrator.
IP Address (if specifying)	An IP address that is unique and valid on your network and in the same subnet as your PC. There is no default.
	If you selected DHCP or BOOTP, this prompt does not display.
	Enter all IP addresses in dot-quad notation. Do not use leading zeros in the fields for dot-quad numbers less than 100. For example, if your IP address is 172.19.201.28, do not enter 028 for the last octet.
	Note: Configurations with the same IP subnet on multiple interfaces (Ethernet or PPP) are not currently supported.
Subnet Mask	The subnet mask specifies the network segment on which the SLC 8000 advanced console manager resides. There is no default. If you selected DHCP or BOOTP, this prompt does not display.
Default Gateway	IP address of the router for this network. There is no default.
Hostname	The default host name is slcXXXX, where XXXX is the last 4 characters of the hardware address of Ethernet Port 1. There is a 64-character limit (contiguous characters, no spaces).
	Note: The host name becomes the prompt in the command line interface.

CLI Quick Setup Settings	Description
Domain	If desired, specify a domain name (for example, support.lantronix.com). The domain name is used for host name resolution within the SLC unit. For example, if abcd is specified for the SMTP server, and mydomain.com is specified for the domain, if abcd cannot be resolved, the SLC 8000 advanced console manager attempts to resolve abcd.mydomain.com for the SMTP server.
Time Zone	If the time zone displayed is incorrect, enter the correct time zone and press Enter . If the entry is not a valid time zone, the system guides you through selecting a time zone. A list of valid regions and countries displays. At the prompts, enter the correct region and country.
Date/Time	If the date and time displayed are correct, type n and continue. If the date and time are incorrect, type y and enter the correct date and time in the formats shown at the prompts.
Sysadmin password	Enter a new sysadmin password.

After you complete the Quick Setup script, the changes take effect immediately.

Figure 4-9 Quick Setup Completed in CLI

Welcome to the Lantronix SLC8000 Advanced Console Manager Model Number: SLC8032

Quick Setup will now step you through configuring a few basic settings.

The current settings are shown in brackets ('[]'). You can accept the current setting for each question by pressing <return>.

```
Ethernet Port and Default Gateway
The SLC8032 has two ethernet ports, Eth1 and Eth2.
By default, both ports are configured for DHCP.
Configure Eth1: (1) obtain IP Address from DHCP
(2) obtain IP Address from BOOTP
(3) static IP Address
```

Enter 1-3: [1]

The SLC8032 can be configured to use a default gateway. Enter gateway IP Address: [none]

```
____Hostname_
```

```
The current hostname is 'slc0348', and the current domain is '<undefined>'.
The hostname will be shown in the CLI prompt.
Specify a hostname: [slc0348]
Specify a domain: [<undefined>]
```

Time Zone

The current time zone is 'GMT'. Enter time zone: [GMT]

```
Date/Time

The current time is Wed May 18 20:51:04 2016

Change the current time? [n]

Sysadmin Password

The default sysadmin (administrator user) password is 'PASS'.

Enter new password: [PASS]

Quick Setup is now complete.

For a list of commands, type 'help'.
```

Next Step

After completing quick setup on the SLC 8000 advanced console manager, you may want to configure other settings. You can use the web page or the command line interface for configuration.

- For information about the web and the command line interfaces, go to Chapter 5: Web and Command Line Interfaces.
- To continue configuring the SLC unit, go to Chapter 6: Basic Parameters.

5: Web and Command Line Interfaces

The following figure shows a typical web page:

The SLC advanced console manager offers three interfaces for configuring the SLC unit: a command line interface (CLI), a web interface, and an LCD with keypad buttons on the front panel. This chapter discusses the web and command line interfaces.

Note: See Chapter 4: Quick Setup on page 48 for instructions on using the LCD front panel to configure basic network settings, Web Manager, and CLI to perform quick setup.

Web Manager

A Web Manager allows the system administrator and other authorized users to configure and manage the SLC 8000 advanced console manager using most web browsers (Firefox, Chrome or Internet Explorer web applications with the latest browser updates). The SLC unit provides a secure, encrypted web interface over SSL (secure sockets layer).

Note: The web server listens for requests on the unencrypted (HTTP) port (port 80) and redirects all requests to the encrypted (HTTPS) port (port 443). Web Telnet and Web SSH features (utilized in SLC console managers with firmware 7.2.0.0 or earlier) require Java 1.1 (or later) support in the browser.

Logout Button	Logott Host stolego: Host stoleg	_Dashboard
Tabs	Network Services User Authentication Devices Maintenance Quick Setup &? 🛱 🗉	-Icons
	Network Settings	_
	Ethernet Interfaces Hostname & Name Servers	Help
Options /	Eth1 Settings © Otain from DHCP © Otain from DHCP © Otain from BOCTP © Specify: © Otain from BOCTP © Specify: © Otain from BOCTP © Specify: © Otain from BOCTP	Button
	IP Address DNS Servers Subnet Mask 255 255 0.0 Subnet Mask #1: 172 19.1.1 IP66 Address IP76 Address #2	
Entry Fields —— and Options	IPV6 Address (Gobal) 2001 db80 ac13 db1e 280; (Gobal) #3: IPv6 Address (bit Local) IPv6 Address (bit Local) DHCP-Acquired DNS Servers (bit Local) Mode: Auto #1: 172.18.1.1 Mode: Auto #2: 172.18.1.2 MTU: 1500 #3: None HW Address: 0.080:336:86:03 Prefit IPV4 DNS Records:	
	Enable IPv6 @ (Requires reboot) SEP NIC Info & Dispnostics > IP Forwarding: Desbled Forwarding: Ethernet Bonding: Disabled Forwarding: Ethernet Bonding Status > Number of Probes: 5 Interval: 600 secs	
	HX Bytes Packets Errors Multicast Bytes Packets Errors Eini 52050770 3597753 0 0 75339141 468499 0 Eth2 0 0 0 0 0 0 0 0	
	Gateway. The fail-over gateway is used if an IP address usually accessible through the default gateway fails to return one or more pings.	
	Default Network Fail-over: Fail-over None Status HOP-Acquired: 172.19.0.1 IP Address to Ping: Mobile	
	Precedence: DHCP-Acquired Ethernet Port for Ping: Eth 1 Eth 2 PIN # for SIM Card Retype: SIM Card Delay between Pings: 3 seconds PIN Lock	
	IPv6 Default Number of Failed 10 SIM PUK Retype	
	Admin Login	

Figure 5-1 Web Page Layout

The web page has the following components:

- Tabs: Groups of settings to configure.
- **Options:** Below each tab are options for specific types of settings.

Note: Only those options for which the currently logged-in user has rights display.

Figure 5-2 Sample Dashboards 1 3 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 35 37 39 41 43 45 47 U1 **U**2 4 6 8 10 12 14 16 18 34 36 38 42 44 46 48 2 30 3 Device Port 40 3 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 35 37 39 41 43 45 47 U2 4 6 8 10 12 14 16 18 20 22 24 26 28 30 32 34 36 38 40 42 44 46 48 2 Eth Port 2 SFP 1000BASE-T 3 5 7 9 11 13 15 17 192123 33 35 37 39 41 43 45 47 112 2 4 6 8 10 12 14 16 18 34 36 38 40 42 44 46 48 20

Ethernet Port 2

Dashboard

The appearance of the user interface dashboard will differ according to the type of NIC card and bay modules installed in the back of the SLC 8000. See *Figure 2-2 SLC 8048 Unit Samples (Back Side) - Part Number SLC80482201S (on page 24), Figure 3-7 Sample Device Port Connections (Back Side) (on page 38),* and *Figure 5-2 Sample Dashboards (on page 60).*

- The light green LCD button allows you to configure the front panel LCD.
- The beige SD button allows you to configure the SD card, if a card is inserted. See *Chapter 9: USB/SD Card Port on page 181*.
- The gray U1 button allows you to configure the upper USB device (flash drive or modem) plugged into the front panel USB connector. The gray U2 button allows you to configure the lower USB device plugged into the front panel USB connector. See Chapter 9: USB/ SD Card Port on page 181.
- The brown **MD** button allows you to configure the internal modem, if an internal modem is installed.
- The blue E1 and E2 buttons display the Network > Network Settings page for the Ethernet
 port.
- The F1 and F2 buttons display the Network > Network Settings page for the SFP transceiver port.
- The number buttons allow you to select a port and display its settings. Only ports to which the currently logged-in user has rights are enabled.

Below the bar are options for use with the port buttons. Selecting a port and the **Configuration** option takes you to the *Device Ports > Settings (1 of 2)* page. Selecting a port and the **WebSSH** option displays the WebSSH window for the device port --if Web SSH is enabled, and if SSH is enabled for the device port. Selecting the port and the **Connected Device** button allows access to supported devices such as remote power

managers (RPMs) and/or SensorSoft temperature and humidity probes connected to the device port.

- The yellow orange **A** and **B** buttons display the status of the power supplies.
- Entry Fields and Options: Allow you to enter data and select options for the settings.

Note: For specific instructions on completing the fields on the web pages, see Chapters 5 through 12.

- Apply Button: Apply on each web page makes the changes immediately and saves them so they will be there when the SLC 8000 advanced console manager is rebooted.
- Icons: The icon bar above the Main Menu has icons that display the following:
 - Home page.
 - **?** Information about the SLC unit and Lantronix contact information.
 - Configuration site map.
 - Status of the SLC 8000 advanced console manager.
- Help Button: Provides online Help for the specific web page.

Logging in

Only the system administrator or users with web access rights can log into the Web Manager. More than one user at a time can log in, but the same user cannot login more than once.

To log in to the SLC Web Manager:

- 1. Open a web browser.
- 2. In the URL field, type https:// followed by the IP address of your SLC 8000 advanced console manager.
- 3. To configure the SLC unit, use sysadmin as the user name and PASS as the password. (These are the default values.)

Note: The system administrator may have changed the password using one of the Quick Setup methods in the previous chapter.

The Lantronix SLC *Quick Setup* page displays automatically the first time you log in. Subsequently, the Lantronix SLC Home page displays. (If you want to display the *Quick Setup* page again, click **Quick Setup** on the main menu.)

Logging Out

To log off the SLC web interface:

1. Click the **Logout** button located on the upper left part of any Web Manager page. You are brought back to the login screen when logout is complete.

Web Page Help

To view detailed information about an SLC web page:

1. Click the **Help** button to the right of any Web Manager page. Online Help contents will appear in a new browser window.

Command Line Interface

A command line interface (CLI) is available for entering all the commands you can use with the SLC 8000 advanced console manager. In this user guide, after each section of instructions for using the web interface, you will find the equivalent CLI commands. You can access the command line interface using Telnet, SSH, or a serial terminal connection.

Note: By default, Telnet is disabled and SSH is enabled. To enable Telnet, use the Services > SSH/Telnet/Logging web page, a serial terminal connection, or an SSH connection. (See Chapter 7: Services.)

The sysadmin user and users with who have full administrative rights have access to the complete command set, while all other users have access to a reduced command set based on their permissions.

Logging In

To log in to the SLC command line interface:

- 1. Do one of the following:
 - With a serial terminal connection, power up, and when the command line displays, press **Enter**.
 - If the SLC 8000 advanced console manager already has an IP address (assigned previously or assigned by DHCP), Telnet (if Telnet has been enabled) or SSH to xx.xx.xx (the IP address in dot quad notation) and press **Enter**. The login prompt displays.
- 2. To log in as the system administrator for setup and configuration, enter sysadmin as the user name and press **Enter**.
- 3. Enter PASS as the password and press **Enter**. The first time you log in, the Quick Setup script runs automatically. Normally, the command prompt displays. (If you want to display the Quick Setup script again, use the admin quicksetup command.)

Note: The system administrator may have changed the password using one of the Quick Setup methods in the previous chapter.

To log in any other user:

- 1. Enter your SLC user name and press Enter.
- 2. Enter your SLC password and press Enter.

Logging Out

To log out of the SLC command line interface, type logout and press Enter.

Command Syntax

Commands have the following format:

```
<action> <category> <parameter(s)>
```

where

<action> is set, show, connect, admin, diag, or logout.

<category> is a group of related parameters whose settings you want to configure or view. Examples are ntp, deviceport, and network.

<parameter(s) > is one or more name-value pairs in one of the following formats:

<parameter name<="" th=""><th>> <aa bb></aa bb></th><th>User must specify one of the values (aa or bb) separated by a vertical line (). The values are in all lowercase and must be entered exactly as shown. Bold indicates a default value.</th></parameter>	> <aa bb></aa bb>	User must specify one of the values (aa or bb) separated by a vertical line (). The values are in all lowercase and must be entered exactly as shown. Bold indicates a default value.
<parameter name<="" td=""><td>> <value></value></td><td>User must specify an appropriate value, for example, an IP address. The parameter values are in mixed case. Square brackets [] indicate optional parameters.</td></parameter>	> <value></value>	User must specify an appropriate value, for example, an IP address. The parameter values are in mixed case. Square brackets [] indicate optional parameters.

Command Line Help

- For general Help and to display the commands to which you have rights, type: help
- For general command line Help, type: help command line
- For release notes for the current firmware release, type: help release
- For more information about a specific command, type help followed by the command. For example: help set network or help admin firmware

Tips

 Type enough characters to identify the action, category, or parameter name uniquely. For parameter values, type the entire value. For example, you can shorten:

```
set network port 1 state static ipaddr 122.3.10.1 mask 255.255.0.0
```

to

se net po 1 st static ip 122.3.10.1 ma 255.255.0.0

- Use the Tab key to automatically complete action, category, or parameter names. Type a partial name and press **Tab** either to complete the name if only one is possible, or to display the possible names if more than one is possible. Following a space after the preceding name, Tab displays all possible names.
- Should you make a mistake while typing, backspace by pressing the Backspace key and/or the Delete key, depending on how you accessed the interface. Both keys work if you use VT100 emulation in your terminal access program when connecting to the console port. Use the left and right arrow keys to move within a command.
- Use the up and down arrows to scroll through previously entered commands. If desired, select one and edit it. You can scroll through up to 100 previous commands entered in the session.
- To clear an IP address, type 0.0.0.0, or to clear a non-IP address value, type CLEAR.
- When the number of lines displayed by a command exceeds the size of the window (the default is 25), the command output is halted until the user is ready to continue. To display the

next line, press **Enter**, and to display the page, press the space bar. You can override the number of lines (or disable the feature altogether) with the set cli command.General CLI Commands

The following commands relate to the CLI itself.

To configure the current command line session:

set cli scscommands <enable|disable>

Allows you to use SCS-compatible commands as shortcuts for executing commands:

Note: Settings are retained between CLI sessions for local users and users listed in the remote users list.

SCS Commands	Commands
info	'show sysstatus'
version	'admin version'
reboot	'admin reboot'
poweroff	'admin shutdown'
listdev	'show deviceport names'
direct	'connect direct deviceport'
listen	'connect listen deviceport'
clear	'set locallog clear'
telnet	'connect direct telnet'
ssh	'connect direct ssh'

Table 5-3 SCS Commands

To set the number of lines displayed by a command:

set cli terminallines <disable | Number of lines>

Sets the number of lines in the terminal emulation (screen) for paging through text one screenful at a time, if the SLC 8000 unit cannot detect the size of the terminal automatically.

To show current CLI settings:

show cli

To view the last 100 commands entered in the session:

show history

To clear the command history:

set history clear

To view the rights of the currently logged-in user:

show user

Note: For information about user rights, see Chapter 12: User Authentication.

Keyboard Shortcut	Description
Control + [a]	Move to the start of the line.
Control + [e]	Move to the end of the line.
Control + [b]	Move back to the start of the current word.
Control + [f]	Move forward to the end of the next word.
Control + [u]	Erase from cursor to the beginning of the line.
Control + [k]	Erase from cursor to the end of the line.

Table 5-4 CLI Keyboard Shortcuts

6: Basic Parameters

This chapter explains how to set the following basic configuration settings for the SLC advanced console manager using the SLC web interface or the CLI:

- Network parameters that determine how the SLC 8000 advanced console manager interacts with the attached network
- Firewall and routing
- Date and time

Note: If you entered some of these settings using a Quick Setup procedure, you may update them here.

Requirements

If you assign a different IP address from the current one, it must be within a valid range and unique to your network. If a valid gateway address has not been assigned the IP address must be on the same subnet as workstations connecting to the SLC 8000 over the network.

To configure the unit, you need the following information:

Eth1	IP address:	 	
	Subnet mask:	 -	
Eth2	IP address (optional):	 	
	Subnet mask (optional):	 	
Gateway:		 ·	
DNS:			

Network Port Settings

Network parameters determine how the SLC unit interacts with the attached network. Use this page to set the following basic configuration settings for the network ports (Eth1 and Eth2).

The SLC supports the following types of network interfaces:

- RJ-45 ports, as part of the standard SLC RJ45 NIC board. In the web UI port banner bar, these are represented as **E1** and **E2**. These ports can be configured for speeds of 10Mbit, 100 Mbit or 1000 Mbit, at half-duplex or full-duplex. The RJ45 Ethernet NIC LEDs display the following states:
 - Green Light On: indicates a link at 1000 BASE-T
 - Green Light Off: indicates a link at other speeds, or no link
 - Yellow Light On: indicates a link is established
 - Yellow Light Blinking: indicates link activity
- A variety of SFP modules, installed in the SLC SFP NIC board. In the web UI port banner bar, these are represented as F1 and F2, in a variety of colors. Single mode 1000 BASE-LX optical SFPs are shown in yellow as F1. Multi mode 1000 BASE-SX optical SFPs are shown as F1. RJ45 1000 BASE-T SFPs are shown in blue as F1. A port with no SFP module is shown in white as F1. A port with an unknown SFP module is shown as F1. The SFP Ethernet NIC LEDs are located between the two SFP module slots; the LEDs for Ethernet 1 are on the left, and the LEDs for Ethernet 2 are on the right. They display the following states:
 - Green Light On: indicates a link is established
 - Green Light Off: indicates no link
 - Yellow Light On: indicates no link activity
 - Yellow Light Blinking: indicates link activity

These ports are fixed at 1000 Mbit full-duplex. Note that in some vendor's RJ45 1000 BASE-T transceivers, the RX LOS is internally ground, so the link status feature may fail.

To enter settings for one or both network ports:

 Click the Network tab and select the Network Settings option. Either the Network > Network Settings or the Network > Network Settings (SFP Model) displays depending on your SLC 8000 model.

LANTR	ONIX [®] Host: sic433	SLC 804	8 LCD SD U1	MD E1 1 3 E2 2 4	5 7 9 11 13 6 8 10 12 14	3 15 17 19 16 18 20	21 23 25 27 29 31 33 35 22 24 26 28 30 32 34 36	37 39 41 43 4 38 40 42 44 4	5 47 A 6 48 B
Network Serv Network Setting	User: sysad vices User Aut gs IP Filter Re	imin thentication outing VPN	Devices Mai Security Perf	intenance Monitoring	Quick Setur	WebSSH	(DP only) Connected L	A ? 단	,]- E
			Netw	ork Settii	ngs			[Help?
Ethernet Interface	es						Hostname & Name	Servers	
Eth1 Settings:	 Disabled Obtain from DH Obtain from BC Specify: 	ICP)OTP	Eth2 Settings:	 Disabled Obtain free Obtain free Obtain free Specify: 	om DHCP om BOOTP		Hostname: SIC Note: The hostr prompt in the C Domain:	4331 ame will be use ommand Line Ir	ed as the nterface.
IP Address Subnet Mask	172.19.100.12	4	IP Address: Subnet Mask:	:			DNS Servers		
IPv6 Address (Static	;		IPv6 Address (Static)				#1: #2:		
IPv6 Address (Global IPv6 Address (Link Local	2001:db80:ac1	3:d91e:280: fe96:4331/6·	IPv6 Address (Link Local)				#3: DHCP-Acquired	DNS Server	<u>'S</u>
Mode: MTU:	Auto 1500	¥	Mode: MTU:	Auto 1500	¥		#1: 172 #2: 172 #3: Nor	2.19.1.1 2.19.1.2 ne	
HW Address: 0 Multicast: 2 2	0:80:a3:96:43:31 39.255.255.251 24.0.0.1		HW Address: Multicast:	00:80:a3:96: 224.0.0.1	43:32		Prefer IPv4 DNS Records:		
Enable IPv6: IP Forwarding: IPv6	 (Requires rebo 	oot) E	thernet Bonding:	Disabled	nding Status	T	TCP Keepalive P Start Probes	arameters 600	secs
Forwarding:				Linemet Do	nung sutus		Number of Probes	: 5 • 60	
Byte	R s Packets	x Errors I	Multicast Byt	es Pack	k (ets Error	s	Interva	. 00	Sets
Eth1 12558 Eth2	8394 84042 0 0	0	0 451 0	2723 0	6539 0	0			
<u>Gateway</u>					The fail-ove through	er gateway the defau Fail-ove	y is used if an IP addre It gateway fails to retur	ss usually ac n one or mor	cessible re pings.
Default:	1		Network Fail-over			Device	None 🔻 Statu	S 🔪	

Figure 6-1 Network > Network Settings

Default:		Network Fail-over:			Fail-over Device:	None v	Status >
DHCP-Acquired:	172.19.0.1	IP Address to Ping:			APN of Mobile Carrier:		
Precedence:	DHCP-Acquired	Ethernet Port for Ping:	Eth1	Eth2	PIN # for SIM Card:		Retype:
	 Default 	Delay between Pings:	3	seconds	PIN Lock:		
IPv6 Default:		Number of Failed Pings:	10		SIM PUK:		Retype:
					Admin Login:		
					Admin Password:		Retype:
		[Apply				

Note: The SFP NIC Info & Diagnostics link in the Network > Network Settings (SFP Model) page only appears in SLC units equipped with an SFP NIC board.

Figure	o-z networ	K >	Netwo	ork Set	ungs (a		iodel)				
LANTRONIX° SLC	8048 LCC) <mark>SD</mark> U1 U2	F1 1 F2 2	3 5 7 9 4 6 8 10	11 13 15 1 12 14 16 1	7 19 21 2 8 20 22 2	3 25 27 29 31 33 4 26 28 30 32 34	35 37 39 36 38 40	41 4 42 4	3 45 4 46	47 A 48 B
Logout Host siceduz User: sysadmin		Sel	ect port fo	or 💿 Configu	iration 🔘 V	VebSSH (D	P only) O Connec	ted Devic	e (DP	only)	
Network Services User Authentica	tion Devices	Ma	intenan	ce Quio	k Setup			6	} ?	÷Ę	}
Network Settings IP Filter Routing	VPN Security	Perf	Monito	ring							
		Netw	vork S	ettinas						ŀ	lelp?
Ethernet Interfaces				j-			Hostname & Na	me Ser	vers	-	
Disabled			O Disa	abled			Hostname	slc8d0	2		
Eth1 Settings: Obtain from DHCP	Eth2 Set	ttings:	Obt	ain from DH	ICP		Note: The h	nostname	- will be	e use	d as the
 Obtain from BOOTP Specify: 			Obt	ain from BC	OTP		prompt in t	he Comm	and Li	ine In	nterface.
ID Address: 172 10 100 214		ddroor		city.			Domain:				
IP Address. 172.19.100.214	IP A	aaress					DNS Server	<u>s</u>			
Subnet Mask: 255.255.0.0	Subne	t Mask	c			_	#1:	172.19).1.1		
IPv6 Address: (Static)	IPv6 A	ddress (Statio	s: :)				#2:				
IPv6 Address: (Global) 2001:db80:ac13:d91e	:280:						#3:				
IPv6 Address: (Link Local) fe80::280:a3ff:fe96:8d	02/6· IPv6 A	ddress	5: }				DHCP-Acqu	ired DN	IS Se	nver	\$
Mode: Auto		Mode:	Auto		-		#1:	172.19.	1.1	1101	2
Milli 1500		MTLE	1500		-		#2:	172.19.	1.2		
HW Address: 00:80:33:96:8d:02	HW Ad	dress:	00.80.3	3-96-84-03			#3:	None			
Multicast: 239.255.255.251	Mul	ticast:	224.0.0	.1			Prefer IPv4 DNS Records:	\$			
224.0.0.1											
Enable IPv6: 🕑 (Requires reboot)	SFP NIC I	nfo &	Diagno	stics >				_			
IP Forwarding:	Ethernet Bor	nding:	Disabl	ed		T	TCP Keepaliv	e Parar	neter:	<u>s</u>	1
IPv6			Etherne	et Bonding	Status >		Start Pro	bes: 0	0		secs
Forwarding.							Number of Pro	bes: 5			
Rx				Тх		_	Inte	erval: 6)		secs
Bytes Packets Error	S Multicast	8y 753	tes 20171	Packets	Errors	0					
Eth2 0 0	0 0	753	0	400499		0					
			-								
<u>Gateway</u>				Th	e fail-over	gateway	is used if an IP ad	ddress u	sually	y ac	cessible
					unough u			return o		mor	e pings
Default:	Network F	ail-ove	er:			Device:	None v S	itatus >			
DUCP Acquired: 172 19 0 1	IP Addross	to Din	a:			APN of Mobile				1	
5Hol -Acquired: 172.10.0.1	II Address	101111	9.			Carrier:					
DHCP-Acquired	Ethernet	Port f Pin	or 💿 E	th1 🔵 Eth	12 F SI	PIN # for M Card		Retype	c		
Precedence: Default	Delay betwee	n Ping	s: 3	second	ds P	IN Lock:					
IPv6 Default	Number of	of Faile	ed 10		ç	IM PLIK		Return			
		Ping	s:		3	Admin		retype	•		
						Login:					
					Pa	Admin assword		Retype	c		
			Appl	У							

Figure 6-2 Network > Network Settings (SFP Model)

Logout SLC 8048			SD U1 F1 1 3 5 U2 F2 2 4 6 Select port for	7 9 11 13 15 1 8 10 12 14 16 1 Configuration 0	7 19 21 23 25 27 29 31 33 35 37 39 4 8 20 22 24 26 28 30 32 34 36 38 40 4 NebSSH (DP only) Onnected Device	1 43 45 47 A 2 44 46 48 B (DP only)
Network Services	User Authentication	Devices	Maintenance	Quick Setup	岱	? 🕀 🗉
Network Settings IP Filter Routing VPN Security						
Network - SFP NIC Information & Diagnostics						

Figure 6-3 Network Settings > SFP NIC Information & Diagnostics

Eth1 SFP Module: 1000BA SE-LX Single Mode (Vendor: Fiberstore PN: SFP1G-EX-55 Rev: A0) Eth2 SFP Module: 1000BA SE-LX Single Mode (Vendor: FiberStore PN: SFP1G-ZX-55 Rev: A)

SFP	Diagnostic	Information
	-	

	<u> </u>							_
Port_	Temp	Voltage_	Current	Output Power_	Input Power	_LOS_	TX Fault_	
Eth1	36.53 degC/97.76 d	legF 3.2058V	23.800mA	0.5475mW	0.5622mW	No	No	
Eth2	48.42 degC/119.15	degF 3.1902V	20.000mA	1.0741mW	0.000mW	Yes	No	

Sack to Network Settings

2. Enter the following information:

Ethernet Interfaces (Eth1 and Eth2)

Note: Configurations with the same IP subnet on multiple interfaces (Ethernet or PPP) are not currently supported.

Eth 1 Settings or Eth 2 Settings	 Disabled: If selected, disables the network port. Obtain from DHCP: Acquires IP address, subnet mask, hostname and gateway from the DHCP server. (The DHCP server may not provide the hostname gateway, depending on its setup.) This is the default setting. If you select this option, skip to Gateway. Obtain from BOOTP: Lets a network node request configuration information from a BOOTP "server" node. If you select this option, skip to Gateway. Specify: Lets you manually assign a static IP address, generally provided by the system administrator. 		
IP Address (if specifying)	 Enter an IP address that will be unique and valid on your network. There is no default. Enter all IP addresses in dot-quad notation. Do not use leading zeros in the fields for dot-quad numbers less than 100. For example, if your IP address is 172.19.201.28, do not enter 028 for the last segment octet. Note: Currently, the SLC unit does not support configurations with the same IP subnet on multiple interfaces (Ethernet or PPP). 		
Subnet Mask	If specifying an IP address, enter the network segment on which the SLC unit resides. There is no default.		
IPv6 Address	Address of the port in IPv6 format.		
(Static)	Note: The SLC 8000 advanced console manager supports IPv6 connections for the following services: the web, SSH, Telnet, remote syslog, SNMP, NTP, LDAP, Kerberos, RADIUS, TACACS+, connections to device ports, and diagnostic ping.		
	IPv6 addresses are written as 8 sets of 4-digit hexadecimal numbers separated by colons. There are several rules for modifying the address. For example:		
	1234:0BCD:1D67:0000:0000:8375:BADD:0057 may be shortened to 1234:BCD:1D67::8375:BADD:57.		

IPv6 Address (Global)"	IPv6 address with global scope that is generated by address autoconfiguration. The address is generated from a combination of router advertisements and MAC address to create a unique IPv6 address. This field is read only.			
	<i>Note:</i> This field will not appear in the absence of an IPv6 global address.			
IPv6 Address (Link Local)	An IPv6 address that is intended only for communications within the segment of a local network. This field is read only.			
Mode	Select the direction, duplex mode (full duplex or half-duplex), and speed (10, 100, or 1000 Mbit) of data transmission. The default is Auto, which allows the Ethernet port to auto-negotiate the speed and duplex with the hardware endpoint to which it is connected.			
МТО	Specifies the maximum transmission unit (MTU) or maximum packet size of packets at the IP layer (OSI layer 3) for the Ethernet port. When fragmenting a datagram, this is the largest number of bytes that can be used in a packet.			
HW Address	Displays the hardware address of the Ethernet port.			
Multicast	Displays the multicast address of the Ethernet port.			
Enable IPv6	Select this box to enable the IPv6 protocol. If changed, the SLC unit will need to reboot. Enabled by default.			
IP Forwarding	If enabled, IP forwarding enables IPv4 network traffic received on one interface (Eth1, Eth2, or an external/USB modem attached to the SLC unit with an active PPP connection) to be transferred out another interface (any of the above). The default behavior (if IP forwarding is disabled) is for network traffic to be received but not routed to another destination.			
	Enabling IP forwarding is required if you enable Network Address Translation (NAT) for any device port modem or USB/ISDN modem. IP forwarding allows a user accessing the SLC 8000 advanced console manager over a modem to access the network connected to Eth1 or Eth2.			
IPv6 Forwarding	If enabled, IPv6 forwarding enables IPv6 network traffic received on one interface (Eth1, Eth2, or an external/USB modem attached to the SLC unit with an active PPP connection) to be transferred out another interface (any of the above). The default behavior (if IP forwarding is disabled) is for network traffic to be received but not routed to another destination.			
Ethernet Bonding	Ethernet 1 and Ethernet 2 can be bonded to support redundancy (Active Backup), aggregation (802.3ad), and load balancing. Disabled by default. Note that if Ethernet Bonding is enabled, assigning individual IP Addresses to Device Ports is not supported.			
SFP NIC Info & Diagnostics (Link)	Clicking the link brings you to the Network Settings > SFP NIC Information & Diagnostics page showing information and diagnostics about the SFP connection port, temperature, voltage, current, output power, input power, LOS, and TX fault. Click Back to Network Settings to return to the Network > Network Settings page.			
	Note: The SFP NIC Info & Diagnostics link in the Network > Network Settings page only appears in SLC units equipped with an SFP NIC board.			
Ethernet Bonding Status (Link)	Click the link to access Ethernet bonding status information. Ethernet 1 and Ethernet 2 can be bonded to support redundancy (Active Backup), aggregation (802.3ad), and load balancing. Disabled by default. Note that if Ethernet Bonding is enabled, assigning individual IP Addresses to Device Ports is not supported. Click Back to Network Settings link to return to the Network Settings page.			
Prefer IPv4 DNS Records	If enabled, IPv4 DNS records will be preferred when DNS hostname lookups are performed. Otherwise IPv6 records will be preferred (when IPv6 is enabled). Enabled by default.			

Note: Configurations with the same IP subnet on multiple interfaces (Ethernet or PPP) are not currently supported.

Gateway

Default	IP address of the IPv4 router for this network.				
	If this has not been set manually, any gateway acquired by DHCP for Eth1 or Eth2 displays.				
	All network traffic that matches the Eth1 IP address and subnet mask is sent out Eth1. All network traffic that matches the Eth2 IP address and subnet mask is sent out Eth 2.				
	If you set a default gateway, any network traffic that does not match Eth1 or Eth2 is sent to the default gateway for routing.				
DHCP-Acquired	Gateway acquired by DHCP for Eth1 or Eth2. View only.				
Precedence	Indicates whether the gateway acquired by DHCP or the default gateway takes precedence. The default is DHCP Gateway. If the DHCP Gateway is selected and both Eth1 and Eth2 are configured for DHCP, the SLC unit gives precedence to the Eth1 gateway.				
IPv6 Default	Indicates the IPv6 default gateway.				
Network Fail-over	An alternate IP address of the router for this network, to be used if an IP address usually accessible through the default gateway fails to return one or more pings.				
	Note: The fail-over gateway is not supported when DHCP is used.				
IP Address to Ping	IP address to ping to determine whether to use the fail-over gateway.				
Ethernet Port to Ping	Ethernet port to use for the ping.				
Delay between Pings	Number of seconds between pings				
Number of Failed Pings	Number of pings that fail before the SLC 8000 advanced console manager uses the fail-over gateway.				
Fail-over Device	Select an integrated device to be used as the fail-over gateway. Currently the Lantronix PremierWave XC HSPA+ Cellular Gateway is supported (the HSPA+ gateway must be configured in gateway mode before it can be used as the fail-over gateway). This feature requires that both Ethernet port be configured with a static IP address. Using DHCP on one of the Ethernet ports may overwrite the default route, interfering with fail-over and fail-back.				
	Note: The commands sent to the fail-over device to retrieve status and update the configuration are shown in the syslog (Network syslog, some message may be displayed at the Debug level). If there are errors retrieving status or updating the configuration, check the device administrator login/password, connectivity to the device, the firmware version of the device (minimum HSPA+ firmware version is 8.1.0.0), and the messages in the Network syslog.				
	When the SLC sends an updated configuration to the fail-over device, even if the SLC indicates that the update was successful, it is recommended to check the syslog. Responses from the fail-over device indicating that the device needs to be rebooted for configuration changes to take affect may also be in the syslog. The configuration will be resent to the device if any of the fail-over device settings are changed, or the selected fail-over device is changed from None to one of the supported fail-over device types.				
APN of Mobile Carrier	For the HSPA+ gateway, configure the Access Point Name for the mobile carrier. May have up to 256 characters.				
Pin # for SIM Card/ Retype	For the HSPA+ gateway, the PIN number for the SIM card used by the gateway. May have up to 8 characters.				
PIN Lock (checkbox)	For the HSPA+ gateway, enable a lock so that the SIM card used by the gateway cannot be used by anyone who does not have the PIN.				
------------------------------------	--				
SIM PUK/Retype	For the HSPA+ gateway, the SIM Personal Unblocking Key. May have up to 16 characters.				
Admin Login and Password/Retype	For the selected Fail-over Device, the administrator login and password used to retrieve status from the device and send configuration updates to the device. The login may have up to 32 characters, and the password may have up to 64 characters.				

Hostname & Name Servers

Hostname	The default host name is slcXXXX, where XXXX is the last 4 characters of the hardware address of Ethernet Port 1. There is a 64-character limit (contiguous characters, no spaces). The host name becomes the prompt in the command line interface.
Domain	If desired, specify a domain name (for example, support.lantronix.com). The domain name is used for host name resolution within the SLC unit. For example, if abcd is specified for the SMTP server, and mydomain.com is specified for the domain, if abcd cannot be resolved, the SLC 8000 advanced console manager attempts to resolve abcd.mydomain.com for the SMTP server.

DNS Servers

#1 - #3	Configure up to three name servers with an IPv4 or IPv6 address. #1 is required if you choose to configure DNS (Domain Name Server) servers.
	The first three DNS servers acquired via DHCP through Eth1 and/or Eth2 display automatically.

DHCP-Acquired DNS Servers

	#1 - #3 Dis	isplays the IP address of the name servers if automatically assigned by DHCP.
--	--------------------	---

TCP Keepalive Parameters

Start Probes	Number of seconds the SLC unit waits after the last transmission before sending the first probe to determine whether a TCP session is still alive. The default is 600 seconds (10 minutes).
Number of Probes	Number of probes the SLC 8000 advanced console manager sends before closing a session. The default is 5.
Interval	The number of seconds the SLC unit waits between probes. The default is 60 seconds.

3. To save your entries, click the **Apply** button. **Apply** makes the changes immediately and saves them so they will be there when the SLC 8000 advanced console manager is rebooted.

Ethernet Counters

The *Network > Network Settings* page displays statistics for each of the SLC Ethernet ports since boot-up. The system automatically updates them.

Note: For Ethernet statistics for a smaller time period, use the diag perfstat command.

Network Commands

Go to *Network Commands* to view CLI commands which correspond to the web page entries described above.

IP Filter

IP filters (also called a rule set) act as a firewall to allow or deny individual or a range of IP addresses, ports, and protocols. When a network connection is configured to use an IP filter, all network traffic through that connection is compared, in order, to the rules of that filter. Network traffic may be allowed to pass, it may be dropped (without notice), or it may be rejected (sends back an error packet) depending upon the rules of that filter rule set.

The administrator uses the *Network* > *IP Filter* page to view, add, edit, delete, and map IP filters.

Warning: IP filters configuration is a feature for advanced users. Adding and enabling IP filter sets incorrectly can disable access to your SLC unit.

Viewing IP Filters

You can view a list of filters and a table showing how each filter is mapped to an interface.

To view a list of IP filters:

1. Click the **Network** tab and select the **IP Filter** option. The following page displays:

Logout Host: slc4331 User: sysadmin	CD SD U1 MD E1 1 U2 MD E2 2 Select port for (3 5 7 9 11 13 15 17 19 21 2 4 6 8 10 12 14 16 18 20 22 2 Configuration WebSSH (DP) 10	3 25 27 29 31 33 35 37 39 4 4 26 28 30 32 34 36 38 40 4 only) Connected Device (I	1 43 45 47 A 2 44 46 48 B DP only)
Network Services User Authentication	Devices Maintenance	Quick Setup	岱	? 🕀 🗉
Network Settings IP Filter Routing VPN	Security Perf Monitoring			
	IP Filter			Help?
Enable IP Filter: Packets Dropped: 0 Packets Rejected	: 0		<u>IP F</u>	ilter Status
Test Timer: No Yes, minut Time Remaining: 0 minutes	es (1-120):	Use the Test Timer to v automatically be	verify the IP Filter Ruleset disabled when the Test 1	s; IP Filter will imer expires.
Add Ruleset Edit Ruleset Delete Ruleset	Ma	ap Ruleset to Interface: Eth	hernet 1 v	
IP Filter Rulesets		IP Filter Mapp	ings	
Name	l Ir	nterface	Ruleset	
	Apply			

Figure 6-4 Network > IP Filter

Mapping Rulesets

The administrator can assign an IP Filter Rule Set to a network interface (Ethernet interface), a modem connected to a device port, or a USB modem or an internal modem (if installed).

To map a ruleset to a network interface:

- 1. Click the **Network** tab and select the **IP Filter** option. The *Network > IP Filter* page displays.
- 2. Select the IP filter rule set to be mapped.
- 3. From the **Interface** drop-down list, select the desired network interface and click the **Map Ruleset** button. The Interface and rule set display in the IP Filter Mappings table.

To delete a mapping:

- 1. Click the **Network** tab and select the **IP Filter** option. The *Network > IP Filter* page displays.
- 2. Select the mapping from the list and click the **Delete Mappings** button. The mapping no longer displays.
- 3. Click the Apply button.

Enabling IP Filters

On the *Network > IP Filter* page, you can enable all filters or disable all filters.

Note: There is no way to enable or disable individual filters.

To enable IP filters:

1. Enter the following:

Enable IP Filter	Select the Enable IP Filter checkbox to enable all filters, or clear the checkbox to disable all filters. Disabled by default.
Packets Dropped	Displays the number of data packets that the filter ignored (did not respond to). View only.
Packets Rejected	Displays the number of data packets that the filter sent a "rejected" response to. View only.
Test Timer	Timer for testing IP Filter rulesets. Select No to disable the timer. Select Yes, minutes (1-120) to enable the timer and enter the number of minutes the timer should run. The timer automatically disables the IP Filters when the time expires.
Time Remaining	Indicates how many minutes are left on the timer before it expires and IP Filters disabled. View only.

Configuring IP Filters

The administrator can add, edit, delete, and map IP filters.

Note: A configured filter has no effect until it is mapped to a network interface. See Mapping Rulesets on page 75.

To add an IP filter:

1. On the *Network > IP Filter* page, click the **Add Ruleset** button. The following page displays:

LANTRON	X [°] SLC 8048	LCD SD U1 MD E1 1 U2 DE 2	3 5 7 9 11 13 15 <mark>17 19 21 23</mark> 2 4 6 8 10 12 14 16 <mark>18 20 22 24</mark> 2	5 27 29 31 33 35 37 39 41 43 45 47 A 6 28 30 32 34 36 38 40 42 44 46 48 B
Logout U	ost: slc4331 ser: sysadmin	Select port for	Configuration O WebSSH (DP only	y) Connected Device (DP only)
Network Services	User Authentication Devic	es Maintenance	Quick Setup	🖓 ? 🛱 🗉
Network Settings IP	Filter Routing VPN Secur	ity Perf Monitoring	1	
	Ne	twork - IP Filte	r Ruleset	Help?
Ruleset Name:		Number of Rules: 1		
Rule Parameters		Rules (in order of pre	ecedence)	
IP Address(es):		0.0.0.0/0;All;;Drop		*
Subnet Mask:				
Protocol: All	_			
Port Range:				
Action: O Dr	an O Baiast O Assant			_
Clear				*
	BOOTP/DHCP	Telnet	O HTTP	O FTP
Generate rule to allow service: Add Rule	O DNS	SNMP	NIS	SFTP
	RIP	SMTP	LDAP	TFTP
	NTP	NFS	RADIUS	VPN
	Syslog	SMB/CIFS	Kerberos	LDP
	SSH	HTTPS	TACACS+	SLC Logging
Back to IP Filter		Apply		

Figure 6-5 Network > IP Filter Ruleset (Adding/Editing Rulesets)

Rulesets can be added or updated on this page.

2. Enter the following:

Ruleset Name	Name that identifies a filter; may be composed of letters, numbers, and hyphens only. (The name cannot start with a hyphen.)
	Example: FILTER-2

Rule Parameters

IP Address(es)	Specify a single IP address to act as a filter.
	Example: 172.19.220.64 – this specific IP address only
Subnet Mask	Specify a subnet mask to act determine how much of the address should apply to the filter.
	Example: 255.255.255.255 to specify the whole address should apply.
Protocol	From the drop-down list, select the type of protocol through which the filter will operate. The default setting is All .
Port Range	 Enter a range of destination TCP or UDP port numbers to be tested. An entry is required for TCP, TCP New, TCP Established, and UDP, and is not allowed for other protocols. Separate multiple ports with commas. Separate ranges of ports by colons. Examples: 22 - filter on port 22 only 23,64,80 - filter on ports 23, 64 and 80 23:64,80,143:150 - filter on ports 23 through 64, port 80 and ports 143 through 150
Action	Select whether to Drop , Reject , or Allow communications for the specified IP address, subnet mask, protocol, and port range. Drop ignores the packet with no notification. Reject ignores the packet and sends back an error message. Allow permits the packet through the filter.
Clear	Click the Clear button to clear any Rule Parameter information set above.
Generate rule to allow service	You may wish to "punch holes" in your filter set for a particular protocol or service.
	For instance, if you have configured your NIS server and wish to create an opening in your filter set, select the NIS option and click the Add Rule button. This entry adds a new rule to your filter set using the NIS -configured IP address. Other services and protocols added automatically generate the necessary rule to allow their use.

- 3. Click the right arrow 🖻 button to add the new rule to the bottom of the Rules list box on the right. A maximum of 64 rules can be created for each ruleset.
- 4. To remove a rule from the filter set, highlight that line and click the left < arrow. The rule populates the rule definition fields, allowing you to make minor changes before reinserting the rule. To clear the definition fields, click the **Clear** button.
- 6. To save, click the **Apply** button. The new filter displays in the menu tree.

Note: To add another new filter rule set, click the **Back to IP Filter** link to return to the Network > IP Filter page.

Updating an IP Filter

To update an IP filter rule set:

- From the Network > IP Filter page, the administrator selects the IP filter ruleset to be edited and clicks the Edit Ruleset button to return to the Network > IP Filter Ruleset (Adding/Editing Rulesets) page (see Figure 6-5).
- 2. Edit the information as desired and click the **Apply** button.

Deleting an IP Filter

To delete an IP filter rule set:

1. On the *Network* > *IP Filter* page, the administrator selects the IP filter ruleset to be deleted and clicks the **Delete Ruleset** button.

IP Filter Commands

Go to *IP Filter Commands* to view CLI commands which correspond to the web page entries described above.

Routing

The SLC 8000 advanced console manager allows you to define static routes and, for networks using Routing Information Protocol (RIP)-capable routes, to enable the RIP protocol to configure the routes dynamically.

To configure routing settings:

1. Click the **Network** tab and select the **Routing** option. The following page displays:

LANTRON Logout Ho	st: slc4331 er: sysadmin	8048 LCD	SD U1 MD E1 1 5 U2 MD E2 2 5 Select port for •	3 5 7 9 11 13 1 4 6 8 10 12 14 10 Configuration V	5 <mark>17 19 21 23 25 27 29 31</mark> 5 <mark>18 20 22 24 26 28 30 32</mark> /ebSSH (DP only) Conn	33 35 37 39 41 43 45 47 A 34 36 38 40 42 44 46 48 B ected Device (DP only)
Network Services	User Authentica	tion Devices	Maintenance	Quick Setup		🖧 ? 🛱 🗉
Network Settings IP F	ilter Routing	VPN Security	Perf Monitoring			
			Routing			Help?
Enable RIP	: 🔲 RIP Ve	rsion: 1 • 2	1 and 2		The Ro wit	uting Table can be viewed h the IP Routes Report >.
Enable Static Routing	: 🗆				To e select the radio button	dit or delete a static route, in the right column below.
IP Address	c .				Static Routes	
Subnet Mask				No IP Address	Subnet Mask	Gateway
Gateway	c					
Add	//Edit Route lete Route Apply					

2. Enter the following:

Dynamic Routing

Enable RIP	Select to enable Dynamic Routing Information Protocol (RIP) to assign routes
	automatically. Disabled by default.

Figure 6-6 Network > Routing

RIP Version Select the RIP version. The default is 2 .	
---	--

Static Routing

Enable Static Routing	Select to assign the routes manually. The system administrator usually provides the routes. Disabled by default.
	 To add a static route, enter the IP Address, Subnet Mask, and Gateway for the route and click the Add/Edit Route button. The route displays in the Static Routes table. You can add up to 64 static routes. To edit a static route, select the radio button to the right of the route, change the IP Address, Subnet Mask, and Gateway fields as desired, and click the Add/Edit Route button. To delete a static route, select the radio button to the right of the route and click the Delete Route button.

3. Click the **Apply** button.

Note: To display the routing table, status or specific report, see the section, *Status/Reports on page 267.*

Routing Commands

Go to *Routing Commands* to view CLI commands which correspond to the web page entries described above.

VPN

This page can be used to create a Virtual Private Network (VPN) tunnel to the SLC 8000 advanced console manager for secure communication between the SLC unit and a remote host or gateway. The SLC 8000 advanced console manager supports IPSec tunnels using Encapsulated Security Payload (ESP). The SLC unit supports host-to-host, net-to-net, host-to-net, and roaming user tunnels.

Note: To allow VPN tunnel access if the SLC firewall is enabled, traffic to UDP ports 500 and 4500 from the remote host should be allowed, as well as protocol ESP from the remote host.

To complete the VPN page:

1. Click the **Network** tab and select the **VPN** option. The following page displays:

		Figure 6-7	Network > V	PN (1 of 2)		
	Host: sic4331 User: svsadmin	8 048 LCD s	D U1 MD E1 1 3 5 U2 E2 2 4 6 Select port for O Cor	7 9 11 13 15 17 8 10 12 14 16 18 Ifiguration WebS	19 21 23 25 27 2 20 22 24 26 28 3 SH (DP only)	9 31 33 35 37 39 41 43 45 47 A 0 32 34 36 38 40 42 44 46 48 B Connected Device (DP only)
Network	ervices User Authenticati	ion Devices	Maintenance Q	uick Setup		& ? ≣
Network Set	ttings IP Filter Routing	VPN Security	Perf Monitoring			
			VPN			Help?
Enable VPN Tunnel:			Current	Tunnel Status:	Down	
Name:						
Ethernet Port:	1 2 Default R	loute				
Remote Host:						
Remote Id:]				
Remote Hop/Router:						
Remote Subnet(s):						View Detailed Status
Local Id:]				<u>View VPN Logs</u>
Local Hop/Router:						View SLC RSA Public Key
Local Subnet(s):						View X.509 Certificates
IKE Negotiation: IKE v2: IKE Encryption:	Main Mode Aggress Permit Any Authentication:	sive Mode	DH Group: Any 🔻			
ESP	Any Authentication:	Any 🔻	DH Group: Any V			
Authoritication:	BSA Bublia Kov Pro	Shared Key	X E00 Cortificato			
RSA Public		e-Shareu Key	X.509 Certificate			
Key for Remote						
Pre-Shared Kev:		Retype Pre-Sh	ared Key:			
Certificate Authority for		Upload File				
Remote Peer:						
for Remote Peer:		Upload File				
Certificate Authority for Local Peer:	r	Upload File				
Certificate File for Local Peer:		Upload File				
Key File for Local Peer:	r	Upload File				
Perfect Forward Secrecy: SA Lifetime:	t ₩ 28800					
Mode Configuration Client						

Eigure 6.7 Notwork > VDN (1 of 2)

XAUTH Client:	
XAUTH Login:	
XAUTH Password:	Retype Password:
Remote Peer Type:	IETF (non-Cisco) Cisco
Force Encapsulation:	
Dead Peer Detection:	○ No ● Yes, Delay: 30 seconds
Dead Peer Detection Timeout:	120
Dead Peer Detection Action:	Hold v
	Apply

Figure 6-8 Network > VPN (2 of 2)

2. Enter the following:

Enable VPN Tunnel	Select to create a tunnel.
Name	The name assigned to the tunnel. Required to create a tunnel.
Ethernet Port	Select Ethernet port 1 or 2, or the default route (default is 1). If default route is selected, VPN will automatically use the local address of the default route interface (as determined at IPsec startup time); this also overrides any value supplied for Local Hop/Router.
Remote Host	The IP address of the remote host's public network interface. The special value of any can be entered if the remote host is a roaming user who may not have the same IP address each time a tunnel is created. In this case, it is recommended that the Remote Id also be configured.
Remote Id	How the remote host should be identified for authentication. The Id is used to select the proper credentials for communicating with the remote host.
Remote Hop/Router	If the remote host is behind a gateway, this specifies the IP address of the gateway's public network interface.
Remote Subnet(s)	One or more subnets behind the remote host, expressed in CIDR notation (IP address/mask bits). If multiple subnets are specified, the subnets should be separated by a comma.
Local Id	How the SLC 8000 advanced console manager should be identified for authentication. The Id is used by the remote host to select the proper credentials for communicating with the SLC advanced console manager.
Local Hop/ Router	If the SLC unit is behind a gateway, this specifies the IP address of the gateway's public network interface.
Local Subnet(s)	One or more subnets behind the SLC 8000 advanced console manager, expressed in CIDR notation (IP address/mask bits). If multiple subnets are specified, the subnets should be separated by a comma.

IKE Negotiation	The Internet Key Exchange (IKE) protocol is used to exchange security options between two hosts who want to communicate via IPSec. The first phase of the protocol authenticates the two hosts to each other and establishes the Internet Security Association Key Management Protocol Security Association (ISAKMP SA). The second phase of the protocol establishes the cryptographic parameters for protecting the data passed through the tunnel, which is the IPSec Security Association (IPSec SA). The IPSec SA can periodically be renegotiated to ensure security. The IKE protocol can use one of two modes: Main Mode , which provides identity protection and takes longer, or Aggressive Mode , which provides no identity protection but is quicker. With Aggressive Mode, there is no negotiation of which cryptographic parameters in the initial package of the exchange, otherwise the exchange will fail. If Aggressive Mode is used, the IKE Encryption , IKE Authentication , and IKE DH Group must be specified.
IKE v2	IKE version 2 settings to be used. Currently the accepted values are Permit, (the default) signifying no IKEv2 should be transmitted, but will be accepted if the other ends initiates to us with IKEv2; Never signifying no IKEv2 negotiation should be transmitted or accepted; Propose signifying that the SLC will permit IKEv2, and also use it as the default to initiate; Insist, signifying that the SLC only accept and receive IKEv2 and IKEv1 negotiations will be rejected.
	If the IKEv2 setting is set to Permit or Propose, the SLC will try and detect a "bid down" attack from IKEv2 to IKEv1. Since there is no standard for transmitting the IKEv2 capability with IKEv1, the SLC uses a special Vendor ID "CAN-IKEv2". If a fall back from IKEv2 to IKEv1 was detected, and the IKEv1 negotiation contains Vendor ID "CAN-IKEv2", the SLC will immediately attempt an IKEv2 rekey and refuse to use the IKEv1 connection. With an IKEv2 setting of Insist, no IKEv1 negotiation is allowed, and no bid down attack is possible.
IKE Encryption	The type of encryption, 3DES , AES , SHA2_256 or SHA2_512 used for IKE negotiation. Any can be selected if the two sides can negotiate which type of encryption to use.
Authentication (IKE)	The type of authentication, SHA1 or MD5 , used for IKE negotiation. Any can be selected if the two sides can negotiate which type of authentication to use.
DH Group (IKE)	The Diffie-Hellman Group, 2 , 5 , 14 or 15 used for IKE negotiation. Any can be selected if the two sides can negotiate which Diffie-Hellman Group to use.
ESP Encryption	The type of encryption, 3DES or AES , used for encrypting the data sent through the tunnel. Any can be selected if the two sides can negotiate which type of encryption to use.
Authentication (ESP)	The type of authentication, SHA1 , MD5 , or SHA2_512 used for authenticating data sent through the tunnel. Any can be selected if the two sides can negotiate which type of authentication to use.
DH Group (ESP)	The Diffie-Hellman Group, 2 , 5 , 14 or 15 , used for the key exchange for data sent through the tunnel. Any can be selected if the two sides can negotiate which Diffie-Hellman Group to use.

Authentication	The type of authentication used by the host on each side of the VPN tunnel to verify the identity of the other host.				
	 For RSA Public Key, each host generates a RSA public-private key pair, and shares its public key with the remote host. The RSA Public Key for the SLC 8000 advanced console manager (which has 2192 bits) can be viewed at either the web or CLI. For Pre-Shared Key, each host enters the same passphrase to be used for authentication. For X.509 Certificate, each host is configured with a Certificate Authority certificate along with a X.509 certificate with a corresponding private key, and shares the X.509 certificate with the remote host. 				
RSA Public Key for Remote Host	If RSA Public Key is selected for authentication, enter the public key for the remote host.				
Pre-Shared Key	If Pre-Shared Key is selected for authentication, enter the key.				
Retype Pre-Shared Key	If Pre-Shared Key is selected for authentication, re-enter the key.				
Certificate Authority for Remote Peer	A certificate can be uploaded to the SLC unit for peer authentication. The certificate for the remote peer is used to authenticate the SLC to the remote				
Certificate File for Remote Peer	peer, and at a minimum contains the public certificate file of the remote peer. The certificate may also contain a Certificate Authority file; if the Certificate Authority file is omitted, the SLC may display "issuer cacert not found" and "X.509 certificate rejected" messages, but still authenticate. The Certificate Authority file and public certificate File must be in PEM format, e.g.: BEGIN CERTIFICATE (certificate in base64 encoding)				
	END CERTIFICATE				
Certificate Authority for Local Peer	A certificate can be uploaded to the SLC unit for peer authentication. The certificate for the local peer is used to authenticate any remote peer to the				
Certificate File for Local Peer	private key file. The public certificate file can be shared with any remote peer for authentication. The Certificate Authority and public certificate file				
Rey File for Local Feel	must de in PEM format, e.g.:				
	BEGIN CERTIFICATE				
	(Certificate in Dase64 encoding)				
	END CERTIFICATE				
	The key file must be in RSA private key file (PKCS#1) format, eg: BEGIN RSA PRIVATE KEY (private key in base64 encoding) END RSA PRIVATE KEY				
Porfact Forward Socrocy	When a new IPSec SA is negotiated after the IPSec SA lifetime expires a				
Ferrect Forward Secrecy	new Diffie-Hellman key exchange can be performed to generate a new session key to be used to encrypt the data being sent through the tunnel. If this is enabled, it provides greater security, since the old session keys are destroyed.				
SA Lifetime	How long a particular instance of a connection should last, from successful negotiation to expiry, in seconds. Normally, the connection is renegotiated (via the keying channel) before it expires.				

Mode Configuration Client	If this is enabled, the SLC unit can receive network configuration from the remote host. This allows the remote host to assign an IP address/netmask to the SLC advanced console manager side of the VPN tunnel.
XAUTH Client	If this is enabled, the SLC 8000 advanced console manager will send authentication credentials to the remote host if they are requested. XAUTH, or Extended Authentication, can be used as an additional security measure on top of the Pre-Shared Key or RSA Public Key.
XAUTH Login (Client)	If XAUTH Client is enabled, this is the login used for authentication.
XAUTH Password	If XAUTH Client is enabled, this is the password used for authentication.
Retype Password	If XAUTH Client is enabled, this is the password used for authentication.
Remote Peer Type	Defines the type of the remote peer, either IETF (non-Cisco) or Cisco. When set to Cisco, support for Cisco IPsec gateway redirection and Cisco obtained DNS and domainname are enabled.
Force Encapsulation	In some cases, for example when ESP packets are filtered or when a broken IPsec peer does not properly recognise NAT, it can be useful to force RFC-3948 encapsulation.
Dead Peer Detection	Sets the delay (in seconds) between Dead Peer Detection (RFC 3706) keepalives (R_U_THERE, R_U_THERE_ACK) that are sent for the tunnel (default 30 seconds). Dead Peer Detection can also be disabled.
Dead Peer Detection Timeout	Sets the length of time (in seconds) the SLC will idle without hearing either an R_U_THERE poll from the peer, or an R_U_THERE_ACK reply. The default is 120 seconds. After this period has elapsed with no response and no traffic, the SLC will declare the peer dead, remove the Security Association (SA), and perform the action defined by Dead Peer Detection Action.
Dead Peer Detection Action	When a Dead Peer Detection enabled peer is declared dead, the action that should be taken. Hold (the default) means the tunnel will be put into a hold status. Clear means the Security Association (SA) will be cleared. Restart means the SA will immediately be renegotiated.

- 3. To save, click **Apply** button.
- 4. To see a details of the VPN tunnel connection, including the cryptographic algorithms used, select the **View Detailed Status** link.
- 5. To see the last 100 lines of the logs associated with the VPN tunnel, select the **View VPN** Logs link.
- To see the RSA public key for the SLC 8000 advanced console manager (required for configuring the remote host if RSA Public Keys are being used), select the View SLC RSA Public Key link.
- 7. To see the X.509 Certificates for the SLC 8000 advanced console manager, select the **View X.509 Certificates** link.

VPN Commands

Go to VPN Commands to view CLI commands which correspond to the web page entries described above.

Security

The SLC 8000 advanced console manager supports a security mode that complies with the FIPS 140-2 standard. FIPS (Federal Information Processing Standard) 140-2 is a security standard developed by the United States federal government that defines rules, regulations and standards for the use of encryption and cryptographic services. The National Institute of Standards and Technology (NIST) maintains the documents related to FIPS at: http://csrc.nist.gov/publications/PubsFIPS.html

FIPS 140-2 defines four security levels, Level 1 through Level 4. The SLC unit uses a FIPS module certified at Level 1.

Note: The SSH client keyboard-interactive authentication type is not supported while the SLC unit is in FIPS mode. The SLC 8000 can support a limit of 25 concurrent CLI sessions simultaneously when in FIPs mode.

To enable FIPS mode, the **Network -> Security -> FIPS Mode** flag needs to be enabled and the SLC unit rebooted. Each time the SLC unit is booted in FIPS mode, it will perform a power up self test to verify the integrity of the SLC unit's cryptographic module. If there are any issues with the integrity of the cryptographic module, FIPS mode will be disabled and the SLC unit will be rebooted into non-FIPS mode.

When the SLC unit is running in FIPS mode, the following protocols are supported: TLS 1.0, TLS 1.1, TLS 1.2, and SSH v2.

For SSL, the SLC unit will support the following cipher suites:

- AES128-SHA
- AES128-SHA256
- AES128-GCM-SHA256
- AES256-SHA
- AES256-SHA256
- AES256-GCM-SHA384

SSL/secure certificates imported for use with the web server or LDAP authentication must use either the SHA1 or SHA2 hash with a RSA public key of 1024, 2048 or 3072 bits.

For SSH, the SLC unit will support the following cipher suites:

- * AEAD-AES-128-GCM-SSH
- * AEAD-AES-256-GCM-SSH
- * AES128-CTR
- * AES256-CTR
- * AES192-CTR

SSH Keys imported for use with SSH authentication must use a RSA public key of 1024, 2048 or 3072 bits. SSH Keys exported by the SLC must use a RSA public key of 2048 or 3072 bits.

When the SLC unit is running in FIPS mode, the following protocols/functions will not be supported: NIS, Kerberos, RADIUS, TACACS+, Telnet/WebTelnet, WebSSH, IPSec/VPN, SSH v1, FTP, PPP, CIFS/Samba, TCP, UDP, unencrypted LDAP, performance monitoring, and SNMP. If any of these protocols/functions are enabled prior to enabling FIPS mode, they will be automatically disabled.

LDAP authentication must be configured with the following:

- StartTLS encryption (SSL encryption over port 636 is not supported)
- A SSL/secure certificate
- Either Bind with Login or a Bind Name and Password

Note: In FIPS mode, passphrases are not supported for SSH keys and SSL certificates.

Figure 6-9 Network > Security					
Logout Host: slc4331 User: sysadmin U1 User: sysadmin E1 1 3 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 35 37 39 41 43 45 47 A Bott: slc4331 User: U2 E2 2 4 6 8 10 12 14 16 18 20 22 24 26 8 30 32 34 36 38 40 42 44 46 8 B					
Network Services User Authentication Devices	Maintenance Quick Setup	₿ 🗉			
Network Settings IP Filter Routing VPN Security					
	Security	Help?			
Enable FIPS Mode: Description of the second					
	Apply				

To enable FIPS:

Note: The SSH client keyboard-interactive authentication type is not supported while the SLC unit is in FIPS mode.

- 1. Check the Enable FIPS Mode check box on the Networks > Security page.
- Click Apply. The SLC unit will need to be rebooted to initiate FIPS mode. Once the SLC module is running in FIPS mode, the Security page, will display all processes that are running in FIPS mode.

To disable FIPS:

- 1. Uncheck the Enable FIPS Mode check box on the Networks > Security page.
- Click Apply. The SLC unit will need to be rebooted for this change to take effect. When rebooted after disabling FIPS mode, information about processes running in FIPS mode will no longer display on the Security page.

Performance Monitoring

The SLC supports Performance Monitoring probes for analyzing network performance. Probes for DNS Lookup, HTTP Get, ICMP Echo, TCP Connect, UDP Jitter and UDP Jitter VoIP are supported. Up to 15 different probes can be configured. Each probe will run a series of operations, each of which sends a series of packets to a destination host. The SLC will measure how long it took to receive a response, and record the results. For each operation, the user can view the results for each packet (round trip times), or the accumulated statistics for all packets - minimum, average and maximum latency, and for jitter probes, minimum, average, maximum and standard deviation of the jitter delay. Dropped packets and other error conditions are recorded for each operation. Thi capability allows an administrator to analyze network efficiency across the network.

An operation consists of sending a specified number of packets to a destination host and optional port, with a specified amount of time between each packet. All results for each operation are stored in one data file, and the results can be viewed later. Accumulated statistics can also be pulled from the SLC via SNMP Gets.

Repository and Operations Kept: The SLC can be configured to store probe results on the local SLC storage, or an external USB thumb drive or SD card. The number of operations that can be stored per probe on the local SLC storage is 50 operations; for external USB thumb drive or SD, 200 operations can be stored per probe.

Responders: The SLC can act as a responder for probes that require a responder to answer packets that are sent from the SLC (UDP jitter, UDP jitter VoIP, UDP Echo and TCP Connect). The SLC UDP jitter responder can support packet responses for up to 15 UDP jitter or UDP jitter VoIP probes. The UDP Echo and TCP Connect can support packets responses for one UDP Echo or TCP Connect probe.

Jitter Probes and Clock Skew: For jitter probes, it is important to have both the sender and responder synchronized to a reliable NTP server. Significant clock skew can greatly affect jitter results, as timestamps are recorded in the sender probe and the responder, and these timestamps are used to measure one-way latency for the packets. At the start of each jitter operation, the clock skew between the sender and the responder will be output to the system log.

Compatibility with Cisco Responders: The SLC Performance Monitor sender is compatible with Cisco IP SLA responders (IOS versions 12.2 and 15.0) for jitter probes. The SLC uses a simplified version of the IP SLA v2 (Engine II) protocol to communicate with the Cisco IP SLA responders. This compatibility gives the administrator a large number of devices with which to measure network performance.

High Resolution Timers: Performance Monitoring requires that high resolution timers be enabled in order to generate accurate results down to the microsecond. The high resolution timers are disabled by default, and can be enabled on the *Maintenance > Firmware & Configurations* web page. A reboot is required if the setting is changed. Enabling high resolution timers may affect SLC performance.

To manage or view status for a Performance Monitoring probe:

1. Click the **Network** tab and select the **Perf Monitoring** option. The following page displays.

l igure o	- To Metwork > T err Monitoring	
LOGOUT	LCD SD U1 U2 MD E1 1 3 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 35 37 39 41 LCD SD U1 U2 MD E2 2 4 6 8 10 12 14 16 18 20 22 24 26 28 30 32 34 36 84 42 Select port for Configuration WebSSH (DP only) Connected Device (DP	43 45 47 A 44 46 48 B only)
Network Services User Authentication Devi	ices Maintenance Quick Setup	₿ 🗉
Network Settings IP Filter Routing VPN Secu	urity Perf Monitoring	
	Performance Monitoring	Help?
Number of operations kept for each probe: 50	UDP Jitter Responder:	
Repository for operations: Local	▼ UDP Echo Responder: □ UDP Port:	
	TCP Connect Responder: TCP Port:	
	Apply	

Figure 6-10 Network > Perf Monitoring

		<u>Refresh</u>	Add Probe Operations Latest RTT Results Latest A		Latest Ac	cumulate	ed Statistics		
0 pro	bes(s)				State:	Restart	Edit Pro	be [Delete Probe
Id	Name	State	Sta Firs	rt Time st Op	Finish Time Last Op	Error	or Operations Comp/Total		ns /tal

2. In the upper section of the page, modify the global Performance Monitoring settings:

Number of operations kept for each probe	Specifies the number of operation set files to keep for each probe. The limit for Local storage is 50 sets. The limit for external (USB or SD card) is 200 sets. While a probe is running, the operation set files will be automatically culled to remove the oldest operation set files.
Repository for operations	The repository where the operation set files will be kept - Local storage, a USB thumb drive inserted in the upper USB Port U1 or lower USB Port U2, or the SD card slot. The data is stored in individual directories under a directory called "perfmon". Once probes have been run and operation set files have been generated, changing the repository will cause all of the existing files to be moved from the old repository directory to the new repository directory. It is recommended that the repository only be changed when probes are not actively running. If external storage is used for the repository, it is recommended that the external storage device not be removed from the SLC while probes are actively running.
UDP Jitter Responder	Starts the UDP Jitter responder to reply to UDP jitter or UDP jitter VoIP packets. The responder will listen on UDP port 1967 for control messages requesting to start individual responders on a specific UDP port. The SLC UDP jitter responder can support up to 15 UDP jitter senders.
UDP Echo Responder	Starts the UDP Echo responder on the port configured in UDP Port to reply to UDP echo packets. The SLC UDP Echo responder supports one UDP echo sender.
	When the UDP Echo responder is enabled, the SLC will verify that the responder UDP port is not being used by any other SLC processes, including port 1967 which is reserved for the UDP Jitter responder.

TCP Connect Responder	Starts the TCP Connect responder on the port configured in TCP Port to reply to TCP connect requests. The SLC TCP Connect responder supports one TCP connect sender.
	When the TCP Connect responder is enabled, the SLC will verify that the responder TCP port is not being used by any other SLC processes.

3. Click the **Apply** button.

4. In the lower section of the page, select a probe by clicking the radio button to the far right in the probe's row. The options that are available for that probe will be ungreyed. Select one of the following options:

Refresh	Refreshes the information on the Performance Monitoring page.
Add Probe	Displays the <i>Performance Monitoring - Add/Edit Probe</i> web page to add a new probe.
Operations	Displays a list of completed operations for the selected probe and allows the user to view either raw packet results or accumulated statistics for any operation.
Latest Results	Displays the latest raw packet results for the selected probe.
Latest Accumulated	Displays the latest accumulated statistics for the selected probe.
State: Restart	Allows the state of a probe to be controlled: the user can Restart a completed or running probe. When a probe is added, it will automatically start running, depending on how the probe start time is configured. Once a probe has run all of its configured operations, it will be in the "Complete" state. If the SLC is rebooted, all probes will automatically be restarted.
Edit Probe	Displays the <i>Performance Monitoring - Add/Edit Probe</i> web page to edit the currently selected probe.
Delete	Deletes the selected probe, after a confirmation.

The table at the bottom of the page lists information about completed and running probes.

ld	Unique identifier for the probe.
Name	Name assigned to the probe.
State	The current state of the probe: Complete if all operations have been run, or Running if there are still operations that need to be run.
Start Time First Op	The date and time that the first operation started.
Finish Time Last Op	The date time that the most recently completed operation finished.
Error	 Any errors reported by the probe: NMT: the current repository is an external source, but the USB thumb drive or SD card is not mounted NDR: the repository directory for the probe does not exist OPF: failed to open an operation data file SCT: error initializing a socket CFG: error retrieving probe configuration EXP: probe start time has expired
Operations Comp/ Total	The number of operations that have been completed and the total number of operations that will be run.

Performance Monitoring - Add/Edit Probe

The *Performance Monitoring - Add/Edit Probe* web page allows a user to add a new Performance Monitoring probe or edit an existing Performance Monitoring probe.

To add a new probe or edit an existing probe:

- 1. Click the **Network** tab and select the Perf Monitoring option. The *Network > Perf Monitoring* page displays.
- 2. To add a new probe, in the lower section of the page, select the **Add Probe** link. To edit an existing probe, select a probe by clicking the radio button to the right right in the probe's row, then select the **Edit Probe** button. In both cases, the following page displays.

Logout Host: slc4331 User: sysadmin	U E1 1 3 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 35 37 39 41 43 45 47 A U2 U2 H 6 8 10 12 14 16 18 20 22 24 26 28 30 32 34 36 38 40 42 44 46 48 B Select port for © Configuration WebSSH (DP only) © Connected Device (DP only)
Network Services User Authentication Devices	Maintenance Quick Setup
Network Settings IP Filter Routing VPN Security	/ Perf Monitoring
Per	formance Monitoring
Number of operations kept for each probe: 50 Repository for operations: Local	UDP Jitter Responder: UDP Port: UDP Echo Responder: UDP Port: TCP Connect Responder: TCP Port:
	Apply
Performance Mo	pnitoring settings successfully updated.
Refresh > Add I	Probe Operations Latest RTT Results Latest Accumulated Statistics
1 probes(s)	State: Restart Edit Probe Delete Probe

Start Time

02/13 10:15

First Op

State

running

Finish Time

Last Op

N/A

Error

Operations Comp/Total

۲

0/100

Figure 6-11 Performance Monitoring - Add/Edit Probe

3. Modify the probe settings:

ld

1

Name

test

Probe Type	Select from one of the available probe types:
	 DNS Lookup - Performs a DNS lookup on the hostname specified in the Destination Host using the Name Server. By default port 53 is always used as the Destination Port.
	 HTTP Get - Performs a HTTP Get to the home (root) of the web server at the Destination Host and Destination Port.
	 ICMP Echo - Sends ICMP Echo (ping) packets to the Destination Host.
	 TCP Connect - Performs a TCP Connection to the Destination Host and Destination Port.
	 UDP Echo - Sends UDP Echo packets to the Destination Host and Destination Port.
	 UDP Jitter - Sends UDP jitter packets using a simplified version of the Cisco IP SLA v2 (Engine II) protocol to the Destination Host and Destination Port. UDP Jitter VoIP - Sends UDP jitter packets configured to simulate Voice over IP network traffic (VoIP) using a simplified version of the Cisco IP SLA v2 (Engine II) protocol to the Destination Host and Destination Port.

Name	Probe name, up to 40 characters long. Valid characters are letters, numbers, dashes (-), periods and underscores (_).
Number of Operations	Number of operations to perform for the probe. Probes can for a specific number of operations. The valid range is 1 - 1000, and the default is 100.
Frequency between Operations	Time between probe operations, in seconds. The valid range is 5 - 3600 seconds, and the default is 60 seconds.
Number of Packets	Number of packets to send for each probe. For DNS Lookup probes, this is the number of lookups to perform. For HTTP Get probes, this is the number of HTTP Gets to perform. For TCP Connect probes, this is the number of TCP connections to perform. The valid range is 1 - 1000 for the Local repository and 1 - 2000 for a USB or SD card respository. The default is 10 packets.
Interval between Packets	Interval between packets in milliseconds. The valid range is 10 - 5000 milliseconds, and the default is 500 milliseconds. For HTTP Get, DNS Lookup and TCP Connect probes, the timeout must be less than the interval due to a new socket being created and destroyed for each packet.
Start Time	Time to start the probe: Now starts the probe immediately; At date/time will start the probe at the specified date and time in the future; After waiting will start the probe after waiting a period of time that is less than 24 hours. When the SLC is rebooted, the probe will start according to the Start Time settings: (a) immediately if it set to Now , (b) at a date and time in the future if it is set to At date/time and the date and time is in the future, (c) after waiting a period of time if it is set to After waiting .
Destination Host	The hostname or IP address to send packets to. For DNS Lookup probes this is the hostname to lookup.
Destination Port	The TCP or UDP port to send packets to. For ICMP probes, the port setting is not used. For DNS Lookup probes, the destination port is always port 53. Port 1967 is reserved for the UDP jitter responder. The valid range is 1 - 65535.
Precision	The precision to view results in - milliseconds (the default) or microseconds. Jitter results are always displayed in milliseconds.
Data Size	The size in bytes to use for the payload portion of the packet - this size is in addition to the IPv4 header and the TCP, UDP or ICMP header. Any additional space in the packet that is not used by the protocol will be padded with random data that can be used for data verification (see below).
	This parameter is only supported for ICMP Echo, TCP Connect, UDP Echo, UDP Jitter, and UDP Jitter VoIP probes. The maximum payload for any probe is 1460 bytes. The minimum payload size for probes is: UDP Jitter VoIP G.729a codec probes - 32 bytes; all other UDP Jitter probes - 64 bytes; ICMP Echo probes - 18 bytes; TCP Connect probes - 1 bytes; UDP Echo probes - 4 bytes.
	If no data size is specified (e.g., it is set to zero), a default payload size will be used for the probes as follows:
	 ICMP Echo - 56 bytes UDP Jitter VolP G.729A - 32 bytes UDP Jitter (all others) - 64 bytes TCP Connect and UDP Echo - 256 bytes
Verify Data	If enabled, indicates that the SLC should verify if there is data corruption in the reply packets. This parameter is only supported for ICMP Echo, UDP Echo, UDP Jitter, and UDP Jitter VoIP probes.
Timeout	How long the SLC will wait for a packet to arrive, in milliseconds. If the packet arrives after the timeout it will be considered a Late Arrival error (see <i>Error Conditions</i>). The valid range is 10 - 1000, and the default is 200 msec.

UDP Jitter VoIP Codec	For UDP Jitter VoIP probes, the codec to simulate. The following codecs are available:
	 G.729A - 32 byte packets sent 20 msec apart, 1000 packets per operation, 60 seconds between operations G.711 A-law - 172 byte packets sent 20 msec apart, 1000 packets per operation, 60 seconds between operations G.711 mu-law - 172 byte packets sent 20 msec apart, 1000 packets per operation, 60 seconds between operations The default values for the VoIP probes can be overridden to use different packet sizes, intervals, etc.
ICMP Ethernet Interface	For ICMP Echo probes, which Ethernet interface can be used for the probe: both interfaces, Ethernet Port 1, or Ethernet Port 2.
TOS (Type of Service)	Sets the IPv4 Type of Service field in the IPv4 header. This is available for UDP Jitter and UDP Jitter VoIP probes only. The range is 0 - 255, and the default value is 0.
DNS Name Server IP Address	For DNS Lookup probes, the IP address of the DNS name server to use for lookups.

4. Click the **Apply** button.

Performance Monitoring - Results

The Performance Monitoring - Operations page displays all of the operations that have been saved for a selected probe. The probe ID and name are shown at the top of the web page. From this page, the user may select any operation to view its round trip time (RTT) results, or the accumulated statistics for all round trip times in an operation.

An operation consists of sending a specified number of packets to a destination host and optional port, with a specified amount of time between each packet. All results for each operation are stored in one data file.

Round Trip Times

The results for each packet in an operation can be displayed with the **RTT Results** link. Each packet will be displayed with the packet start time and any error that resulted from sending the packet. For non-jitter probes, the total round trip time is displayed in either millisconds or microseconds, depending on how the probe's precision setting:

Probe	e 6/icmp-p	probe,	operation	icmp_1700	527_	235709.dat:
Pkt	Time		R	I Time		Result
1	17-06-27	23:57:	:09.171	0.419	ms	OK
2	17-06-27	23:57:	:09.211	0.378	ms	OK
3	17-06-27	23:57:	:09.251	0.366	ms	OK
4	17-06-27	23:57:	:09.291	0.354	ms	OK
5	17-06-27	23:57:	:09.332	0.448	ms	OK
6	17-06-27	23:57:	:09.372	0.382	ms	OK
7	17-06-27	23:57:	:09.412	0.308	ms	OK
8	17-06-27	23:57:	:09.452	0.334	ms	OK
9	17-06-27	23:57:	:09.492	0.365	ms	OK
10	17-06-27	23:57:	09.532	0.361	ms	OK

For jitter probes, the source to destination and destination times are displayed in the probe's configured precision:

```
Probe 7/udp-jitter-probe, operation udpjitter 170628 002049.dat:
                    Src To Dst Time Dst To Src Time Result
Pkt Time
1 17-06-28 00:20:49.621 31029 usec 44191 usec OK
2 17-06-28 00:20:49.717
                            35409 usec
                                            44170 usec OK
                                          34120 usec OK
3
   17-06-28 00:20:49.808
                           35558 usec
   17-06-28 00:20:49.898
                            25500 usec
                                            34175 usec OK
 4
5 17-06-28 00:20:49.988
                            35210 usec
                                            34196 usec OK
                            25517 usec
35210 usec
25549 usec
6 17-06-28 00:20:50.079
                                            34177 usec OK
                                           34177 usec OK
54166 usec Late Arrival
34170 usec OK
34255 usec OK
   17-06-28 00:20:50.169
7
8 17-06-28 00:20:50.259
9 17-06-28 00:20:50.350
                            25313 usec
                                            34255 usec OK
10 17-06-28 00:20:50.440 24848 usec 34351 usec OK
```

Accumulated Statistics

A summary of all round trip time and any error conditions is displayed. The display will vary for non-jitter and jitter results. For example, non-jitter accumulated results will show:

```
Probe 6/icmp-probe, operation icmp_170627_235709.dat:
Operation Type:
    ICMP Echo to 10.0.1.162, Ethernet Port: both
    30 packets sent 40 ms apart, timeout 1000 ms
Operation Start Time: 17-06-27 23:57:09.171
Last Packet RTT: 0.340 msec
Round Trip Time Results:
    Number of RTT: 30
    RTT Min/Avg/Max: 0.306/0.362/0.448 msec
Number of Successes: 30
Number of Errors: 0
    Lost Packet: 0 (0%)
    Out of Sequence: 0
    Late Arrival: 0
    Miscellaneous Error: 0
```

For jitter probes, positive (increasing latency) and negative (decreasing latency) statistics are shown, as well as the number of positive or negative jitter samples in each direction, and the sum and (and sum squared) of the positive or negative jitter times. These numbers give a summary of how much variation there was in latency times and if the variation was small or large.

```
Probe 7/udp-jitter-probe, operation udpjitter_170628_002049.dat:
Operation Type:
    UDP Jitter to 10.0.1.93:50505
    50 packets sent 60 ms apart, timeout 1000 msec
Operation Start Time: 17-06-28 00:20:49.071
Last Packet RTT: 69.334 msec
Round Trip Time Results:
    Number of RTT: 50
    RTT Min/Avg/Max: 57.327/63.863/89.376 msec
One-way Latency Results:
    Number of samples: 50
    Source to Destination Min/Avg/Max: 23.174/27.467/45.206 msec
Destination to Source Min/Avg/Max: 34.068/36.396/54.166 msec
```

```
Jitter, Source to Destination:
   Number of Samples: 49
    Positive and Negative Min/Avg/Max: 1/4/20 msec
   Positive Min/Avg/Max: 1/7/20 msec
   Positive Number Of/Sum of All/Sum of All Squared: 13/100/1090 msec
   Negative Min/Avg/Max: 1/5/20 msec
   Negative Number Of/Sum of All/Sum of All Squared: 17/96/1018 msec
Jitter, Destination to Source:
   Number of Samples: 49
    Positive and Negative Min/Avg/Max: 10/3/20 msec
    Positive Min/Avg/Max: 10/12/20 msec
    Positive Number Of/Sum of All/Sum of All Squared: 7/90/1300 msec
   Negative Min/Avg/Max: 10/12/20 msec
   Negative Number Of/Sum of All/Sum of All Squared: 8/100/1400 msec
Number of Successes: 49
Number of Errors: 1
   Lost Packet: 0 (0%)
   Out of Sequence: 0
   Late Arrival: 1
   Miscellaneous Error: 0
```

Table 6-12 Error Conditions

The following error conditions are detected by the probes. Except where noted, the RTT results for a packet with errors will not be counted in the accumulated statistics.

Error Condition	Description
Timeout	a response was never received for the packet. These packets are listed as Lost Packets under the accumulated statistics.
Late Arrival	a response was received for a packet, but the response was received after the timeout configured for the probe. The SLC will wait at most 2 times the probe's timeout for late arrival packets. The RTT results will be included in the accumulated statistics.
Not Connected	a packet could not be sent because the connection to the destination host could not be established, or because the attempt to send the packet failed.
Sequence Error	a packet response was received with an unexpected sequence number. Possible reasons are: a duplicate packet was received, a response was received after it timed out, a corrupted packet was received and was not detected.
Verify Data Error	a response was received for a packet with payload data that does not match the expected data.
DNS Server Timeout	a DNS lookup could not be completed because the SLC could not connect to the DNS name server.
DNS Lookup Error	a DNS lookup failed - the requested hostname could not be resolved. This is not considered a protocol error, but rather an expected result, depending on the hostname being resolved. The RTT results will be included in the accumulated statistics.
TCP Connect Timeout	a TCP connect could not be completed because a connection to the TCP server could not be established.
HTTP Transaction Timeout	a HTTP Get that failed because no response was received from the HTTP server before the timeout expired.

Error Condition	Description
HTTP Error	a HTTP Get succeeded, but the HTTP content (base page) that was downloaded had errors: missing "HTTP/" header string, missing "Connection: close" string, or response has an HTTP error code (the code was not 200/OK). This is not considered a protocol error. The RTT results will be included in the accumulated statistics.
Generic Error	any error that does fall into any of the above error conditions.

To view results for a Performance Monitoring probe:

- 1. Click the **Network** tab and select the **Perf Monitoring** option. The *Network > Perf Monitoring* page displays.
- 2. Select a probe from the table in the lower part of the page and select the **Operations** link. The **Performance Monitoring Operations** page displays.

LOGOUT	SLC 804	B LCD SD U1 U2 Selec	MD E1 1 3 5 E2 2 4 6 at port for O C	7 9 11 13 15 8 10 12 14 16 onfiguration V	17 19 21 23 25 2 18 20 22 24 26 2 VebSSH (DP only)	27 29 31 33 35 37 3 28 30 32 34 36 38 4 Connected Devia	9 41 4 10 42 4 e (DP 1	13 45 47 A 14 46 48 B only)
Network Services Use	r Authentication	Devices Main	ntenance	Quick Setup		4	8 ?	(]
Network Settings IP Filter	Routing VPN	Security Perf N	Monitoring					
	Pe	rformance Mo	onitoring	- Operation	S			Help?
< Back to Perf Monitoring		Prob	e #1 / test					
		Refresh > R	RTT Results	Accumulat	ed Statistics			
	Operations							
	Set Number	Set Name						

Figure 6-13 Performance Monitoring - Operations

3. A table will list all available operations for the selected probe, with the most recent operation listed first. The table may be empty if no operations have been run for the probe or the operations for the probe have been deleted. Select an operation by clicking the radio button to the far right in the operation's row. The options that are available for that operation will be ungreyed. Select one of the following options:

Refresh	Refreshes the information on the Performance Monitoring - Operations page.
RTT Results	Displays the round trip time (RTT) results for the selected operation in a separate window. The results show:
	 the time that the packet was sent, the total round trip time for non-jitter probes or the source to destination time and destination to source time for jitter probes, and the status for the packet - OK/successful or an error condition.
	For more information, see <i>Round Trip Times</i> or <i>Error Conditions</i>).
Accumulated Results	Displays the accumulated statistics for the selected operation in a separate window. The results show parameters used for the selected operation, and the minimum, average and maximum round trip times for all probes. For jitter probes, the results show minimum, average and maximum one way latency times, as well as jitter results for source to destination and destination to source. For a probes, a summary of lost packets and error conditions is displayed.

Performance Monitoring Commands

Go to *Performance Monitoring Commands* to view CLI commands which correspond to the web page entries described above.

7: Services

System Logging and Other Services

Use the **Services** tab to:

- Configure the amount of data sent to the logs.
- Enable or disable SSH and Telnet logins.
- Enable a Simple Network Management Protocol (SNMP) agent.

Note: The SLC advanced console manager supports both MIB-II (as defined by RFC 1213) and a private enterprise MIB. The private enterprise MIB provides read-only access to all statistics and configurable items provided by the SLC unit. It provides read-write access to a select set of functions for controlling the SLC 8000 advanced console manager and device ports. See the MIB definition file for details.

- Identify a Simple Mail Transfer Protocol (SMTP) server.
- Enable or disable SSH and Telnet logins.
- Configure an audit log.
- View the status of and manage the SLC 8000 advanced console managers on the Secure Lantronix network.
- Set the date and time.
- Configure NFS and CIFS shares.
- Configure the web server.

SSH/Telnet/Logging

To configure SSH, Telnet, and Logging settings:

1. Click the **Services** tab and select the **SSH/Telnet/Logging** option. The following page displays.

LANTRON	X° SLC 8048	1 MD E1 1 3 5 7 9 11 13 15 17 19 21 2 E2 2 4 6 8 10 12 14 16 18 20 22	23 25 27 29 31 33 35 37 39 41 43 45 47 A 24 26 28 30 32 34 36 38 40 42 44 46 48 B
Logout Hos	st: slc4331 Se er: sysadmin Se	lect port for 💿 Configuration 🔵 WebSSH (DF	only) Connected Device (DP only)
Network Services	User Authentication Devices Ma	aintenance Quick Setup	础 ? 冄 国
SSH/Telnet/Logging	NMP NFS/CIFS Secure Lantronix N	letwork Date & Time Web Server	
	SSH/1	felnet/Logging	Help?
System Logging		<u>SSH</u>	
Network Level:	Warning •	Enable Logins:	Veb SSH:
Services:	Warning •	Timeout:	No Yes: 0 minutes
Authentication:	Warning •	Timeout Data Direction:	Both Directions •
Device Ports:	Warning •	SSH Port: 2	22
Diagnostics:	Warning •	SSH V1 Logins:	✓
General:	Warning •	DSA Keys:	✓
Remote Server #1:		Use only SHA2 and Higher: [
#2:		Telucí	
RPM Log Size:	20 Kbytes	Enable Logins:	Web Telnet
Other Log Size:	200 Kbytes	Timeout:	No Yes: 0 minutes
		Timeout Data Direction:	Both Directions 🔻
Audit Log		Escape Sequence: 🕅	x1bT
Enable Log:		Outgoing Telpet	
Size:	50 Kbytes		
Include CLI Commands:		Web SSH/Web Telnet Settings	
Include in System Log		Terminal Buffer Size: 2	250
SMTP		Phone Home	
Server:		Enable:	
Sender:	donotreply@\$host.\$domain	IP Address	
	Note: '\$host' and '\$domain' will be	Last Attempt: N	I/A
	substituted with hostname and domain.	Results: N	I/A
		Apply	

Figure 7-1 Services > SSH/Telnet/Logging

2. Enter the following settings:

System Logging

Alert Levels	 Select one of the following alert levels from the drop-down list for each message category: Off: Disables this type of logging. Error: Saves messages that are output because of an error. Warning: Saves message output from a condition that may be cause for concern, in addition to error messages. This is the default for all message types. Info: Saves informative message, in addition to warning and error messages. Debug: Saves extraneous detail that may be helpful in tracking down a problem, in addition to information, warning, and error messages.
Network Level	Messages concerning the network activity, for example about Ethernet and routing.
Services	Messages concerning services such as SNMP and SMTP.
Authentication	Messages concerning user authentication.
Device Ports	Messages concerning device ports and connections.
Diagnostics	Messages concerning system status and problems.
General	Any message not in the categories above.
Remote Servers (#1 and #2)	The IPv4 or IPv6 address of the remote server(s) where system logs are stored. The system log is always saved to local SLC storage. It is retained through SLC unit reboots for files up to Other Log Size (see below). Saving the system log to a server that supports remote logging services (see RFC 3164) allows the administrator to save the complete system log history. <i>Note: If the SLC is unable resolve the Remote Server hostnames or contact the Remote Servers to send syslog messages, the syslog messages that cannot be sent to</i>
	a Remote Server may appear on the SLC console port.
RPM Log Size	The maximum size in Kbytes that RPM logs can grow to before they are pruned. When the file is pruned, it will be pruned to 50% of the RPM Log Size.
Other Log Size	The maximum size in Kbytes that all logs other than the RPM logs can grow to before they are pruned. When the file is pruned, it will be pruned to 50% of the Other Log Size.

Audit Log

Enable Log	Select to save a history of all configuration changes in a circular log. Disabled by default. The audit log is saved through SLC 8000 advanced console manager reboots.
Size	The log has a default maximum size of 50 Kbytes (approximately 500 entries). You can set the maximum size of the log from 1 to 500 Kbytes.
Include CLI Commands	Select to cause the audit log to include the CLI commands that have been executed. Disabled by default.
Include In System Log	If enabled, the contents of the audit log are added to the system log (under the General/Info category/level). Disabled by default.

SMTP

Server	IP address of your network's Simple Mail Transfer Protocol (SMTP) relay server. If an SMTP server is not specified, the SLC module will attempt to look up the MX record for the domain in the destination email addresses of outgoing emails.
Sender	The email address of the sender of outgoing emails. The strings "\$host" and "\$domain" can be part of the email address - they will be substituted with the actual hostname and domain. The default is donotreply@\$host.\$domain.

SSH

Enable Logins	Enables or disables SSH logins to the SLC unit to allow users to access the CLI using SSH. Enabled by default.
	This setting does not control SSH access to individual device ports. (See <i>Device Ports</i> - <i>Settings (on page 128)</i> for information on enabling SSH access to individual ports.)
	Most system administrators enable SSH logins, which is the preferred method of accessing the system.
Web SSH	Enables or disables the ability to access the SLC command line interface or device ports (connect direct) through the Web SSH window. Disabled by default.
Timeout	If you enable SSH logins, you can cause an idle connection to disconnect after a specified number of minutes. Select Yes and enter a value of from 1 to 30 minutes.
Timeout Data Direction	 If idle connection timeouts are enabled, this setting indicates the direction of data used to determine if the connection has timed out. Select the type of data direction: Both Directions Incoming Network Outgoing Network
SSH Port	Allows you to change the SSH login port to a different value in the range of 1 - 65535. The default is 22. Use of ports other than 22 that are less than 1025 is not recommended.
SSH V1 Logins	Enables or disables SSH version 1 connections to the SLC 8000 advanced console manager. Enabled by default.
DSA Keys	Enables or disables support for DSA keys for incoming and outgoing connections for the SLC unit. Any imported or exported DSA keys will be retained but will not be visible on the web or the CLI. Enabled by default.
Use only SHA2 and Higher	Enables or disables support for only SHA2 and higher ciphers for incoming connections for the SLC unit. Disabled by default. Enabling this option will also disable MACs with tag sizes lower than 128 bits (e.g. umac-64-etm@openssh.com and umac-64@openssh.com).

Telnet

Enable Logins	Enables or disables Telnet logins to the SLC unit to allow users to access the CLI using Telnet. Disabled by default.
	This setting does not control Telnet access to individual device ports. (See <i>Device Ports</i> > <i>Settings (1 of 2) (on page 129)</i> for information on enabling Telnet access to individual ports.) You may want to keep this option disabled for security reasons.
Web Telnet	Enables or disables the ability to access the SLC command line interface or device ports (connect direct) through the Web Telnet window. Disabled by default.
Timeout	If you enable Telnet logins, you can cause an idle connection to disconnect after a specified number of minutes. Select Yes and enter a value of from 1 to 30 minutes.
Timeout Data Direction	 If idle connection timeouts are enabled, this setting indicates the direction of data used to determine if the connection has timed out. Select the type of data direction: Both Directions Incoming Network Outgoing Network

Escape Sequence	A single character or a two-character sequence that causes the SLC unit to terminate a Telnet client. Currently the Escape Sequence is only used for Web Telnet sessions. The default value is Esc+T (escape key, then uppercase "T" performed quickly but not simultaneously). You would specify this value as \x1bT , which is hexadecimal (\x) character 27 (1B) followed by a T . A control character can be specified with the hexidecimal number for the control character; for example, Control-E can be specified as \x05. Note that some browsers do not report key press events if Control is pressed for non-alphanumeric keys, so it is recommended to only use letters with Control character sequences.
Outgoing Telnet	Enables or disables the ability to create Telnet out connections.

Web SSH/Web Telnet Settings

Terminal Buffer Size	Number of lines in the Web SSH or Web Telnet terminal window that are available for scrolling back through output.
	Note: For tips on browser issues with Web SSH or Web Telnet, see Troubleshooting Browser Issues.

Phone Home

Enable	If enabled, allows SLC 8000 advanced console manager to directly contact a vSLM™ management appliance and request addition to the database
IP Address	IP address of the SLM device.
Last Attempt (view only)	Displays the date and time of last connection attempt.
Results (view only)	Indicates whether the attempt was successful.

3. To save, click the **Apply** button.

SSH Commands

Go to *SSH Key Commands* to view CLI commands which correspond to the web page entries described above.

Logging Commands

Go to *Logging Commands* to view CLI commands which correspond to the web page entries described above.

SNMP

Simple Network Management Protocol (SNMP) is a set of protocols for managing complex networks. The SLC unit supports both MIB-II (as defined by RFC 1213) and a private enterprise MIB. The private enterprise MIB provides read-only access to all statistics and configurable items provided by the SLC unit. It provides read-write access to a select set of functions for controlling the SLC unit and device ports. See the MIB definition file for details. The SLC MIB definition file and the top level MIB file for all Lantronix products is accessible from the SNMP web page.

1. Click the Services tab and select the SNMP option. The following page displays:

	Figure 7	-2 Services > SNMP		
	NX [®] SLC 8048	D SD U1 MD E1 1 3 5 7 9 11 13 15 17 19	21 23 25 27 29 31 33 35 37 39 41 43	45 47
Logout	Host: slc4331	Select port for Configuration WebSSH	1 (DP only) Connected Device (DP or	46 48 nly)
etwork Services	User Authentication Devices	Maintenance Quick Setun	쇼 ?	¢ (
SSH/Telnet/Logging	SNMP NFS/CIFS Secure Lantr	onix Network Date & Time Web Serv	er	
		SNMP		Help
Enable Agent:	Top Level MIB SLC MIB SLC MON MIB	Traps Enable	d for Sending	
Enable v1		coldStart (1.3.6.1.6.3.1.1.5.1)		
Enable VI.		linkDown (1.3.6.1.6.3.1.1.5.3)		
Enable V2c:	(linkUp (1.3.6.1.6.3.1.1.5.4)		
Enable Traps:		authenticationFailure (1.3.6.1.6.3.1.1	.5.5)	
Trap Version:	2c •	slcEventPowerSupply (1.3.6.1.4.1.24	4.1.1.0.1)	
NMS #1:		sicEventSysadminPassword (1.3.6.1.	4.1.244.1.1.0.2)	
NMS #2		sicEventSLCShutdown (1.3.6.1.4.1.2	44.1.1.0.3)	
NW3 #2.		slcEventDevicePortData (1.3.6.1.4.1.	244.1.1.0.4)	
Alarm Delay:	60 seconds	sicEventDevicePortSLMData (1.3.6.1	.4.1.244.1.1.0.5)	
Engine ID:	800000F4030080A3964331	sicEventDevicePortSLMConfig (1.3.6	.1.4.1.244.1.1.0.6)	
		sicEventDevicePortDeviceLowTemp	(1.3.6.1.4.1.244.1.1.0.7)	
Location:	location	sicEventDevicePortDeviceHighTemp	(1.3.6.1.4.1.244.1.1.0.8)	
Contact:	contact		lity (1.3.6.1.4.1.244.1.1.0.9)	
		slcEventDevicePortDeviceHighHumio	dity (1.3.6.1.4.1.244.1.1.0.10)	
1/v2c Communities		slcEventDevicePortDeviceError (1.3.	6.1.4.1.244.1.1.0.11)	•
Read-Only:	public	slcEventUSBAction (1.3.6.1.4.1.244.	1.1.0.14)	•
5		slcEventInternalTemp (1.3.6.1.4.1.24	4.1.1.0.13)	•
Read-Write:	private	slcEventDevicePortError (1.3.6.1.4.1.	244.1.1.0.15)	•
Trap:	public	slcEventSDCardAction (1.3.6.1.4.1.2	44.1.1.0.16)	•
		slcEventNoDialToneAlarm (1.3.6.1.4.	1.244.1.1.0.17)	
ersion 3		slcEventRPMAction (1.3.6.1.4.1.244.	1.1.0.18)	1
Security:	No Auth/No Encrypt	slcEventPingHostFails (1.3.6.1.4.1.24	44.1.1.0.19)	1
	Auth/No Encrypt Auth/Encrypt	slcEventDevicePortDeviceContactCh	anged (1.3.6.1.4.1.244.1.1.0.20)	
	- Addirenciypt	slcEventSFPAction (1.3.6.1.4.1.244.1	.1.0.21)	
Auth with:	🖲 MD5 🔍 SHA	slcEventDevicePortAction (1.3.6.1.4.	1.244.1.1.0.22)	
Encrypt with:	• DES AES	slcEventNetworkFailover (1.3.6.1.4.1	.244.1.1.0.23)	
			SNMP Traps Sent/	Fail: 0
<u>/3 Users</u>	Read-Only	Read-Write	<u>Trap</u>	_
User Name:	snmpuser	snmprwuser	snmptrapuser	
Password:	•••••	•••••	•••••	
Retype Password:		•••••	•••••	
Passphrase:				
Retyne Passnhrase:				

2. Enter the following:

Enable Agent	Enables or disables the Simple Network Management Protocol (SNMP) agent, which allows read-only access to the system. Disabled by default.
Top Level MIB (link)	Click the link to access the top level MIB file for all Lantronix products.
SLC MIB (link)	Click the link to access the SLC MIB definition file for SLC 8000 advanced console managers and advanced console managers.
SLC MON MIB (link)	Click the link to access the SLC monitor MIB definition file for SLC 8000 advanced console managers and advanced console managers.
Enable v1	If checked, SNMP version 1 (which uses the Read-Only and Read-Write Communities) is enabled. The default is disabled.
Enable v2c	If checked, SNMP version 2c (which uses the Read-Only and Read-Write Communities) is enabled. The default is enabled.
Enable Traps	Traps are notifications of certain critical events. Disabled by default. This feature is applicable when SNMP is enabled. Traps that the SLC unit sends include: coldStart (generic trap 0, OID 1.3.6.1.6.3.1.1.5.1) linkDown (generic trap 2, OID 1.3.6.1.6.3.1.1.5.3) linkUp (generic trap 3, OID 1.3.6.1.6.3.1.1.5.4) authenticationFailure (generic trap 4, OID 1.3.6.1.6.3.1.1.5.5) slcEventPowerSupply (1.3.6.1.4.1.244.1.1.0.1) slcEventSysadminPassword (1.3.6.1.4.1.244.1.1.0.2) slcEventSLCShutdown (1.3.6.1.4.1.244.1.1.0.3) slcEventDevicePortBat (1.3.6.1.4.1.244.1.1.0.4) slcEventDevicePortSLMData (1.3.6.1.4.1.244.1.1.0.6) slcEventDevicePortSLMConfig (1.3.6.1.4.1.244.1.1.0.6) slcEventDevicePortDeviceLowTemp (1.3.6.1.4.1.244.1.1.0.6) slcEventDevicePortDeviceLowTemp (1.3.6.1.4.1.244.1.1.0.9) slcEventDevicePortDeviceLowTemp (1.3.6.1.4.1.244.1.1.0.9) slcEventDevicePortDeviceLowTemp (1.3.6.1.4.1.244.1.1.0.9) slcEventDevicePortDeviceError (1.3.6.1.4.1.244.1.1.0.10) slcEventDevicePortDeviceError (1.3.6.1.4.1.244.1.1.0.11) slcEventDevicePortDeviceContertChanged (1.3.6.1.4.1.244.1.1.0.10) slcEventDevicePortDeviceContactChanged (1.3.6.1.4.1.244.1.1.0.20) slcEventSPAction (1.3.6.1.4.1.244.1.1.0.17) slcEventDevicePortDeviceContactChanged (1.3.6.1.4.1.244.1.1.0.20) slcEventDevicePortDeviceContactChanged (1.3.6.1.4.1.244.1.1.0.20) slcEventDevicePortDeviceContactChanged (1.3.6.1.4.1.244.1.1.0.20) slcEventDevicePortDeviceContactChanged (1.3.6.1.4.1.244.1.1.0.20) slcEventDevicePortAction (1.3.6.1.4.1.244.1.1.0.17) slcEventDevicePortAction (1.3.6.1.4.1.244.1.1.0.17) slcEventDevicePortAction (1.3.6.1.4.1.244.1.1.0.21) slcEventDevicePortAction (1.3.6.1.4.1.244.1.1.0.22) slcEventDevicePortAction (1.3.6.1.4.1.244.1.1.0.22) slcEventDevicePortAction (1.3.6.1.4.1.244.1.1.0.23) The

Trap Version	When traps are sent, which SNMP version to use when sending the trap: v1, v2c or v3. The default is v2c.
NMS #1 (or #2)	When SNMP is enabled, an NMS (Network Management System) acts as a central server, requesting and receiving SNMP-type information from any computer using SNMP. The NMS can request information from the SLC 8000 advanced console manager and receive traps from the SLC unit. Enter the IPv4 or IPv6 address of the NMS server. At least NMS #1 is required if you selected Enable Traps .
Alarm Delay	Number of seconds delay between outgoing SNMP traps.
Engine ID	The unique SNMP engine identifier for the SLC. This identifier may be required by the NMS in order to received v3 traps.
Location	Physical location of the SLC 8000 advanced console manager (optional). Useful for managing the SLC unit using SNMP. Up to 20 characters.
Contact	Description of the person responsible for maintaining the SLC 8000 advanced console manager, for example, a name (optional). Up to 20 characters.

v1/v2c Communities

Read-Only	A string that SNMP agent provides. The default is public .
Read-Write	A string that acts like a password for an SNMP manager to access the read-only data from the SLC unit SNMP, like a password for an SNMP manager to access the read-only data the SLC SNMP agent provides, and to modify data where permitted. The default is private .
Тгар	The trap used for outgoing generic and enterprise traps. Traps sent with the Event trigger mechanism still use the trap community specified with the Event action. The default is public .

Version 3

Security	Levels of security available with SNMP v. 3.				
	 No Auth/No Encrypt: No authentication or encryption. Auth/No Encrypt: Authentication but no encryption. (default) Auth/Encrypt: Authentication and encryption. 				
Auth with	For Auth/No Encryp or Auth/Encrypt, the authentication method:				
	 MD5: Message-Digest algorithm 5 (default) 				
	SHA: Secure Hash Algorithm				
Encrypt with	Encryption standard to use:				
	 DES: Data Encryption Standard (default) 				
	 AES: Advanced Encryption Standard 				

V3 User Read-Only

User Name	SNMP v3 is secure and requires user-based authorization to access SLC MIB objects. Enter a user ID. The default is snmpuser . Up to 20 characters.
Password/Retype Password	Password for a user with read-only authority to use to access SNMP v3. The default is SNMPPASS . Up to 20 characters.
Passphrase/ Retype Passphrase	Passphrase associated with the password for a user with read-only authority. Up to 20 characters. If this is not specified it will default to the v3 Read-Only Password.

V3 User Read-Write

User Name	SNMP v3 is secure and requires user-based authorization to access SLC MIB objects. Enter a user ID for users with read-write authority. The default is snmprwuser . Up to 20 characters.
Password/ Retype Password	Password for the user with read-write authority to use to access SNMP v3. The default is $\ensuremath{SNMPRWPASS}$. Up to 20 characters.
Passphrase/ Retype Passphrase	Passphrase associated with the password for a user with read-write authority. Up to 20 characters. If this is not specified it will default to the v3 Read-Write Password.

V3 User Trap

User Name	SNMP v3 is secure and requires user-based authorization to access SLC unit MIB objects. Enter a user ID for users with authority to send traps. The default is snmptrapuser. Up to 20 characters.
Password/ Retype Password	Password for the user with authority to send v3 traps. The default is SNMPTRAPPASS. Up to 20 characters.
Passphrase/ Retype Passphrase	Passphrase associated with the password for a user with authority to send v3 traps. Up to 20 characters. If this is not specified it will default to the v3 Trap Password.

3. To save, click the **Apply** button.

Services Commands

Go to *Services Commands* to view CLI commands which correspond to the web page entries described above.

NFS and SMB/CIFS

Use the Services > NFS & SMB/CIFS page if you want to save configuration and logging data onto a remote NFS server, or export configurations by means of an exported CIFS share.

Mounting an NFS shared directory on a remote network server onto a local SLC directory enables the SLC advanced console manager to store device port logging data on that network server. This configuration avoids possible limitations in the amount of disk space on the SLC unit available for the logging file(s). You may also save SLC configurations on the network server.

Similarly, use SMB/CIFS (Server Message Block/Common Internet File System), Microsoft's filesharing protocol, to export a directory on the SLC 8000 advanced console manager as an SMB/ CIFS share. The SLC unit exports a single read-write CIFS share called "public," with the subdirectory the config directory, which contains saved configurations and is read-write.

The share allows users to access the contents of the directory or map the directory onto a Windows computer.

To configure NFS and SMB/CIFS:

1. Click the **Services** tab and select the **NFS/CIFS** option. The following page displays:

	Logout	5LC 8048	LCD SD U1 U2 Selec	E1 1 3 5 E2 2 4 6 t port for ()	7 9 11 1 8 10 12 1 Configuration	3 15 17 19 21 23 4 16 18 20 22 24 WebSSH (DF	25 27 29 31 33 3 26 28 30 32 34 3 only) Connecte	5 37 39 41 6 38 40 42 d Device (DF	43 45 47 A 44 46 48 B
Netw	ork Services User Aut	hentication De	vices Maint	tenance	Quick Set	up		<u>م</u>	? 🗗 🗉
SSH	I/Telnet/Logging SNMP N	FS/CIFS Secure	Lantronix Net	work Date	e & Time	Web Server			
			NFS &	SMB/CI	FS				Help?
NFS	Mounts								
	Remote Directory		Local Direc	tory			Read-Write	Mount	Mounted
#1:									
#2:	-								
#3:									
	SMB/CIFS Share Share SMB/CIFS directory: Network Interfaces: CIFS User Password: Retype Password:	The SLC can b This	e configured to directory can a 19.100.148)	share a dire Iso be used	ectory conta for saving Eth2	aining the syste SLC configurati	m logs to a Micro ons via <u>Firmwar</u> The S accessed	soft Windo e & Config MB/CIFS s b by the 'ci	ows network. g <u>urations</u> ≻. share can be fsuser' login.
	Workgroup:			Apply					

Figure 7-3 Services > NFS & SMB/CIFS

2. Enter the following for up to three directories:

NFS Mounts

Remote Directory	The remote NFS share directory in the format: nfs_server_hostname or ipaddr:/exported/path
Local Directory	The local directory on the SLC 8000 advanced console manager on which to mount the remote directory. The SLC unit creates the local directory automatically.
Read-Write	If enabled, indicates that the SLC 8000 advanced console manager can write files to the remote directory. If you plan to log port data or save configurations to this directory, you must enable this option.
Mount	Select the checkbox to enable the SLC unit to mount the file to the NFS server. Disabled by default.
Mounted	Indicates if the SLC was able to successfully mount the NFS share directory.

3. Enter the following:

SMB/CIFS Share

Share SMB/CIFS directory	Select the checkbox to enable the SLC 8000 advanced console manager to export an SMB/CIFS share called "public." Disabled by default.
Network Interfaces	Select the network ports from which the share can be seen. The default is for the share to be visible on both network ports.
CIFS User Password/Retype Password	Only one user special username (cifsuser) can access the CIFS share. Enter the CIFS user password in both password fields. The default user password is CIFSPASS . More than one user can access the share with the cifsuser user name and password at the same time.
Workgroup	The Windows workgroup to which the SLC unit belongs. Every PC exporting a CIFS share must belong to a workgroup. Can have up to 15 characters.

- 4. To save, click the **Apply** button.
- 5. Click the Firmware & Configurations link to access the *Firmware & Configurations (on page 252)* to save SLC configuration, as desired.

NFS and SMB/CIFS Commands

Go to *NFS and SMB/CIFS Commands* to view CLI commands which correspond to the web page entries described above.

Secure Lantronix Network

Use the Secure Lantronix Network option to view and manage SLC and SLB console managers, SLC 8000 advanced console managers, and Lantronix Spider® devices on the local subnet.

Note: Status and statistics shown on the web interface represent a snapshot in time. To see the most recent data, reload the web page.

To access SLC and SLB console managers, and Lantronix Spider devices on the local network:

1. Click the Services tab and select the Secure Lantronix Network option. The following page displays.



Figure 7	-4	Services	>	Secure	I antronix	Network
i igui c i	_	001110003	-	Occurc	Landonix	NOLWOIN

Secure Lantronix Managers and Spiders on the local subnet.	Search Options
Each host can be managed by selecting its IP address.	Refresh

9	D	evi	ice(s) f	οι	Ind	
---	---	-----	------	---	-----	----	-----	--

<u>Hostname</u>	Model	IP Address/ Web Interface	<u>FW</u> Ver	SSH/ Teinet to CLI	Ports Click on bright green ports to Web SSH or Web Telnet.
slc4331	SLC8048	<u>172.19.100.124</u> >	7.4.0.0B4	<u>SSH</u> ≯ <u>Telnet</u> ≯	1 3 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 35 37 39 41 43 45 47 2 4 6 8 10 12 14 16 18 20 22 24 26 28 30 32 34 36 38 40 42 44 46 48
slcfc61	SLC8016	<u>172.19.100.82</u>	7.4.0.0R3	N/A	1 3 5 7 9 11 13 15 2 4 6 8 10 12 14 16
slc48250120-740B4	SLC8048	<u>172.19.250.120</u>	7.4.0.0B4	<u>SSH</u> > Telnet>	1 3 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 35 37 39 41 43 45 47 2 4 6 8 10 12 14 16 18 20 22 24 26 28 30 32 34 36 38 40 42 44 46 48
slc	SLC8048	<u>172.19.100.154</u> >	7.0.0.0R11	N/A	1 3 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 35 37 39 41 43 45 47 2 4 6 8 10 12 14 16 18 20 22 24 26 28 30 32 34 36 38 40 42 44 46 48
slc48SFP251-7400B4	SLC8016	<u>172.19.39.251</u> >	7.4.0.0B4	<u>SSH</u> > Telnet>	1 3 5 7 9 11 13 15 2 4 6 8 10 12 14 16
slc-md	SLC8048	<u>172.19.226.40</u> >	7.3.0.6A2	N/A	1 3 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 35 37 39 41 43 45 47 2 4 6 8 10 12 14 16 18 20 22 24 26 28 30 32 34 36 38 40 42 44 46 48
slcfc57	SLC8016	<u>172.19.100.167</u> >	7.4.0.0B4	N/A	1 3 5 7 9 11 13 15 2 4 6 8 10 12 14 16
slc035c	SLC8016	<u>172.19.100.30</u> >	7.3.0.6A2	<u>SSH</u> > Telnet>	1 3 5 7 9 11 13 15 2 4 6 8 10 12 14 16
slcfc2b	SLC8016	<u>172.19.217.201</u>	7.4.0.0R3	N/A	1 3 5 7 9 11 13 15 2 4 6 8 10 12 14 16

2. Access your device or device port through any of the methods below.
To directly access the web interface for a secure Lantronix device:

- 1. Make sure Web Telnet and Web SSH is enabled for the specific device or device port.
- 2. Click the IP address of a specific secure Lantronix device to open a new browser page with the web interface for the selected secure Lantronix device.
- 3. Log in as usual.



SLC8048
Login to SLC8048
Login:
Password:

To directly access the CLI interface for a device:

 Click the SSH or Telnet link in the SSH/Telnet to CLI column directly beside the port you would like to access.

Note: For SLC console managers with 7.2.0.0 firmware releases and earlier, an SSH or Telnet popup window for Java appears (see Figure 7-6) before login. Click OK to dismiss this popup window and continue on to the login. For SLC console managers with 7.3.0.0 firmware releases and later, the SSH or Telnet popup window is bypassed and you are brought directly to the login in a non-Java based browser window (see Figure 7-7). For tips on troubleshooting browser issues for the non-Java based Web SSH/Telnet application, see Browser Issues (on page 111).

Opening webssh. jnlp	Opening webtelnet.jnlp
You have chosen to open	You have chosen to open
webssh.jnlp which is a: INUP File (853 bytes) from: https://172.19.208.100 What should Firefox do with this file? <u>Open with</u> Java(TM) Web Start Launcher (default) <u>Save File Do this gutomatically for files like this from now on. </u>	webtelnet.jnp which is a: JNLP File (848 bytes) from: https://172.19.208.100 What should Firefox do with this file? Ogen with Java(TM) Web Start Launcher (default) Save File Do this gutomatically for files like this from now on.
OK Cancel	OK Cancel

Figure 7-6 SSH and Telnet Opening File Popups

- 2. Click your mouse into the CLI login interface that appears and login. The CLI interface will indicate when your connection is established.
- 3. When using the non-Java Web SSH or Web Telnet window, to terminate the session, use either the host's logoff command. You may also use ^] to terminate a Telnet session or ~. to terminate an SSH session.





To directly access a specific port on a particular device:

- 1. You have two options:
 - Dashboard

Make sure the **WebSSH (DP only)** radio button directly beneath the Dashboard is selected and click the desired port number. The Dashboard is located on the upper right corner of each Web Manager page (see *Chapter 5: Web Page Layout.*) An SSH popup window appears.

Note: WebTelnet is not available from the Dashboard. See **Dashboard on** page 60 as the dashboard may vary in appearance.



- Secure Lantronix Page

Click the **Services** tab, then click the **Secure Lantronix Network** link (see *Figure 7-4.*) Select the port you want to configure. Enabled port numbers are in bright green boxes and will allow you to select either a **WebSSH** or a **WebTeInet** session. If enabled, an SSH or Telnet popup window appears depending on what is clicked. For SLC console managers with 7.2.0.0 firmware releases and earlier, an SSH or Telnet popup window for Java appears (see *Figure 7-6*) before login. Click OK to dismiss this popup window and continue on to the login. For SLC console managers with 7.3.0.0 firmware releases and later, the SSH or Telnet popup window is bypassed and you are brought directly to the login in a non-Java based window (see *Figure 7-7*). For tips on troubleshooting browser issues for the non-Java based Web SSH/Telnet application, see *Browser Issues (on page 111)*.

Note: Port numbers that are disabled are in dark green boxes; clicking a disabled port number generates a popup window indicating the port is disabled (see Figure 7-8 below.)

Figure 7-8 Disabled Port Number Popup Window

SSH In & Telnet In for this port are disabled.
Prevent this page from creating additional dialogs.

- 2. Click your mouse into the CLI login interface that appears (see *Figure 7-7*) and login. The CLI interface will indicate when your connection is established.
- 3. When using the non-Java Web SSH or Web Telnet window, to terminate the session, use either the host's logoff command, or use ^] to terminate a Telnet session or ~. to terminate an SSH session.

Browser Issues

Please check the Lantronix Knowledge Base at <u>http://ltxfaq.custhelp.com/app/answers/list</u> to research any browser errors.

To configure how secure Lantronix devices are searched for on the network:

1. Click the **Search Options** link on the top right of the *Services > Secure Lantronix Network* page. The following web page displays:

Logout Host: slc4331 User: sysadmin	U1 E1 1 3 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 35 37 39 41 43 45 U2 U2 E2 2 4 6 8 10 12 14 16 18 20 22 24 26 28 30 32 34 36 38 40 42 44 46 Select port for © Configuration © WebSSH (DP only) © Connected Device (DP only)	47 A 48 B
Network Services User Authentication	Devices Maintenance Quick Setup	
SSH/Telnet/Logging SNMP NFS/CIFS Sec	cure Lantronix Network Date & Time Web Server	
Secur	e Lantronix Network - Search Options	elp?
Secure Lantronix Network Search:	 Local Subnet Manually Entered IP Address List Both 	
IP Address Add IP Address Delete IP Address	IP Address List No IP Address	
	Apply	

Figure 7-9 Services > Secure Lantronix Network > Search Options

2. Enter the following:

Secure Lantronix Network Search	 Select the type of search you want to conduct. Local Subnet performs a broadcast to detect secure Lantronix devices on the local subnet. Manually Entered IP Address List provides a list of IP addresses that may not respond to a broadcast because of how the network is configured. Both is the default selection.
IP Address	If you selected Manually Entered IP Address List or Both, enter the IP address of the secure Lantronix device you want to find and manage.

- If you entered an IP address, click the Add IP Address button. The IP address displays in the IP Address List.
- 4. Repeat steps 2 and 3 for each IP address you want to add.
- 5. To delete an IP address from the IP Address List, select the address and click the **Delete IP** Address button.
- Click the Apply button. When the confirmation message displays, click Secure Lantronix Network on the main menu. The Services > Secure Lantronix Network page displays the secure Lantronix devices resulting from the search. You can now manage these devices.

Secure Lantronix Network Commands

The following commands for the command line interface correspond to the web page entries described above.

To detect and view all SLC advanced console managers or user-defined IP addresses on the local network:

set slcnetwork <one or more parameters>

Parameters

```
add <IP Address>
delete <IP Address>
search <localsubnet|ipaddrlist|both>
```

To detect and display all SLC and SLB console managers and Lantronix Spider devices on the local network:

show slcnetwork [ipaddrlist <all|Address Mask>]

Note: Without the ipaddrlist parameter, the command searches the network according to the search setting. With the ipaddrlist parameter, the command displays a sorted list of all IP addresses or displays the IP addresses that match the mask (for example, 172.19.255.255 would display all IP addresses that start with 172.19).

Date and Time

Use the Date and Time Settings page to specify the local date, time, and time zone at the SLC location, or enable the SLC unit to use NTP to synchronize with other NTP devices on your network. Note that changing the date/time and/or timezone, or enabling NTP may affect the user's ability to login to the web; if this happens, use the CLI admin web restart command to restart the web server.

The CLI show ntp command will display the current NTP status if NTP is enabled. The column headings are as follows: the host names or addresses shown in the remote column correspond to configured NTP server names; however, the DNS names might not agree if the names listed are not the canonical DNS names. The refid column shows the current source of synchronization, while the st column reveals the stratum, t the type (u = unicast, m = multicast, l = local, - = don't know), and poll the poll interval in seconds. The when column shows the time since the peer was last heard in seconds, while the reach column shows the status of the reachability register (see RFC-1305) in octal. The remaining entries show the latest delay, offset and jitter in milliseconds. The symbol at the left margin displays the synchronization status of each peer. The currently selected peer is marked *, while additional peers designated acceptable for synchronization, but not currently selected, are marked +. Peers marked * and + are included in the weighted average computation to set the local clock; the data produced by peers marked with other symbols are discarded.

To set the local date, time, and time zone:

1. Click the **Services** tab and select the **Date & Time** option. The following page displays:

			. igu									
LΛ	NTRO	Host: slc433	SLC 8048	LCD SD U1 U2 MD Select por	1 1 3 5 7 2 2 4 6 8	9 11 13 10 12 14	15 17 1 16 18 2 WebSS	9 21 23 2 0 22 24 2 H (DP only	25 27 29 31 3 26 28 30 32 3	33 35 37 39 4 34 36 38 40 4 cted Device (D	1 43 45 47 2 44 46 48	A B
	Logour	User: sysadr	nin	Colocipor	tion 🕘 coninge		110000	1(21 011)		0.000 200000 (2		_
Netwo	rk Services	User Aut	nentication Devi	ces Maintenai	ice Quick	Setup				盈	? ቲታ 🗉	E.
SSH/	Telnet/Logging	SNMP N	S/CIFS Secure L	antronix Network	Date & Tin	ne Wel	o Serve	r				
				Date &	Time						Help	?
	Ch	nange Date/Tim	ie:									
		Da	te: March 🔻	22 • 2017 •	,							
		Tim	ne: 04 v : 07 v	: 33 v am v]							
		Time Zor	ne: GMT		•							
		Enable NT	P: 🕑					The with	e SLC can s a remote tin	synchronize ne server us	its clock ing NTP.	
	Cur	rrent NTP statu	IS: remote	refi	d st	t when	poll	reach	delay	offset	jitter	
			104.156.99.2	26 204.123.2	.72 2	u 14	64	1	32.182	0.304	0.001	
			*LOCAL(0)	.LOCL.	10	1 13	64	1	0.000	0.000	0.001	
		Synchronize v	ia: OBroadcast fro Poll NTP Ser	om NTP Server rver(s):								
			Local: 🔘	#1:								
				#2:								
				#3:								
			Public: 🖲	NTP Pool	0.pool.ntp.c	org (rand	lom)		•]		
				App	bly							

Figure 7-10 Services > Date & Time

2. Enter the following:

Change Date/Time	Select the checkbox to manually enter the date and time at the SLC location.
Date	From the drop-down lists, select the current month, day, and year.
Time	From the drop-down lists, select the current hour and minute.
Time Zone	From the drop-down list, select the appropriate time zone. For information on each timezone, see <u>http://en.wikipedia.org/wiki/List_of_tz_database_time_zones</u>

3. To save, click the **Apply** button.

To synchronize the SLC 8000 advanced console manager with a remote timeserver using NTP:

1. Enter the following:

Enable NTP	Select the checkbox to enable NTP synchronization. NTP is disabled by default.
Current NTP status	Displays the current NTP status if NTP is enabled above.

Synchronize via	Select one of the following:
	 Broadcast from NTP Server: Enables the SLC unit to accept time information periodically transmitted by the NTP server. This is the default if you enable NTP.
	 Poll NTP Server: Enables the SLC 8000 advanced console manager to query the NTP Server for the correct time. If you select this option, complete one of the following:
	Local: Select this option if the NTP servers are on a local network, and enter the IPv4 or IPv6 address of up to three NTP servers. This is the default, and it is highly recommended.
	Public: Select this option if you want to use a public NTP server, and select the address of the NTP server from the drop-down list. This is not recommended because of the high load on many public NTP servers. All servers in the drop-down list are stratum-2 servers. (See <u>www.ntp.org</u> for more information.) Each public NTP server has its own usage rulesplease refer to the appropriate web site before using one. Our listing them here is
	to provide easy configuration but does not indicate any permission for use.

2. To save, click the Apply button.

Date and Time Commands

The following CLI commands correspond to the web page entries described above.

To set the local date, time, and local time zone (one parameter at a time):

```
set datetime <one parameter>
```

Parameters

```
date <MMDDYYhhmm[ss]>
timezone <Time Zone>
```

Note: If you do not know a valid <Time Zone>, enter 'timezone <invalid time zone>' and you will be guided through selecting one from the available time zones.

To view the local date, time, and time zone:

show datetime

To synchronize the SLC 8000 unit with a remote time server using NTP:

set ntp <one or more ntp parameters>

Parameters

```
localserver1 <IP Address or Hostname>
localserver2 <IP Address or Hostname>
localserver3 <IP Address or Hostname>
poll <local|public>
publicserver <IP Address or Hostname>
state <enable|disable>
sync <broadcast|poll>
```

To view NTP settings:

show ntp

Web Server

The Web Server supports all versions of the TLS protocol, but due to security concerns, does not support any versions of the SSL protocol. The Web Server page allows the system administrator to:

- Configure attributes of the web server.
- View and terminate current web sessions.
- Import a site-specific SSL certificate.
- Enable an iGoogle gadget that displays the status of ports on multiple SLC units.

To configure the Web Server:

1. Click the Services tab and select the Web Server option. The following page appears:

Logout Host: slc4331 User: sysadmin	48 LCD SD U1 MD E1 1 3 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 33 34 35 11 13 15 17 19 21 23 25 27 29 31 33 34 34 35 35 36 36 37 39 11 13 15 17 19 21 23 25 27 29 31 33 37 37 38 36 <t< th=""><th>5 37 39 41 43 45 47 A 5 38 40 42 44 46 48 B Device (DP only)</th></t<>	5 37 39 41 43 45 47 A 5 38 40 42 44 46 48 B Device (DP only)
Network Services User Authentication	Devices Maintenance Quick Setup	& ? ♧ 🗉
SSH/Telnet/Logging SNMP NFS/CIFS	Secure Lantronix Network Date & Time Web Server	
	Web Server	Help?
Timeout:	 No Yes, minutes (5-120): 30 	Web Sessions
Enable TLS v1.0 Protocol:	8	SSL Certificate
Enable TLS v1.1 Protocol:		
Cipher:	 High (256,168,128) High (256,168,128), Medium (128) FIPS Approved 	
Use only SHA2 and Higher Ciphers:		
Note:	Changing TLS protocol or cipher requires a reboot or the CLI command "admin web restart".	
Group Access:		
Banner:		
Note:	Line feeds can be included in the banner with the '\n' character sequence.	
Network Interfaces:	✓ Eth1 ✓ Eth2 ✓ PPP	
Run Web Server:	Setting can be changed via the CLI.	
Enable iGoogle Gadget Web Content:		
	Apply	

Figure 7-11 Services > Web Server

2. Enter the following fields:

Timeout	 Select No to disable Timeout. Select Yes, minutes (5-120) to enable timeout. Enter the number of minutes (must be between 30 and 120 minutes) after which the SLC web session times out. The default is 5.
	Note: If a session times out, refresh the browser page and login to a new web session. If you close the browser without logging off the SLC unit first, you will have to wait for the timeout time to expire. You can also end a web session by using the admin web terminate command at the CLI or by asking your system administrator to terminate your active web session.
	 To view or terminate current web sessions, click the Web Sessions link. See Services - Web Sessions. To view, import, or reset the SSL Certificate, click the SSL Certificate link. See Services - SSL Certificate.
Enable TLS v1.0 Protocol	By default, the web supports the TLS v1.0 protocol. Uncheck this to disable the TLS v1.0 protocol. Changing this option requires a reboot or restarting the web server with the CLI command "admin web restart" for the change to take effect.
Enable TLS v1.1 Protocol	By default, the web supports the TLS v1.1 protocol. Uncheck this to disable the TLS v1.1 protocol. Changing this option requires a reboot or restarting the web server with the CLI command "admin web restart" for the change to take effect.
Cipher	By default, the web uses High/Medium security (128 bits or higher) for the cipher. This option can be used to configure the web to also support just High security ciphers (256 bit, 168 bit and some 128 bit), or FIPS approved ciphers (see <i>Security</i> .) Changing this option requires a reboot or restarting the web server with the CLI command admin web restart for the change to take effect.
Use only SHA2 and Higher Ciphers	By default, the web supports SHA1 as well as SHA2 and higher ciphers. Check this option to support only SHA2 and higher ciphers. Changing this option requires a reboot or restarting the web server with the CLI command "admin web restart" for the change to take effect.
Group Access	Specify one or more groups to allow access to the Web Manager user interface. If undefined, any group can access the web. If one or more groups are specified (groups are delimited by the characters ',' (comma) or ';' (semicolon)), then any user who logs into the web must be a member of one of the specified groups, otherwise access will be denied. Users authenticated via RADIUS may have a group (or groups) provided by the RADIUS server via the Filter-Id attribute that overrides the group defined for a user on the SLC. A group provided by a remote server must be either a single group or multiple groups delimited by the characters ',' (comma), ';' (semicolon), or '=' (equals) - for example "group=group1,group2;" or "group1,group2,group3".
Banner	Enter to replace default text displayed on the Web Manager home page after the user logs in. May contain up to 1024 characters. Blank by default. To create additional lines in the banner use the \n character sequence.
Network Interfaces	The interfaces that the web server is available on. By default, Eth1, Eth2 and PPP interfaces on modems are enabled.
Run Web Server	If enabled, the web server will run and listen on TCP ports 80 and 443 (all requests to port 80 are redirected to port 443). By default, the web server is enabled. The web server supports TLS 1.0, TLS 1.1, and TLS 1.2. Due to security vulnerabilities, SSL is not supported. <i>Note: This option can only be changed at the CLI.</i>
Enable iGoogle Gadget Web Content	Select the check box to enable an SLC iGoogle gadget. The iGoogle gadget allows an iGoogle user to view the port status of many SLCs on one web page.

3. Click the **Apply** button to save.

Admin Web Commands

Go to Administrative Commands to view CLI commands which correspond to the web page entries described above.

Services - Web Sessions

The Services > Web Server page enables you to view and terminate current web sessions.

To view or terminate current web sessions:

 On the Services tab, click the Web Server page and click the Web Sessions link to the right. The following page displays:

		Figure	-12 Web Sessio	0115			
Logout Host: slc4331 User: sysadmin Logout Host: slc4331 User: sysadmin Elect port for © Configuration WebSSH (DP only) © Connected Device (DP only)							
Network Services	User Authe	entication Devices	Maintenance Quick	Setup		샵 ?	₿ E
SSH/Telnet/Logging	SNMP NF	S/CIFS Secure Lantro	nix Network Date & Tir	ne Web Server			
		Web S	erver - Web Sessio	ons			Help?
< Back to Web Server							
	Curre	ent Web Sessions		Term	inate		
	ld	User	Login Time	Idle Time			
	1	sysadmin	05/21/16 00:44	0:00:00:00			

Figure 7-12 Web Sessions

- 2. To terminate, click the check box in the row of the session you want to terminate and click the Terminate button.
- 3. To return to the Services > Web Server page, click the Back to Web Server link.

Services - SSL Certificate

The Services > Web Server page enables you to view and update SSL certificate information. The SSL certificate, consisting of a public/private key pair used to encrypt HTTP data, is associated with the web server. You can import a site-specific SSL certificate or generate a custom selfsigned SSL certificate. The custom self-signed SSL certificates generated by the SLC use the SHA256 hash algorithm.

To view, reset, import, or change an SSL Certificate:

1. On the **Services** tab, click the **Web Server** page and click the **SSL Certificate** link. The following page displays the current SSL certificate.

		Figure 7-13 SS	L Certificate				
LANTRONI Logout	SLC 8048	LCD SD U1 E1 1 U2 E2 2 Select port fo	3 5 7 9 11 13 15 17 19 21 23 4 6 8 10 12 14 16 18 20 22 24 r 	25 27 29 31 33 35 26 28 30 32 34 36 only) © Connected	5 37 39 4 5 38 40 42 Device (D	1 43 4 2 44 4 P only	45 47 A 46 48 B /)
Network Services U	ser Authentication De	evices Maintenand	e Quick Setup		岱	? {	₿ E
SSH/Telnet/Logging SN	IMP NFS/CIFS Secure	a Lantronix Network	Date & Time Web Server				
	v	Veb Server - SS	L Certificate			1	Help?
Current SSL Certificate (D	efault)						
Current SSL Certificate (D Certificate: Data: Version: 1 (Serial Numbe 92:18:6a Signature Algori Issuer: C=US Validity Not Befo Not Afte Subject: C=U Subject: C=U Subject Publ Public K Publ Modu	erauit) 0x0) r: :cl:26:cf:b3:20 thm: shalWithRSAEnc: , ST=California, L=1 re: Jan 25 13:16:34 r : Jan 24 13:16:34 S, ST=California, L= ic Key Info: ey Algorithm: rsaEnc ic-Key: (2048 bit) lus: 00:cl:05:fa:da:9a:06	ryption Irvine, O=Lantron 2016 GMT 2026 GMT =Irvine, O=Lantro ryption 5:9c:8e:c7:6a:cc:	<u>ix, CN-SLC</u> nix, <u>CN-SLC</u> 44:48:2a:				THE
Reset to Default Certificate:			Note: c	hanging the SSL a reboot or restar for the up	Certificat ting the v idate to t	te req veb s ake e	luires erver ∋ffect.
Import SSL Certificate:			Generate custom self-signed SSL Certificate:				
Import via:	HTTPS -		Number of Bits:	2048 -			
Certificate Filename:		Upload File	Number of Days:				
Key Filename:		Upload File	Country Name:				
Passphrase:			State or Province Name:				
Retype Passphrase:			Locality Name:				
Host:			Organization Name:				
Login:			Organization Unit Name:				
Path:			Hostname or				
Password:	<u></u>		Email Address				
Dit Diener			Optional Challenge	[7	
Retype Password:			Password:				
			Retype Password:				
Back to Web Server2. If desired, enter	er the following:	Apply					

Reset to Default	To reset to the default certificate, select the checkbox to reset to the default
Certificate	certificate. Unselected by default.

Import SSL Certificate	To import your own SSL Certificate, select the checkbox. Unselected by default.
Import via	From the drop-down list, select the method of importing the certificate (SCP , SFTP , or HTTPS). The default is HTTPS .
Certificate Filename	Filename of the certificate. If HTTPS is selected as the method for import, the Upload File link will be selectable to upload a certificate file.
Key Filename	Filename of the private key for the certificate. If HTTPS is selected as the method for import, the Upload File link will be selectable to upload a key file.
Passphrase / Retype Passphrase	Enter the passphrase associated with the SSL certificate if the private key is encrypted.
Host	Host name or IPaddress of the host from which to import the file.
Path	Path of the directory where the certificate will be stored.
Login	User ID to use to SCP or SFTP the file.
Password / Retype Password	Password to use to SCP or SFTP the file.
Generate custom self- signed SSL Certificate	To generate your own custom self-signed certificate with attributes specific to your site, select the checkbox. The SHA256 hasing alogorithm will be used to generate the certificate. Unselected by default.
Number of Bits	The number of bits to use when generating the certificate: 2048, 3072 or 4096.
Number of Days	The number of days that the certificate can be used before it expires, up to 7500 days.
Country Name	The two letter country code for the custom certificate, e.g. "US" or "FR".
State or Province Name	The state or province for the custom certificate, e.g. "California". Must be at least 2 characters long.
Locality Name	The locality or city for the custom certificate, e.g. "Irvine". Must be at least 2 characters long.
Organization Name	The organization or company name for the custom certificate, e.g. "Lantronix". Must be at least 2 characters long.
Organization Unit Name	The unit name for the custom certificate, e.g. "Engineering" or "Sales". Must be at least 2 characters long.
Hostname or Common Name	The hostname or other name associated with the SLC the certificate is generated on, e.g., "slc100.engineering.lantronix.com". Must be at least 2 characters long.
Email Address	An optional email address to associate with the custom certificate.
Optional Challenge Password & Retype Password	An optional password use to encrypt the custom certificate.

3. Click the **Apply** button.

Note: You must reboot the SLC advanced console manager for the update to take effect.

4. To return to the Services > Web Server page, click the Back to Web Server link.

iGoogle Gadgets

You can create iGoogle gadgets that enables you to view the status of the ports of multiple SLC 8000 advanced console managers on one web page.

Anyone with a Google email account (gmail.com) can create an iGoogle gadget for viewing web pages. There are two types of iGoogle gadgets: public gadgets and private gadgets. The public gadgets are listed for import on iGoogle web pages. The SLC gadget is a private gadget, whose location is not publicly advertised.

To set up an SLC iGoogle gadget:

1. Load the following XML code on a web server that is accessible over the Internet. This code describes how to retrieve information and how to format the data for display.

```
<?xml version="1.0" encoding="UTF-8" ?>
<Module>
<ModulePrefs title=" UP model Devport Status"
      title url="http://www.lantronix.com"
      directory title="SLC/ Status" description="Devport
      status and counters" scrolling="true" width="400"
      height="360" />
<UserPref name="model" display name="Model" datatype="enum"</pre>
      default value="slc">
<EnumValue value="SLC" display value="SLC" />
<EnumValue value="SLC" display value="SLC" />
      </UserPref>
<UserPref name="ip" display name="IP Address" required="true" />
<UserPref name="rate" display name="Refresh Rate"
      datatype="enum" default value="10">
<EnumValue value="1" display value="1 second" />
<EnumValue value="5" display_value="5 seconds" />
<EnumValue value="10" display value="10 seconds" />
<EnumValue value="30" display value="30 seconds" />
<EnumValue value="60" display value="1 minute" />
<EnumValue value="300" display value="5 minutes" />
<EnumValue value="600" display value="10 minutes" />
      /UserPref>
<Content type="url" href="http://_UP_ip_/devstatus.htm" />
      </Module>
```

- 2. On the iGoogle web page, click the Add stuff link.
- 3. On the new page, click the Add feed or gadget link.
- 4. In the field that displays, type the URL of the gadget location.
- 5. Return to the gadget viewing page and complete the SLC gadget configuration fields. You should see an iGoogle gadget similar to the following:

Figure 7-14 iGoogle Gadget Example

me	Lantro		Add a tab	sle™	Google	e Sea
I ntr Host	ronix SLC	Device 0.0.203/S	Port Status	2		280
No	Name	DSR	Bytes Input/Output	Errors	Connection Status	
1	Port-1	No	0/0	0	Idle	=
2	Port-2	No	0/0	0	Idle	
3	Port-3	Yes	0/0	0	Idle	
4	Port-4	Yes	0/0	0	Idle	
5	Port-5	No	0/0	0	Idle	
6	Port-6	No	0/0	0	Idle	
7	Port-7	No	0/0	0	Idle	
8	Port-8	No	0/0	0	Idle	
						>

8: Device Ports

This chapter describes how to configure and use an SLC advanced console manager port connected to an external device, such as a server or a modem. The subsequent chapter, *Chapter 11: Connections* describes how to use the *Devices > Connections* web page to connect external devices and outbound network connections (such as Telnet or SSH) in various configurations. The *Devices > Console Port* page allows you to configure the console port, if desired.

Connection Methods

A user can connect to a device port in one of the following ways:

- 1. Telnet or SSH to the Eth1 or Eth2 IP address, or connect to the console port, and log in to the command line interface. At the command line interface, issue the connect direct or connect listen commands.
- 2. If Telnet is enabled for a device port, Telnet to <Eth1 IP address>:< telnet port number> or <Eth2 IP address>:<telnet port number>, where telnet port number is uniquely assigned for each device port.
- 3. If SSH is enabled for a device port, SSH to <Eth1 IP address>:<ssh port number> or <Eth2 IP address>:<ssh port number>, where ssh port number is uniquely assigned for each device port.
- 4. If TCP is enabled for a device port, establish a raw TCP connection to <Eth1 IP address>:<tcp port number> or <Eth2 IP address>:<tcp port number>, where tcp port number is uniquely assigned for each device port.
- 5. If a device port has an IP address assigned to it, you can Telnet, SSH, or establish a raw TCP connection to the IP address. For Telnet and SSH, use the default TCP port number (23 and 22, respectively) to connect to the device port. For raw TCP, use the TCP port number defined for TCP In to the device port according to the *Device Ports Settings (on page 128)* section.
- 6. Connect a terminal or a terminal emulation program directly to the device port. If logins are enabled, the user is prompted for a username/password and logs in to the command line interface.

For #2, #3, #4, #5, and #6, if logins or authentication are not enabled, the user is directly connected to the device port with no authentication.

For #1 and #6, if logins are enabled, the user is authenticated first, and then logged into the command line interface. The user login determines permissions for accessing device ports.

Permissions

There are three types of permissions:

- 1. **Direct (or data) mode:** The user can interact with and monitor the device port (connect direct command).
- 2. Listen mode: The user can only monitor the device port (connect listen command).
- Clear mode: The user can clear the contents of the device port buffer (set locallog <port> clear buffer command).

The administrator and users with local user rights may assign individual port permissions to local users. The administrator and users with remote authentication rights assign port access to users authenticated by NIS, RADIUS, LDAP, Kerberos and TACACS+.

I/O Modules

The SLC module port configuration can be changed by adding or replacing I/O modules in the I/O module bays. Any changes to the I/O modules must be done while the SLC unit is powered off. The following I/O module configurations are supported (Bay 1 is the leftmost bay when viewing the back of the SLC 8000 advanced console manager where the device ports are located):

Model	Bay 1	Bay 2	Bay 3
SLC 8008	8-port module	Empty	Empty
SLC 8016	16-port module	Empty	Empty
SLC 8024	8-port module	16-port module	Empty
SLC 8032	16-port module	16-port module	Empty
SLC 8040	8-port module	16-port module	16-port module
SLC 8048	16-port module	16-port module	16-port module

Table 8-1 Supported I/O Module Configurations

Note: A 16-port RJ45 module is shown as "RJ45-16" in the About page in the Web interface and the output of the admin version command in the CLI, and a 8-port module is shown as "RJ45-08". A 16-port USB module is shown as "USB-16." For example, I/O Module Type(s): RJ45-08, RJ45-16, and RJ45-16 indicate that the SLC unit has an 8-port I/O module in Bay 1, and 16-port modules in Bay 2 and 3. Please note that only the following configurations are available from Lantronix: SLC 8008, SLC 8016, SLC 8032 and SLC 8048 modules. The SLC 8024 and SLC 8040 console managers can only be created by adding 16-port RJ45 modules to an existing SLC 8008 unit.

The number of device ports in a SLC 8000 advanced console manager can be expanded by adding 16-port I/O modules in Bay 2 and Bay 3, or by swapping an 8-port I/O module in Bay 1 for a 16-port module. The configurations listed above are the only valid configurations; if any other configuration is detected at boot, the SLC unit will still boot, disable use of the device ports, and provide indications in the boot messages, in the CLI and in the web that the I/O configuration is invalid. When an invalid configuration is corrected by reconfiguring the I/O modules into a valid configuration, after the SLC module is powered up and booted, the valid configuration will be detected and the SLC module ports can be used again.

For the SLC 8024 and SLC 8040 modules, with an 8-port I/O module in Bay 1, the device ports will be numbered 1-8 and 17-32 (for the SLC 8024 model) and 1-8 and 17-48 (for the SLC 8040 model). See *Figure 8-2 Devices > Device Status on page 125*.

Restoring a configuration to the SLC 8000 advanced console manager will automatically adjust the number of device ports to reflect the number of ports in the SLC unit the configuration is being restored to. For example, a configuration that is saved on an SLC 8048 unit and restored to an SLC 8016 unit will have the last 32 ports removed from the configuration. Conversely, a configuration that is saved on a SLC 8016 unit and restored to a SLC 8048 unit will have 32 device ports (with factory default settings) added to the configuration.

Device Status

The *Devices > Device Status* page displays the status of the SLC ports, USB ports and SD card ports.

1. Click the **Devices** tab and select the **Device Status** option. The following page displays:

atur	ork Servie		ser Authentiest	ion	Avices Maintenand	e Quieł	Setup		ቆ?₿
Dovi	ce Status	es 0		Port II	SB / SD Card Intern	al Modem	PPMe (onnections Host Lists So	rinte Sites
201	ce status L	Jevice I			SD7 SD Gard Intern	a modern		Somections most Lists Sc	inpra unea
					Device S	tatus			He
Cons	ole Port: Con	nected							
		Device	Port Status and	Counte	rs			USB Ports / SD Card	
No	Name	DSR	Bytes Input/Output	Errors	Connection Status	Port	Device	Туре	State
1	Port-1	Yes	32/0	0	Idle	112	none	N/A	N/A
2	Port-2	Yes	0/32	0	Command Line	SD	none		N/A
2	Port 2	Voc	0/0	0	Internace	Card	none	N/A	IN/A
3 1	Port 4	Vec	0/0	0	Idle				
- 5	Port-5	Yee	0/0	0	Idle				
6	Port-6	Yes	0/0	0	Idle				
7	Port-7	No	0/4	0	Idle				
8	Port-8	No	0/0	0	Idle				
9	Port-9	No	0/0	0	Idle				
10	Port-10	No	0/0	0	Idle				
11	Port-11	No	0/0	0	Idle				
12	Port-12	No	0/0	0	Idle				
13	Port-13	No	0/0	0	Idle				
14	Port-14	No	0/0	0	Idle				
15	Port-15	No	0/0	0	Idle				
16	Port-16	No	0/0	0	Idle				
17	Port-17	No	0/0	0	Idle				
18	Port-18	No	0/0	0	Idle				
19	Port-19	No	0/0	0	Idle				
20	Port-20	No	0/0	0	Idle				
21	Port-21	No	0/0	0	Idle				
22	Port-22	No	0/0	0	Idle				
23	Port-23	No	0/0	0	Idle				
24	Port-24	No	0/0	0	Idle				
25	Port-25	No	0/0	0	Idle				
26	Port-26	No	0/0	0	Idle				
27	Port-27	No	0/0	0	Idle				
28	Port-28	NO No	0/0	0	Idle				
29	Port 20	INO No	0/0	0	Idle				
3U 24	Port-30	NO Vee	0/0	0	Idle				
31	Port 22	No	0/0	0	Idle				
32	Port-33	No	0/0	0	Idle				
34	Port-34	No	0/0	0	Idle				
35	Port-35	No	0/0	0	Idle				
36	Port-36	No	0/0	0	Idle				
37	Port-37	No	0/0	0	Idle				
38	Port-38	No	0/0	0	Idle				
39	Port-39	No	0/0	0	Idle				
40	Port-40	No	0/0	0	Idle				
41	Port-41	No	0/0	0	Idle				
42	Port-42	No	0/0	0	Idle				
43	Port-43	No	0/0	0	Idle				
10									

Figure 8-2 Devices > Device Status

No 0/0

0

Idle

48 Port-48

Device Ports

On the *Devices > Device Ports* page, you can set up the numbering of Telnet, SSH, and TCP ports, view a summary of current port modes, establish the maximum number of direct connections for each device port, and select individual ports to configure.

1. Click the **Devices** tab and select the **Device Ports** option. The following page displays:

Logout Host: slc4331 User: sysadmin Sele	E1 E2 ect port	1 3 5 7 9 2 4 6 8 10 t for O Configur	11 13 15 17 19 21 23 25 27 29 31 33 35 37 39 12 14 16 18 20 22 24 26 28 30 32 34 36 38 40 ration WebSSH (DP only) Connected Device	9 41 43 45 47 A 9 42 44 46 48 B e (DP only)
Network Services User Authentication Devices Main	ntena	ince Quick	(Setup	
Device Status Device Ports Console Port USB / SD Card	RPN	ls Connecti	ions Host Lists Scripts Sites	
Dev	ice	Ports		Help?
Teinet/SSH/TCP In Port Numbers	Por	ts:	1-16 17-32 33-48	Configure
Renumber the Telnet In, SSH In or TCP In Port Number for all Device Ports.	No	Name	Mode	Select
Starting Telnet Port: 2001	1	Port-1	Idle	0
Starting SSH Port: 3001	2	Port-2	Idle	0
Starting TCP Port: 4001	3	Port-3	Idle	0
	4	Port-4	Idle	0
Apply	5	Port-5	Idle	0
ТРРУ	6	Port-6	Idle	
	7	Port-7	Idle	0
	8	Port-8	Idle	۲
	9	Port-9	Idle	۲
	10	Port-10	Idle	0
	11	Port-11	Idle	0
	12	Port-12	Idle	0
	13	Port-13	Idle	0
	14	Port-14	Idle	0
	15	Port-15	Idle	0
	16	Port-16	Idle	0

Figure 8-3 Devices > Device Ports

Current port numbering schemes for Telnet, SSH, and TCP ports display on the left. The list of ports 1-16 on the right includes the individual ports and their current mode.

Note: For units with more ports, click the buttons above the table to view additional ports.

Icons that represent some of the possible modes include:

Idle	The port is not in use.
-	The port is in data/text mode.
7.001	<i>Note:</i> You may set up ports to allow Telnet access using the IP Setting per Device Ports - Settings (on page 128).
	An external modem is connected to the port. The user may dial into or out of the port.
4	Telnet in or SSH in is enabled for the device port. The device port is either waiting for a Telnet or SSH login or has received a Telnet or SSH login (a user has logged in).

To set up Telnet, SSH, and TCP port numbering:

1. Enter the following:

Telnet/SSH/TCP in Port Numbers

Starting Telnet Port	Each port is assigned a number for connecting via Telnet. Enter a number (1025-65528) that represents the first port. The default is 2000 plus the port number. For example, if you enter 2001, port 1 will be 2001 and subsequent 2000 ports are automatically assigned numbers 2001, 2002, and so on.
Starting SSH Port	Each port is assigned a number for connecting via SSH. Enter a number (1025-65528) that represents the first port. The default is 3000 plus the port number. For example, if you enter 3001, port 1 will be 3001 and subsequent 3000 ports are automatically assigned numbers 3001, 3002, and so on.
Starting TCP Port	Each port is assigned a number for connecting through a raw TCP connection. Enter a number (1025-65528) that represents the first port. The default is 4000 plus the port number. For example, if you enter 4001, port 1 will be 4001 and subsequent 4000 ports are automatically assigned numbers 4001, 4002, and so on.
	You can use a raw TCP connection in situations where a TCP/IP connection is to communicate with a serial device. For example, you can connect a serial printer to a device port and use a raw TCP connection to send print jobs to the printer over the network.
	Note: When using raw TCP connections to transmit binary data, or where the break command (escape sequence) is not required, set the Break Sequence of the respective device port to null (clear it).

Caution: Ports 1-1024 are RFC-assigned and may conflict with services running on the SLC 8000 advanced console manager. Avoid this range.

2. Click the **Apply** button to save the settings.

To set limits on direct connections:

- 1. Enter the maximum number (1-10) of simultaneous direct connections for each device port. The default is 1.
- 2. Click the **Apply** button to save the settings.

To configure a specific port:

- 1. You have two options:
 - Select the port from the ports list and click the Configure button. The Device Ports > Settings (1 of 2) page for the port displays.
 - Click the port number on the green bar at the top of each page.
- 2. Continue with directions in the section, Device Ports Settings (on page 128).

DevicePort Global Commands

Go to *Device Port Commands* to view CLI commands which correspond to the web page entries described above.

Device Ports - Settings

On the *Device Ports > Settings (1 of 2)* page, configure IP and data (serial) settings for individual ports, and if the port connects to an external modem, modem settings as well.

To open the Device Ports - Settings page:

- 1. You have two options:
 - Dashboard

Make sure the **Configuration** radio button directly beneath the *Dashboard* is selected and click the desired port number in the *Dashboard*. The Dashboard is located on the upper right corner of each Web Manager page (see *Chapter 5: Web Page Layout*.)



- Device Ports Page

Click the Devices tab, then click the Device Ports link. Select the port you want to configure and then click the Configure button. Higher numbered ports can be displayed using the "1-16", "17-32" and "33-48" buttons at the top of the Device Port list.

Host: slc4331	LCD SD U1 E1 U2 E2	1 3 5 7 9 2 4 6 8 10	11 13 15 17 19 21 23 25 27 29 31 33 3 12 14 16 18 20 22 24 26 28 30 32 34 3	85 37 39 41 43 45 47 A 86 38 40 42 44 46 48 B
Logout User: sysadmin	Select por	rt for (O) Configu	Iration (WebSSH (DP only) (Connecte	d Device (DP only)
Network Services User Authentication	Devices Maintena	ance Quic	k Setup	
Device Status Device Ports Console Port	USB / SD Card RPM	Vis Connect	tions Host Lists Scripts Sites	
	Device	Ports		Help?
Telnet/SSH/TCP In Port Numbers	Por	rts:	1-16 17-32 33-48	Configure
Renumber the Telnet In, SSH In or TCP In Port Number for all Device Ports.	No	Name	Mode	Select
Starting Telnet Port: 2001	1	Port-1	Idle	0
Starting SSH Port: 3001	2	Port-2	Idle	۲
Starting TCP Port: 4001	3	Port-3	Idle	0
Starting FOF Port. 4001	4	Port-4	Idle	
Apply	5	Port-5	Idle	۲
, 19P1)	6	Port-6	Idle	
	7	Port-7	Idle	\odot
	8	Port-8	Idle	\odot
	9	Port-9	Idle	۲
	10	Port-10	Idle	0
	11	Port-11	Idle	0
	12	Port-12	Idle	0
	13	Port-13	Idle	0
	14	Port-14	Idle	0
	15	Port-15	Idle	0
	16	Port-16	Idle	0

The following page displays:

LANTRONIX° SLC 804	LCD SD U1 E1 1 3 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 35 37 39 41 43 45 47 A LCD SD U2 MD E2 2 4 6 8 10 12 14 16 18 20 22 24 26 28 30 32 34 36 38 40 42 44 64 8 10 12 14 16 18 20 22 24 26 28 30 32 34 36 38 40 42 44 46 48 B
Logout Host: slc4331 User: sysadmin	Select port for <a> Configuration WebSSH (DP only) Connected Device (DP only)
Network Services User Authentication	Devices Maintenance Quick Setup
Device Status Device Ports Console Port	USB / SD Card Internal Modem RPMs Connections Xmodem Host
Lists Scripts Sites	Device Ports - Settings
Port: 3 Mode: Idle	Logging & Events: <u>Settings</u> Power Management: <u>Settings</u>
Name: Port-3	
Detect Port Name:	IP Settings
Detect Name <mark>∏<>#%</mark> \$	Telnet In: Port: 2003 Authentication:
Tokens:	Telnet Timeout: 🖉 Seconds: 600 Data Direction: Both Directions 🔻
Group Access:	Telnet Soft IAC Mode:
Banner:	SSH In: Port 3003 Authentication:
# of Sessions Msg:	SCH Timoutt Scande: 600 Data Direction: Both Directions
Idle Timeout Msg:	
Connected Msg:	ICP In: Port: 4003 Authentication:
	TCP Timeout: Seconds: 600 Data Direction: Incoming Network V
Break Sequence: \x1bB	IP Address/Netmask Bits:
Note: remove break Sequence for Device Ports connected to raw binary connections.	Send Term String: Term String:
View Port Log Seq: \x1bV	
View Port Log:	
Zero Port Counters:	
Data Sottings	Modern Settinge
Baud: 9600 V	State: Disabled V PPP Logging:
Data Bits: 8 🔻	Mode: Text PPP PPP PPP Debug:
Stop Bits: 1 V	Use Sites:
Parity: none	Initialization Script:
Flow Control: none	Modem Timeout: No Yes seconds (1-9999):
Enable Logins:	
Max Direct Connects: 1	
Show Lines On No	Dial-back Number: Fixed Number:
Connecting: Yes, # of Lines: 24	Dial-back Delay: 15 seconds
Hardware Signals	Dial-back Retries: 3
Check DSR on Connect	Text Mode
Disconnect on DSR:	Timeout Logins: No Yes, minutes (1-30):
Assert DTR:	Dial-in Host List: undefined V Host Lists
Toggle DTR:	PPP Mode
Reverse Pinout:	Ves Local IP:
USB VBUS: 📝	No Remote IP:
	Authentication: PAP CHAP

Figure 8-4 Device Ports > Settings (1 of 2)

Port Status an	d Counters	Host/User Name:
DSR/CD	Yes	CHAP Handshake: Secret/User Password:
DTR	Yes	Retype Password:
CTS	Yes	CHAP Auth Uses: CHAP Host CHAP St.
RTS	Yes	Same authentication
Bytes input	0	for Dial-in & Dial-on-Demand (DOD):
Bytes output	0	DOD Authentication: PAP CHAP
Framing errors	0	Host/User Name:
Parity errors	0	
Overrun errors	0	DOD CHAP Handshake: Secret/User Password:
Flow Control errors	0	Retype Password:
Seconds since zeroed	6994	Enable NAT: Note: Enabling NAT requires IP Forwarding to be enabled.
		Dial-out Number: Remote/Dial-out Login: Remote/Dial-out Password: Restart Delay: 30 seconds CBCP Server
		Allow No Callback:
		CBCP Client Type. Admin-defined Number User-defined Number
< <u>Back to Device</u>	Ports	Apply Apply Settings: none to Device Ports: Note: In addition to applying settings to the currently selected Device Port, all or some of the settings can also be applied to other Device Ports.

Figure 8-5 Device Ports > Settings (2 of 2)

2. Enter the following:

Device Port Settings

Port	Displays number of port; displays automatically.	
Mode	The status of the port; displays automatically.	
USB Device	This field is only displayed for USB ports. If a USB device is connected to the device port, this displays the USB version, speed, and a short type description for the USB device. The SLC supports up to 48 USB type A (Host) devices at data rates of HS (480 Mbit/s), FS (12 Mbit/s) or LS (1.5 Mbit/s). Each port has VBUS 5V support of up to 100mA (but not too exceed 600mA total per 16-port USB I/O module). Drawing more than 150 mA on a USB device port will shut down the VBUS 5V. USB ports are designed for data traffic only, and are not designed for charging or powering devices. Overcurrent conditions may disrupt operations.	
Name	The name of the port. Valid characters are letters, numbers, dashes (-), periods, and underscores (_).	
Detect Port Name	If enabled, the SLC will attempt to detect the hostname of the device connected to the device port, and set the device port name to the detected hostname. Many devices use their hostname or another identifier as the the device prompt, and the SLC can extract this name from the prompt using the Detect Name Tokens . If the device port name is set to the default value, when a user interacts with a device port and set the SLC will leak for the device prompt and set	
	the device connected to a device port, the SLC will look for the device prompt and set the device port name. The device prompt must be output at least 3 times in a single session for the prompt to be detected and the name extracted from the prompt. Any characters that are not part of the allowed characters for the device port Name will be removed. If the device name is automatically detected, the name will be logged in the Device Ports log.	

Detect Name Tokens	If Detect Port Name is enabled, the SLC will attempt to extract a hostname or other identifier from the device prompt, to use as the device port name. The SLC will extract any name between either the start of a line sent from the device up until one of the tokens, or any part of a prompt that does not include the tokens, as the device port name.
	For example, if the device prompt is set to [slc431d]>, and the Detect Name Tokens include "[" and "]", the SLC will extract the identifier slc431d and set it as the device port name. If the device prompt is set to myrouter>, and the Detect Name Tokens include ">", the SLC will extract the identifier myrouter and set it as the device port name.
Group Access	If undefined, any group can access the device port. If one or more groups are specified (groups are delimited by the characters ' ' (space), ',' (comma), or ';' (semicolon)), then any user who logs into the device port must be a member of one of the specified groups, otherwise access will be denied. Users authenticated via RADIUS may have a group (or groups) provided by the RADIUS server via the Filter-Id attribute that overrides the group defined for a user on the SLC unit. A group provided by a remote server must be either a single group or multiple groups delimited by the characters ' ' (space), ',' (comma), ';' (semicolon), or '=' (equals) - for example "group=group1,group2;" or "group1,group2,group3".
Banner	Text to display when a user connects to a device port by means of Telnet, SSH, or TCP. If authentication is enabled for the device port, the banner displays once the user successfully logs in. Blank is the default.
# of Sessions Msg	If enabled, a message will be displayed to a user when connecting to a device port that indicates how many users are currently connected to the device port. Disabled by default.
Idle Timeout Msg	If enabled, a message will be displayed to a user when their connection to a device port will be terminated soon due to the connection being idle. Disabled by default.
	Note: When the Idle Timeout Msg is enabled, the terminal application timeout values for Telnet, SSH and TCP should be set to a value greater than 15 seconds.
Connected Msg	If enabled, a message will be displayed to a user when they initially connect to a device port. Enabled by default.
Minimize Latency	Minimize device port latency by reducing read delays. This may improve communication efficiency in scenarios where a series of short messages are exchanged, but may increase CPU utilization and decrease throughput in cases where large messages are transmitted. Disabled by default.
Break Sequence	A series of one to ten characters users can enter on the command line interface to send a break signal to the external device. A suggested value is Esc+B (escape key, then uppercase "B" performed quickly but not simultaneously). You would specify this value as \x1bB , which is hexadecimal (\x) character 27 (1B) followed by a B .
	See <i>Key Sequences on page 179</i> for notes on key sequence precedence and behavior.
View Port Log Seq	The key sequence used to view the Port Log while in Connect Direct mode. Non- printing characters can be specified by giving their hexidecimal code (see Break Sequence above). The default is Esc+V (\x1bV).
	See <i>Key Sequences on page 179</i> for notes on key sequence precedence and behavior.
View Port Log	Select to allow the user to enter the View Port Log Sequence to view the Port Log during Connect Direct mode. The default is disabled.
Zero Port Counters	Resets all of the numerical values in the Port Counters table at the bottom of the page to zero (0).

Logging & Events	Click the Settings link to configure file logging (see <i>Device Ports - Logging and Events on page 144</i>), email logging, local logging, and USB logging.	
Power Management	Click the Settings link to configure power supplies for the device connected to this device port on the <i>Device Ports - Power Management</i> page.	
Connected to	The type of device connected to the device port. Currently, the SLC unit supports Remote Power Managers (PDUs and UPSes) from 140+ vendors, as well as Sensorsoft devices. If the connected device is an RPM, the user can assign an RPM to the device port by either select an existing RPM (via the Select dropdown) or clicking the Add RPM link to configure a new RPM for the SLC. If an RPM is already assigned to the device port, the user can click on the Selected RPM link to view status and configuration for the RPM. If the connected device is a Sensorsoft device, the user can click on Device Commands to manage the Sensorsoft device. If the type of device connected to the device port is not listed, select Undefined .	
	Note: Sensorsoft temperature/humidity devices are supported with USB-to-serial adapters (ftdi/pl2303/cp210x) but are not supported for use with USB-to-Serial CDC_ACM devices.	

IP Settings

Telnet In	Enables access to this port through Telnet. Disabled by default.
SSH In	Enables access to this port through SSH. Disabled by default.
TCP in	Enables access to this port through a raw TCP connection. Disabled by default:
	Note: When using raw TCP connections to transmit binary data, or where the break command (escape sequence) is not required, set the Break Sequence of the respective device port to null (clear it).
Port	Automatically assigned Telnet, SSH, and TCP port numbers. You may override this value, if desired. The value must be unique on the SLC 8000; for example, you cannot have two or more ports numbered 10001.
Authentication	If selected, the SLC unit requires user authentication before granting access to the port. Authenticate is selected by default for Telnet in and SSH in , but not for TCP in .
Telnet/SSH/TCP Timeout	Select the checkbox to cause an idle Telnet, SSH or TCP connection to disconnect after a specified number of seconds as defined in the Seconds field to the right.
Seconds	Enter a value from 1 to 1800 seconds if selecting the Telnet, SSH or TCP Timeout checkbox to the left. The default is 600 seconds.
	Note: When the Idle Timeout Msg is enabled, the terminal application timeout values for Telnet, SSH and TCP should be set to a value greater than 15 seconds.
Data Direction	If a Telnet, SSH or TCP connection has the idle Timeout enabled, this setting indicates the direction of data use to determine if the connection has timed out: incoming network data, outgoing network data, or data from both directions. The default is Both Directions for Telnet and SSH , and Incoming Network data for TCP .
Telnet Soft IAC Mode	When Telnet Soft IAC mode is enabled, the Telnet server will not block waiting for the initial Telnet protocol IAC option responses. An abbreviated list of IAC options will be sent to the client, including a request for client side Echoing. Disabled by default.

IP Address/Netmask Bits	IP address used for this device port so a user can Telnet, SSH, or establish a raw TCP connection to this address and connect directly to the device port. The optional netmask bits specify the netmask to use for the IP address. For example, for a netmask of 255.255.255.0 specify 24 bits. If the netmask bits are not specified, a default netmask used for the class of network that the IP address falls in will be used.
	For Telnet and SSH, the default TCP port numbers (22 and 23, respectively) are used to connect to the device port. For raw TCP, the TCP port number defined for TCP In to the device port is used.
	Note: If Ethernet Bonding is enabled, assigning individual IP Addresses to Device Ports is not supported. Note that the IP address will be bound to Eth1 only, so if Eth2 is connected and configured, and Eth1 is not, this feature will not work.
Send Term String/Term String	If Send Term String is enabled and a Term String is defined, when a network connection to a device port is terminated, the termination string is sent to the device connected to the device port. The string should be defined so that it sends the appropriate command(s) to the device to terminate any active user sessions, e.g. "logout" or "exit". The string may contain multiple commands separated by a newline ("\n") character. This is a security mechanism used to close sessions that are inadvertently left open by users.

Data Settings

Note: Check the serial device's equipment settings and documentation for the proper settings. The device port and the attached serial device must have the same settings.

Baud	The speed with which the device port exchanges data with the attached serial device.
	From the drop-down list, select the baud rate. Most devices use 9600 for the administration port, so the device port defaults to this value. Check the equipment settings and documentation for the proper baud rate.
Data Bits	Number of data bits used to transmit a character. From the drop-down list, select the number of data bits. The default is ${\bf 8}$ data bits.
Stop Bits	The number of stop bit(s) used to indicate that a byte of data has been transmitted. From the drop-down list, select the number of stop bits. The default is 1 .
Parity	Parity checking is a rudimentary method of detecting simple, single-bit errors. From the drop-down list, select the parity. The default is none .
Flow Control	A method of preventing buffer overflow and loss of data. The available methods include none , xon/xoff (software), and rts/cts (hardware). The default is none .
Enable Logins	For serial devices connected to the device port, displays a login prompt and authenticates users. Successfully authenticated users are logged into the command line interface.
	The default is disabled. This is the correct setting if the device port is the endpoint for a network connection.
Max Direct Connects	Enter the maximum number (1-15) of simultaneous connections for the device port. The default is 1.

Show Lines on Connecting	If enabled, when the user either does a connect direct from the CLI or connects directly to the port using Telnet or SSH, the SLC outputs up to 24 lines of buffered data as soon as the serial port is connected.
	For example, an SLC user issues a connect direct device 1 command to connect port 1 to a Linux server.
	For example, if the SLC user issues the ls command to display a directory on a Linux server, then exits the connection, the results of the ls will be stored in the buffer. When the SLC user then issues another direct connect device 1, the last 24 lines of the ls command is displayed so the user can see what state the server was left in.

Hardware Signal Triggers

Note: When the DSR signal drops on a device port, indicating that the attached cable has been disconnected or the attached device has been powered off, the SLC will log the event in the Device Ports system log and send a slcEventDevicePortAction SNMP trap. The log message and SNMP trap only occur if there is an active (connect direct or network connection) to the device port.

Check DSR on Connect	If this setting is enabled, the device port only establishes a connection if DSR (Data Set Ready) is in an asserted state. DSR should already be in an asserted state, not transitioning to, when a connection attempt is made. Disabled by default unless dial-in, dial-out, or dial-back is enabled for the device port.
	Note. Applies to serial RJ45 device poils only.
Disconnect on DSR	If a connection to a device port is currently in session, and the DSR signal transitions to a de-asserted state, the connection disconnects immediately. Disabled is the default unless dial-in, dial-out, or dial-back is enabled for the device port.
	Note: Applies to serial RJ45 device ports only.
Assert DTR	By default, DTR is asserted on a device port nearly all of the time (except momentarily when a port is opened for operations). Unchecking this option will deassert DTR, simulating a cable disconnection for the device that is connected to a device port.
	Note: Applies to serial RJ45 device ports only.
Toggle DTR	Applies to RJ45 device ports only. If enabled, when a user disconnects from a device port, DTR will be toggled. This feature can be used when a serial connection requires DSR to be active for the attached device to connect. In this case, toggling DTR will end any active connection on the device.
Reverse Pinout	If enabled, swaps the positions of the serial lines, such that the direction of data or the signal is reversed. For instance, TX is swapped with RX. Enabling Reverse Pinout facilitates connections to Cisco and Sun style RS-45 console ports using a straight through Ethernet patch cable, without the need for a rolled cable or adapter. Enabled by default.
	Note: Applies to serial RJ45 device ports only. All Lantronix serial adapters are intended to be used with Reverse Pinout disabled. If you are replacing an original SLC unit with an SLC 8000 advanced console manager, disable the reverse pinout so you can use the original cables and adapters.

USB VBUS	For USB Device Ports only. If enabled, the USB VBUS signal provides power to the USB device attached to a device port. Disabling VBUS will power down the device as long as it is bus-powered instead of self-powered. The VBUS 5V signal is up to 100 mA per port, but not to exceed 600mA total per USB I/O Module. Drawing more than 150 mA on a USB port will shut down the VBUS 5V.	
	<i>Caution:</i> USB ports are designed for data traffic only. They are not designed for charging or powering devices. Over-current conditions on VBUS 5V may disrupt operations.	

Modem Settings (Device Ports)

Note:	Depending on th	ne State and Mode	you select,	different fields	are available.
-------	-----------------	-------------------	-------------	------------------	----------------

State	Used if an external modem is attached to the device port. If enabling, set the modem to dial-out, dial-in, dial-back, dial-on-demand, dial-in/host list, dial-back & dial-on-demand, dial in & dial-on-demand, CBCP Server, and CBCP Client. Disabled by default. See <i>Modem Dialing States (on page 175)</i> for more information.		
Mode	The format in which the data flows back and forth:		
	 Text: In this mode, the SLC advanced console manager assumes that the modem will be used for remotely logging into the command line. Text mode can only be used for dialing in or dialing back. Text is the default. PPP: This mode establishes an IP-based link over the modem. PPP connections can be used in dial-out mode (e.g., the SLC unit connects to an external network), dial-in mode (e.g., the external computer connects to the network that the SLC 8000 advanced console manager is part of), or dial-on-demand. 		
Use Sites	Enables the use of site-oriented modem parameters which can be activated by various modem-related events (authentication, outbound network traffic for dial- on-demand connections, etc.). Sites can be used with the following modem states: dial-in, dial-back, dial-on-demand, dial-in & dial-on-demand, dial-back & dial-on-demand, and CBCP server.		
Initialization Script	Commands sent to configure the modem may have up to 100 characters. Consult your modem's documentation for recommended initialization options. If you do not specify an initialization script, the SLC unit uses a default initialization string of AT S7=45 SO=0 L1 V1 X4 &D2 &C1 E1 Q0.		
	Note: We recommend that the modem initialization script always be preceded with AT and include E1 V1 x4 Q0 so that the SLC 8000 advanced console manager may properly control the modem. For information on AT commands, refer to the modem user guide, or do a web search for at command set. Serial modems may need to include &B1 in the modem initialization string to set the DTE rate to a fixed baud rate.		
Modem Timeout	Timeout for all modem connections. Select Yes (default) for the SLC unit to terminate the connection if no traffic is received during the configured idle time. Enter a value of from 1 to 9999 seconds. The default is 30 seconds.		
Caller ID Logging	Select to enable the SLC advanced console manager to log caller IDs on incoming calls. Disabled by default.		
Madam Commond	Note: For the Caller ID AT command, refer to the modern user guide.		
wodem Command	Modem AT command used to initiate caller ID logging by the modem.		
	Note: For the AT command, refer to the modem user guide.		

Dial-Back Number	Users with dial-back access can dial into the SLC device and enter their login and password. Once the SLC 8000 advanced console manager authenticates them, the modem hangs up and dials them back.
	Select the phone number the modem dials back on -a fixed number or a number associated with their login. If you select Fixed Number , enter the number (in the format 2123456789).
	The dial-back number is also used for CBCP client as the number for a user- defined number. See <i>Device Ports - Settings (on page 128)</i> for more information.
Dial-Back Delay	For dial-back and CBCP Server, the number of seconds between the dial-in and dial-out portions of the dialing sequence.
Dial-Back Retries	For dial-back and CBCP Server, the number of times the SLC unit will retry the dial-out portion of the dialing sequence if the first attempt to dial-out fails.

Modem Settings: Text Mode

Timeout Logins	If you selected Text mode, you can enable logins to time out after the connection is inactive for a specified number of minutes. The default is No . This setting is only applicable for text mode connections. PPP mode connections stay connected until either side drops the connection. Disabled by default.
Dial-in Host List	From the drop-down list, select the desired host list. The host list is a prioritized list of SSH, Telnet, and TCP hosts that are available for establishing outgoing modem connections or for connect direct at the CLI. The hosts in the list are cycled through until the SLC 8000 advanced console manager successfully connects to one. To establish and configure host lists, click the Host Lists link.

Modem Settings: PPP Mode

Negotiate IP Address	If the SLC unit and/or the serial device have dynamic IP addresses (e.g., IP addresses assigned by a DHCP server), select Yes . Yes is the default. If the SLC advanced console manager or the modem have fixed IP addresses, select No , and enter the Local IP (IP address of the port) and Remote IP (IP address of the modem).
Authentication	Enables PAP or CHAP authentication for modem logins. PAP is the default. With PAP, users are authenticated by means of the Local Users and any of the remote authentication methods that are enabled. With CHAP, the CHAP Handshake fields authenticate the user.
CHAP Handshake	The Host/User Name (for UNIX systems) or Secret/User Password (for Windows systems) used for CHAP authentication. May have up to 128 characters.
CHAP Auth Uses	For CHAP authentication, determines what is used to validate the CHAP host/ user sent by the remote peer: either the CHAP Host defined for the modem, or any of the users in the Local Users list.
Same authentication for Dial-in & Dial-on-Demand (DOD)	Select this option to let incoming connections (dial-in) use the same authentication settings as outgoing connections (dial-on-demand). If this option is not selected, then the dial-on-demand connections take their authentication settings from the DOD parameter settings. If DOD Authentication is PAP , then the DOD CHAP Handshake field is not used.
DOD Authentication	Enables PAP or CHAP authentication for dial-in & dial-on-demand. PAP is the default. With PAP, users are authenticated by means of the Local Users and any of the remote authentication methods that are enabled. With CHAP , the DOD CHAP Handshake fields authenticate the user.

DOD CHAP Handshake	For DOD Authentication , enter the Host/User Name for UNIX systems) or Secret/User Password (for Windows systems) used for CHAP authentication. May have up to 128 characters.
Enable NAT	Select to enable Network Address Translation (NAT) for dial-in and dial-out PPP connections on a per modem (device port or USB port) basis. Users dialing into the SLC 8000 advanced console manager access the network connected to Eth1 and/or Eth2.
	Note: IP forwarding must be enabled on the Network > Network Settings page for NAT to work. See Chapter 6: Basic Parameters on page 66.
Dial-out Number	Phone number for dialing out to a remote system or serial device. May have up to 20 characters. Any format is acceptable.
Remote/Dial-out Login	User ID for dialing out to a remote system. May have up to 32 characters.
Remote/Dial-out Password	Password for dialing out to a remote system. May have up to 64 characters.
Retype	Re-enter remote/dial-out password for dialing out to a remote system. May have up to 64 characters.
Restart Delay	The number of seconds after the timeout and before the SLC unit attempts another connection. The default is 30 seconds.
CBCP Server Allow No Callback	For CBCP Server state, allows "No Callback" as an option in the CBCP handshake in addition to User-defined Number and Admin-defined Number.
CBCP Client Type	For CBCP Client, this selects the number that the client would like to use for callback - either a user-defined number passed to the server (specified by the Fixed Dial-back Number) or an administrator-defined number determined by the server based on the login that is PAP or CHAP authenticated.

3. To save settings for just this port, click the **Apply** button.

4. To save selected settings to ports other than the one you are configuring:

- From the Apply Settings drop-down box, select none, a group of settings, or All.
- In to **Device Ports**, type the device port numbers, separated by commas; indicate a range of port numbers with a hyphen (e.g., 2, 5, 7-10).

Note: It may take a few minutes for the system to apply the settings to multiple ports.

Port Status and Counters

Port Counters describe the status of signals and interfaces. SLC advanced console manager updates and increments the port counters as signals change and data flows in and out of the system. These counters help troubleshoot connections or diagnose problems because they give the user an overview of the state of various parameters. By setting them to zero and then re-checking them later, the user can view changes in status.

The chart in the middle of the page displays the flow control lines and port statistics for the device port. The system automatically updates these values. To reset them to zeros, select the **Zero** port counters checkbox in the IP Settings section of the page.

Note: Status and statistics shown on the web interface represent a snapshot in time. To see the most recent data, you must reload the web page. Status may display "N/A" if SLC is unable to dynamically determine the connected/inserted device.

Table 8-6 Port Status and Counters

Port Status and	Counters
DSR/CD	No
DTR	Yes
стѕ	No
RTS	Yes
Bytes input	0
Bytes output	0
Framing errors	0
Parity errors	0
Overrun errors	0
Flow Control errors	0
Seconds since zeroed	106734

Device Ports - Power Management

In the Device Ports - Power Management page, configure power supplies that provide power to the device or server connected to the device port. Up to 4 power supplies can be configured, by selecting an RPM, an outlet on the RPM, and defining a unique name for the RPM/outlet pair. The RPM outlet pair can also be controlled (power cycled, turned on, turned off).

This page also allows the user to define the Power Management Sequence, which, when entered while the user is connected to a device port via the connect direct command, will display the Power Management menu:

Power Management Menu							
RPN	<pre>/outlet>>></pre>	tri	.ppOUT4	ser	ntry30UT15		
Α.	Status	D.	Turn On	G.	Turn On		
Β.	Help	Ε.	Turn Off	Η.	Turn Off		
С.	Quit	F.	Power Cycle	I.	Power Cycle		

This menu allows the administrator to query status and control any of the power supplies that provide power to the device connected to the device port.

To configure power management settings for a device port:

- Connect to a specific port on the Devices > Device Ports page according to instructions in To open the Device Ports - Settings page: (on page 128).
- 2. Click the **Settings** link beside **Power Management** to access the *Device Ports Power Management* page.

Logout Host: slc. User: sys	SLC 8048 4331 admin	LCD SD U1 U2 Sele	E1 1 3 5 7 9 E2 2 4 6 8 1 act port for • Configure	9 11 13 1 10 12 14 1 ration	5 17 19 21 23 25 6 18 20 22 24 26 WebSSH (DP only)	27 29 31 33 3 28 30 32 34 3 Connected	5 37 39 41 4 6 38 40 42 4 Device (DP	13 45 47 A 14 46 48 B only)
Network Services User	Authentication	Devices Ma	intenance Quicl	k Setup			公 ?	ţ
Device Status Device Ports	Console Port U	ISB / SD Card	Internal Modem	RPMs	Connections	Host Lists	Scripts	Sites
	Dev	vice Ports	- Power Manag	gemen	t			Help?
Port: Name: Power Management Sequence:	5 Port-5 \x1bP				Select up to 4 for the de Typing the Po connected f for con	RPM outlets evice connect ower Manage to a device po trolling each o	which pro ed to this c ment Sequ ort will disp of the powe	vide power levice port. ence while lay a menu er supplies.
Managed Power Supplies					<u>RPM O</u>	utlets: SLP16	snmp	
#1 RPM: Outlet: Name: State: Action: #2 RPM: Outlet: Name: State: Action: #3 RPM: Outlet: Name: State: Action:	SLP16snmp	Viev Viev Viev Viev Viev Viev Viev Viev Viev Viev Viev Viev Viev Viev Viev	w Outlets >> Select Outlet w Outlets >> Select Outlet w Outlets >> Select Outlet	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16	TowerA_Out TowerA_Out TowerA_Out TowerA_Out TowerA_Out TowerA_Out TowerA_Out TowerA_Out TowerA_Out TowerA_Out TowerA_Out TowerA_Out TowerA_Out TowerA_Out TowerA_Out	<pre>let1 let2 let3 let4 let5 let6 let7 let8 let9 let10 let11 let12 let13 let14 let15 let16</pre>		
#4 RPM: Outlet: Name: State: Action:	select RPM	▼ Vie	W Outlets >> Select Outlet					¥

Figure 8-7 Device Ports - Power Management

3. Enter the following:

Power Management Sequence	A series of one to ten characters that will display the Power Management menu when connected to the device port. The default value is Esc+P (escape key, then uppercase "P"). This value is specified as $xlbP$, which is hexidecimal (x) character 27 (1B) followed by a P. See <i>Key Sequences on page 179</i> for notes on key sequence precedence and behavior.
RPM	For each managed power supply, select a RPM, most likely a PDU, which has outlets that can be individually controlled, and which provides power to the device connected to the device port.

Outlet	For each managed power supply, enter the outlet on the selected RPM. As an aid to selecting the outlet, click the View Outlets button, then select an outlet from the list and click the Select Outlet button. The managed power supply outlet number will be filled in, as well as the managed power supply outlet name if a name is listed for the outlet and one has not already been defined for the managed power supply. A unique name for the managed power supply name is required; this is what will be displayed on the Power Management menu.
Name	For each managed power supply, enter the name on the selected RPM. As an aid to selecting the name, click the View Outlets button, then select an outlet from the list and click the Select Outlet button. The managed power supply outlet number will be filled in, as well as the managed power supply outlet name if a name is listed for the outlet and one has not already been defined for the managed power supply. A unique name for the managed power supply name is required; this is what will be displayed on the Power Management menu.
State	Displays the current state of the outlet when the Device Ports - Power Management web page is loaded: on , off or unknown if the RPM does not provide status for individual outlets or the SLC was unable to obtain the status of the outlet.
Action	The action to take on the outlet: Cycle Power, On or Off.

4. To save, click **Apply**.

Device Ports - RPMs - Add Device

On the *Devices > Device Ports* page, access the *Device Ports > RPMs - Add Device* page to configure a new managed remote power manager (RPM) for the SLC configuration.

To add a new managed RPM :

- 1. Connect to a specific port on the **Devices > Device Ports** page according to instructions in *To open the Device Ports Settings page: (on page 128).*
- In the Connected to drop-down menu above the IP Settings section of the Device Ports > Settings (1 of 2) page, select RPM.
- 3. Click the Add RPM link. The *Device Ports > RPMs Add Device* page displays.

Note: The Device Ports > RPMs - Add Device page can also be accessed via the Devices > RPMs page.

4. Update the configuration settings on this page according to directions in *RPMs - Add Device (on page 193)*.

LANTRONI	SLC 8048 U1 E1 1 3 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 35 37 U2 E2 2 4 6 8 10 12 14 16 18 20 22 24 26 28 30 32 34 36 38	39 41 43 45 47 A 40 42 44 46 48 B
Logout Host	slc4331 Select port for Configuration WebSSH (DP only) Connected Dev	rice (DP only)
Network Services U	ser Authentication Devices Maintenance Quick Setup	🕼 ? 🗗 🗉
Device Status Device P	orts Console Port USB / SD Card RPMs Connections Host Lists Scripts Sites	
	RPMs - Add Device	Help?
Vendor:	select one	
	(U) - USB, (S) - Serial, (N) - Network, (P) - SNMP	
Model:	select one v	
	USB	
Managed via:	Serial Network	
	SNMP	
USB Device:	select one 🔻	
Name:		
# of Outlets:		
IP Address:		
IF Address.		
Port:	Enter "0" for a front USB port.	
Driver Opts:		
Login:		
Password:		
Retype Password:		
Log Status:	No Yes, minutes:	
Critical SNMP Traps:		
Critical Emails		
official Efficie.	C. Shuidaura this UDO	
Low Battery:	Shutdown all UPSes	
	Allow battery failure Shutdown both SLC UPSes	
Shutdown Order:		
Provides SLC Power:		
	Apply	

Figure 8-8 Device Ports > RPMs - Add Device

Device Port - Sensorsoft Device

Devices made by Sensorsoft are used to monitor environmental conditions.

1. In the Connected to drop-down menu above the IP Settings section of the Device Ports > Settings (1 of 2) page, select Sensorsoft.

Note: Sensorsoft temperature/humidity devices are supported with USB-to-serial adapters (ftdi/ pl2303/cp210x) but not supported for use with USB-to-Serial CDC_ACM devices.

2. Click the Device Commands link. The following page displays:

Figure 8-9 Devices > Device Ports > Sensorsoft					
LANTRONIX° SLC 804	LCD SD U1 MD E1 1 3 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 35 37 39 LCD SD U2 U2 MD E2 2 4 6 8 10 12 14 16 18 20 22 24 26 28 30 32 34 36 38 40	41 43 45 47 A 42 44 46 48 B			
Logout Host: slc4331 User: sysadmin	Select port for 💿 Configuration 🔵 WebSSH (DP only) 🔘 Connected Device (OP only)			
Network Services User Authentication	Devices Maintenance Quick Setup	? 🗗 🗉			
Device Status Device Ports Console Port	USB / SD Card Internal Modem RPMs Connections Host Lists Scripts	Sites			
	Device Ports - Sensorsoft	Help?			

Device Ports - Sensorsoft

	Sensorsoft Devices										
Dev Port	Device Port Name	Curr Temp	Low Temp	High Temp	Use °F	Humidity (%)	Low Humidity	High Humidity	Contact	Traps	Show Status
5	Port-5	0.0 °C	0	25		0.0	0	100	N/A	1	۲

< Back to Device Port Settings

Apply

3. Select a port and enter or view the following information:

Dev Port	Displays the number of the SLC port.
Device Port Name	Displays the name of the SLC port.
Curr Temp	Current temperature (degrees Celsius) on the device the sensor is monitoring.
Low Temp	Enter the temperature (degrees Celsius) permitted on the monitored device below which the SLC 8000 advanced console manager sends a trap.
High Temp	Enter the temperature (degrees Celsius) permitted on the monitored device above which the SLC unit sends a trap.
Use °F	Display and set the temperature for this device in degrees Fahrenheit, instead of Celsius, which is the default.
Humidity (%)	Current relative humidity on the device the sensor is monitoring.
Low Humidity	Enter the relative humidity permitted on the device the sensor is monitoring below which the sensor sends a trap to the SLC advanced console manager.
High Humidity	Enter the highest relative acceptable humidity permitted on the device above which the sensor sends a trap to the SLC unit.
Contact	Displays the current contact closure status of the sensor, if supported by the connected Sensorsoft device. If the Sensorsoft device does not report a contact status, N/A will be displayed. If Traps are enabled for the Sensorsoft device, an <pre>slcEventDevicePortDeviceContactChanged trap will be sent when the contact state changes from Open to Closed and from Closed to Open.</pre>
Traps	Select to indicate whether the SLC 8000 unit should send a trap or configured Event Alert when the sensor detects an out-of-range configured threshold.

- 4. Click the **Apply** button.
- 5. To view the status detected by the Sensorsoft, click the **Show Status** link in the far right column of the table.

Lantronix SLC8048 - Device St	tatus - Google Chrome	
▲ Not secure bttps://172.19.39.251/tmpfile.htm SLC8048 - Sensorsoft		
Device Port Name: Sensorsoft Device Model: Revision: Device Status: Contact State:	Port-9 SS6402 2.01 0a 0 (Open)	
4		•

Figure 8-10 Sensorsoft Status

Device Port Commands

Go to *Device Port Commands* to view CLI commands which correspond to the web page entries described above.

Device Commands

Go to *Device Commands* to view CLI commands which correspond to the web page entries described above.

Interacting with a Device Port

Once a device port has been configured and connected to an external device such as the console port of an external server, the data received over the device port can be monitored at the command line interface with the connect listen command, as follows:

To connect to a device port to monitor it:

connect listen deviceport <Port # or Name>

In addition, you can send data out the device port (for example, commands issued to an external server) with the connect direct command, as follows:

To connect to a device port to monitor and/or interact with it, or to establish an outbound network connection:

connect direct <endpoint>

endpoint is one of:

```
deviceport <Port # or Name>
ssh <IP Address> [port <TCP Port>][<SSH flags>]
where:
```

```
<SSH flags> is one or more of:
user <Login Name>
version <1|2>
command <Command to Execute>
tcp <IP Address> port <TCP Port>
telnet <IP Address> [port <TCP Port>]
udp <IP Address> port <UDP Port>
hostlist <Host List>
```

Notes: To escape from the connect direct command when the endpoint of the command is deviceport, tcp, or udp and return to the command line interface, type the escape sequence assigned to the currently logged in user. If the endpoint is telnet or SSH, logging out returns the user to the command line prompt.

To escape from the connect listen command, press any key. Setting up a user with an escape sequence is optional. For any NIS, LDAP, RADIUS, Kerberos, or TACACS+ user, or any local user who does not have an escape sequence defined, the default escape sequence is Esc+A.

When connecting to a USB device port, buffered data collected while there was no active connection to the device port may be displayed initially. This is due to clearing internal buffers in preparation for the new connection to the device port.

Device Ports - Logging and Events

The SLC products support port buffering of the data on the system's device ports as well as notification of receiving data on a device port. Port logging is disabled by default. You can enable more than one type of logging (local, NFS file, token and data detection, SD card, or USB port) at a time. The buffer containing device port data is cleared when any type of logging is enabled.

Local Logging

If local logging is enabled, each device port stores 256 Kbytes (approximately 400 screens) of I/O data in a true FIFO buffer. You may view this data (in ASCII format) at the CLI with the show locallog command or on the *Devices > Device Ports - Logging & Events* page. Buffered data is normally stored in RAM and is lost in the event of a power failure if it is not logged using an NFS mount solution. If the buffer data overflows the buffer capacity, only the oldest data is lost, and only in the amount of overrun (not in large blocks of memory).

NFS File Logging

Data can be logged to a file on a remote NFS server. Data logged locally to the SLC 8000 advanced console manager is limited to 256 Kbytes and may be lost in the event of a power loss. Data logged to a file on an NFS server does not have these limitations. The system administrator can define the directory for saving logged data on a port-by-port basis and configure file size and number of files per port.

The directory path must be the local directory for one of the NFS mounts. For each logging file, once the file size reaches the maximum, a new file opens for logging. Once the number of files reaches the maximum, the oldest file is overwritten. The file naming convention is: <Device Port Number>_<Device Port Name>_<File number>.log.
Examples:

02_Port-2_1.log 02_Port-2_2.log 02_Port-2_3.log 02_Port-2_4.log 02_Port-2_5.log

USB and SD Card Logging

Data can be logged to a USB flash drive that is loaded into the USB ports or the SD card slot on the front of the SLC unit and properly mounted. Data logged locally to the SLC advanced console manager is limited to 256 Kbytes and may be lost in the event of a power loss. Data logged to a USB flash drive or SD card does not have these limitations. The system administrator can define the file size and number of files per port. For each logging file, once the file size reaches the maximum, a new file opens for logging. Once the number of files reaches the maximum, the oldest file is overwritten. The file naming convention is:

```
<Device Port Number> <Device Port Name> <File number>.log
```

Examples:

02_Port-2_1.log 02_Port-2_2.log 02_Port-2_3.log 02_Port-2_4.log 02_Port-2_5.log

Token/Data Detection

The system administrator can configure the device log to detect when a user-defined string or number of characters is received from the device, and automatically perform one or more actions: send a message to the system log, send an SNMP trap, send an email alert, send a string to the device, or control one of the power supplies associated with the device.

Syslog Logging

Data can be logged to the system log. If this feature is enabled, the data will appear in the Device Ports log, under the Info level. The log level for the Device Ports log must be set to Info for the data to be saved to the system log. See *Device Ports - Logging and Events (on page 144)*.

To set logging parameters:

1. In the top section of the *Device Port Settings* page, click the **Settings** link in the Logging field. The following page displays:

Logout Host: si User: sy Network Services User Device Status Device Port	SLC 8048	U1 E1 1 3 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 35 37 39 41 43 45 47 A U2 E2 2 4 6 8 10 12 14 16 18 20 22 24 26 28 30 32 34 36 38 40 42 44 66 8 B Select port for Image: Configuration WebSSH (DP only) Connected Device (DP only) Connected Device (DP only) Image: Connection Section
Service Status Device POIL		
	Device Por	rts - Logging & Events Help?
Port: 14 Name: Por	rt-14	For NFS File Logging, the directory to log to must reside on an external NFS server. Specify the local directory for the <u>NFS mount</u>
Token & Data Detection:		Local Logging:
Trigger on: 🥚	Data Byte Count Token/Character String	Clear Local Log: <u>View Local Log</u> Log Viewing Attributes
Byte Threshold: 10	0	Display: Tail Head
Token:		Number of Lines: 40
Actions System		NFS File Logging:
2,510g. 🔄		NFS Log to View: Most Recent ▼ View >
SNMP Trap: 🔲		Directory to Log to: select one V
Email: 🖉		Max Number of Files: 10
Email To:		Max Size of Files: 2048 bytes
Email Subject: Po	rt %d Logging	USB / SD Card Logging:
Soud String to Dovice:		Log to View: Most Recent View
String to Send:		Log to: Port U1 Port U2 SD Card
Suring to Send:		Max Number of Files: 10
Control Power Supply:		Max Size of Files: 2048 bytes
Power Supply:	¥	System Longing:
Power Action:	Cycle Power	Note: The logging level for the Device Ports log must be set to 'Info'
	Turn Off	to view Syslog entries for Device Port logging.
See online help for how D	elay parameters affect Actions.	
Action Delay: 60	seconds	
Restart Delay: 60	seconds	
< Back to Device Port Setting	<u>s</u>	Apply Apply settings to Device Ports: Note: In addition to applying settings to the currently selected Device Port,

Figure 8-11 Devices > Device Ports - Logging & Events

2. Enter the following:

Token & Data Detection

Token & Data Detection	Select to enable token and data detection on the selected device port, with a set of actions that can be enabled if a data trigger occurs. The default is disabled.	
Trigger on	Select the method of triggering an action:	
	 Data Byte Count: A specific number of bytes of data. This is the default. Token/Character String: A specific pattern of characters, which you can defin by a regular expression. 	
	Note: Token/Character String recognition may negatively impact the SLC unit's performance, particularly when regular expressions are used.	

Byte Threshold	The number of bytes of data the port will receive before the SLC unit will captur log data and initiate the selected actions. The default is 100 bytes.				
	In most cases, the console port of your device does not send any data unless there is an alarm condition. After the SLC unit receives a small number of bytes, it perceives that your device needs some attention.				
	A threshold set to 30 characters means that as soon as the unit receives 30 bytes of data, it performs the actions that are selected for this port.				
Token	The specific pattern of characters the SLC unit must recognize before initiating the actions configured for this port. The maximum is 100 characters. You may use a regular expression to define the pattern. For example, the regular expression "abc[def]g" recognizes the strings abcdg, abceg, abcfg.				
	The SLC console manager supports GNU regular expressions; for more information, see:				
	 <u>http://www.gnu.org/software/libc/manual/html_node/Regular-Expressions.html</u> <u>http://www.delorie.com/gnu/docs/regex/regex.html</u> 				
Actions	Select one or more actions to perform if there is a data trigger:				
	• Syslog: A message is logged to the system log indicating what the data trigger was along with the initial portion of the data received.				
	• SNMP Irap: A sicEventDevicePortData trap will be sent to the NMS configured in the SNMP settings				
	 Email: An email alert will be sent to the address configured for the device port. 				
	• Send String to Device: A string will be sent to the device connected to the				
	 Control Power Supply: The state of one or more of the device port power supplies can be changed. 				
Email to	The email address of the message recipient(s) for an email alert. To enter more than one email address, separate the addresses with a single space. You can enter a total of 128 characters.				
Email Subject	A subject text appropriate for your site. May have up to 128 characters.				
	The email subject line is pre-defined for each port with its port number. You can use the email subject to inform the desired recipients of the problem on a certain server or location (e.g., server location or other classification of your equipment).				
	Note: The character sequence %d anywhere in the email subject is automatically replaced with the device port number.				
String to Send	The string to send to the device connected to the device port. The string supports the following special characters: newline $("\n")$, double quote $("\"")$, single quote $("\"")$, and escape $("\xlb")$. You can enter a total of 128 characters.				
Power Supply	The power supply that provides power to the device connected to the device port which to control. Select either all power supplies or an individual power supply.				
Power Action	The action to perform on the selected power supply or power supplies - Cycle Power, Turn On or Turn Off.				
Action Delay	A time limit of how long, in seconds, the device port will capture data after the data trigger is detected and before closing the log file (with a fixed internal buffer maximum capacity of 1500 bytes) and performing the selected actions. The default is 60 seconds.				
Restart Delay	The number of seconds for the period of time, after performing the selected action, during which the device port will ignore additional characters received. The data will simply be ignored and not trigger additional actions until this time elapses. The default is 60 seconds.				

Local Logging

Local Logging	If you enable local logging, each device port stores 256 Kbytes (approximately 400 screens) of I/O data in a true FIFO buffer. Disabled by default.
Clear Local Log	Select the checkbox to clear the local log.
View Local Log	Click this link to see the local log in text format.

Log Viewing Attributes

Display	Select to view either the beginning (Head) or end (Tail) of the log.		
Number of Lines	Number of lines from the head or tail of the log to display.		

NFS File Logging

NFS File Logging	Select the checkbox to log all data sent to the device port to one or more files on an external NFS server. Disabled by default.				
NFS Log to View	Available log files in the selected NFS Directory to view.				
Directory to Log to	The path of the directory where the log files will be stored.				
	Note: This directory must be a directory exported from an NFS server mounted on the SLC 8000 advanced console manager Specify the local directory path for the NFS mount.				
Max Number of Files	The maximum number of files to create to contain log data to the port. These files keep a history of the data received from the port. Once this limit is exceeded, the oldest file is overwritten. The default is 10 .				
Max Size of Files	The maximum allowable file size in bytes. The default is 2048 bytes. Once the maximum size of a file is reached, the SLC unit begins generating a new file.				

USB / SD Card Logging

Select to enable USB / SD card logging. A USB thumb drive or SD card must be loaded into one of the ports of the SLC and properly mounted. Disabled by default.
Available log files in the selected USB / SD card slot to view.
Select the USB port or SD card to use for logging.
The maximum number of files to create to contain log data to the port. These files keep a history of the data received from the port. Once this limit is exceeded, the oldest file is overwritten. The default is 10.
The maximum allowable file size in bytes. The default is 2048 bytes. Once the maximum size of a file is reached, the SLC 8000 advanced console manager begins generating a new file. The default is 2048 bytes.

Syslog Logging

Syslog Logging	Select to enable system logging.			
	Note: The logging level for the device ports log must be set to Info to view Syslog entries for Device Port logging on the Services > SSH/Telnet/Logging page.			

Note: To apply the settings to additional device ports, in the Apply settings to Device Ports field, enter the additional ports, (e.g., 1-3, 5, 6)

3. To apply settings to other device ports in addition to the currently selected port, select the

Apply settings to Device Ports and enter port numbers separated by commas. Indicate a range of port numbers with a hyphen (e.g., 2, 5, 7-10), and separate ranges with commas.

4. To save, click the **Apply** button.

Logging Commands

Go to *Logging Commands* to view CLI commands which correspond to the web page entries described above.

Console Port

The console port initially has the same defaults as the device ports. Use the *Devices > Console Port* page to change the settings, if desired.

To set console port parameters:

1. Click the **Devices** tab and select **Console Port**. The following page displays:

Logout Host: slc4331 User: sysadmin Network Services User Authentication Device Status Device Ports Console Port	8 U1 E1 1 3 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 35 37 39 41 43 45 47 U2 E2 2 4 6 8 10 12 14 16 18 20 22 24 26 28 30 32 34 36 38 40 42 44 46 48 Select port for © Configuration WebSSH (DP only) Connected Device (DP only) Devices Maintenance Quick Setup	B
	Console Port Hel	?
St E Data Stop P Flow Co Tim Show Lines On Conner Group Ac	tatus: Not Connected Baud: 9600 ▼ Bits: 8 ▼ Parity: none ♥ Parity: none ♥	

Figure 8-12 Devices > Console Port

2. Change the following as desired:

Baud	The speed with which the device port exchanges data with the attached serial device.				
	From the drop-down list, select the baud rate. Most devices use 9600 for the administration port, so the console port defaults to this value.				
Data Bits	Number of data bits used to transmit a character. From the drop-down list, select the number of data bits. The default is ${\bf 8}$ data bits.				
Stop Bits	The number of stop bits that indicate that a byte of data has been transmitted. From the drop-down list, select the number of stop bits. The default is 1 .				

Parity	Parity checking is a rudimentary method of detecting simple, single-bit errors. From the drop-down list, select the parity. The default is none .				
Flow Control	t method of preventing buffer overflow and loss of data. The available methods include none , xon/xoff (software), and rts/cts (hardware). The default is none .				
Timeout	The number of minutes (1-30) after which an idle session on the console is automatically logged out. Disabled by default.				
Show Lines on Connecting	If selected, when you connect to the console port with a terminal emulator, you will see the last lines output to the console, for example, the SLC boot messages or the last lines output during a CLI session on the console.				
Group Access	If undefined, any group can access the console port. If one or more groups are specified (groups are delimited by the characters '' (space), ',' (comma), or ';' (semicolon)), then any user who logs into the console port must be a member of one of the specified groups, otherwise access will be denied. Users authenticated via RADIUS may have a group (or groups) provided by the RADIUS server via the Filter-Id attribute that overrides the group defined for a user on the SLC 8000 advanced console manager. A group provided by a remote server must be either a single group or multiple groups delimited by the characters '' (space), ',' (comma), ',' (semicolon), or '=' (equals) - for example "group=group1,group2;" or "group1,group2,group3".				

3. Click the **Apply** button to save the changes.

Console Port Commands

Go to *Console Port Commands* to view CLI commands which correspond to the web page entries described above.

Internal Modem Settings

This section describes how to configure an internal modem in the SLC advanced console manager. The SLC 8000 internal modem is an optional part. If the modem is installed, a message will be displayed when the SLC unit is booted:

Internal modem installed.

The presence of the modem will also be displayed in the CLI admin version command, the web *About SLC* page, and the System Configuration report. The internal modem provides a subset of the modem functionality available for modems connected to a Device Port and USB modems. If the internal modem is installed, the Internal Modem web page can be displayed by selecting the Internal Modem option from the main menu, or by selecting the **MD** button in the *Sample Dashboards* on the upper right corner of the web page.

Note: The internal modem only supports Dial-in, Dial-out and Dial-back.

Setting Up Internal Modem Storage

An internal modem may be configured on the *Devices > Internal Modem* page and accessed through the *Sample Dashboards* only if it is installed into the SLC 8000 advanced console manager.

To set up internal modem storage in the SLC 8000 advanced console manager:

1. Insert an internal modem into the SLC unit according to the instructions in *Modem Installation* (on page 41).

Note: Your internal modem will appear in the Sample Dashboards in the upper right hand corner once the SLC unit is reboots.

- 2. Reboot the SLC 8000 advanced console manager.
- 3. Log into the SLC unit and click **Devices**.
- 4. Click Internal Modem. *Figure 8-13* shows the page that displays.

	Host: slc4	SLC 8048	B LCD SD L S	E1 1 3 E2 2 4 elect port for	5 7 9 11 13 13 6 8 10 12 14 10 Configuration	5 <mark>17 19 21 23 25</mark> 5 <mark>18 20 22 24 26</mark> WebSSH (DP only)	27 29 31 33 35 28 30 32 34 36 Connected	5 37 39 41 4 5 38 40 42 4 Device (DP c	13 45 47 A 14 46 48 B only)
Network Servi	ices User A	uthentication	Devices M	aintenance	Quick Setup			☆?	₿ 🗉
Device Status	Device Ports	Console Port	USB / SD Card	i Internal N	lodem RPMs	Connections	Host Lists	Scripts	Sites
			l m é						Hole 2
			inte		em				neip :
		0	tata: Disablad	-		View Mode	em Log >		
		SI	ade: Disabled			PPP Logging	g:		
		Use S	ites:	U FFF		FFF Debu	g		
		Group Acc	ess:		1				
		Initialization Sc	cript:						
		Modem Time	eout: No	Yes, se	conds (1-9999);				
		Caller ID Loop	aina: 🔲 Mode	m Command	:				
		Check Dial T	one: 💿 No	Yes. mir	nutes (5-600):	15			
		Dial-back Num	ber: Eixed N	lser Number lumber:					
		Dial-back De	elay: 15	econds					
		Dial-back Ret	ries: 3						
	Те	xt Mode							
		Timeout Log	gins: 💿 No 🛛	Yes, minutes	s (1-30):				
	PP	P Mode							
	١	Negotiate IP Addr	Yes ess:	Local	IP:				
		5	No	Remote	IP:				
		Authentica	tion: PAP	CHAP					
				lost/User Nar	ne:				
		CHAP Handsh	nake: Secret	/User Passwo	ord:				
				etype Passwo ⊣oot	ora:				
				Finabling NAT re	ai Osers nuires IP Forwardin	r to be enabled			
		Dial-out Num	ber:		lanco <u>n' r'orwaran</u>	g to be chabled.			
	R	emote/Dial-out I c	pain:]				
	Remo	te/Dial-out Passw	/ord:		Retype:				
		Restart De	elay: 30	seconds]		
				Apply					

Figure 8-13 Devices > Internal Modem

	5.	Enter	the	following	fields
--	----	-------	-----	-----------	--------

State	Indicates whether the internal is enabled. When enabling, set the modem to Disabled , Dial-in , Dial-out , and Dial-back . Disabled by default.
Mode	The format in which the data flows back and forth.
	 With Text selected, the SLC unit assumes that the modem will be used for remotely logging into the command line. Text mode is only for dialing in. This is the default. PPP establishes an IP-based link over the modem. PPP connections can be used in dial-out mode (e.g., the SLC unit connects to an external network) or dial-in mode (e.g., the external computer connects to the network that the SLC unit is part of), dial-back (dial-in followed by dial-out), CBCP server and CBCP client.
Use Sites	For more information see Sites (on page 172).
Group Access	If undefined, any group can access the modem (text login only). If one or more groups are specified (groups are delimited by the characters ',' (comma) or ';' (semicolon)), then any user who logs into the modem must be a member of one of the specified groups, otherwise access will be denied. Users authenticated via RADIUS may have a group (or groups) provided by the RADIUS server via the Filter-Id attribute that overrides the group defined for a user on the SLC unit. A group provided by a remote server must be either a single group or multiple groups delimited by the characters ',' (comma), ';' (semicolon), or '=' (equals) - for example "group=group1,group2;" or "group1,group2,group3".
Initialization Script	Commands sent to configure the modem may have up to 100 characters. Consult your modem's documentation for recommended initialization options. If you do not specify an initialization script, the SLC uses a uses a default initialization string of: AT S7=45 SO=0 L1 V1 X4 &D2 &c1 E1 Q0 Note: We recommend that the modem initialization script always be pre- pended with AT and include E1 V1 x4 Q0 so that the SLC unit may properly control the modem.
Modem Timeout	Timeout for modem connections. Set to No by default.
	To configure the modem connection to time out when no traffic is received choose Yes and enter a value of 1 to 9999 seconds.
Caller ID Logging	Select to enable the SLC unit to log caller IDs on incoming calls. Disabled by default.
Modem Command	Modem AT command used to initiate caller ID logging by the modem.
	Note: For the AT command, use +VCID=1 to enable Caller ID with formatted presentation, and use +VCID=2 to enable Caller ID with unformatted presentation. This is subject to subscribing to a Caller ID service for the modem line.
Check Dial Tone	If set to Yes , the SLC will periodically check the modem for a dial tone while waiting for a dial in (e.g., if the Modem State is set to Dial-in, or if the Modem State is set to Dial-back and the SLC unit is in the Dial-in portion of the sequence). The SLC unit can issue a trap or an event can be setup to notify the user if no dial tone is detected. Set to Yes by default (every 15 minutes).

Dial-back Number	Users with <i>Dial-back</i> can dial into the SLC unit and enter their login and password. Once the SLC unit authenticates them, the modem hangs up and dials them back .
	Select the phone number the modem dials back on: a fixed number or a number associated with their login. If you select Fixed Number , enter the number (in the format 2123456789).
	The dial-back number is also used for CBCP client as the number for a user- defined number. See <i>CBCP Server and CBCP Client</i> for more information.
Dial-back Delay	For dial-back and CBCP Server, the number of seconds between the dial-in and dial-out portions of the dialing sequence.
Dial-back Retries	For dial-back and CBCP Server, the number of times the SLC unit will retry the dial-out portion of the dialing sequence if the first attempt to dial-out fails.
Timeout Logins	If you selected text mode, you can enable logins to time out after the connection is inactive for a specified number of minutes. The default is No . This setting only applies to text mode connections. PPP mode connections stay connected until either side drops the connection. Disabled by default.
Negotiate IP Address	If the SLC and/or the serial device have dynamic IP addresses (e.g., IP addresses assigned by a DHCP server), select Yes . This is the default.
	If the SLC unit or the modem have fixed IP addresses, select No , and enter the Local IP (IP address of the internal modem) and Remote IP (IP address of the modem).
Authentication	Enables PAP or CHAP authentication for modem logins. PAP is the default.
	With PAP , users are authenticated by means of the Local Users and any of the remote authentication methods that are enabled.
	With CHAP, the CHAP Handshake fields authenticate the user.
CHAP Handshake	The Host/User Name (for UNIX systems) or
CHAP Handshake	The Host/User Name (for UNIX systems) or Secret/User Password (for Windows systems) used for CHAP authentication. May have up to 128 characters.
CHAP Handshake CHAP Auth Uses	The Host/User Name (for UNIX systems) or Secret/User Password (for Windows systems) used for CHAP authentication. May have up to 128 characters. For CHAP authentication, determines what is used to validate the CHAP host/ user sent by the remote peer: either the CHAP Host defined for the modem, or any of the users in the Local Users list.
CHAP Handshake CHAP Auth Uses Enable NAT	The Host/User Name (for UNIX systems) or Secret/User Password (for Windows systems) used for CHAP authentication. May have up to 128 characters. For CHAP authentication, determines what is used to validate the CHAP host/ user sent by the remote peer: either the CHAP Host defined for the modem, or any of the users in the Local Users list. Select to enable Network Address Translation (NAT) for dial-in and dial-out PPP connections on a per modem (device port, USB port, or internal modem) basis. Users dialing into the SLC unit access the network connected to Eth1 and/or Eth2.
CHAP Handshake CHAP Auth Uses Enable NAT	The Host/User Name (for UNIX systems) or Secret/User Password (for Windows systems) used for CHAP authentication. May have up to 128 characters. For CHAP authentication, determines what is used to validate the CHAP host/ user sent by the remote peer: either the CHAP Host defined for the modem, or any of the users in the Local Users list. Select to enable Network Address Translation (NAT) for dial-in and dial-out PPP connections on a per modem (device port, USB port, or internal modem) basis. Users dialing into the SLC unit access the network connected to Eth1 and/or Eth2. Note: IP forwarding must be enabled on the Network Settings (on page 54) for NAT to work.
CHAP Handshake CHAP Auth Uses Enable NAT Dial-out Number	 The Host/User Name (for UNIX systems) or Secret/User Password (for Windows systems) used for CHAP authentication. May have up to 128 characters. For CHAP authentication, determines what is used to validate the CHAP host/ user sent by the remote peer: either the CHAP Host defined for the modem, or any of the users in the Local Users list. Select to enable Network Address Translation (NAT) for dial-in and dial-out PPP connections on a per modem (device port, USB port, or internal modem) basis. Users dialing into the SLC unit access the network connected to Eth1 and/or Eth2. Note: IP forwarding must be enabled on the Network Settings (on page 54) for NAT to work. Phone number for dialing out to a remote system or serial device. May have up to 20 characters. Any format is acceptable.
CHAP Handshake CHAP Auth Uses Enable NAT Dial-out Number Remote/Dial-out Login	 The Host/User Name (for UNIX systems) or Secret/User Password (for Windows systems) used for CHAP authentication. May have up to 128 characters. For CHAP authentication, determines what is used to validate the CHAP host/ user sent by the remote peer: either the CHAP Host defined for the modem, or any of the users in the Local Users list. Select to enable Network Address Translation (NAT) for dial-in and dial-out PPP connections on a per modem (device port, USB port, or internal modem) basis. Users dialing into the SLC unit access the network connected to Eth1 and/or Eth2. Note: IP forwarding must be enabled on the Network Settings (on page 54) for NAT to work. Phone number for dialing out to a remote system or serial device. May have up to 20 characters. Any format is acceptable. User ID for authentication when dialing out to a remote system, or if a remote system requests authentication from the SLC module when it dials in. May have up to 32 characters.
CHAP Handshake CHAP Auth Uses Enable NAT Dial-out Number Remote/Dial-out Login Remote/Dial-out Password/ Retype	 The Host/User Name (for UNIX systems) or Secret/User Password (for Windows systems) used for CHAP authentication. May have up to 128 characters. For CHAP authentication, determines what is used to validate the CHAP host/ user sent by the remote peer: either the CHAP Host defined for the modem, or any of the users in the Local Users list. Select to enable Network Address Translation (NAT) for dial-in and dial-out PPP connections on a per modem (device port, USB port, or internal modem) basis. Users dialing into the SLC unit access the network connected to Eth1 and/or Eth2. Note: IP forwarding must be enabled on the Network Settings (on page 54) for NAT to work. Phone number for dialing out to a remote system or serial device. May have up to 20 characters. Any format is acceptable. User ID for authentication when dialing out to a remote system, or if a remote system requests authentication from the SLC module when it dials in. May have up to 32 characters. Password for authentication when dialing out to a remote system, or if a remote system requests authentication from the SLC unit when it dials in. May have up to 20 characters.

6. Click Apply.

Internal Modem Commands

Go to *Internal Modem Commands* to view CLI commands which correspond to the web page entries described above.

Host Lists

A host list is a prioritized list of SSH, Telnet, and TCP hosts available for establishing incoming modem connections or for the connect direct command on the CLI. The SLC unit cycles through the list until it successfully connects to one.

To add a host list:

1. Click the **Devices** tab and select the **Host Lists** option. The following page displays:

Logout Logout Network Servi Device Status	Host: slc4 User: sys Ces User A Device Ports	SLC 804 331 admin uthentication Console Port	B LCD S Devices USB / SD C	U1 E1 1 U2 E2 2 Select port for Maintenanc ard RPMs	3 5 7 9 11 13 4 6 8 10 12 14 Configuration Quick Set Connections	15 17 19 21 2 16 18 20 22 2 WebSSH (D UP Host Lists	3 25 27 29 4 26 28 30 P only) 0 0 Scripts	31 33 35 3 32 34 36 3 Connected De Sites	7 39 41 4 8 40 42 4 evice (DP o	13 45 47 A 14 46 48 B only) € €
				Host Lis	sts					Help?
Id	Hos Name	at Lists			V	/iew Host List	Delete	Host List		
Host List I Host List Nam Retry Cour Authenticatio	d: 0 e: n:					ear Host List dd Host List dit Host List				
Host Parameters			<u>Hosts</u> (in	order of prec	edence)					
Hos Protoco Po Escape Sequenc Cle	at: d: TCP ▼ ft: e: ar Host Para	neters								

Figure 8-14 Devices > Host Lists

2. Enter the following:

Note: To clear fields in the lower part of the page, click the **Clear Host List** button.

Host List Id	Displays after a host list is saved.
Host List Name	Enter a name for the host list.
Retry Count	Enter the number of times the SLC advanced console manager should attempt to retry connecting to the host list.
Authentication	Select to require authentication when the SLC unit connects to a host.

- 3. You have the following options:
 - To save the host list without adding hosts at this time, click the **Add Host List** button.
 - To add hosts, enter the following:

Host Parameters

Host	Name or IP address of the host.
Protocol	Protocol for connecting to the host (TCP, SSH, or Telnet).
Port	Port on the host to connect to.
Escape Sequence	The escape character used to get the attention of the SSH or Telnet client. It is optional, and if not specified, Telnet and SSH use their default escape character.
	For Telnet, the escape character is either a single character or a two-character sequence consisting of '^' followed by one character. If the second character is '?', the DEL character is selected. Otherwise, the second character is converted to a control character and used as the escape character.
	For SSH, the escape character is a single character.
	Note: When the Device Port Esc Sequence/ViewLog/PowerMenu Escape Sequence is configured, the following escape sequence precedent behavior can be expected: 1) Escape 2) PowerMenu 3) ViewLogs A clear/restart of the remaining escape events occurs when there is a match in any configured sequence. All the sequences should have unique sequence defined and user should avoid overlapping sequence strings. When detecting key sequences, after receiving the first character(s) of a sequence, the SLC will wait 3 or more seconds for the remaining characters, before timing out and sending all characters to the device. For example, if the Escape Sequence is ABCD, and the user types "AB", the SLC will wait at least 3 seconds for the next character ("C") before timing out and sending the "AB" characters to the device.

- 4. Click the right 🗭 arrow. The host displays in the Hosts box.
- 5. Repeat steps 2-4 to add more hosts to the host list.
- 6. Click the Clear Host Parameters button to clear fields before adding the next host.
- 7. You have the following options:
 - To remove a host from the host list, select the host in the Hosts box and click the left 🗲 arrow.
 - To give the host a higher precedence, select the host in the Hosts box and click the up arrow.
 - To give the host a lower precedence, select the host in the Hosts box and click the down 🗲 arrow.
- Click the Add Host List button. After the process completes, a link back to the *Device Ports* > Settings (1 of 2) page displays.

To view or update a host list:

1. In the Host Lists table, select the host list and click the **View Host List** button. The list of hosts display in the Hosts box.

LOGOUT	Host: slc4 User: sysa	SLC 804	48 De	LCD SD U1 U2 Sele evices Mai	E1 1 3 E2 2 4 ect port for ntenance	3 5 7 9 11 1 4 6 8 10 12 1 • Configuration • Quick Se	3 15 17 19 21 2 4 16 18 20 22 2 WebSSH (D	3 25 27 29 3 4 26 28 30 3 P only) Ca	31 33 35 37 22 34 36 38 onnected Dev	39 4 40 4 rice (E	1 43 2 44 DP onl ?	45 47 46 48 y)	B
Device Status D	evice Ports	Console Por	t US	B / SD Card	RPMs	Connections	Host Lists	Scripts	Sites				_
				H	ost Lis	ts						Help	?
	Hos	t Lists											
Id	Name						View Host List	Delete I	Host List				
1	abc		۲										
Host List Id: Host List Name: Retry Count: Authentication:	1 abc 2			Hosto (in orde		C A E	lear Host List Add Host List Edit Host List						
Host Parameters				111.111.111.	111:tcp/2	2:				A			
Protocol: Protocol: Port: Escape Sequence: Clear	TCP	neters	•			-							

Figure 8-15 View Host Lists

2. View, add, or update the following:

Host List Id	Displays after a host list is saved.
Host List Name	Enter a name for the host list.
Retry Count	Enter the number of times the SLC 8000 advanced console manager should attempt to retry connecting to the host list.
Authentication	Select to require authentication when the SLC unit connects to a host.

Host Parameters

Host	Name or IP address of the host.
Protocol	Protocol for connecting to the host (TCP, SSH, or Telnet).
Port	Port on the host to connect to SLC advanced console manager
Escape Sequence	The escape character used to get the attention of the SSH or Telnet client. It is optional, and if not specified, Telnet and SSH use their default escape character.
	For Telnet, the escape character is either a single character or a two-character sequence consisting of '^' followed by one character. If the second character is '?', the DEL character is selected. Otherwise, the second character is converted to a control character and used as the escape character.
	For SSH, the escape character is a single character.

- 3. You have the following options:
 - To add a host to the host list, click the right 🖻 arrow. The host displays in the Hosts box.
 - To remove a host from the host list, select the host in the Hosts box and click the left arrow.
 - To give the host a higher precedence, select the host in the Hosts box and click the up 1 arrow.
 - To give the host a lower precedence, select the host in the Hosts box and click the down I arrow.
- Click the Edit Host List button. After the process completes, a link back to the Device Ports > Settings (1 of 2) page displays.

To delete a host list:

- 1. Select the host list in the Host Lists table.
- Click the Delete Host List button. After the process completes, a link back to the Device Ports > Settings (1 of 2) page displays.

Host List Commands

Go to *Host List Commands* to view CLI commands which correspond to the web page entries described above.

Scripts

The SLC unit supports two types of scripts:

- Interface Scripts which use a subset of the Expect/Tcl scripting language to perform pattern detection and action generation on Device Port output.
- Batch Scripts which are a series of CLI commands. A user can create scripts at the web, view scripts at the web and the CLI, and utilize scripts at the CLI. For a description of the syntax allowed in Interface Scripts, see Interface Script Syntax at the end of this page.

All scripts have permissions associated with them; a user who runs a script must have the permissions associated with the script in order to run the script.

To add a script:

1. Click the **Devices** tab and select the **Scripts** option. This page displays.

	r	-igure 8-16	Devices > 3	scrip	15	
	(* SLC 8048	LCD SD U1 U2	E1 1 3 5 7 9 E2 2 4 6 8 10	11 13 12 14	15 <mark>17 19 21 23 25 27 29 31 33 35</mark> 16 <mark>18 20 22 24 26 28 30 32 34 36</mark>	37 39 41 43 45 47 🔥 38 40 42 44 46 48 в
Logout	sysadmin	Sele	ct port for (Configu	uration	WebSSH (DP only) Connected	Device (DP only)
Network Services Us	er Authentication	Devices Mair	ntenance Quid	:k Setu	P	🕼 ? 🗗 🗉
Device Status Device Po	rts Console Port U	ISB / SD Card	RPMs Connec	tions	Host Lists Scripts Sites	
			-			Hole 2
			scripts			itely :
Add Script						
Edit Script					Scripts	
Rename Script		Name	Туре	Grp	Permissions	
New Name:						
Delete Script						
Change Permissions						
onunge i ennissions						
Group:	Default Users					
Croup.	Administrators					
Eull Administrativo:	-					
Notworking:						
Services:						
Secure Lantronix Network:						
Date/Time:						
Local Users:						
Remote Authentication:						
SSH Keys:						
User Menus:						
Web Access:						
Diagnostics & Reports:						
Reboot & Shutdown:						
Firmware & Configuration:						
Device Port Operations:						
Device Port Configuration:						
USB:						
Internal Modem:						
SD Card:						
RPMs:						

Figure 8-16 Devices > Scripts

2. Click the **Add Scripts** button. The page for editing script attributes displays.

Logout Host: User: Network Services Us	SLC 8040 sic4331 sysadmin er Authentication	8 LCD SD U1 V2 Sel Devices Mai	E1 1 3 4 E2 2 4 6 elect port for intenance	5 7 9 11 13 6 8 10 12 14 Configuration	15 17 19 21 2 16 18 20 22 2 WebSSH (Di	3 25 27 29 4 26 28 30 P only) C	31 33 35 32 34 36 Connected	37 39 4 38 40 4 Device (I	11 43 12 44 DP on ?	45 4 46 4 ly)	7 A 8 B
Device Status Device Po	rts Console Port	USB / SD Card	RPMs C	onnections	Host Lists	Scripts	Sites				
			Scripts							He	lp?
Script Name:											
Type: Interface	e 🖉 Batch										
Type. The interface	Butch										
										11	
S		U	Jser Rights								
	Default Users		.								
Group:	Power Users										
	Administrators										
Full Administrative:		Lo	ocal Users:		Firmware &	Configurat	tion: 🔲				
Networking:		Remote Auth	nentication:		In	iternal Mod	lem: 🔲				
Services:		\$	SSH Keys:		Device P	ort Operati	ons: 🔲				
Secure Lantronix Network:		Us	ser Menus:		Device Port	Configurat	tion: 🔲				
Date/Time:		We	eb Access:			L	JSB:				
Reboot & Shutdown:		Diagnostics	& Reports:			SD C	ard: 📃				
RPMs:											

Figure 8-17 Adding or Editing New Scripts

3. Enter the following:

Scripts

Script Name	A unique identifier for the script.
Туре	 Select Interface for a script that utilizes Expect/Tcl to perform pattern detection and action generation on Device Port output. Select Batch for a script of CLI commands.

4. In the User Rights section, select the user Group to which NIS users will belong:

User Rights

Group	Select the group to which the NIS users will belong:
	 Default Users: This group has only the most basic rights. You can specify additional rights for the individual user.
	 Power Users: This group has the same rights as Default Users plus Web Access, Networking, Date/Time, Reboot & Shutdown, and Diagnostics & Reports
	 Administrators: This group has all possible rights.

5. Assign or unassign **User Rights** for the specific user by checking or unchecking the following boxes:

Full Administrative	Right to add, update, and delete all editable fields.				
Networking	Right to enter Network settings.				
Services	Right to enable and disable system logging, SSH and Telnet logins, SNMP, and SMTP.				
Secure Lantronix Network	Right to view and manage secure Lantronix units (e.g., Spider, or SLC devices) on the local subnet.				
Date/Time	Right to set the date and time.				
Reboot & Shutdown	Right to shut down and reboot the SLC unit.				
Local Users	Right to add or delete local users on the system.				
Remote Authentication	Right to assign a remote user to a user group and assign a set of rights to the user.				
SSH Keys	Right to set SSH keys for authenticating users.				
User Menus	Right to create a custom user menu for the CLI.				
Web Access	Right to access Web-Manager.				
Diagnostics & Reports	Right to obtain diagnostic information and reports about the unit.				
Firmware & Configuration	Right to upgrade the firmware on the unit and save or restore a configuration (all settings). Selecting this option automatically selects Reboot & Shutdown.				
Internal Modem	Right to configure internal modem settings.				
Device Port Operations	Right to control device ports.				
Device Port Configuration	Right to enter device port configurations.				
USB	Right to enter modem settings for USB modems and to control USB storage devices.				
SD Card	Right to view and enter settings for SD card.				
RPM	Right to view and enter remote power manager settings.				

6. To save, click the **Apply** button. If the type of script is Interface, the script will be validated before it is saved. Once the script is saved, the main *Scripts* page is displayed.

To view or update a script:

- 1. In the Scripts table, select the script and click the **Edit Script** button. The page for editing script attributes displays (see *Figure 8-17*).
- 2. Update the script **attributes** (see *To add a script:* above).

3. To save, click the Apply button.

To rename a script:

- 1. In the Scripts table, select the script and enter a new script name in the New Name field.
- Click the Rename Script button. The script will be renamed and the Devices > Scripts page redisplays.

To delete a script:

- 1. In the Scripts table, select the script to delete.
- 2. Click the **Delete Script** button. After a confirmation, the script will be deleted and the *Devices > Scripts* page redisplays.

To change the permissions for a script:

- 1. In the Scripts table, select the script and select the new Group and/or Permissions.
- Click the Change Permissions button. The script updates and the Devices > Scripts page redisplays.

To use a script at the CLI:

- To run an Interface Script on a device port for pattern recognition and action generation, use the connect script <Script Name> deviceport <Device Port # or Name> command.
- 2. To run a Batch Script at the CLI with a series of CLI commands, use the set script runcli <Script Name> command.

CLI Commands

Go to *CLI Commands* to view CLI commands which correspond to the web page entries described above.

Batch Script Syntax

The syntax for Batch Scripts is exactly the same as the commands that can be typed at the CLI, with the additions described in this section.

The sleep command suspends execution of the script (puts it to 'sleep') for the specified number of seconds. Syntax:

```
sleep <value>
```

The while command allows a loop containing CLI commands to be executed. Syntax:

```
while {<Boolean expression>} {
    CLI command 1
    CLI command 2
    ...
    CLI command n
}
```

Note: The closing left brace '}' must be on a line without any other characters. To support a while command, the set command, variables, and secondary commands are also supported.

Interface Script Syntax

This section describes the abbreviated scripting syntax for Interface Scripts. This limited syntax was created to prevent the creation of scripts containing potentially harmful commands. Script commands are divided into three groups: Primary, Secondary and Control Flow. Primary commands provide the basic functionality of a script and are generally the first element on a line of a script, as in:

send user "Password:"

Secondary commands provide support for the primary commands and are generally not useful by themselves. For example, the expr command can be used to generate a value for a set command.

set <my var> [expr 1 + 1]

Control Flow commands allow conditional execution of other commands based on the results of the evaluation of a Boolean expression.

Term	Definition
Word	A contiguous group of characters delimited on either side by spaces. Not enclosed by double quotes.
Primary Command	One of the primary commands listed in this section.
Secondary Command	One of the secondary commands defined in this section.
Quoted String	A group of characters enclosed by double quote (") characters. A quoted string may include any characters, including space characters. If a double quote character is to be included in a quoted string it must be preceded (escaped) by a backslash character ('\').
Variable Reference	A word (as defined above) preceded by a dollar sign character ('\$').
CLI Command	A quoted string containing a valid CLI show command.
Arithmetic Operator	A single character representing a simple arithmetic operation. The character may be one of the following:
	 A plus sign (+) representing addition A minus sign (-) representing subtraction An asterisk sign (*) representing multiplication A forward slash (/) representing division A percent sign (%) representing a modulus
Boolean Expression	An expression which evaluates to TRUE or FALSE. A Boolean expression has the following syntax: <value> <boolean operator=""> <value> Each can be either a word or a variable reference.</value></boolean></value>
Boolean Operator	A binary operator which expresses a comparison between two operands and evaluates to TRUE or FALSE. The following Boolean operators are valid: • '<' less than • '>' greater than • '<=' less than or equal to • '>=' greater than or equal to • '==' equal to • '!=' not equal to

Table 8-18 Definitions

Primary Commands

These are stand-alone commands which provide the primary functionality in a script. These commands may rely on one or more of the Secondary Commands to provide values for some parameters. The preprocessor will require that these commands appear only as the first element of a command line. The start of a command line is delimited by any of the following:

- The start of a new line of text in the script
- A semicolon (';')
- A left brace ('{')

Command	Description
set	The set command assigns a value to a variable. Syntax:
	set <variable> <value></value></variable>
	where <variable> is a word, and <value> can be defined in one of the following</value></variable>
	ways:
	A quoted string
	 A word A variable reference
	 A value generated via one of the string secondary commands (compare, match, first, etc.)
	 A value generated via the expr secondary command
	 A value generated via the format secondary command
	 A value generated via the expr timestamp command
unset	This command removes the definition of a variable within a script. Syntax:
	unset <variable></variable>
	where <variable> is a word.</variable>
scan	The $scan$ command is analogous to the C language scanf(). Syntax:
	scan <variable> <format string=""> <value 1=""> <value 2=""> <value n=""></value></value></value></format></variable>
	<pre>where <variable> a variable reference, and <format string=""> is a quoted</format></variable></pre>
	string. Each of the <value x=""> elements will be a word.</value>
sleep	The ${\tt sleep}$ command suspends execution of the script (puts it to 'sleep') for the
	specified number of seconds. Syntax:
	sleep <value></value>
	where <value> can be a word, a quoted string or a variable reference.</value>
exec	The exec command executes a single CLI command. Currently only CLI 'show'
	commands may be executed via exec. Syntax:
	exec <cli command=""></cli>
send, send_user	The send command sends output to a sub-process, The send_user
	syntax:
	send <string></string>
	send_user <string></string>
	where <string> can be either a quoted string or a variable reference.</string>

Table 8-19 Primary Commands

Command	Description
expect, expect_user, expect_before, expect_after, expect_background	The expect command waits for input and attempts to match it against one or more patterns. If one of the patterns matches the input the corresponding (optional) command is executed. All expect commands have the same syntax:
	expect { <string 1=""> {command 1} <string 2=""> {command 2} <string n=""> {command n}}</string></string></string>
	where <string x=""> will either be a quoted string, a variable reference or the reserved word 'timeout.' The command x is optional, but the curly braces ('{' and '}') are required. If present it must be a primary command.</string>
return	The return command terminates execution of the script and returns an optional value to the calling environment. Syntax:
	return <value></value>
	where <value> can be a word or a variable reference.</value>

Secondary Commands

These are commands which provide data or other support to the Primary commands. These commands are never used by themselves in a script. The preprocessor will require that these commands always follow a left square bracket ('[') character and be followed on a single line by a right bracket (']').

Command	Description				
string	The string command provides a series of string manipulation operations. The string command will only be used with the set command to generate a value for a variable. There are nine operations provided by the string command. Syntax (varies by operation):				
	string compare <str 1=""> <str 2=""></str></str>				
	Compare two strings				
	string match <str 1=""> <str 2=""></str></str>				
	Determine if two strings are equal				
	<pre>string first <str needle=""> <str haystack=""></str></str></pre>				
	Find and return the index of the first occurrence of 'str_needle' in 'str_haystack'				
	string last <str needle=""> <str haystack=""></str></str>				
	Find and return the index of the last occurrence of 'str_needle' in 'str_haystack'				
	string length <str></str>				
	Return the length of 'str'				
	<pre>string index <str> <int></int></str></pre>				
	Return the character located at position 'int' in 'str'				
	string range <str> <int start=""> <int end=""></int></int></str>				
	Return a string consisting of the characters in 'str' between 'int start' and 'int end'				
	string tolower <str></str>				
	Convert <str> to lowercase</str>				
	string toupper <str></str>				
	Convert <str> to uppercase</str>				
	string trim <str 1=""> <str 2=""></str></str>				
	Trim 'str 2' from 'str 1'				
	string trimleft <str 1=""> <str 2=""></str></str>				
	Trim 'str 2' from the beginning of 'str 1'				
	string trimright <str 1=""> <str 2=""></str></str>				
	Trim 'str 2' from the end of 'str 1'				
	In each of the above operations, each <str *=""> element can either be a quoted string or a variable reference. The <int *=""> elements will be either words or variable references.</int></str>				

Table 8-20 Secondary Commands

Command	Description
expr	This command evaluates an arithmetic expression and returns the result. The expr command will only be used in combination with the set command to generate a value for a variable. Syntax:
	expr <value> <operation> <value></value></operation></value>
	Each <value> will be either a word or a variable reference, and <operation> an arithmetic operation.</operation></value>
timestamp	This command returns the current time of day as determined by the SLC. The timestamp command will only be used in combination with the set command to produce the value for a variable. Syntax: timestamp <format></format>
	where <format> is a quoted string.</format>
format	The format command is analogous to the C language sprintf(). The format command will only be used in combination with the set command to produce the value for a variable. Syntax:
	format <format string=""> <value 1=""> <value 2=""> <value n=""></value></value></value></format>
	where <format string=""> will be a quoted string. Each of the <value x=""> elements will be a word, a quoted string or a variable reference.</value></format>

Control Flow Commands

The control flow commands allow conditional execution of blocks of other commands. The preprocessor treats these as Primary commands, allowing them to appear anywhere in a script that a Primary command is appropriate.

Table 8-21 Control Flow Commands

Command	Description
while	The while command executes an associated block of commands as long as its Boolean expression evaluates to TRUE. After each iteration the Boolean expression is re-evaluated; when the Boolean expression evaluates to FALSE execution passes to the first command following the associated block. Each command within the block must be a Primary command. Syntax:
	while { <boolean expression="">} {</boolean>
	command 1
	command 2
	command n
	}

Command	Description				
if, elseif and else	The if command executes an associated block of commands if its Boolean expression evaluates to TRUE. Each command within the block must be a Primary command. Syntax:				
	if { <boolean expression="">} {</boolean>				
	command 1				
	command 2				
	command n				
	}				
	The elseif command is used in association with an if command - it must immediately follow an if or elseif command. It executes an associated block of commands if its Boolean expression evaluates to TRUE. Each command within the block must be a Primay command. Syntax:				
	elseif { <boolean expression="">} {</boolean>				
	command 1				
	command 2				
	command n				
	}				
	The else command is used in combination with an if or elseif command to provide a default path of execution. If the Boolean expressions for all preceding if and elseif commands evaluate to FALSE the associated block of commands is executed. Each command within the block must be a primary command. Syntax:				
	else {				
	command 1				
	command 2				
	command n				
	}				

Sample Scripts

Interface Script—Monitor Port

The Monitor Port (Monport) script connects directly to a device port by logging into the SLC port, gets the device hostname, loops a couple of times to get port interface statistics, and logs out. The following is the script:

```
set monPort 7
set monTime 5
set sleepTime 2
set prompt ">"
set login "sysadmin"
set pwd "PASS"
#Send CR to echo prompt
send "\r"
sleep $sleepTime
#Log in or check for Command Prompt
```

```
expect {
   #Did not capture "ogin" or Command Prompt
   timeout { send user "Time out login.....\r\n"; return }
   #Got login prompt
   "login" {
      send user "Logging in....\r\n"
      send "$login\r"
      expect {
         timeout { send user "Time out waiting for pwd
            prompt.....\r\n"; return }
         #Got password prompt
         "password" {
#Send Password
send "$pwd\r"
   expect {
            timeout { send user "Time out waiting for prompt.....\r\n";
               return }
            $prompt {}
            }
      }
   }
   }
   #Already Logged in got Command Prompt
   $prompt {
   send user "Already Logged....\r\n"
   }
}
#Get hostname info
send "show network port 1 host\r"
expect {
   timeout { send user "Time out Getting Hostname 1\r\n"; return }
   "Domain" {
      #Get Hostname from SLC
      set hostname "[string range $expect out(buffer) [string first
         Hostname:
      $expect out(buffer)] [expr [string first Domain
         $expect out(buffer)]-2]]"
   }
}
send user "\r\n\r\n\r\n\r\n"
send user "Device [string toupper $hostname]\r\n"
send user "
                                                                     \r\n"
send user "Monitored Port: Port $monPort \r\n"
send user "Monitor Interval Time: $monTime Seconds \r\n"
set loopCtr 0
set loopMax 2
while { $loopCtr < $loopMax } {</pre>
   #Get current time
```

The following is the screen output:

slc247glenn]> conn script ex4 deviceport 7 login: Logging in.... sysadmin Password: PASS Welcome to the Secure Lantronix Console Manager Model Number: SLC 48 For a list of commands, type 'help'. [SLC251glenn]> show network port 1 host show network port 1 host ____Current Hostname Settings Hostname: SLC251glenn Domain: support.int.lantronix.com [SLC251glen Device HOSTNAME: SLC 251GLENN

```
Monitored Port: Port 7
Monitor Interval Time: 5 Seconds
[Current Time:21:16:43]
show portcounter deviceport 7
n]> show portcounter deviceport 7
Device Port: 7 Seconds since zeroed: 1453619
Bytes input: 0 Bytes output: 0
Framing errors: 0 Flow control errors: 0
Overrun errors: 0 Parity errors: 0
[SLC251glenn]>
[Current Time:21:16:58]
show portcounter deviceport 7
show portcounter deviceport 7
Device Port: 7 Seconds since zeroed: 1453634
Bytes input: 0 Bytes output: 0
Framing errors: 0 Flow control errors: 0
Overrun errors: 0 Parity errors: 0
[SLC251glenn]>
Port Counter Monitor Script Ending.....
```

```
Login Out.....
logout
Returning to command line
[slc247glenn]>
```

Batch Script—SLC CLI

This script runs the following SLC CLI commands, then runs the Monport Interface script:

- show network port 1 host
- show deviceport names
- show script
- connect script monport deviceport 7

The following is the screen output of the script:

```
[slc247glenn]> se script runcli cli
[slc247glenn] > show network port 1 host
  Current Hostname Settings
Hostname: slc247glenn
Domain: <none>
[slc247glenn]>
[slc247glenn]> show deviceport names
Current Device Port Names
01 - SCS ALIAS Test 05 - Port-5
02 - Port-2 06 - Port-6
03 - Port-3 07 - SLC -251
04 - Port-4 08 - Port-8
[slc247glenn]>
[slc247glenn]> show script
Interface Scripts Group/Permissions
getSLC Adm/ad, nt, sv, dt, lu, ra, um, dp, pc, rp, rs, fc, dr, sn, wb, sk, po, do
Test Adm/ad, nt, sv, dt, lu, ra, um, dp, pc, rp, rs, fc, dr, sn, wb, sk, po, do
monport Adm/<none>
 Batch Scripts
                         Group/Permissions
cli Adm/ad, nt, sv, dt, lu, ra, um, dp, pc, rs, fc, dr, sn, wb, sk, po, do, rp
[slc247glenn]>
[slc247glenn] > connect script monport deviceport 7
login: Logging in....
sysadmin
sysadmin
Password: PASS
Welcome to the Secure Lantronix Console Manager
Model Number: SLC 48
For a list of commands, type 'help'.
[SLC251glenn] > show network port 1 host
show network port 1 host
  Current Hostname Settings
Hostname: SLC251glenn
Domain: support.int.
Device HOSTNAME: SLC 251GLENN
```

```
Monitored Port: Port 7
Monitor Interval Time: 5 Seconds
[Current Time:21:25:04]
show portcounter deviceport 7
lantronix.com
[SLC251glenn] > show portcounter deviceport 7
Device Port: 7 Seconds since zeroed: 1454120
Bytes input: 0 Bytes output: 0
Framing errors: 0 Flow control errors: 0
Overrun errors: 0 Parity errors: 0
[SLC251qlenn]>
[Current Time:21:25:20]
show portcounter deviceport 7
show portcounter deviceport 7
Device Port: 7 Seconds since zeroed: 1454136
Bytes input: 0 Bytes output: 0
```

```
Framing errors: 0 Flow control errors: 0
Overrun errors: 0 Parity errors: 0
[SLC251glenn]>
Port Counter Monitor Script Ending.....
```

```
Login Out.....

logout

Returning to command line

[slcvz249_glenn]> show script

___Interface Scripts____Group/Permissions_____

test3 Def/do

__Batch Scripts____Group/Permissions_____

test1 Adm/

ad,nt,sv,dt,lu,ra,um,dp,ub,rs,fc,dr,rp,sn,wb,sk,po,do

[slcvz249 glenn]>
```

Sites

A site is a group of site-oriented modem parameters that can be activated by various modemrelated events (authentication on dial-in, outbound network traffic for a dial-on-demand connection, etc.). The site parameters will override parameters that are configured for a modem.

To use sites with a modem, create one or more sites (described below), then enable **Use Sites** for the modem. Sites can be used with the following modem states: dial-in, dial-back, CBCP Server, dial-on-demand, dial-in & dial-on-demand, and dial-back & dial-on-demand. For more information on how sites are used with each modem state, see *Modem Dialing States on page 175*.

To add a site:

1. Click the **Devices** tab and select the **Sites** option. The Sites page displays:

		i igui e e			•				
	X [®] SLC 804	18 LCD SD U	11 E1 1 12 E2 2	3 5 7 9 11 13 1 4 6 8 10 12 14 1	5 17 19 21 2 6 18 20 22 2	3 25 27 29 4 26 28 30	31 33 35 32 34 36	37 39 41 38 40 42	1 43 45 47 A 2 44 46 48 B
User	r: sysadmin	5	elect port for	Configuration	WebSSH (DI	only)	Connected I	Device (D	P only)
Network Services U	Iser Authentication	Devices M	aintenanc	e Quick Setu	P			슙	? 🗗 🗉
Device Status Device F	Ports Console Port	USB / SD Card	RPMs	Connections	Host Lists	Scripts	Sites		
			Sites						Help?
ld Nan	Sites ne				View Site	Delete	e Site		
Site Id:	0			[Reset Site	Add	Site	Edit Site	
Site Name:									
Port:	None Internal Modem Device Port: USB Port U1 USB Port U2			Dial-o Dia Diabou	but Number: I-out Login: t Password:				
				Batura	Deserverd				
Login/CHAP Host:				Retype	e Password:				
CHAP Secret:		Retype:		Dial-ba	ick Number:				
Authentication:	PAP CHAP			Allov	v Dial-back:				
Timeout Logins:	No Yes:	minutes		Dial-	back Delay:	15	seconds		
Negotiato IR Address:	Yes Local	II IP:		Dial-ba	ack Retries:	3			
Negoliale IP Address.	No Remote	e IP:		Mode	m Timeout:	No	Yes:		seconds
Static Route IP Address:				Re	estart Delay:	30	second	s	
Static Route Subnet Mask:				Ci Allow N	BCP Server lo Callback:				
Static Route Gateway:				E	nable NAT:				

Figure 8-22 Devices > Sites

2. In the lower section of the page, enter the following:

Note: To clear fields in the lower part of the page, click the **Reset Site** button.

Site Id	Displays after a site is created.
(view only)	

Site Name	Enter a name for the site.					
Port	Select the port: None , Internal Modem , Device Port , USB Port U1 , or USB Port U2 the site is assigned to. For dial-on-demand sites, a port must be selected. For any other sites, the port selection can be set to None . See <i>Modem</i> <i>Dialing States on page 175</i> .					
Login/CHAP Host	The login name (for PAP authentication) or CHAP host (for CHAP authentication) associated with this site. If a modem has sites enabled and the authentication is successful at dial-in (for modem states dial-in, dial-back, CBCP server, dial-in & dial-on-demand, or dial-back & dial-on-demand), and the name that was authenticated matches the Login/CHAP Host, the site parameters will be used for the remainder of the modem connection.					
CHAP Secret/Retype	The CHAP secret associated with this site. If a modem has sites enabled and CHAP authentication enabled, then at dial-in, if the remote server sends a name in the CHAP challenge response that matches the CHAP host of a site, the CHAP secret for the site will be used to authenticate the CHAP challenge response sent by the remote server.					
Authentication	The type of authentication, PAP or CHAP , for which this site is applicable. On dial-in authentication, only sites with the authentication type that matches the authentication type configured for the modem will be used to try to find a matching site.					
Timeout Logins	For text dial-in connections, the connection can time out after the connection is inactive for a specified number of minutes.					
Negotiate IP Address	If the SLC advanced console manager and the remote server should negotiate the IP addresses for each side of the PPP connection, select Yes. Select No if the address of the SLC unit (Local IP) and remote server (Remote IP) need to be specified.					
Static Route IP Address	The Static Route IP Address, Subnet Mask and Gateway must be configured for dial-on-demand sites. The SLC 8000 advanced console manager will automatically dial-out and establish a PPP connection when IP traffic destined for the network specified by the static route needs to be sent.					
	Note: Static Routing must be enabled on the Network - Routing page for dial-on- demand connections.					
Static Route Subnet Mask	The subnet mask for a dial-on-demand connection.					
Static Route Gateway	The gateway for a dial-on-demand connection.					
Dial-out Number	The dial-out number must be specified for dial-on-demand sites. This indicates the phone number to dial when the SLC unit needs to send IP traffice for a dial-on-demand connection.					
Dial-out Login	User ID for authentication when dialing out to a remote system, or when a remote system requests authentication from the SLC 8000 unit when it dials in. May have up to 32 characters. This ID is used for authenticating the SLC 8000 advanced console manager during the dial-out portion of a dial-back (including CBCP server) and dial-on-demand.					
Dial-out Password	Password for authentication when dialing out to a remote system, or if a remote system requests authentication from the SLC unit when it dials in. May have up to 64 characters					
Retype Password	Re-enter password for dialing out to a remote system. May have up to 64 characters.					
Dial-back Number	The phone number to dial on callback for text or PPP dial-back connections. A					

Allow Dial-back	If enabled, the site is allowed to be used for dial-back connections.
Dial-back Delay	For dial-back and CBCP Server, the number of seconds between the dial-in and dial-out portions of the dialing sequence.
Dial-back Retries	For dial-back and CBCP Server, the number of times the SLC unit will retry the dial-out portion of the dialing sequence if the first attempt to dial-out fails.
Modem Timeout	Timeout for dial-in and dial-on-demand PPP connections. Select Yes (default) for the SLC 8000 advanced console manager to terminate the connection if no traffic is received during the configured idle time. Enter a value of from 1 to 9999 seconds. The default is 30 seconds.
Restart Delay	The number of seconds after the modem timeout and before the SLC unit attempts another connection. The default is 30 seconds.
CBCP Server Allow No Callback	For a CBCP Server site, allows "No Callback" as an option in the CBCP handshake in addition to User-defined Number and Admin-defined Number.
Enable NAT	Select to enable Network Address Translation (NAT) for PPP connections. Note: IP forwarding must be enabled on Network Settings (on page 54) for NAT to work.

3. Click the Add Site button.

To view or update a site:

- 1. In the **Sites** table, select the site and click the **View Site** button. The site attributes are displayed in the bottom half of the page.
- 2. Update any of the site attributes.
- 3. Click the **Edit Site** button.

To delete a site:

- 1. Select the site in the **Sites** table.
- 2. Click the Delete Site button.

Configures a set of site-oriented modem parameters that can be activated by various modemrelated events (authentication, outbound network traffic for DOD connections, etc.).

The site parameters will override any parameters configured for the modem.

Uses sites with a modem, enable 'usesites'. Sites can be used with the following modem states: dialin, dialback, cbcpserver, dialondemand, dialin+ondemand, and dialback+ondemand.

Site Commands

Go to *Site Commands* to view CLI commands which correspond to the web page entries described above.

Modem Dialing States

This section describes how each modem state that supports sites operates when sites are enabled.

Dial In

The SLC 8000 advanced console manager waits for a peer to call the SLC unit to establish a text (command line) or PPP connection.

 For text connections, the user will be prompted for a login and password, and will be authenticated via the currently enabled authentication methods (Local Users, NIS, LDAP, etc). The site list will be searched for a site that (a) the Login/CHAP Host matches the name that was authenticated, (b) Authentication is set to PAP, and (c) the Port is set to None or matches the port the modem is on.

If a matching site is found, the **Timeout Logins** parameter configured for the site will be used for the rest of the dial-in connection instead of the **Timeout Logins** parameter configured for the modem. Once authenticated, a CLI session will be initiated, and the user will remain connected to the SLC 8000 advanced console manager until they either logout of the CLI session, or (if **Timeout Logins** is enabled) the CLI session is terminated if it has been idle.

For PPP connections, the user will be authenticated via PAP or CHAP (determined by the Authentication setting for the modem). For PAP, the Local/Remote User list will be used to authenticate the login and password sent by the PPP peer, and the site list will be searched for a site that (a) the Login/CHAP Host matches the name that was authenticated, (b) Authentication is set to PAP, and (c) the Port is set to None or matches the port the modem is on. For CHAP, the site list will be searched for a site that (a) the Login/CHAP Host and CHAP Secret match the name and secret sent in the CHAP Challenge response by the PPP peer, (b) Authentication is set to CHAP, and (c) the Port is set to None or matches the port the modem is on. If the remote peer requests PAP or CHAP authentication from the SLC unit, the Remote/Dial-out Login and Remote/Dial-out Password configured for the modem (not the site) will be provided as authentication tokens.

If a matching site is found, its **Negotiate IP Address**, **NAT**, and **Modem Timeout** parameters will be used for the rest of the dial-in connection instead of the parameters configured for the modem. Once authenticated, a PPP session will be established using either negotiated IP addresses or specific IP addresses (determined by the **Negotiate IP Address** setting). The PPP connection will stay active until no IP traffic is sent for **Modem Timeout** seconds.

Dial-back

The SLC advanced console manager waits for a peer to call the SLC unit, establishes a text (command line) or PPP connection, authenticates the user, and if the SLC 8000 advanced console manager is able to determine a dial-back number to use, hangs up and calls the dial-back number to establish either a text or PPP connection.

 For text connections, the user will be prompted for a login and password, and will be authenticated via the currently enabled authentication methods (Local Users, NIS, LDAP, etc). The site list will be searched for a site that (a) the Login/CHAP Host matches the name that was authenticated, (b) Authentication is set to PAP, and (c) the Port is set to None or matches the port the modem is on.

If a matching site is found, its **Timeout Logins**, **Dial-back Number**, **Allow Dial-back**, and **Dial-back Delay** parameters will be used for the rest of the dial-back connection instead of the parameters configured for the modem. Once the remote server is authenticated, if **Allow Dial-back** is enabled for the site and a **Dial-back Number** is defined, the SLC unit will hang up and wait **Dial-back Delay** seconds before initiating the dial-back. The SLC 8000 advanced console manager will dial, prompt the user again for a login and password, and a CLI session

will be initiated. The user will remain connected to the SLC unit until they either logout of the CLI session, or (if **Timeout Logins** is enabled) the CLI session is terminated if it has been idle.

For PPP connections, the user will be authenticated via PAP or CHAP (determined by the Authentication setting for the modem). For PAP, the Local/Remote User list will be used to authenticate the login and password sent by the PPP peer, and the site list will be searched for a site that (a) the Login/CHAP Host matches the name that was authenticated, (b) Authentication is set to PAP, and (c) the **Port** is set to **None** or matches the port the modem is on. For CHAP, the site list will be searched for a site that (a) the Login/CHAP Host and CHAP Secret match the name and secret sent in the CHAP Challenge response by the PPP peer, (b) Authentication is set to CHAP, and (c) the Port is set to None or matches the port the modem is on. If the remote peer requests PAP or CHAP authentication from the SLC 8000 advanced console manager, the Remote/Dial-out Login and Remote/Dial-out Password configured for the modem (not the site) will be provided as authentication tokens. If a matching site is found, its Dial-back Number, Allow Dial-back, Dial-back Delay, Dialout Login, Dial-out Password, Negotiate IP Address, NAT, and Modem Timeout parameters will be used for the rest of the dial-back connection instead of the parameters configured for the modem. Once the remote server is authenticated, if Allow Dial-back is enabled for the site and a **Dial-back Number** is defined, the SLC unit will will hang up and wait Dial-back Delay seconds before initiating the dial-back. The SLC 8000 advanced console manager will dial, and if the remote peer requests PAP or CHAP authentication, provide the Dial-out Login and Dial-out Password as authentication tokens. Once authenticated, a PPP session will be established using either negotiated IP addresses or specific IP addresses (determined by the Negotiate IP Address setting).

Dial-on-demand

The SLC unit automatically dial outs and establishes a PPP connection when IP traffic destined for a remote network needs to be sent. It will remain connected until no data packets have been sent to the peer for a specified amount of time.

When this modem state is initiated, the SLC 8000 advanced console manager searches the site list for all sites that (a) have a **Dial-out Number** defined, (b) have a **Static Route IP Address**, **Static Route Subnet Mask** and **Static Route Gateway** defined, and (c) the **Port** matches the port the modem is on. A dial-on-demand connection will be started for each, waiting for IP traffic destined for a remote network.

When IP traffic needs to be sent, the SLC unit dials the appropriate **Dial-out Number** for the site, and if the remote peer requests PAP or CHAP authentication, provides the **Dial-out Login** and **Dial-out Password** as authentication tokens. Once authenticated, a PPP session will be established using either negotiated IP addresses or specific IP addresses (determined by the **Negotiate IP Address** setting). The PPP connection will stay active until no IP traffic is sent for **Modem Timeout** seconds. Once the timeout has expired, the PPP connection will be terminated and will not be reestablished for at least **Restart Delay** seconds.

Dial-in & Dial-on-demand

A modem is configured to be in two modes: answering incoming calls to establish a PPP connection, and automatically dialing out to establish a PPP connection when IP traffic destined for a remote network needs to be sent. When either event occurs (an incoming call or IP traffic destined for the remote network), the other mode will be disabled.

 For Dial-in, the user will be authenticated via PAP or CHAP (determined by the Authentication setting for the modem). For PAP, the Local/Remote User list will be used to authenticate the login and password sent by the PPP peer, and the site list will be searched for a site that (a) the Login/CHAP Host matches the name that was authenticated, (b) Authentication is set to PAP, and (c) the **Port** is set to **None** or matches the port the modem is on. For CHAP, the site list will be searched for a site that (a) the **Login/CHAP Host** and **CHAP Secret** match the name and secret sent in the CHAP Challenge response by the PPP peer, (b) **Authentication** is set to CHAP, and (c) the **Port** is set to **None** or matches the port the modem is on. If the remote peer requests PAP or CHAP authentication from the SLC advanced console manager, the **Remote/Dial-out Login** and **Remote/Dial-out Password** configured for the modem (not the site) will be provided as authentication tokens. If a matching site is found, its **Negotiate IP Address**, **NAT**, and **Modem Timeout** parameters will be used for the rest of the dial-in connection instead of the parameters configured for the modem. Once authenticated, a PPP session will be established using either negotiated IP addresses or specific IP addresses (determined by the **Negotiate IP Address** setting). The PPP connection will stay active until no IP traffic is sent for **Modem Timeout** seconds.

For Dial-on-Demand, the SLC unit searches the site list for all sites that (a) have a Dial-out Number defined, (b) have a Static Route IP Address, Static Route Subnet Mask and Static Route Gateway defined, and (c) the Port matches the port the modem is on. A dial-on-demand connection will be started for each, waiting for IP traffic destined for a remote network. When IP traffic needs to be sent, the SLC 8000 advanced console manager dials the appropriate Dial-out Number for the site, and if the remote peer requests PAP or CHAP authentication, provides the Dial-out Login and Dial-out Password as authentication tokens. Once authenticated, a PPP session will be established using either negotiated IP addresses or specific IP addresses (determined by the Negotiate IP Address setting). The PPP connection will stay active until no IP traffic is sent for Modem Timeout seconds. Once the timeout has expired, the PPP connection will be terminated and will not be reestablished for at least Restart Delay seconds.

Dial-back & Dial-on-demand

A modem is configured to be in two modes: answering incoming calls to initiate a dial-back, and automatically dialing out to establish a PPP connection when IP traffic destined for a remote network needs to be sent. When either event occurs (an incoming call or IP traffic destined for the remote network), the other mode will be disabled.

For Dial-back, the user will be authenticated via PAP or CHAP (determined by the Authentication setting for the modem). For PAP, the Local/Remote User list will be used to authenticate the login and password sent by the PPP peer, and the site list will be searched for a site that (a) the Login/CHAP Host matches the name that was authenticated, (b) Authentication is set to PAP, and (c) the Port is set to None or matches the port the modem is on. For CHAP, the site list will be searched for a site that (a) the Login/CHAP Host and CHAP Secret match the name and secret sent in the CHAP Challenge response by the PPP peer, (b) Authentication is set to CHAP, and (c) the Port is set to None or matches the port the modem is on. If the remote peer requests PAP or CHAP authentication from the SLC unit, the Remote/Dial-out Login and Remote/Dial-out Password configured for the modem (not the site) will be provided as authentication tokens.

If a matching site is found, its **Dial-back Number**, **Allow Dial-back**, **Dial-back Delay**, **Dial-out Login**, **Dial-out Password**, **Negotiate IP Address**, **NAT**, and **Modem Timeout** parameters will be used for the rest of the dial-back connection instead of the parameters configured for the modem. Once the remote server is authenticated, if **Allow Dial-back** is enabled for the site and a **Dial-back Number** is defined, the SLC 8000 advanced console manager will will hang up and wait **Dial-back Delay** seconds before initiating the dial-back. The SLC unit will dial, and if the remote peer requests PAP or CHAP authentication, provide the **Dial-out Login** and **Dial-out Password** as authentication tokens. Once authenticated, a PPP session will be established using either negotiated IP addresses or specific IP addresses (determined by the **Negotiate IP Address** setting).

For Dial-on-Demand, the SLC 8000 advanced console manager searches the site list for all sites that (a) have a Dial-out Number defined, (b) have a Static Route IP Address, Static Route Subnet Mask and Static Route Gateway defined, and (c) the Port matches the port the modem is on. A dial-on-demand connection will be started for each, waiting for IP traffic destined for a remote network.

When IP traffic needs to be sent, the SLC unit dials the appropriate **Dial-out Number** for the site, and if the remote peer requests PAP or CHAP authentication, provides the **Dial-out Login** and **Dial-out Password** as authentication tokens. Once authenticated, a PPP session will be established using either negotiated IP addresses or specific IP addresses (determined by the **Negotiate IP Address** setting). The PPP connection will stay active until no IP traffic is sent for **Modem Timeout** seconds. Once the timeout has expired, the PPP connection will be terminated and will not be reestablished for at least **Restart Delay** seconds.

CBCP Server and CBCP Client

Callback Control Protocl (CBCP) is a PPP option that negotiates the use of callback where the server, after authenticating the client, terminates the connection and calls the client back at a phone number that is determined by the CBCP handshake. For more information on CBCP, see http://technet.microsoft.com/en-us/library/cc957979.aspx. CBCP is used primarily by Microsoft PPP peers. CBCP supports two options for determining the number to dial on callback: the client can specify a user-defined number for the server to dial on callback, or the client can request the server use an administrator-defined number to dial on callback. Optionally, some servers may also allow "no callback" as an option.

CBCP Server

The SLC 8000 advanced console manager waits for a client to call the SLC unit, establishes a PPP connection, authenticates the user, and negotiates a dial-back number with the client using CBCP. If the SLC 8000 advanced console manager is able to determine a dial-back number to use, it hangs up and calls the dial-back number.

When a call is received, a PPP connection is established, and the user will be authenticated via PAP or CHAP (configured with the **Authentication** setting). For PAP, the Local/Remote list will be used to authenticate the login and password sent by the PPP peer. For CHAP, the CHAP Handshake Host/User Name and Secret/User Password will be used to authenticate CHAP Challenge response sent by the PPP peer. If the remote peer requests PAP or CHAP authentication from the SLC unit, the Remote/Dial-out Login and Remote/Dial-out Password will be provided as authentication tokens. Once authenticated, the CBCP handshake with the client determines the number to use for dial-back. The SLC unit will present the client with the available options: if the authenticated user is a Local/Remote User with Allow Dial-back enabled and a Dial-back Number defined, the administrator-defined option is allowed; if this is not the case, the user-defined number is allowed. Additionally, if CBCP Server Allow No Callback is enabled, the client can also select no callback (the PPP connection established at dial-in will remain up). The client will select from the available callback options. If the SLC unit can determine a dial-back number to use, it will hang up and wait Dial-back Delay seconds before initiating the dial-back (if the dial-back fails, the SLC will try Dial-back Retries times to dial-back). The SLC unit will call back the previously authenticated remote peer, and if the remote peer requests PAP or CHAP authentication, provide the Remote/Dial-out Login and Remote/Dial-out Password as authentication tokens. Once authenticated, a PPP session will be established using either negotiated IP addresses or specific IP addresses (determined by the Negotiate IP Address setting).

CBCP Client

The SLC unit will dial out to a CBCP server, establish a PPP connection, negotiate a callback number with the server using CBCP, terminate the connection, and wait for the server to call back. The SLC unit dials the **Dial-out Number**, and if the remote peer requests PAP or CHAP authentication, provides the Remote/Dial-out Login and Remote/Dial-out Password as authentication tokens. Once authenticated, the CBCP handshake with the server determines the number to use for dial-back. The SLC device will request the type of number defined by CBCP **Client Type** - either an Admin-defined Number (the CBCP server determines the number to call) or a User-defined Number (the SLC unit will provide the Fixed Dial-back Number as the number to call). If the CBCP handshake is successful, the SLC unit will terminate the PPP connection, hang up, and wait for the server to dial back. When the remote server calls back the SLC unit and the PPP connection is established, the user will be authenticated via PAP or CHAP (configured with the Authentication setting). For PAP, the Local/Remote list will be used to authenticate the login and password sent by the PPP peer. For CHAP, the CHAP Handshake Host/User Name and Secret/User Password will be used to authenticate CHAP Challenge response sent by the PPP peer. Once authenticated, a PPP session will be established using either negotiated IP addresses or specific IP addresses (determined by the Negotiate IP Address setting).

Notes:

- In a state where the modem will be answering a call, the modem should always be configured for manual answer, not auto answer.
- When answering a call, the SLC unit answers after the 2nd ring.
- Any text or PPP connection can be terminated by setting the modem state to disabled.

Key Sequences

The default values for the various key sequences (Escape Sequence, Break Sequence, View Port Log Sequence, Power Menu Sequence) are set to different key sequences, and it is recommended that they always be set to different key sequences so that the SLC can properly handle each of the functions accessed by the key sequence while connected to a device.

For example, if the View Port Log Sequence is set to the same sequence as the Power Menu Sequence, and this sequence is typed while connected to a device port, both the Power Menu and the option to display Port Log will be displayed, with the Power Menu taking precedence and processing user input.

If any of the key sequences are set to the same value, the precedence used to process the key sequences is:

- Escape Sequence
- Power Management Sequence
- View Port Log Sequence

It is also recommended that the key sequences not share a significant amount of overlap other than the first character. For example, if the View Port Log Sequence is set to **ABCD** and the Power Management Sequence is set to **ABCE**, the first three characters of both sequences are the same - this is not recommended.

When any portion of key sequences overlap, typing a complete escape sequence for one of the sequences will reset recognition of the other sequences back to the beginning of the key sequence. For example, with the default View Port Log sequence of **ESC-V** and the default Power Management sequence of **ESC-P**, if the user types "ESC-V" and views the port log and then

returns to interacting with the device, they need to type "ESC-P" to view the Power Menu, and not just "P".

When detecting key sequences, after receiving the first character(s) of a sequence, the SLC will wait 3 or more seconds for the remaining characters, before timing out and sending all characters to the device. For example, if the Escape Sequence is **ABCD**, and the user types "AB", the SLC will wait at least 3 seconds for the next character ("C") before timing out and sending the "AB" characters to the device.
9: USB/SD Card Port

This chapter describes how to configure storage by using the *Devices* > *USB / SD Card* page and CLI. This page can be used to configure the thumb drive and modems. The thumb drive or SD card is useful for firmware updates, saving and restoring configurations and for device port logging. See *Firmware & Configurations (on page 252)*.

The SLC advanced console manager supports a variety of thumb drives.

This chapter describes the Web Manager pages and available CLI commands that configure the SLC USB, ports and SD card. This chapter contains the following sections:

- Set Up of USB/SD Card Storage
- Manage Files
- USB Commands

Set Up of USB/SD Card Storage

The *Devices* > *USB / SD Card* page has a checkbox for both USB Access and SD card access. These checkboxes are a security feature to ensure that access to any USB device or the SD card is disabled if the box is unchecked. If unchecked, the SLC unit ignores any device plugged into the port.

To set up USB or SD card storage in the SLC 8000 advanced console manager:

- Insert any of the supported storage devices into the USB port or the SD card slot on the front of the SLC unit. You can do this before or after powering up the SLC 8000 advanced console manager. If the first partition on the storage device is formatted with a file system supported by the SLC unit (ext2, FAT16 and FAT32), the card mounts automatically.
- 2. Log into the SLC unit and click **Devices**.
- Click USB / SD Card. Figure 9-1 shows the page that displays. Your storage device should display in the appropriate row of the USB ports / SD card table if you have inserted it. If is does not display and you have inserted it, refresh the web page.
- 4. View the USB/SD card information and options available on the page:

Port (view only)	Port on the SLC unit where the USB device or SD card is inserted.
Device (view only)	Type of USB device or SD card (modem or storage).
Type (view only)	Information read from USB device or SD card.
State (view only)	Indicates if the device is mounted, and if mounted, how much space is available.
USB Access (check box)	Check to enable USB Access . Uncheck to disable USB access.
SD Card Access (check box)	Check to enable SD Card Access . Uncheck to disable SD card access.

Logout Bit: slc48250120-740B4 User: sysadmin Logout E1 1 3 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 35 37 39 41 43 45 47 A B Host: slc48250120-740B4 User: sysadmin Select port for © Configuration WebSSH (DP only) Connected Device (DP only) Connected Device (DP only)										
Network	Services	User A	uthentication	Devices	Maintenance	Quick Set	tup		公	? 🗗 🗉
Device St	tatus Devi	ce Ports	Console Port	USB / SD C	Card Internal I	Modem RP	Ms Connections	Host Lists	Scripts	Sites
					USB / SD C	Card				Help?

Figure 9-1 Devices > USB / SD Card

USB Devices USB Ports / SD Card Configure If a USB device or SD Card has been inserted but Port Device Type State is not visible in the table, U1 modem U.S. Robotics inserted \bigcirc please refresh the web page. fat32, mounted, Size/Used/Avail Chipsbank Microelectronics Co., Ltd To configure the settings for a U2 storage \bigcirc CBM2080 Flash drive controller 31.2M/122.0K/31.1M USB device or SD Card, select the radio button ext2, mounted, Size/Used/Avail 234.0M/2.2M/219.7M SD 256MB storage 0 in the right column.

USB Access: 🗹 SD Card Access: 🗹

Apply

To configure a USB/SD card storage port, from the USB Ports / SD Card table,

- 1. Click the radio button (on the far right) of a USB or SD card device storage port.
- 2. Click Configure.
 - Figure 9-2 shows the page that displays if a USB storage device is inserted.
 - *Figure 9-3* shows the page that displays if an SD Card is inserted.

Figure 9-2 Devices > SD Card > Configure

	Host: sic4: User: sysa	SLC 804	8 LCD SD	U1 E1 1 U2 E2 2 Select port for	3 5 7 9 11 13 4 6 8 10 12 14	15 17 19 21 23 16 18 20 22 24 WebSSH (DP	25 27 29 31 3 26 28 30 32 3 only) Conne	3 35 37 39 4 4 36 38 40 4 ected Device (I	1 43 4 2 44 4 DP only)	5 47 A 6 48 B
Network Serv	ices User A	uthentication	Devices	Maintenanc	e Quick Set	up		奋	Υt	
Device Status	Device Ports	Console Port	USB / SD Car	rd RPMs	Connections	Host Lists	Scripts Sit	es		
			USB / S	SD Card	- Storage					Help ?
Port	SD					Мог	unt:			
Device:	Storage					Unmou	unt: 📃			
Туре:	256MB					Form	nat: 📃			
State:	ext2, mounted	, Size/Used/Ava	il 234.0M/2.2M/	219.7M		Filesyste	em: 💿 Ext2	FAT16	● FA	T32
					F	ilesystem Che	eck:			
						Manage Fil	es on Storage	e Device >		
				Apply						

Logout Host: slc4331 User: sysadmin	8 LCD SD U1 E1 1 3 U2 E2 2 4 Select port for	3 5 7 9 11 13 15 17 19 21 23 4 6 8 10 12 14 16 18 20 22 24 Configuration WebSSH (DP or example)	25 27 29 31 33 35 37 39 41 43 45 47 A 26 28 30 32 34 36 38 40 42 44 46 B conly) Connected Device (DP only) Connected Device (DP only) A B
Network Services User Authentication	Devices Maintenance	e Quick Setup	☆? 다 🗉
Device Status Device Ports Console Port	USB / SD Card RPMs	Connections Host Lists	Scripts Sites
	USB / SD Card	- Storage	Help?
Port: U1		Mour	nt:
Device: Storage		Unmour	nt:
Type: Toshiba Corp. Kingston Data	Traveler 2.0 Stick (2GB)	Forma	at:
State: fat32, mounted, Size/Used/Ava	ail 14.4G/167.7M/14.3G	Filesyster	m: • Ext2 FAT16 FAT32
		Filesystem Chec	k: 🔲
		<u>Manage File</u>	s on Storage Device >
	Apply		

Figure 9-3 Devices > USB > Configure

3. Enter the following fields.

Mount	Select the checkbox to mount the first partition of the storage device on the SLC unit (if not currently mounted). Once mounted, a USB thumb drive or SD card is used for firmware updates, device port logging and saving/restoring configurations.
Unmount	To eject the USB thumb drive or SD card from the SLC unit , first unmount the thumb drive or SD card . Select the checkbox to unmount it.
	<i>Warning:</i> If you eject a thumb drive or SD card from the SLC unit without unmounting it, subsequent mounts of a USB thumb drive or SD card in may fail, and you will need to reboot the device to restore thumb drive or SD card functionality.
Format	Select to:
	 Unmount the USB/SD card device (if it is mounted) Remove all existing partitions Create one partition Format it with the selected file system (ext2, FAT16 or FAT32) Mount the USB device
Filesystem	Select Ext2, FAT16 or FAT32, the filesystems the SLC supports.
Filesystem Check	Select to run a filesystem integrity check on the thumb drive. This is recommended if the filesystem does not mount or if the filesystem has errors.

- 4. Click Apply.
- 5. Click the **Manage Files on Storage Device** link to view and manage files on the selected USB thumb drive or SD Card. Files on the storage device may then be deleted, downloaded or renamed. See *Manage Files on page 188* for more information.

To configure the USB Modem port, from the USB Ports table:

- 1. Click the radio button (on the far right) for Port U1 or U2.
- 2. Click **Configure**. *Figure* 9-4 shows the page that displays if a USB modem is inserted in Port U1, or if Port U2 is selected.

Logout Host: slc4331 User: sysadmin	48 U1 E1 1 3 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 35 37 39 41 LCD SD U2 E2 2 4 6 8 10 12 14 16 18 20 22 24 26 28 30 32 34 36 38 40 42 4 Select port for © Configuration WebSSH (DP only) © Connected Device (DP only) © Connected Device (DP only) © Connected Device (DP only) © Connected Device (DP only) © Connected Device (DP only) © Connected Device (DP only) © Connected Device (DP only) © Connected Device (DP only) © Connected Device (DP only) Connected D	13 45 47 A 14 46 48 B only)
Network Services User Authentication	Devices Maintenance Quick Setup	부트
Device Status Device Ports Console Por	t USB / SD Card RPMs Connections Host Lists Scripts Sites	
	USB - Modem	Help?
Dort: 114	State: Diel in	dom Le - V
Device: Modem	State. Diarin ▼ <u>View Mo</u>	uem Log /
Type: Hitachi I td	Mode: IEXT O PPP PPP Log	iging: 🔽
stato: N/A	Use Sites: PPP De	edug: 🔽
State. N/A	Group Access:	
	Initialization Script: ATE1V1x4Q0M0	
Data Settings	Modem Limeout: No Yes, seconds (1-9999):	
Baud: 115200 ▼ Data Bits: 8 ▼	Local User Number	
Parity: none •	Dial-back Number:	
Stop Bits: 1 -	Dial-back Delay: 15 seconds	
Flow Control: rts/cts -	Dial-back Retries: 3	
	Text Mode	
	Dialin Host List Jundefined Ves, minutes (1-30):	
	PPP Mode	
	Nogotiato IP Addross: O Yes Local IP: 12.1.1.1	
	No Remote IP: 12.1.1.2	
	Authentication:	
	Host/User Name:	
	CHAP Handshake: Secret/User Password:	
	CHAP Auth Uses: CHAP Host	
	Same authentication	
	for Dial-in & Dial-on-Demand (DOD):	
	Host/Liser Name	
	DOD CHAP Handshake: Secret/User Password:	
	Retype Password:	
	Enable NAT: Note: Enabling NAT requires IP Forwarding to be	enabled.
	Dial-out Number:	
	Remote/Dial-out Login:	
	Remote/Dial-out Pwd: Retype:	
	Restart Delay: 30 seconds	
	Allow No Callback:	
	CBCP Client Type: CBCP Client T	nber
	Service: None Telnet SSH TCP	
	Telnet Port: 2049 Authenticate: 📝	
	SSH Port: 3049 Authenticate: 🗹	
	TCP Port: 4049 Authenticate:	
	Apply	

Figure 9-4 Devices > USB > Modem

3. Enter the following fields.

Data Settings

Note: Check the modem's equipment settings and documentation for the proper settings. The attached modem must have the same settings.

Baud	The speed with which the device port exchanges data with the attached serial device.
	From the drop-down list, select the baud rate. Most devices use 9600 for the administration port, so the device port defaults to this value. Check the equipment settings and documentation for the proper baud rate.
	<i>Note:</i> Cypress ACM-based USB to serial chip set does not support 230400 baud rate.
Data Bits	Number of data bits used to transmit a character. From the drop-down list, select the number of data bits. The default is ${\bf 8}$ data bits.
Parity	Parity checking is a rudimentary method of detecting simple, single-bit errors. From the drop-down list, select the parity. The default is none .
Stop Bits	The number of stop bit(s) used to indicate that a byte of data has been transmitted. From the drop-down list, select the number of stop bits. The default is 1 .
Flow Control	A method of preventing buffer overflow and loss of data. The available methods include none, xon/xoff (software), and rts/cts (hardware). The default is none .

Modem Settings

Note: Depending on the **State** and **Mode** you select, different fields are available.

State	Indicates whether an external modem is attached to the device port. If enabling, set the modem to dial-out, dial-in, dial-back, dial-on-demand, dial-in/host list, or dial in, dial-on-demand, CBCP Server, and CBCP Client. Disabled by default. See <i>Modem Dialing States (on page 175)</i> for more information.
Mode	 The format in which the data flows back and forth: Text: In this mode, the SLC unit assumes that the modem will be used for remotely logging into the command line. Text mode can only be used for dialing in or dialing back. Text is the default. PPP: This mode establishes an IP-based link over the modem. PPP connections can be used in dial-out mode (e.g., the SLC 8000 advanced console manager connects to an external network), dial-in mode (e.g., the external computer connects to the network that the SLC unit is part of), or dial-on-demand.
Use Sites	Enables the use of site-oriented modem parameters which can be activated by various modem-related events (authentication, outbound network traffic for dial-on-demand connections, etc.). Sites can be used with the following modem states: dial-in, dial-back, dial-on-demand, dial-in & dial-on-demand, dial-back & dial-on-demand, and CBCP server.

Group Access	If undefined, any group can access the modem (text login only). If one or more groups are specified (groups are delimited by the characters ' ' (space), ',' (comma), or ',' (semicolon)), then any user who logs into the modem must be a member of one of the specified groups, otherwise access will be denied. Users authenticated via RADIUS may have a group (or groups) provided by the RADIUS server via the Filter-Id attribute that overrides the group defined for a user on the SLC 8000 advanced console manager. A group provided by the characters ' ' (space), ',' (comma), ';' (semicolon), or '=' (equals) - for example "group=group1,group2;" or "group1,group2,group3".
Initialization Script	Commands sent to configure the modem may have up to 100 characters. Consult your modem's documentation for recommended initialization options. If you do not specify an initialization script, the SLC unit uses a default initialization string of AT S7=45 SO=0 L1 V1 X4 &D2 &C1 E1 Q0. <i>Note:</i> We recommend that the modem initialization script always be preceded with AT and include E1 V1 x4 Q0 so that the SLC unit may properly control the modem.
Modem Timeout	Timeout for all modem connections. Select Yes (default) for the SLC 8000 advanced console manager to terminate the connection if no traffic is received during the configured idle time. Enter a value of from 1 to 9999 seconds. The default is 30 seconds.
Caller ID Logging	Select to enable the SLC unit to log caller IDs on incoming calls. Disabled by default. <i>Note:</i> For the Caller ID AT command, refer to the modem user guide.
Modem Command	Modem AT command used to initiate caller ID logging by the modem.
	<i>Note:</i> For the AT command, refer to the modem user guide.
Dial-back Number	Users with dial-back access can dial into the SLC 8000 advanced console manager and enter their login and password. Once the SLC unit authenticates them, the modem hangs up and dials them back.
	Select the phone number the modem dials back on -a fixed number or a number associated with their login. If you select Fixed Number , enter the number (in the format 2123456789).
	The dial-back number is also used for CBCP client as the number for a user- defined number. See <i>Device Ports - Settings (on page 128)</i> for more information.
Dial-back Delay	For dial-back and CBCP Server, the number of seconds between the dial-in and dial-out portions of the dialing sequence.
Dial-back Retries	Specify the number of times to retry dialing back.

Text Mode

Timeout Logins	If you selected Text mode, you can enable logins to time out after the connection is inactive for a specified number of minutes. The default is No . This setting is only applicable for text mode connections. PPP mode connections stay connected until either side drops the connection. Disabled by default.
Dial-in Host List	From the drop-down list, select the desired host list. The host list is a prioritized list of SSH, Telnet, and TCP hosts that are available for establishing outgoing modem connections or for connect direct at the CLI. The hosts in the list are cycled through until the SLC unit successfully connects to one. To establish and configure host lists, click the Host Lists link.

PPP Mode

Negotiate IP Address	If the SLC unit and/or the serial device have dynamic IP addresses (e.g., IP addresses assigned by a DHCP server), select Yes . Yes is the default. If the SLC unit or the modem have fixed IP addresses, select No , and enter the Local IP (IP address of the port) and Remote IP (IP address of the modem).
Authentication	Enables PAP or CHAP authentication for modem logins. PAP is the default. With PAP, users are authenticated by means of the Local Users and any of the remote authentication methods that are enabled. With CHAP, the CHAP Handshake fields authenticate the user.
CHAP Handshake	The Host/User Name (for UNIX systems) or Secret/User Password (for Windows systems) used for CHAP authentication. May have up to 128 characters.
CHAP Auth Uses	For CHAP authentication, determines what is used to validate the CHAP Host and Chap Local host/user sent by the remote peer: either the CHAP Host defined for the modem, or any of the users in the Local Users list.
Same authentication for Dial-in & Dial-on-Demand (DOD)	Select this option to let incoming connections (dial-in) use the same authentication settings as outgoing connections (dial-on-demand). If this option is not selected, then the dial-on-demand connections take their authentication settings from the DOD parameter settings. If DOD Authentication is PAP , then the DOD CHAP Handshake field is not used.
DOD Authentication	Enables PAP or CHAP authentication for dial-in & dial-on-demand. PAP is the default. With PAP, users are authenticated by means of the Local Users and any of the remote authentication methods that are enabled. With CHAP, the DOD CHAP Handshake fields authenticate the user.
DOD CHAP Handshake	For DOD Authentication , enter the Host/User Name for UNIX systems) or Secret/User Password (for Windows systems) used for CHAP authentication. May have up to 128 characters.
Enable NAT	Select to enable Network Address Translation (NAT) for dial-in and dial-out PPP connections on a per modem (device port or USB port) basis. Users dialing into the SLC access the network connected to Eth1 and/or Eth2.
	Note: IP forwarding must be enabled on the Network > Network Settings page for NAT to work. See Chapter 6: Basic Parameters on page 66.
Dial-out Number	Phone number for dialing out to a remote system or serial device. May have up to 20 characters. Any format is acceptable.
Remote/Dial-out Login	User ID for authentication when dialing out to a remote system, or if a remote system requests authentication from the SLC device when it dials in. May have up to 32 characters. This ID is used for authenticating the SLC unit during the dial-out portion of a dial-back (including CBCP server) and dial-on-demand.
Remote/Dial-out Pwd	Password for authentication when dialing out to a remote system, or if a remote system requests authentication from the SLC unit when it dials in. May have up to 64 characters.
Retype	Re-enter password for dialing out to a remote system. May have up to 64 characters.
Restart Delay	The number of seconds after the timeout and before the SLC 8000 advanced console manager attempts another connection. The default is 30 seconds.
CBCP Server Allow No Callback	For CBCP Server state, allows "No Callback" as an option in the CBCP handshake in addition to User-defined Number and Admin-defined Number.
CBCP Client Type	For CBCP Client, this selects the number that the client would like to use for callback - either a user-defined number passed to the server (specified by the Fixed Dial-back Number) or an administrator-defined number determined by the server based on the login that is PAP or CHAP authenticated.

IP Settings

Service	The available connection services for this modem port (None , Telnet , SSH , or TCP). Only one can be active at a time. The default is None .
Telnet Port	 Telnet Port Telnet session port number to use if you selected Telnet. Defaults: USB Port U1: 2049 USB Port U2: 2050 Range: 1025-65535
SSH Port	 The SSH session port number to use if you selected SSH. Defaults: USB Port U1: 3049 USB Port U2: 3050 Range: 1025-65535
TCP Port	 The TCP (raw) session port number to use if you selected TCP. Defaults: USB Port U1: 4049 USB Port U2: 4050 Range: 1025-65535
Authenticate (checkbox)	If selected, the SLC unit requires user authentication before granting access to the port. Authenticate is selected by default for Telnet Port and SSH Port , but not for TCP Port .

4. Click Apply.

Manage Files

To manage files, perform the following steps.

1. Click the Manage Files on the Storage Device link on the *Devices > USB > Configure* page.

rigule 3-3 Tilliwale and Configurations - Manage File	Figure 9-5	Firmware and	Configurations -	Manage Fil	es
---	------------	---------------------	------------------	------------	----

LAN	TROM	↓ X° SLC 804	8 LCD SD	U1 <mark>E1</mark> 1 3 5 U2 <mark>E2</mark> 2 4 6	5 7 9 11 13 1 5 8 10 12 14 1	<mark>5</mark> 17 19 21 23 6 18 20 22 24	3 25 27 29 31 4 26 28 30 32	33 35 37 39 4 [,] 34 36 38 40 4,	1 43 45 47 A 2 44 46 48 B
Logo	ut	lost: slc4331 Jser: sysadmin		Select port for (Configuration	WebSSH (DF	only) 🔵 Con	nected Device (D	P only)
Network	Services	User Authentication	Devices	Maintenance	Quick Setup			岱	? 🔂 🗉
Device St	tatus Devid	e Ports Console Port	USB / SD Ca	ard RPMs C	onnections	Host Lists	Scripts S	ites	

Firmware & Configurations - Manage Files

Help?

Files - USB Port U1					
Name	Date/Time Saved	SSH Keys	SSL Certificate	Scripts	
slccpy-slccfg.tgz	04/13/16 23:43:18	N	N	Ν	
apassslc48Ref-120- slccfg.tgz	04/14/16 08:55:08	Y	Y	Y	
slcRef48120_73R5- slccfg.tgz	04/14/16 09:04:32	Y	Y	Y	
SLC-UPDATE- 7.2.0.0R20.rom	06/25/15 07:33:58	N/A	N/A	N/A	
rootfs.ubifs	06/25/15 07:11:08	N/A	N/A	N/A	

Sack to USB / SD Card - Storage

Note: The Delete, Download, and Rename options are at the bottom of the page (Figure 9-5).

- 2. To delete a file, click the check box next to the filename and click **Delete File**. A confirmation message displays.
- 3. To download a file, click the Download File button. Select the file from the list.
- 4. To rename a file, click the check box next to the filename and enter a new name in the **New File Name** field.
- 5. Click Rename File.

USB Commands

Go to *USB Access Commands*, USB Device Commands, USB Storage Commands, and USB Modem Commands to view CLI commands which correspond to the web page entries described above.

SD Card Commands

Go to *SD Card Commands* to view CLI commands which correspond to the web page entries described above.

10: Remote Power Managers

The SLC supports managing remote power managers (RPMs) for devices from over 140 vendors. The RPMs can be either PDUs or UPSes, and can be managed via SNMP, serial port, network and USB connections. The RPMs web page displays a list of all currently managed RPMs with an overview of their current status, with options to control and view detailed status for each RPM, depending on its supported capabilities.

Network and SNMP managed RPMs are disabled in FIPS mode. The only action that can be performed on a network or SNMP managed RPM in FIPS mode is that it can be deleted via the CLI.

For notes on optimizing the management of specific devices, see *Optimizing and Troubleshooting RPM Behavior (on page 202)*.

Devices - RPMs

To control or view status for an RPM:

1. Click the **Devices** tab and select the **RPMs** option. The RPMs page displays.

		lost: slc4	SLC 804 331 admin	B LCD SI	U1 MD E1 1 3 U2 E2 2 4 Select port for	5 7 9 6 8 10 Configu	11 13 15 12 14 16 ration	17 19 21 23 25 2 18 20 22 24 26 2 VebSSH (DP only)	27 29 31 33 35 28 30 32 34 36 Connected	37 39 41 38 40 42 Device (DP c	13 45 47 A 14 46 48 B only)
Network	Services	User A	uthentication	Devices	Maintenance	Quic	k Setup			岱?	₿ 🗉
Device St	tatus Devic	e Ports	Console Port	USB / SD Ca	ard Internal M	lodem	RPMs	Connections	Host Lists	Scripts	Sites
					RPMs						Help?

Figure 10-1 Devices > RPMs

	////	enataenni erae		ounouno	110 / 11	and batta	Logo,			manag		00000
RPM	s: 3 device(s)		B	eeper:	Enable	Mute	Disab	le Devi	ce: Reb	ooot S	hutdown	Delete
ld	Name	Managed Via	Туре	Outlet #, On	Input (V)	Power (VA)	Power (W)	Battery (%)	Load (%)	Beeper	Status	
1	SLP16snmp	SNMP-172.19.237.30	PDU	16, 16	N/A	N/A	N/A	N/A	N/A	N/A	normal	۲
2	CyberPower- 900-UPS	USB-front port	UPS	10,N/A	114	N/A	68	100	0	on	OL	0
3	STech16SNMP	SNMP-172.19.100.24	PDU	6, 16	113	52	38	N/A	N/A	N/A	normal	0

Patrash Add Davice Shutdown Order Notifications Paw Data Logs Environmental Manage Davice Outlate

 In the lower section of the page, select an RPM by clicking on the radio button to the far right in the RPM's row. The options that are available for that RPM will be available (ungreyed). Select one of the following options:

Refresh	Refreshes the information in the RPMs table.
Add Device	Displays the <i>Device Ports > RPMs - Add Device</i> to add a new managed PDU or UPS.
Shutdown Order	Displays the order in which all UPS devices are shutdown in the event that a UPS reaches a low battery state. See <i>Figure 10-2</i> . For more information, see <i>RPM Shutdown Procedure</i> .

Notifications	Displays the notifications configured for each PDU and UPS. See <i>Figure 10-3</i> .
Raw Data	Displays a window with all of the information returned by the driver when a query for status is requested. This option is available for all RPMs. See <i>Figure 10-4</i> .
Logs	Displays a window with any logging information that has been accumulated for the selected RPM, if logging is enabled for the RPM. This option is available for all RPMs. See <i>Figure 10-5</i> .
Environmental	Displays a window with any environmental (humidity and temperature) information that may be available for the selected RPM, if sensors are installed for the RPM. This option is available for all RPMs. See <i>Figure 10-6</i> .
Managed Device	Displays the <i>RPMs</i> - <i>Manage Device</i> page, with the complete status and configuration for the selected RPM. This option is available for all RPMs.
Outlets	Displays the <i>RPMs</i> - <i>Outlets</i> page for RPMs that support individual outlet control and status.
Beeper: Enable, Mute, Disable	If the RPM has a beeper than can be controlled, these options allow the administrator to Enable , Mute , or Disable the beeper. If you try to use Mute to silence a beeper and the beeper continues to sound, the UPS most likely does not support mute, and the Disable option will be the only way to silence the beeper.
Reboot	Reboots the RPM immediately, which may interrupt the power provided by the RPM while it is rebooting. Some PDUs and UPSes have a default delay that they will wait before initiating a reboot; this setting may be visible in the raw data (see above) as "ups.delay.reboot".
Shutdown	Shutsdown the RPM immediately, which will interrupt the power provided by the RPM. Some PDUs and UPSes have a default delay that they will wait before initiating a shutdown; this setting may be visible in the raw data (see above) as "ups.delay.shutdown".
Delete	Deletes the selected RPM, after a confirmation.

Figure 10-2 RPM Shutdown Order

🔚 Lantro	onix SLC8048 - Device Status - Go	ogle Chrome		
🖹 bttps	://172.19.100.148/rpmstatus.ht	m?report=sdorder		Ð
SLC	8048 - <mark>RPM</mark> Shu	ıtdown Orde	e r	
RPM Id	Shutdown Order for UPS	Remote Power Man Shutdown Order	Low Battery Action	Provides SLC Power
2 5 2 UP	Eaton Cyber S(s).	2 50	Shutdown this UPS Shutdown this UPS	No Yes

Figure 10-3	RPM	Notifications
-------------	-----	---------------

🔠 Lanti	ronix SLC8048 - Device Status - Go	ogle Chrome	9	
🖹 http	s://172.19.100.148/rpmstatus.ht	m?report=n	otify	ଭ
SLC	8048 - RPM Not	ificati	ons	
	Notification Configura	tion for	Remot	e Power Managers
RPM	Name	Log	SNMP	Email
Id		Status	Trap	Address
1	APC750	1 min	Yes	[none]
2	Eaton	1 min	Yes	[none]
3	ServerTechTelnet	1 min	Yes	[none]
4	SerTechSNMP	1 min	Yes	[none]
5	Cyber	1 min	Yes	[none]
5 RP	M(s).			
•				

Figure 10-4 RPM Raw Data Log

1	🛿 Lantronix SLC8048 - Device Status - Google Chrome 📃 🔲 📂	ζ	
é	ی https://172.19.100.148/rpmstatus.htm?report=rawdata&rpmid=1	7	(
	SLC8048 - RPM #1/SLP16snmp: Raw Data		
	ambient.2.humidity: 41.00		
	ambient.2.temperature: 24.00		
	device.mfr: Lantronix SLP		
	device.model: Glenn-Tower		
	device.serial: 13900002		
	device.type: SLP PDU		
	driver.name: snmp-ups		
	driver.parameter.pollinterval: 2		
	driver.parameter.port: 172.19.237.30		
	driver.parameter.synchronous: no		
	driver.version: 2.7.3		
	driver.version.data: slp MIB 17.12.07		
	driver.version.internal: 0.72		
	outlet.1.desc: TowerA_Outlet1		
	outlet.1.id: A1		

Figure 10-5 RPM Logs

* https://172	2.19.100.148/	rpmst	atus.htm?report=l	ogs&rpmid=1			
SLC804	48 - RF	M	#1/SLP16	Ssnmp: L	.ogs	5	
					•		-
ormal	10101 DO 11010	100000				121 2 121	
05/24/16	21:22:09	RPM	#1/SLP16snmp	Input Volta	ge:NA	Output	C
05/24/16	21:23:09	RPM	#1/SLP16snmp	Input Volta	ge:NA	Output	C
05/24/16	21:24:10	RPM	#1/SLP16snmp	Input Volta	ge:NA	Output	C
05/24/16	21:25:09	RPM	#1/SLP16snmp	Input Volta	ge:NA	Output	C
05/24/16	21:26:09	RPM	#1/SLP16snmp	Input Volta	ge:NA	Output	C
05/24/16	21:27:09	RPM	#1/SLP16snmp	Input Volta	ge:NA	Output	C
05/24/16	21:28:09	RPM	#1/SLP16snmp	Input Volta	ge:NA	Output	C
05/24/16	21:29:09	RPM	#1/SLP16snmp	Input Volta	ge:NA	Output	C
05/24/16	21:30:09	RPM	#1/SLP16snmp	Input Volta	ge:NA	Output	C
05/24/16	21:31:09	RPM	#1/SLP16snmp	Input Volta	ge:NA	Output	C
05/24/16	21:32:09	RPM	#1/SLP16snmp	Input Volta	ge:NA	Output	C
05/24/16	21:33:09	RPM	#1/SLP16snmp	Input Volta	ge:NA	Output	C

Figure 10-6 RPM Environmental Log



RPMs - Add Device

The **Add Device** page assists the administrator with adding a new managed RPM to the SLC configuration. With over 140 different vendors and nearly 1000 different models that are supported, the key to ensuring the SLC can properly manage a PDU or UPS is selecting the right model (with its associated driver) and any required driver options, especially for USB managed devices. On the *Devices > RPMs* page, access the *Device Ports > RPMs - Add Device* page to configure a new managed remote power manager (RPM) for the SLC configuration.

Note: The Device Ports > RPMs - Add Device page with the same functionality can also be accessed through the Devices > Device Ports page.

To add a new managed RPM :

- 1. Click the **Devices** tab and select the **RPMs** option. *Figure 10-1* shows the page that displays.
- 2. Click the Add Device link on the Devices > RPMs page. The following page displays.

Logout Host User Network Services U Device Status Device P	SLC 8048 ICD 50 U1 E1 1 3 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 35 37 slc4331 Select port for © Configuration WebSSH (DP only) © Connected Devices ser Authentication Devices Maintenance Quick Setup orts Console Port USB / SD Card RPMs Connections Host Lists Scripts Sites RPMs - Add Device	39 41 43 45 47 A 40 42 44 46 48 B rice (DP only) ☆ ? [] [] [] Help?]
Vendor	select one	
vendor.	(U) - USB, (S) - Serial, (N) - Network, (P) - SNMP	
Model:	select one •	
Managed via:	USB Serial Network SNMP	
USB Device:	select one v	
Name:		
# of Outlets:		
IP Address:		
Port:	Enter "0" for a front USB port.	
Driver Opts:		
Login:		
Password:		
Retype Password:		
Log Status:	No Yes, minutes:	
Critical SNMP Traps:		
Critical Emails:		
Low Battery:	Shutdown this UPS Shutdown all UPSes Allow battery failure Shutdown both SLC UPSes	
Shutdown Order:		
Provides SLC Power:		
	Apply	

Figure 10-7 Device Ports > RPMs - Add Device

3. Enter the following:

Vendor

Select the correct vendor from the drop-down menu.

Model	Select the Model in the drop-down menu. The drop-down menu will be populated with models supported for the selected vendor above. To the left of each model name is one or two letters in parentheses that indicate the type of control available for the selected model: P - SNMP, S - serial port, U - USB port, N - network. Some of the model names in the dropdown may be truncated because the list of models is very long - in this case, hover over the model name and the complete model name(s) will be displayed.				
Managed via	If there is more than one way to manage the selected model, select the appropriate management method.				
USB Device	For USB controlled devices, if the RPM is connected to a USB port, the devices should be displayed in the USB Device dropdown. Select the correct device This will automatically fill in the Port with the correct port number and the Driver Opts with the USB vendor and product ID (see below).				
Name	Specify the unique name of the RPM (up to 20 characters).				
# of Outlets	Specify the number of outlets on the RPM (maximum of 120 outlets).				
IP Address	For SNMP and Network (Telnet) managed RPMs, specify the IP address of the RPM.				
Port	For network (Telnet) managed RPMs, this is assumed to be port 23 (if left blank), or it can be filled in with an alternate TCP port. For USB managed RPMs, this is one of the front USB ports ("0") or the device port that the RPM is connected to on the SLC (this may be automatically filled in when the USB Device is selected). For serially controlled RPMs, this is the device port that the RPM is connect to on the SLC.				
Driver Opts	For the driver associated with the RPM device, these are extra options which may be required to make the driver work. The most frequent use of the driver options is for USB devices (the vendor and product ID may be required so that the SLC can find the correct device on the USB bus), or in the event that the default driver options do not work with the RPM. The vendor and product ID may be automatically filled in if a USB Device is selected. There may also be other driver options that are filled in by the SLC from an internal table - these will be automatically set and can be viewed after the RPM has been added, and can always be overridden by driver options, refer to the <i>Network UPS Tools Hardware Compatibility List</i> . The format of the driver options setting is one or more comma-separated parameters-value pairs, e.g. <pre><pre>cparameter name>=<value>.</value></pre></pre>				
Login	For Network and serially managed RPMs, this is the administrator login.				
Password/Retype Password	For Network and serially managed RPMs, this is the administrator password.				
Read Community	For SNMP managed RPMs, this is the SNMP read (get) community.				
Write Community/Retype Write Comm	For SNMP managed RPMs, this is the SNMP write (set) community.				
Log Status	Indicates if the status of the RPM is periodically logged. Select Yes, minutes to log the status periodically and enter a value between 1 and 60 minutes. The logs can be viewed by viewing the <i>Devices</i> > <i>RPMs</i> page and clicking on "Logs".				
Critical SNMP Traps	If enabled, under critical conditions (UPS goes onto battery power, UPS battery is low, UPS forced shutdown in progress, UPS on line power, UPS battery needs to be replaced, RPM is unavailable, communications with RPM lost, communications with RPM established), a slcEventRPMAction trap will be sent to the NMS configured in the <i>SNMP</i> settings. This requires that SNMP traps be enabled.				

Critical Emails	If an email address is specified, under critical conditions (see Critical SNMP Traps above), an email notification will be sent to the email address. The Server and Sender configured in the <i>SMTP</i> settings will be used to send the email.
Low Battery	For UPS devices only. Indicates the behavior to take when the UPS reaches a low battery state. Options are to Shutdown this UPS - shutdown only the UPS that has reached a low battery state; Shutdown all UPSes - shutdown all UPSes managed by the SLC; Allow battery failure - allow the battery to completely fail, which may result in the unsafe shutdown of the devices it provides power to; Shutdown both SLC UPSes - shutdown both UPSes that provide power to the SLC, including the UPS with that has reached a low battery state (some SLCs have dual power supplies). For more information, see <i>RPM Shutdown Procedure</i> .
Shutdown Order	For UPS devices only. If any of the UPSes managed by the SLC reaches a low battery state AND is configured for Shutdown all UPSes for its Low Battery setting, this indicates the order in which this UPS will be shutdown. All UPSes with a shutdown order of "1" will be shutdown first, followed by all UPSes with a shutdown order of "2", etc. Shutdown orders are in the range of 1 to 49, with 50 being reserved for UPSes that provide power to the SLC - they will always be shutdown last (see Provides SLC Power below).
Provides SLC Power	For UPS devices only. Indicates if this UPS provides power to the SLC.

4. Click Apply to Save.

RPMs - Manage Device

The Manage Device page allows the administrator to modify the settings for a managed RPM.

To modify a managed RPM:

- 1. Click the **Devices** tab and select the **RPMs** option. *Figure 10-1 Devices > RPMs* shows the page which displays.
- 2. Select an RPM and click the **Manage Device** link. *Figure 10-8 RPMs Managed Device* shows the page which displays.

	Host: slc4331 User: sysadmin	B LCD SD U1 U2 Sel	E1 1 3 5 7 9 E2 2 4 6 8 10 ect port for Configure 	11 13 19 12 14 10 rration	5 <mark>17 19 21 23 25 27</mark> 5 18 20 22 24 26 28 WebSSH (DP only)	29 31 33 30 32 34 Connecte	35 37 39 41 4 36 38 40 42 4 d Device (DP o	13 45 47 A 14 46 48 B only)
Network Servic	es User Authentication	Devices Mai	ntenance Quic	k Setup			岱?	₿ 🗉
Device Status	evice Ports Console Port	USB / SD Card	Internal Modem	RPMs	Connections	lost Lists	Scripts	Sites
		RPMs - I	Manage Devic	e				Help?
RPM Id:	1		Manad	red via: !	SNMP			
Name:	SI P16snmp		IP A	ddress:	172 19 237 30	P	ort:	
Status:	normal		Drive	or Onto:				
Vendor:	Lantronix SLP		DIVE	er Opts.				
Model:	Glenn-Tower		Read Com	munity:	public			
# of Outlets:	16		Write Com	munity:	•••••			
Outlets On:	16		Retype Write	Comm:	•••••			
F/W Version:	SecureLinx Power Manager 5.3p	Version	Log	Status:	🔵 No 💿 Yes, n	ninutes: 1		
Serial Num:	13900002		Critical SNMF	P Traps:				
MAC Address:	[none]		Critical	Emails:				
Current:	0.5 amps				Shutdown this I	IPS		
Input Voltage:	N/A				Shutdown all U	PSes		
Apparent Power:	N/A		Low	Battery:	Allow battery fa	ilure		
Nominal Apparent Power:	N/A				Shutdown both	SLC UPS	es	
Real Power:	N/A		Shutdown	order:				
Nominal Real Power:	N/A		Provides SLC	Power:				Outlets >
			Apply					

3. Enter the following:

RPM Id (view only)	The unique number associated with the RPM.
Name	Specify the unique name of the RPM (up to 20 characters).
Status (view only)	The current status of the RPM. Any error status will be shown here.
Vendor (view only)	The manufacturer of the RPM.
Model (view only)	The model of the RPM. The model is read from the device, if it is provided; not all RPMs provide a model string. If the device normally provides the device model and becomes unreachable, or does not provide a model string, the Model is derived from the supported model list strings.
# of Outlets	Specify the number of outlets on the RPM (maximum of 120 outlets).
Outlets On (view only)	The number of outlets that are currently turned on, if this information is provided by the RPM.
F/W Version (view only)	The firmware version of the RPM, if this information is provided by the RPM.
Serial Num (view only)	The serial number of the RPM, if this information is provided by the RPM.
MAC Address (view only)	The MAC address of the RPM, if this information is provided by the RPM.

Figure 10-8 RPMs - Managed Device

Current (view only)	The total current value for the RPM in Amperes, if this information is provided by the RPM. If the RPM consists of two separate towers or units, each with its own current value, both current values will be displayed, separated by a slash.
Input Voltage (view only)	The input voltage for the RPM in Volts, if this information is provided by the RPM. If the RPM consists of two separate towers or units, each with its own input voltage value, both voltage values will be displayed, separated by a slash.
Apparent Power (view only)	The apparent power value for the RPM in Volt-Amperes, if this information is provided by the RPM. If the RPM consists of two separate towers or units, each with its own apparent power value, both power values will be displayed, separated by a slash.
Nominal Apparent Power (view only)	The nominal apparent power value for the RPM in Volt-Amperes, if this information is provided by the RPM. If the RPM consists of two separate towers or units, each with its own nominal apparent power value, both power values will be displayed, separated by a slash.
Real Power (view only)	The real power value for the RPM in Watts, if this information is provided by the RPM. If the RPM consists of two separate towers or units, each with its own real power value, both power values will be displayed, separated by a slash.
Battery Charge (view only)	For UPS devices only. Displays the current charge level for the battery, as a percentage.
Battery Runtime (view only)	For UPS devices only. Displays the amount of time remaining in the UPS battery life.
Beeper Status (view only)	For UPS devices only. Displays the current state of the UPS beeper.
Managed via (view only)	Displays the method used to control the RPM device (SNMP, Network, Serial Port, USB port).
IP Address	For SNMP and Network (Telnet) managed RPMs, specify the IP address of the RPM.
Port	For network (Telnet) managed RPMs, this is assumed to be port 23 (if left blank), or it can be filled in with an alternate TCP port. For USB managed RPMs, this is one of the front USB ports ("0") or the device port that the RPM is connected to on the SLC. For serially controlled RPMs, this is the device port that the RPM is connect to on the SLC.
Driver Opts	For the driver associated with the RPM device, these are extra options which may be required to make the driver work. The most frequent use of the driver options is for USB devices (the vendor and product ID may be required so that the SLC can find the correct device on the USB bus), or in the event that the default driver options do not work with the RPM. There may also be other driver options that are filled in by the SLC from an internal table - these will be automatically set and can be viewed after the RPM has been added, and can always be overridden by driver options, refer to <i>Network UPS Tools Hardware Compatibility List</i> . The format of the driver options setting is one or more comma-separated parameters-value pairs, e.g. " <pre>parameter name>=<value>".</value></pre>
Login	For Network and serially managed RPMs, this is the administrator login.
Password/Retype Password	For Network and serially managed RPMs, this is the administrator password.
Read Community	For SNMP managed RPMs, this is the SNMP read (get) community.
Write Community/ Retype Write Comm	For SNMP managed RPMs, this is the SNMP write (set) community.

Log Status	Indicates if the status of the RPM is periodically logged. Select Yes, minutes to log the status periodically and enter a value between 1 and 60 minutes. The logs can be viewed by viewing the RPMs web page and clicking on "Logs".
Critical SNMP Traps	If enabled, under critical conditions (UPS goes onto battery power, UPS battery is low, UPS forced shutdown in progress, UPS on line power, UPS battery needs to be replaced, RPM is unavailable, communications with RPM lost, communications with RPM established), a slcEventRPMAction trap will be sent to the NMS configured in SNMP settings. This requires that SNMP traps be enabled.
Critical Emails	If an email address is specified, under critical conditions (see Critical SNMP Traps above), an email notification will be sent to the email address. The Server and Sender configured in the <i>SMTP</i> settings will be used to send the email.
Low Battery	For UPS devices only. Indicates the behavior to take when the UPS reaches a low battery state. Options are to Shutdown this UPS - shutdown only the UPS that has reached a low battery state; Shutdown all UPSes - shutdown all UPSes managed by the SLC; Allow battery failure - allow the battery to completely fail, which may result in the unsafe shutdown of the devices it provides power to; Shutdown both SLC UPSes - shutdown both UPSes that provide power to the SLC, including the UPS with that has reached a low battery state (some SLCs have dual power supplies). For more information, see <i>RPM Shutdown Procedure</i>
Shutdown Order	For UPS devices only. If any of the UPSes managed by the SLC reaches a low battery state AND is configured for Shutdown all UPSes for its Low Battery setting, this indicates the order in which this UPS will be shutdown. All UPSes with a shutdown order of "1" will be shutdown first, followed by all UPSes with a shutdown order of "2", etc. Shutdown orders are in the range of 1 to 49, with 50 being reserved for UPSes that provide power to the SLC - they will always be shutdown last (see Provides SLC Power in the next field below).
Provides SLC Power	For UPS devices only. Indicates if this UPS provides power to the SLC.

3. To save, click **Apply**.

RPMs - Outlets

The **Outlets** page allows the administrator to view the current status of each individual outlet on an RPM, and change the state of the outlets. Not all RPMs support individual outlet status and control.

To control and view status for RPM outlets:

- Click the **Devices** tab and select the **RPMs** option. *Figure 10-1 Devices > RPMs* shows the page which displays.
- Select an RPM and click the **Outlets** link. *Figure 10-9 RPMs Outlets* shows the page which displays. This page will, at a minimum, list the outlet numbers and their state **On** or **Off**. If the RPM provides additional information for the outlets, the custom name and the current reading in Amperes will also be displayed for each outlet.

				guit			411010				
LVN.	TROM	IX lost: slc4	SLC 8048	8 LCD 50	U1 MD E1 1 U2 MD E2 2	3 5 7 9 2 4 6 8 10	11 13 15) 12 14 16	17 19 21 23 25 18 20 22 24 26	27 29 31 33 35 28 30 32 34 36	5 37 39 41 4 5 38 40 42 4	43 45 47 🛕 44 46 48 🖪
Logo	ut i	Jser: sys	admin		Select port for	Configu	iration 🔘	WebSSH (DP only)	Connected	Device (DP c	only)
Network	Services	User A	uthentication	Devices	Maintenance	Quic	k Setup			☆?	₿Е
Device St	tatus Devid	ce Ports	Console Port	USB / SD Ca	ard Interna	I Modem	RPMs	Connections	Host Lists	Scripts	Sites
				F	PMs - Ou	tlets					Help?

Figure 10-9 RPMs - Outlets

RPM #3	S-STech16SNMP	Outlet: Cycle Powe	er Turn On Turn C	Off
ld	State	Description	Current (amps)	
1	on	Outlet1	0.00	
2	on	TowerA_Outlet2	0.00	
3	on	TowerA_Outlet3	0.00	
4	on	TowerA_Outlet4	0.00	
5	on	TowerA_Outlet5	0.00	
6	on	TowerA_Outlet6	0.00	

Refresh

3. To change the state of one or more outlets, select the outlets, and click the **Cycle Power**, **Turn On** or **Turn Off** buttons. The command will be sent to the RPM and the page will refresh. It may take one or two minutes before the new outlet state(s) are reflected on the Outlets page.

RPM Shutdown Procedure

This section applies to UPS-type RPMs only, and does not apply to PDU-type RPMS. This section describes the shutdown process when a UPS managed by the SLC reaches a low battery state. When one UPS reaches a low battery state, the SLC can be configured to allow the UPS to continue to run until its battery fails completely, to shutdown just the UPS with the low battery, or to shutdown one or more UPSes. UPS-type RPMs can report the following states:

- **OL** On line power
- OB On battery power
- LB Low battery
- HB High battery
- **RB** The battery needs to be replaced
- CHRG The battery is charging
- DISCHRG The battery is discharging (inverter is providing load power)
- BYPASS UPS bypass circuit is active no battery protection available
- CAL UPS is currently performing runtime calibration (on battery)
- **OFF** UPS is offline and is not supplying power to the load
- OVER UPS is overloaded
- **TRIM** UPS is trimming incoming voltage

- **BOOST** UPS is boosting incoming voltage
- FSD UPS is in forced shutdown due to a critical condition

Once a UPS is on line power (status is **OL**) and goes off of line power and onto battery power (status is **OB**), it may reach a low battery state (status is **OB**, **LB** or **LB**). Switching from line power to battery power, and reaching a low battery state are critical states that can result in syslog, email and SNMP trap notifications. The exact point at which a UPS reaches a low battery state is device dependent and is related to the **battery.charge**, **battery.charge.low**, **battery.runtime** and battery.runtime.low settings which can be viewed in the "Raw Data" report.

Once a UPS reaches a low battery state, the **Shutdown Order**, **Low Battery Action** and **Provides SLC Power** settings determine which UPSes to shutdown, and in what order. The UPS with the low battery will be placed into **FSD** (Forced Shutdown) mode. The following actions will be performed based on the **Low Battery Action** setting for the UPS with the failed battery:

- Allow Battery Failure The UPS battery will be allowed to run until it fails completely. If the UPS provides power to the SLC and the battery fails, the SLC will not be cleanly shutdown. In this scenario, the Shutdown Order setting will be ignored. The Shutdown Order setting may be used if another UPS reaches the low battery state (see Shutdown all UPSes below).
- Shutdown This UPS If the UPS provides power to the SLC, the SLC will begin shutdown procedures, shutting down the UPS last. If the UPS does not provide power to the SLC, the UPS will be shutdown, but will continued to be monitored in case it comes back online.
- Shutdown all UPSes The SLC will begin shutting down all UPSes with a non-zero Shutdown Order, shutting down UPSes with a shutdown order of "1" first, UPSes with a shutdown order of "2" second, etc. Any UPS which provides power to the SLC is always forced to have its Shutdown Order set to 50, which the highest (and last) Shutdown Order. If the UPS with the failed battery provides power to the SLC (and thus has a Shutdown Order set to 50), the SLC will also begin shutdown procedures, shutting down the failed UPS last. If none of the UPSes provide power to the SLC, after they are all shutdown their drivers will remaining running in case the UPS comes back online. In this case, any queries to an RPM while it is still offline may report "RPM driver data is stale". If the Low Battery Action for a UPS is set to Allow Battery Failure, but the UPS has a non-zero Shutdown Order, the UPS will still be shutdown if another UPS reaches the low battery state and has its Low Battery Action set to Shutdown all UPSes.
- Shutdown Both SLC UPSes This setting should only be used on dual-power SLC units which have each power supply connected to separate (different) UPS devices, and both UPS devices are being managed by the SLC. If a UPS is configured for Shutdown Both SLC UPSes but does not have Provides SLC Power enabled, this is an ambiguous configuration, and no shutdown action will occur.

For this configuration, when one of the UPSes providing power to the SLC reaches a low battery state, the event will be noted in the system log, and the SLC will continue to run with no further actions until the second UPS providing power to the SLC reaches a low battery state. At this point the SLC will begin shutdown procedures, shutting down both failed UPSes last.

Optimizing and Troubleshooting RPM Behavior

This section gives tips on how to optimize the management of specific PDUs and UPSes, and how to troubleshoot any problems with the SLC connecting to and managing an RPM.

- Sentry3 Network and Serially Managed PDUs Some Sentry3 PDUs have a CLI timeout, with a default setting of 5 minutes. This timeout may cause frequent query errors when requesting information from the Sentry3 PDU. It is recommended that the timeout be set as high as possible to reduce the frequency of the query errors.
- Serially Managed RPMs with Administrator Logins Some serially managed devices will have an administrator login for the console port. It is recommended that any active sessions be logged out before adding the device as an RPM, otherwise the RPM may experience query errors.

If the SLC is unable to communicate with an RPM, or an RPM is displaying the error "driver is not running", the following steps can be used to troubleshoot the driver issues:

- **Correct Driver** The CLI command set rpm driver <RPM Id or Name> action show can be used to display the current running driver for the RPM. Some serially and network managed RPMs do not have drivers; if this is the case for the RPM, the CLI command will indicate this. Otherwise it will display the driver that is running for the RPM, and it should match the driver listed for the device at *Network UPS Tools Hardware Compatibility List*. If the wrong driver is shown, the RPM will need to be deleted and re-added, with the correct vendor and model selected. If no driver is shown, the driver may not be able to start for a variety of reasons; see remaining steps.
- SNMP Settings For SNMP managed devices, verify the IP Address, Read Community and Write Community settings are correct.
- Reverse Pinout Setting For serially managed devices, verify the Reverse Pinout setting (located in the *Device Port Settings* page) is set correctly.
- VendorId and ProductId Driver Options For USB managed devices, verify the vendorid and productid shown in the RPM driver options are correct. These can be set automatically by the SLC from an internal table, set by the user by selecting a specific USB device when adding a USB-managed RPM, or changed by the user at any time. The CLI command show usb_devices displays all connected USB devices with their port, Product ID and Vendor ID.
- Extra Driver Options The driver documentation at Network UPS Tools Hardware Compatibility List may indicate that extra driver options are required for the RPM. Select the driver name link under the Driver column to see any special requirements for the UPS or PDU.
- Driver Debug Mode The driver can be run in debug mode at the CLI and the output examined to determine why the driver is not starting or is unable to communicate with the RPM. The CLI command set rpm driver <RPM Id or Name> action debug [level <1|2|3>] will stop any currently running driver and restart the driver in debug mode with output sent to a local file. Running set rpm driver <RPM Id or Name> action show should show a driver running with one or more -D flags. The debug output can be examined or emailed with the set rpm driver <RPM Id or Name> action viewoutput [email <Email Address>] [display <head|tail>] [numlines <Number or Lines>] command. To return the driver to its normal non-debug state, run set rpm driver <RPM Id or Name> action restart. Note that drivers running in debug mode will generate copious output, and for disk space reasons should not be left running in debug mode for long periods of time (e.g. more than an hour).

RPM Commands

Go to *RPM Commands* to view CLI commands which correspond to the web page entries described above.

11: Connections

Chapter 8: Device Ports on page 123 described how to configure and interact with an SLC advanced console server port connected to an external device. This chapter describes how to use the *Devices > Connections* page to connect external devices and outbound network connections (such as Telnet or SSH) in various configurations.

An SLC unit port attached to an external device can be connected to one of the following endpoints:

- Another device port attached to an external device
- Another device port with a modem attached
- An outgoing Telnet or SSH session
- An outgoing TCP or UDP network connection

This enables the user to set up connections such as those described in the next section. You can establish a connection at various times:

- Immediately. These connections are always re-established after reboot.
- At a specified date and time. These connections connect if the date and time have already passed.
- After a specified amount of data or a specified sequence of data passes through the connection. Following reboot, the connection is not reestablished until the specified data passes through the connection.

Typical Setup Scenarios for the SLC Unit

Following are typical configurations in which SLC connections can be used, with references to settings on the *Devices > Connections* and *Device Ports > Settings (1 of 2)* web pages.

Terminal Server

In this setup, the SLC 8000 advanced console manager acts as a multiplexer of serial data to a single server computer. Terminal devices are connected to the serial ports of the SLC unit and configured as a Device Port to Telnet out type connection on the *Devices > Connections* page. The users of the terminals can access the server as if they were connected directly to it by local serial ports or a console.





Remote Access Server

In this setup, the SLC 8000 advanced console manager is connected to one or more modems by its device ports. Configure the device ports on the *Device Ports > Settings (1 of 2)* web page by selecting the Dial-in option in the Modem Settings section. Most customers use the modems in PPP mode to establish an IP connection to the SLC unit and either Telnet or SSH into the SLC 8000 advanced console manager. They could also select text mode where, using a terminal emulation program, a user could dial into the SLC unit and connect to the command line interface.

Figure 11-2 Remote Access Server



Reverse Terminal Server

In this scenario, the SLC 8000 advanced console manager has one or more device ports connected to one or more serial ports of a mainframe server. Users can access a terminal session by establishing a Telnet or SSH session to the SLC unit. To configure the SLC console manager, select the **Enable Telnet In** or **Enable SSH In** option on the *Device Ports > Settings (1 of 2)* page.





Multiport Device Server

A PC can use the device ports on the SLC unit as virtual serial ports, enabling the ports to act as if they are local ports to the PC. To use the SLC 8000 advanced console manager in this setup, the PC requires special software, for example, Com Port Redirector (available on <u>www.lantronix.com</u>) or similar software).



Figure 11-4 Multiport Device Server

Console Server

For this situation, the SLC unit is configured so that the user can manage a number of servers or pieces of network equipment using their console ports. The device ports on the SLC 8000 advanced console manager are connected to the console ports of the equipment that the user would like to manage. To manage a specific piece of equipment, the user can Telnet or SSH to a specific port or IP address on the SLC unit and be connected directly to the console port of the end server or device. To configure this setup, set the **Enable Telnet** In or **Enable SSH** In option on the *Device Ports > Settings (1 of 2)* page for the device port in question. The user can implement an extra remote management capability by adding a modem to one of the device ports and setting the **Dial-in** option in the Modem Settings section of the *Device Ports > Settings (1 of 2)* page. A user could then dial into the SLC 8000 advanced console manager using another modem and terminal emulation program at a remote location.



Figure 11-5 Console Server

Connection Configuration

Note: These are advanced connection settings for specific applications. If the SLC 8000 advanced console manager is being used as a console or device server it is unlikely that you will need any of the Connection settings described below.

To create a connection:

1. Click the **Devices** tab and select the **Connections** opton. The following page displays:

5			
LANTRONIX° SLC 8048	LCD SD U1 E1 1 3 5 U2 E2 2 4 6	7 9 11 13 15 17 19 21 23 25 27 29 31 8 10 12 14 16 18 20 22 24 26 28 30 32	33 35 37 39 41 43 45 47 A 34 36 38 40 42 44 46 48 B
Logout Host: sic4331 User: sysadmin	Select port for 🔘 C	onfiguration 🔵 WebSSH (DP only) 🔵 Con	nected Device (DP only)
Network Services User Authentication Devi	ces Maintenance Q	uick Setup	☆? 🗘 🗉
Device Status Device Ports Console Port USB	/ SD Card RPMs Con	nections Host Lists Scripts Site	95
	Connections		Help?
Outgoing Connection	Timeout: 🔵 No 💿 Yes:	5 seconds	
Connect: Device Port	ata Flow: 💿 \leftrightarrow	to: Device Po	t 🔻
Port: Settings	•	Hostname:	
	• •	Port:	Settings >
		SSH Out Options	
		User:	
		Version: None 	1 2
		Command:	
Trigger: Connect now 			
Connect at date/time: May	v 24 v 2016 v	07 v : 18 v am v	
Auto-connect on characters trans	ferring: 💿 🔶 🛛 🔶		
 at least character 	rs		
character sequence:			
	Apply		
If a connectio	To view details for a n can be modified, the fields	connection, hold the mouse over the an s above will be filled in; modify the conn	rrow icon in the Flow column ection and select 'Configure'

Figure 11-6 Devices > Connections

If a connection can be modified, the fields above will be filled in; modify the connection and select 'Configure' To terminate a connection, select the radio button in the right column below and select 'Terminate' Web connections can be viewed here

Current Connections		Configure Term	inate Keep Connection:	Re	estart
Port/Service	Flow	Port/Service	<u>User</u>	Time	
Console Port	÷	Command Line	N/A	83:24:58	

2. For a device port, enter the following:

Outgoing	Select to turn on or turn off the connection timeout:
Connection Timeout	 No for no timeout Yes for a timeout. Specify the number of seconds in the seconds field.

Port	The number of the device port you are connecting.
	This device port must be connected to an external serial device and must not have command line interface logins enabled, be connected to a modem, or be running a loopback test.
	Note: To see the current settings for this device port, click the Settings link.
Data Flow	Select the arrow showing the direction (bidirectional or unidirectional) the data will flow in relationship to the device port you are connecting.
to	From the drop-down list, select a destination for the connection: a device port connected to a serial device, a device port connected to a modem, or an outbound network connection (Telnet out , SSH out , TCP Port , or UDP Port).
	Note: To see the current settings for a selected device port, click the Settings link.
Hostname	The host name or IP Address of the destination. This entry is required if the to field is set to Telnet out, SSH out, TCP port, or UDP port.
Port	If the to field is set to Device Port or Modem on Device Port , enter the number of the device port. For all other options, this is the TCP/UDP port number, which is optional for Telnet out and SSH out, but required for TCP Port and UDP Port.
	Note: If you select Device Port , it must not have command line interface logins enabled or be running a loopback test. To view the device port's settings, click the Settings link to the right of the port number.
SSH Out	Select one of the following optional flags to use for the SSH connection.
Options	User: Login ID to use for authenticating on the remote host.
	 Version: Version of SSH. Select 1 or 2. Command: Enter a specific command on the remote host (for example, reboot).
Trigger	Select the condition that will trigger a connection. Options include:
	 Connect now: Connects immediately, or if you reboot the SLC 8000 advanced
	console manager, immediately on reboot.
	 Connect at date/time: Connects at a specified date and time. Use the drop-down lists to complete the date and time. Upon rebooting, the SLC unit reestablishes the connection if the date/time has passed
	 Auto-connect on characters transferring: Select the arrow indicating the direction of the data transfer and either the minimum number of characters or a specific character sequence that will trigger the connection.
	You can select the direction of the data transfer only if Data Flow is bidirectional. Upon rebooting, the SLC 8000 advanced console manager does not reestablish the connection until the specified data has passed through one of the endpoints of the connection.

3. To save, click the **Apply** button.

To view, update, or disconnect a current connection:

The bottom of the *Current Connections* page displays current connections.

Figure 11-7 Current Connections

To view details for a connection, hold the mouse over the arrow icon in the Flow column. If a connection can be modified, the fields above will be filled in; modify the connection and select 'Configure'. To terminate a connection, select the radio button in the right column below and select 'Terminate'. Web connections can be viewed <u>here</u> **Current Connections** Configure Terminate Keep Connection: 🔲 Restart Flow Port/Service Port/Service User Time a Console Port 🚙 Command Line ⇔ sysadmin 2:49:03

- 1. To view details about a connection, hold the mouse over the arrow in the Flow column.
- 2. To disconnect (delete) a connection, select the connection in the **Select** column and click the **Terminate** button.
- 3. To reestablish the connection, create the connection again in the top part of the page.
- 4. To view information about Web connections, click the **here** link in the text above the table. The *Maintenance > Firmware & Configurations* page displays.

Connection Commands

Go to *Connection Commands* to view CLI commands which correspond to the web page entries described above.

12: User Authentication

Users who attempt to log in to the SLC advanced console manager by means of Telnet, SSH, the console port, or one of the device ports are granted access by one or more authentication methods.

The User Authentication page provides a submenu of methods (Local Users, NIS, LDAP, RADIUS, Kerberos, and TACACS+) for authenticating users attempting to log in. Use this page to assign the order in which the SLC unit will use the methods. By default, local user authentication is enabled and is the first method the SLC 8000 advanced console manager uses to authenticate users. If desired, you can disable local user authentication or assign it a lower precedence.

Note: Regardless of whether local user authentication is enabled, the local user sysadmin account is always available for login.

Authentication can occur using all methods, in the order of precedence, until a successful authentication is obtained, or using only the first authentication method that responds (in the event that a server is down).

If you have the same user name defined in multiple authentication methods, the result is unknown.

Example:

There is an LDAP user "joe" and an NIS user "joe" and the order of authentication methods is:

- 1. Local Users
- 2. LDAP
- 3. NIS

User "joe" tries to log in. Because there is an LDAP user "joe," the SLC unit tries to authenticate him against his LDAP password first. If he fails to log in, then the SLC 8000 advanced console manager may (or may not) try to authenticate him against his NIS "joe" user password.

To enable, disable, and set the precedence of authentication methods:

1. From the main menu, select User Authentication. The following page displays:

	Host: slc4331 User: sysadmin	8048	LCD SD U1	E1 1 3 5 E2 2 4 6 elect port for • •	7 9 11 13 6 8 10 12 14 Configuration 1 1 1 1	15 17 19 2 [.] 16 18 20 2: O WebSSH	1 23 25 27 29 2 24 26 28 30 (DP only) C	31 33 35 37 39 41 4 32 34 36 38 40 42 4 Connected Device (DP o	3 45 47 A 4 46 48 B only)
Network Servio	user Authentica	ation Devi	ces Ma	intenance	Quick Setu	P		岱?	₿ 🖻
Auth Methods	Local/Remote Users	NIS LDAP	RADIUS	Kerberos	TACACS+	Groups	SSH Keys	Custom Menus	
			Authent	ication M	ethods				Help?
	The SLC Each aut order tha via SSH,	can be config hentication me t the method is Telnet, the We	ured to use withod is ass s used to a ab or the C	e one or more signed a prec uthenticate a onsole Port.	e authenticatic edence, indic user who log	on methods ating the ins to the S	s. SLC		
	Enabled (in order	methods of precedence):		Disa	abled meth	iods:		
	1	Local Users	×	•	NIS LD RA Ke TA	S AP DIUS rberos CACS+	*		
	Authentic using the or using o	ation can occi next method only the first a	ur using all f the previo uthenticatio	methods, in ous one rejec on method tha	the order of th ted the authe at responds.	neir preced ntication;	lence,		
	1	Attempt next i	method on	authenticatio	n rejection				

Apply

2. To enable a method currently in the **Disabled methods** list, select the method and press the left 🗲 arrow to the left of the list. The methods include:

NIS (Network Information System)	A network naming and administration system developed by Sun Microsystems for smaller networks. Each host client or server computer in the system has knowledge about the entire system. A user at any host can access files or applications on any host in the network with a single user identification and password. NIS uses the client/server model and the Remote Procedure Call (RPC) interface for communication between hosts. NIS consists of a server, a library of client programs, and some administrative tools. NIS is often used with the Network File System (NES)
LDAP (Lightweight Directory Access Protocol)	A set of protocols for accessing information directories, specifically X.500-based directory services. LDAP runs over TCP/IP or other connection-oriented transfer services.
RADIUS (Remote Authentication Dial-In User Service)	An authentication and accounting system used by many Internet Service Providers (ISPs). A client/server protocol, it enables remote access servers to authenticate dial-in users and authorize their access to the requested system or service. RADIUS allows a company to maintain user profiles in a central database that all remote servers can share. It increases security, allowing a company to set up a policy that can be applied at a single administered network point.
Kerberos	Kerberos is a network authentication protocol that enables two parties to exchange private information across an unprotected network. It works by assigning a unique electronic credential, called a ticket, to each user who logs on to the network. The ticket is embedded in messages to identify the sender.

Figure 12-1 User Authentication > Authentication Methods

TACACS+ (Terminal Access Controller Access Control System)	TACACS+ allows a remote access server to communicate with an authentication server to determine whether the user has access to the network. TACACS+ is a completely new protocol and is not compatible with TACACS or XTACACS. The SLC 8000 advanced console manager supports TACACS+ only.
Local Users	Local accounts on the SLC unit used to authenticate users who log in using SSH, Telnet, the web, or the console port.

- 3. To disable a method currently in the **Enabled methods** list, select the method and click the right **→** arrow between the lists.
- 4. To set the order in which the SLC unit will authenticate users, use the up 1 and down arrows to the left of the **Enabled methods** list.
- 5. For Attempt next method on authentication rejection, you have the following options:
 - To enable the SLC 8000 advanced console manager to use all methods, in order of precedence, until it obtains a successful authentication, select the check box. This is the default.
 - To enable the SLC unit to use only the first authentication method that responds (in case a server is down or unavailable), clear the check box.
- 6. Click Apply.

Now that you have enabled one or more authentication methods, you must configure them.

Authentication Commands

Go to *Authentication Commands* to view CLI commands which correspond to the web page entries described above.

User Rights

The SLC has three user groups: Administrators, Power Users, and Default Users. Each has a predefined set of rights; users inherit rights from the user group to which they belong. These rights are in addition to the current functions that a user can perform at the command line interface:

- connect direct/listen
- set locallog/password/history/cli
- show datetime/deviceport/locallog/portstatus/portcounters/
- history/cli/user

The table below shows the mapping of groups and user rights.

User Right	Administrator	Power Users	Default Users
Full Administrative Rights	X		
Networking	X	Х	
Services	Х		
Date/Time	X	Х	

Table 12-2 User Types and Rights

Local Users	X		
Remote Authentication	X		
SSH Keys	X		
User Menus	X		
Device Port Operations	X		
Device Port Configuration	X		
USB	X		
Reboot/Shutdown	X	X	
Firmware/Configuration	X		
Diagnostics and Reports	X	X	
Secure Lantronix Network	X		
Web Access	X	X	
Internal Modem	X		
RPMs	X		
SD Card	X		

You cannot deny a user rights defined for the group, but you can add or remove all other rights at any time.

By default, the system assigns new users to the Default Users group, but you can change their group membership at any time. If you change a user's rights while the user is logged into the web or CLI, the results do not take effect until the next time the user logs in.

Local and Remote User Settings

The system administrator can configure the SLC 8000 advanced console manager to use local accounts and remote accounts to authenticate users.

1. Click the **User Authentication** tab and select the **Local/Remote Users** option. The following page displays.

					i ig		0 0	301	Autilo		Juno			(CIII	1010	0301	•		
		ost: sic43	SLC 331 dmin	804	18	LCD SD U' U: Se	E1 1 E2 2 elect port for	35 46	7 9 11 13 8 10 12 14 configuration	15 1 16 1 	7 19 21 8 20 22 ebSSH (23 25 2 24 26 2 DP only)	7 29 31 33 8 30 32 34 Connecte	35 37 36 38 ed Devi	39 41 4 40 42 4 ice (DP	43 45 47 44 46 48 only)	B		
Network Ser	vices	User A	uthentic	ation	Devic	ces Ma	intenan	ce	Quick Set	up					ቆ?	• 🗗 🛛			
Auth Methods	Local	/Remote	Users	NIS	LDAP	RADIUS	Kerbe	ros	TACACS+	Gr	oups	SSH K	eys Cust	tom M	lenus				
						Local/	Remo	te Us	sers							Help	?		
Enable Local Users: Care used to authenticate users who login to the Multiple Sysadmin Web Logins: Care used to authenticate users who login to the SLC via SSH, Telnet, the Web or the Console Port.								on ne rt.											
Authenticate o	nly rem	ote users	who are	in the	remote ı	users list:				No	o te: rem makir	nove Eso ng raw b	cape & Bre binary conn	ak Se ection	quence is to De	es for use evice Port	rs s.		
Local User Passw	ords																		
Complex Passw	ords:			P	assword	Lifetime:	90	days											
Allow R	euse: 🖪				Warnin	g Period:	No	• Ye	es: 7	day	'S								
Reuse Hi	story: 4			Ma	x Login A	Attempts:	No) Ye	es: 0										
					Lockou	ut Period:	No) Ye	es: 0	min	utes								
	A	dd/Edit L	Jser	Del	ete Use	r						ri Shad	Selec ght column ed users ar	t the r to edi e lock	radio b it or de (ca	outton in th elete a use innot logir	ie er. i).		
Local Users (1	users)	& Remo	te Users	s (0 us	ers)										١	View Loc	al Users	Vi	ew Remote Use
Login	Auth	UID	Group	Perm	issions						Esc Seq	Brk Seq	Custom Menu	DB	Liste	n	Data		Clear
sysadmin	Local	0	Adm	fa,nt,s	sv,lu,ra,d	t,sk,um,dp	,do,ub,rs	s,fc,dr,s	sn,wb,sd,m	id,rp	\x1bA	\x1bB		Ν	1-48,	U1,U2	1-48,U1,U	2	1-48,U1,U2

Figure 12-3 User Authentication > Local/Remote Users

Apply

The top of the page has entry fields for enabling local and remote users and for setting password requirements. The bottom of the page displays a table listing and describing all local and remote users.

To enable local and/or remote users:

1) Enter the following:

Enable Local Users	Select to enable all local users except sysadmin. The sysadmin is always available regardless of how you set the check box. Enabled by default.
Multiple Sysadmin Web Logins	Select to allow the sysadmin to have multiple simultaneous logins to the web interface. Disabled by default.
Sysadmin Access Limited to Console Port	Select to limit sysadmin logins to the Console Port only. Disabled by default.
Authenticate only remote users who are in the remote users list	Select the check box to authenticate users listed in the Remote Users list in the lower part of the page. Disabled by default.

2) Continue to set Local User Passwords:

Complex Passwords	Select to enable the SLC unit to enforce rules concerning the password structure (e.g., alphanumeric requirements, number of characters, punctuation marks). Disabled by default.
	Complexity rules:
	Passwords must be at least eight characters long.
	They must contain one upper case letter (A-Z), one lower case letter (a-z), one digit (0-9), and one punctuation character (()`~!@#\$%%^&*-+=\{[]:;"'<>,.?/_).
Allow Reuse	Select to enable users to continue to reuse old passwords. If you disable the check box, they cannot use any of the Reuse History number of passwords. Enabled by default.
Reuse History	The number of passwords the user must use before reusing an old password. The default is 4 .
	For example, if you set reuse history to 4, the user may reuse an old password after using 4 other passwords.
Password Lifetime (days)	The number of days until the password expires. The default setting is 90 .
Warning Period (days)	The number of days ahead that the system warns that the user's password will expire. The default setting is 7 .
Max Login Attempts	The number of times (up to 8) the user can attempt to log in unsuccessfully before the system locks the user out. The default setting is 0 (disabled).
Lockout Period (minutes)	The number of minutes (up to 90) the locked-out user must wait before trying to log in to the web interface again. The default setting is 0 (disabled).

2. Click the **Apply** button.

Adding, Editing or Deleting a User

Through this *User Authentication > Local/Remote Users* page, you can delete a user listed in the table or open a page for adding or editing a user.

To add a user:

1. On the User Authentication > Local/Remote Users, click the Add/Edit User button. The User Authentication > Local/Remote User > Add/Edit User page displays.

	⊣ost: slc4331 Jser: sysadmin	8 LCD SD U1 E1 1 2 U2 E2 2 Select port for	3 5 7 9 11 13 15 4 6 8 10 12 14 16 Configuration	17 19 21 23 25 27 29 31 33 35 37 39 41 43 45 47 A 18 20 22 24 26 28 30 32 34 36 38 40 42 44 64 B VebSSH (DP only) Ocnnected Device (DP only) Ocnnected Device (DP only) 0
Network Services	User Authentication	Devices Maintenance	e Quick Setup	☆ ? ⇔ 国
Auth Methods Loca	al/Remote Users NIS	LDAP RADIUS Kerber	os TACACS+ G	roups SSH Keys Custom Menus
		Local/Remote Us	er Settings	Help?
Login:		Enable for Dial-back:		Password:
Authentication:	Local Remote	Dial-back Number:		Retype Password:
UID:	101	Escape Sequence:	\x1bA	Password Expires:
Listen Ports:	1-48,U1,U2	Break Sequence:	\x1bB	Allow Password Change: 🕑
Data Ports:	1-48,U1,U2	Custom Menu:	<none> v</none>	Change Password on Next Login:
Clear Port Buffers:	1-48,U1,U2	Display Menu at Login:		Lock Account:
				Account Status: Active
Group	Default Users Power Users Administrators Custom Group: 	one> ▼		Each user is a member of a group which has predefined user rights associated with it. User rights that are associated with a group cannot be modified for individual users.
Full Administrative:		Local Users:		Firmware & Configuration:
Networking		Remote Authentication:		Internal Modem:
Services		SSH Keys:		Device Port Operations:
Secure Lantronix Network:		User Menus:		Device Port Configuration:
Date/Time:		Web Access:		USB:
Reboot & Shutdown:		Diagnostics & Reports:		SD Card:
RPMs:				
Sack to Local/Remot	te Users	Apply]	

Figure 12-4 User Authentication > Local/Remote User > Add/Edit User

2. Enter the following information for the user:

1

Login	User ID of selected user.
Authentication	 Select the type of authenticated user: Local: User listed in the SLC database. Remote: User not listed in the SLC database.
UID	A unique numeric identifier the system administrator assigns to each user. Valid UIDs are 101-4294967295. Note: The UID must be unique. If it is not, SLC unit automatically increments it. Starting at 101, the SLC 8000 advanced console manager finds the next unused UID.
Listen Ports	The device ports that the user may access to view data using the connect listen command. Enter the port numbers or the range of port numbers (for example, 1, 5, 8, 10-15). U1 and U2 denote the USB upper and lower ports on the front of the SLC unit.
Data Ports	The device ports with which the user may interact using the connect direct command. Enter the port numbers or the range of port numbers.
Clear Port Buffers	The device port buffers the users may clear using the set locallog clear command. Enter the port numbers or the range of port numbers.
Enable for Dial-back	Select to grant a local user dial-back access. Users with dial-back access can dial into the SLC unit and enter their login and password. Once the SLC 8000 advanced console manager authenticates them, the modem hangs up and dials them back. Disabled by default.
----------------------------------	--
Dial-back Number	The phone number the modem dials back on depends on this setting for the device port. The user is either dialed back on a fixed number (specified on the Device Port - Settings page), or on a number that is associated with the user's login (specified here).
Escape Sequence	A single character or a two-character sequence that causes the SLC unit to leave direct (interactive) mode. (To leave listen mode, press any key.)
	A suggested value is Esc+A (escape key, then uppercase "A" performed quickly but not simultaneously). You would specify this value as $x1bA$, which is hexadecimal (x) character 27 (1B) followed by an A .
	This setting allows the user to terminate the connect direct command on the command line interface when the endpoint of the command is deviceport, tcp, or udp.
	See <i>Key Sequences on page 179</i> for notes on key sequence precedence and behavior.
Break Sequence	A series of 1-10 characters users can enter on the command line interface to send a break signal to the external device. A suggested value is Esc+B (escape key, then uppercase "B" performed quickly but not simultaneously). You would specify this value as $x1bB$, which is hexadecimal (x) character 27 (1B) followed by a B .
	See <i>Key Sequences on page 179</i> for notes on key sequence precedence and behavior.
Custom Menu	If custom menus have been created, you can assign a default custom menu to the user. The custom menu will display at login.
	Note: In the Local Users table, if the menu assigned to a local user no longer exists, it is marked with an asterisk (*).
Display Menu at Login	If custom menus have been created, select to enable the menu to display when the user logs into the CLI.
Password / Retype Password	When a user logs into the SLC 8000 advanced console manager, the SLC unit prompts for a password (up to 64 characters). The sysadmin establishes that password here.
Password Expires	If not selected, allows the user to keep a password indefinitely. If selected the user keeps the password for a set period. (See the section, <i>Local and Remote User Settings (on page 214)</i> for information on specifying the length of time before the password expires.)
Allow Password Change	Select to allow the user to change password.
Change Password on Next Login	Indicate whether the user must change the password at the next login.
Lock Account	Select to lock the account indefinitely.
Account Status	Displays the current account status: Active Locked Locked (invalid logins)

3. In the **User Rights** section, select the user group to which local/remote users will belong.

Group	Select the group to which the local or remote user will belong:
	 Default Users: This group has only the most basic rights. You can specify additional rights for the individual user.
	 Power Users: This group has the same rights as Default Users plus Web
	Access, Networking, Date/Time, Reboot & Shutdown, and Diagnostics &
	Reports.
	 Administrators: This group has all possible rights.
	 Custom Group: Select a custom group from the drop-down menu.

4. Select or clear the checkboxes for the following rights:

Full Administrative	Right to add, update, and delete all editable fields.
Networking	Right to enter Network settings.
Services	Right to enable and disable system logging, SSH and Telnet logins, SNMP, and SMTP.
Secure Lantronix Network	Right to view and manage Secure Lantronix units (e.g., Spider, or SLC units) on the local subnet.
Date/Time	Right to set the date and time.
Reboot & Shutdown	Right to shut down and reboot the SLC unit.
Local Users	Right to add or delete local users on the system.
Remote Authentication	Right to assign a remote user to a user group and assign a set of rights to the user.
SSH Keys	Right to set SSH keys for authenticating users.
User Menus	Right to create a custom user menu for the CLI.
Web Access	Right to access Web-Manager.
Diagnostics & Reports	Right to obtain diagnostic information and reports about the unit.
Firmware & Configuration	Right to upgrade the firmware on the unit and save or restore a configuration (all settings). Selecting this option automatically selects Reboot & Shutdown .
Internal Modem	Right to update internal modem settings.
Device Port Operations	Right to control device ports.
Device Port Configuration	Right to enter device port settings.
USB	Right to enter modem settings for USB devices and control USB storage devices.
SD Card	Right to enter settings for SD card.
RPM	Right to manage and control remote power managers.

- 5. Click the **Apply** button.
- 6. Click the **Back to Local/Remote Users** link to return to the Local/Remote User Settings page.
- 7. Add another user or click the **Back to Local/Remote Users** link. The Local/Remote Users page displays with the new user(s) listed in the table.

Note: The logged-in user's name displays at the top of the web page. Only the tabs and options for which the user has rights display.

Shortcut

To add a user based on an existing user:

- 1. Display the existing user on the *User Authentication > Local/Remote Users* page. The fields in the top part of the page display the current values for the user.
- 2. Change the Login to that of the new user. It is best to change the Password too.
- 3. Click the **Apply** button.

To edit a local user:

- On the User Authentication > Local/Remote Users page, select the user and click the Add/ Edit User button. The Local/Remote User Settings page displays.
- 2. Update values as desired.
- 3. Click the **Apply** button.

To delete a local user:

- On the User Authentication > Local/Remote Users page, select the user and click the Add/ Edit User button. The Local/Remote User Settings page displays.
- 2. Click the **Delete User** button.
- 3. Click the Apply button.

To change the sysadmin password:

- On the User Authentication > Local/Remote Users page, select sysadmin and click the Add/ Edit User button. The Local/Remote User Settings page displays.
- 2. Enter the new password in the Password and Retype Password fields.

Note: You can change Escape Sequence and Break Sequence, if desired. You cannot delete the UID or change the UID, port permissions, or custom menu.

3. Click the Apply button.

Local Users Commands

Go to *Local Users Commands* to view CLI commands which correspond to the web page entries described above.

Remote User Rights Commands

Go to *Remote User Commands* to view CLI commands which correspond to the web page entries described above.

NIS

The system administrator can configure the SLC advanced console manager to use NIS to authenticate users attempting to log in to the SLC unit through the Web, SSH, Telnet, or the console port. If NIS does not provide port permissions, you can use this page to grant device port access to users who are authenticated through NIS.

All NIS users are members of a group that has predefined user rights associated with it. You can assign additional user rights that are not defined by the group.

To configure the SLC unit to use NIS to authenticate users:

1. Click the **User Authentication** tab and select the **NIS** option.

LANTRONI	(* SLC 804	48 LCD	SU1 E1 1 3	5 7 9 11 13 1	5 17 19 21 23 25 27 29 6 18 20 22 24 26 28 30	<mark>31</mark> 33 35 37 39 41 4 32 34 36 38 40 42 4	3 45 47 A
Logout Host:	slc4331 sysadmin		Select port for	Configuration (WebSSH (DP only)	Connected Device (DP o	nly)
Network Services Us	er Authentication	Devices	Maintenance	Quick Setup		岱?	₿ 🗉
Auth Methods Local/Rem	note Users NIS	LDAP RAD	UUS Kerberos	TACACS+	Groups SSH Keys	Custom Menus	
			NIS				Help?
Enable NIC:				The SLC o	an be configured to use	NIS to authenticate	users who
Enable NIS.				login to t	the SLC via SSH, Telnet	, the Web or the Cor	isole Port.
Note: The NIS	S Domain must match th	e			access throu	igh the port permissi	ions below.
NIS domain	name on the NIS Serve	r.					
Broadcast for INIS Server.							
NIS Slave Server #1:			Custom Monu:	<none></none>	 Data E 	Porte: 1-/8 1 2	
NIS Slave Server #1.			Custonn Menu.		- Data P	orts: 1.48.11.112	
NIS Slave Server #2.		ES	cape Sequence.		Listen P	orts. 1-48,01,02	
NIS Slave Server #3:		B	reak Sequence:	XIDB	Clear Port But	fers: 1-48,01,02	
NIS Slave Server #4:		Enat	le for Dial-back:				
NIS Slave Server #5:		Dia	al-back Number:				
			User Right	s			
Group:	 Default Users Power Users Administrators 		-		All NIS users has predefine defir	are members of a g d user rights associa Additional rights wh led by the group can	roup which ated with it. iich are not n be added.
Full Administrative:			Local Users		Firmware & Configura	ition:	
Networking:		Remo	te Authentication		Internal Mod	dem: 🔲	
Services:			SSH Keys		Device Port Operati	ions:	
Secure Lantronix Network:			User Menus		Device Port Configura	ition:	
Date/Time:			Web Access		ι	JSB:	
Reboot & Shutdown:		Diagn	ostics & Reports		SD C	Card: 🔲	
RPMs:							
			Apply				

Figure 12-5 User Authentication > NIS

2. Enter the following:

Enable NIS	Displays selected if you enabled this method on the Authentication Methods page. If you want to set up this authentication method but not enable it immediately, clear the checkbox.
	Note: You can enable NIS here or on the first User Authentication page. If you enable NIS here, it automatically displays at the end of the order of precedence on the User Authentication page.
NIS Domain	The NIS domain of the SLC 8000 advanced console manager must be the same as the NIS domain of the NIS server.
Broadcast for NIS Server	If selected, the SLC unit sends a broadcast datagram to find the NIS Server on the local network.
NIS Master Server	The IP address or host name of the master server.
NIS Slave Servers #1 -5	The IP addresses or host names of up to five slave servers.
Custom Menu	If custom menus have been created you can assign a default custom menu to NIS users.
Escape Sequence	A single character or a two-character sequence that causes the SLC 8000 advanced console manager to leave direct (interactive) mode. (To leave listen mode, press any key.)
	A suggested value is Esc+A (escape key, then uppercase "A" performed quickly but not simultaneously). You would specify this value as $x1bA$, which is hexadecimal (x) character 27 (1B) followed by an A .
	This setting allows the user to terminate the connect direct command on the command line interface when the endpoint of the command is deviceport, tcp, or udp.
	See <i>Key Sequences on page 179</i> for notes on key sequence precedence and behavior.
Break Sequence	A series of 1-10 characters users can enter on the command line interface to send a break signal to the external device. A suggested value is Esc+B (escape key, then uppercase "B" performed quickly but not simultaneously). You would specify this value as $x1bB$, which is hexadecimal (x) character 27 (1B) followed by a B .
Enable for Dial-back	Select to grant a user <i>Dial-back (on page 175)</i> . Users with dial-back access can dial into the SLC 8000 advanced console manager and enter their login and password. Once the SLC unit authenticates them, the modem hangs up and dials them back. Disabled by default.
Dial-back Number	The phone number the modem dials back on depends on this setting for the device port. The user is either dialed back on a fixed number, or on a number that is associated with the user's login (specified here).
Data Ports	The ports users are able to monitor and interact with using the connect direct command. Enter the port numbers or the range of port numbers (for example, 1, 5, 8, 10-15). U1 and U2 denote the USB upper and lower ports on the front of the SLC unit.
Listen Ports	The ports users are able to monitor using the connect listen command.
Clear Port Buffers	The ports whose port buffer users may clear using the set locallog clear command.

3. In the User Rights section, select the user Group to which NIS users will belong:

Group	Select the group to which the NIS users will belong:
	 Default Users: This group has only the most basic rights. You can specify additional rights for the individual user . Power Users: This group has the same rights as Default Users plus Web
	 Access, Networking, Date/Time, Reboot & Shutdown, and Diagnostics & Reports. Administrators: This group has all possible rights.

4. Assign or unassign **User Rights** for the specific user by checking or unchecking the following checkboxes:

Full Administrative	Right to add, update, and delete all editable fields.
Networking	Right to enter Network settings.
Services	Right to enable and disable system logging, SSH and Telnet logins, SNMP, and SMTP.
Secure Lantronix Network	Right to view and manage secure Lantronix units (e.g., Spider, or SLC units) on the local subnet.
Date/Time	Right to set the date and time.
Reboot & Shutdown	Right to shut down and reboot the SLC unit.
Local Users	Right to add or delete local users on the system.
Remote Authentication	Right to assign a remote user to a user group and assign a set of rights to the user.
SSH Keys	Right to set SSH keys for authenticating users.
User Menus	Right to create a custom user menu for the CLI.
Web Access	Right to access Web-Manager.
Diagnostics & Reports	Right to obtain diagnostic information and reports about the unit.
Firmware & Configuration	Right to upgrade the firmware on the unit and save or restore a configuration (all settings). Selecting this option automatically selects Reboot & Shutdown .
Internal Modem	Right to update internal modem settings.
Device Port Operations	Right to control device ports.
Device Port Configuration	Right to enter device port settings.
USB	Right to enter modem settings for USB devices and control USB storage devices.
SD Card	Right to enter settings for SD card.
RPM	Right to manage and control remote power managers.

5. Click the **Apply** button.

Note: You must reboot the unit before your changes will take effect.

NIS Commands

Go to *NIS Commands* to view CLI commands which correspond to the web page entries described above.

LDAP

The system administrator can configure the SLC 8000 advanced console manager to use LDAP to authenticate users attempting to log in using the Web, Telnet, SSH, or the console port.

LDAP allows SLC unit users to authenticate using a wide variety of LDAP servers, such as OpenLDAP and Microsoft Active Directory. The LDAP implementation supports LDAP servers that do not allow anonymous queries.

Users who are authenticated through LDAP are granted device port access through the port permissions on this page.

All LDAP users are members of a group that has predefined user rights associated with it. You can add additional user rights that are not defined by the group.

To configure the SLC unit to use LDAP to authenticate users:

1. Click the **User Authentication** tab and select **LDAP**. The following page displays.

	Figur	LCD SD U1 E1 1 3	5 7 9 11 13 15 17	DAP 19 21 23 25 27 29 31 <mark>3</mark> 3	35 37 39 41 43	45 47 🔼
Logout	lost: slc4331 Jser: sysadmin	Select port for	6 8 10 12 14 16 18 Configuration Wel	20 22 24 26 28 30 32 34	36 38 40 42 44	46 48 B y)
Network Services	User Authentication	evices Maintenance	Quick Setup		础?	₿ E
Auth Methods	I/Remote Lisers NIS D	AP RADIUS Kerberos	TACACS+ Gro	uns SSH Keys Cur	stom Menus	
Auth methods Loca	Inteniote Osers ING LD	A RADIOS Reiberos		ups sonneys ou.	storn merius	
		LDAP				Help?
Enable DAP:			The SLC can be co	onfigured to use I DAP to	o authenticate u	sers who
Server #1:			login to the SL	C via SSH, Telnet, the V	Web or the Cons	sole Port.
Server #1:			ii port j	LDAP users	are granted Dev	/ice Port
Server #2.	290			access through the	e port permissior	is below.
Port.	389					
Base:	(ovample: do=domain do=com)					
Bind Name:	(example: dc=domain,dc=com)	Custom Menu:	<none> V</none>	Data Ports:	1-48.U1.U2	
Bind Password:		Escape Sequence:	\x1bA	Listen Ports:	1-48 U1 U2	
Retype Password:		Break Sequence:	\x1bB	Clear Port Buffers	1_48 11 12	
Rind with Login:	'\$login' in the Bind Name will	Enable for Dial-back:		olour r olt Bulleto.	1-40,01,02	
Bind with Ebgin.	be substituted with the login					
Group Filter		Dial-back Number:				
Objectclass:						
Group Member Attribute:						
Group Member Value:	DN Name					
Use LDAP Schema:	for User Attributes and Perm	issions				
Active Directory						
Encrypt Messages:	Disabled Start TLS	SSI				
Certificate Authority:		Upload File >				
Certificate File:		Upload File				
Kev File:		Upload File				
		opiouurite				
		User Rights				
	Default Users	eeer rugine		All LDAP users are m	embers of a gro	up which
G	roup: 🔵 Power Users			has predefined user Addit	r rights associate ional rights whic	ed with it. h are not
	Administrators			defined by	the group can b	e added.
Full Administra	ative:	Local Users:	E Firm	nware & Configuration:		
Networ	rking:	Remote Authentication:		Internal Modem:		
Serv	/ices:	SSH Keys:		evice Port Operations:		
Secure Lantronix Net	work:	User Menus:	Dev	vice Port Configuration:		
Date/1	Time:	Web Access:		USB:		
Reboot & Shutd	lown:	Diagnostics & Reports:		SD Card:		
R	PMs:					
		Apply				
2. Enter the fo	ollowing:					

Figure 12-6 User Authentication > LDAP

Enable LDAP	Displays selected if you enabled this method on the first User Authentication page.
	If you want to set up this authentication method but not enable it immediately, clear
	the checkbox.

Server #1 (or Server #2)	The IPv4 or IPv6 address or host name of the primary and secondary LDAP servers. The secondary LDAP server will be used for authentication in the event that the primary LDAP server cannot be reached.
Port	Number of the TCP port on the LDAP server to which the SLC talks. The default is 389 .
Base	The name of the LDAP search base (e.g., dc=company, dc=com). May have up to 80 characters.
Bind Name	The name for a non-anonymous bind to an LDAP server. This item has the same format as LDAP Base. One example is cn=administrator,cn=Users,dc=domain,dc=com
Bind Password / Retype Password	Password for a non-anonymous bind. This entry is optional. Acceptable characters are a-z , A-Z , and 0-9 . The maximum length is 127 characters.
Bind with Login	Select to bind with the login and password that a user is authenticating with. This requires that the Bind Name contain the <pre>\$login</pre> token, which will be replaced with the current login. For example, if the Bind Name is <pre>uid=\$login,ou=People,dc=lantronix,dc=com, and user roberts</pre> logs into the SLC 8000 advanced console manager, LDAP will bind with <pre>uid=roberts,ou=People,dc=lantronix,dc=com</pre> and the password entered by roberts.
User Login Attribute	The attribute used by the LDAP server for user logins. If nothing is specified for the user filter, the SLC unit will use "uid". For AD LDAP servers, the attribute for user logins is typically "sAMAccountName".
Group Filter Objectclass	The objectclass used by the LDAP server for groups. If nothing is specified for the group filter, the SLC 8000 advanced console manager will use "posixGroup". For AD LDAP servers, the objectclass for groups is typically "Group".
Group Member Attribute	The attribute used by the LDAP server for group membership. This attribute may be use to search for a name (ie, "msmith") or a Distinguished Name (ie, "uid=msmith,ou=People,dc=lantronix,dc=com"). Select either Name or DN as appropriate for the LDAP server. If nothing is specified for the group membership attribute, the SLC unit will use "memberUID" for name and "uniqueMember" for DN. For AD LDAP servers, the Group Membership Value is typically DN, with the Group Membership Attribute of "member".
Group Member Value	The attribute used by the LDAP server for group membership. This attribute may be use to search for a name (ie, "msmith") or a Distinguished Name (ie, "uid=msmith,ou=People,dc=lantronix,dc=com"). Select either Name or DN as appropriate for the LDAP server. If nothing is specified for the group membership attribute, the SLC 8000 advanced console manager will use "memberUID" for name and "uniqueMember" for DN. For AD LDAP servers, the Group Membership Value is typically DN, with the Group Membership Attribute of "member".
Use LDAP Schema	Select the check box to obtain remote user attributes (group/permissions and port access) from an Active Directory server's scheme via the user attribute 'Secure LantronixPerms' (see details below). Disabled by default.
Active Directory Support	Select to enable. Active Directory is a directory service from Microsoft that is a part of Windows 2000 and later versions of Windows. It is LDAP- and Kerberos-compliant. Disabled by default.

Encrypt Messages	Select Start TLS or SSL to encrypt messages between the SLC unit and the LDAP server. If Start TLS is selected, the port will automatically be set to 389 and the StartTLS extension will be used to initiate a secure connection; if SSL is selected, the port will automatically be set to 636 and a SSL tunnel will be used for LDAP communication. The port number can be changed to a non-standard LDAP port; if the port number is set to anything other than 636, Start TLS will be used as the encryption method. Disabled by default.
Certificate Authority	A certificate can be uploaded to the SLC unit for peer authentication. In non-FIPS
Certificate File	file (with an optional Key file), or both. A Key file alone is not a valid certificate. In
Key File	FIPS mode, all 3 files (CA, certificate and key) are required. The Certificate Authority and Certificate File are in PEM format, for instance:
	BEGIN CERTIFICATE
	(certificate in base64 encoding) END CERTIFICATE
	The Key File is in PEM format, eg:
	BEGIN RSA PRIVATE KEY
	(private key in base64 encoding)
	END RSA PRIVATE KEY
Custom Menu	If custom menus have been created, you can assign a default custom menu to LDAP users. (See "Custom Menus" on page 248.)
Escape Sequence	A single character or a two-character sequence that causes the SLC 8000 advanced console manager to leave direct (interactive) mode. (To leave listen mode, press any key.)
	A suggested value is Esc+A (escape key, then uppercase "A" performed quickly but not simultaneously). You would specify this value as \x1bA , which is hexadecimal (\x) character 27 (1B) followed by an A .
	This setting allows the user to terminate the connect direct command on the command line interface when the endpoint of the command is deviceport, tcp, or udp.
	See <i>Key Sequences on page 179</i> for notes on key sequence precedence and behavior.
Break Sequence	A series of 1-10 characters users can enter on the command line interface to send a break signal to the external device. A suggested value is Esc+B (escape key, then uppercase "B" performed quickly but not simultaneously). You would specify this value as $x1bB$, which is hexadecimal (x) character 27 (1B) followed by a B.
Enable for Dial-back	Select to grant a user dial-back access. Users with dial-back access can dial into the SLC unit and enter their login and password. Once the SLC 8000 advanced console manager authenticates them, the modem hangs up and dials them back. Disabled by default.
Dial-back Number	The phone number the modem dials back on depends on this setting for the device port. The user is either dialed back on a fixed number, or on a number that is associated with the user's login (specified here).
Data Ports	The ports users are able to monitor and interact with using the connect direct command. U1 and U2 denote the USB upper and lower ports on the front of the SLC unit.
Listen Ports	The ports users are able to monitor using the connect listen command.
Clear Port Buffers	The ports whose port buffer users may clear using the set locallog clear command.

3. In the User Rights section, select the user group to which LDAP users will belong:

roup has aply the most basis rights. You can aposify
e individual user. Toup has the same rights as Default Users plus Web , Date/Time, Reboot & Shutdown, and Diagnostics &
r

4. Select or clear the checkboxes for the following rights:

Full Administrative	Right to add, update, and delete all editable fields.
Networking	Right to enter Network settings.
Services	Right to enable and disable system logging, SSH and Telnet logins, SNMP, and SMTP.
Secure Lantronix Network	Right to view and manage secure Lantronix units (e.g., Spider, or SLC devices) on the local subnet.
Date/Time	Right to set the date and time.
Reboot & Shutdown	Right to shut down and reboot the SLC unit.
Local Users	Right to add or delete local users on the system.
Remote Authentication	Right to assign a remote user to a user group and assign a set of rights to the user.
SSH Keys	Right to set SSH keys for authenticating users.
User Menus	Right to create a custom user menu for the CLI.
Web Access	Right to access Web-Manager.
Diagnostics & Reports	Right to obtain diagnostic information and reports about the unit.
Firmware & Configuration	Right to upgrade the firmware on the unit and save or restore a configuration (all settings). Selecting this option automatically selects Reboot & Shutdown .
Internal Modem	Right to configure internal modem settings.
Device Port Operations	Right to control device ports.
Device Port Configuration	Right to enter device port configurations.
USB	Right to enter modem settings for USB.
SD Card	Right to view and enter settings for SD card.
RPM	Right to manage and control remote power managers.

5. Click the **Apply** button.

Note: You must reboot the unit before your changes will take effect.

LDAP Commands

Go to *LDAP Commands* to view CLI commands which correspond to the web page entries described above.

RADIUS

The system administrator can configure the SLC 8000 advanced console manager to use RADIUS to authenticate users attempting to log in using the Web, Telnet, SSH, or the console port.

Users who are authenticated through RADIUS are granted device port access through the port permissions on this page.

All RADIUS users are members of a group that has predefined user rights associated with it. You can add additional user rights that are not defined by the group.

To configure the SLC unit to use RADIUS to authenticate users:

1. Click the User Authentication tab and select RADIUS. The following page displays.

Figure 12-7 User Authentication > RADIUS					
LANTRONI	(° SLC 8048	LCD <mark>SD</mark> U1 <mark>E1</mark> 1 3 U2 <mark>E2</mark> 2 4	5 7 9 11 13 15 6 8 10 12 1 <u>4 16</u>	17 19 21 23 25 27 29 31 <mark>33</mark> 18 20 22 24 26 28 30 <u>32 34</u>	35 37 39 41 43 45 47 A 36 38 40 42 44 46 48 B
Logout Host: User:	slc4331 sysadmin	Select port for	Configuration	WebSSH (DP only) 🔵 Conne	cted Device (DP only)
Network Services Us	er Authentication	vices Maintenance	Quick Setup		💩 ? 🔂 🗉
Auth Methods Local/Rem	note Users NIS LDA	P RADIUS Kerberos	TACACS+ G	roups SSH Keys Cus	tom Menus
		RADIUS			Help?
Enable RADIUS: RADIUS Server #1: Server #1 Port:	1812		The SLC can be c login to the	onfigured to use RADIUS e SLC via SSH, Telnet, the RADIUS users access through th	to authenticate users who Web or the Console Port. are granted Device Port e port permissions below.
Server #1 Secret:					
RADIUS Server #2:		Custom Menu:	<none> •</none>	Data Ports:	1-48,U1,U2
Server #2 Port:	1812	Escape Sequence:	\x1bA	Listen Ports:	1-48,U1,U2
Server #2 Secret:		Break Sequence:	\x1bB	Clear Port Buffers:	1-48,U1,U2
Timeout:	30 seconds	Enable for Dial-back:			
Use VSA:	for User Attributes and Permissions	Dial-back Number:			
		User Right	5		
Group:	 Default Users Power Users Administrators 			All RADIUS users are n has predefined use Addi defined by	nembers of a group which r rights associated with it. tional rights which are not the group can be added.
Full Administrative:		Local Users:		Firmware & Configuration:	
Networking:		Remote Authentication:		Internal Modem:	
Services:		SSH Keys:		Device Port Operations:	
Secure Lantronix Network:		User Menus:		Device Port Configuration:	
Date/Time:		Web Access:		USB:	
Reboot & Shutdown:		Diagnostics & Reports:		SD Card:	
RPMs:					
		Apply			

2. Enter the following:

Enable RADIUS	Displays selected if you enabled this method on the User Authentication page. If you want to set up this authentication method but not enable it immediately, clear the checkbox.
	Note: You can enable RADIUS here or on the first User Authentication page. If you enable RADIUS here, it automatically displays at the end of the order of precedence on the User Authentication page.
RADIUS Server #1	IPv4 or IPv6 address or hostname of the primary RADIUS server. This RADIUS server may be a proxy for SecurID.
	SecurID is a two-factor authentication method based on the user's SecurID token and pin number. The SecurID token displays a string of digits called a token code that changes once a minute (some tokens are set to change codes every 30 seconds).
Server #1 Port	Number of the TCP port on the RADIUS server used for the RADIUS service. If you do not specify an optional port, the SLC unit uses the default RADIUS port (1812).
Server #1 Secret	Text that serves as a shared secret between a RADIUS client and the server (SLC unit). The shared secret is used to encrypt a password sent between the client and the server. May have up to 128 characters.
RADIUS Server #2	IPv4 or IPv6 address or host name of the secondary RADIUS server. This server can be used as a SecurID proxy.
Server #2 Port	Number of the TCP port on the RADIUS server used for the RADIUS service. If you do not specify an optional port, the SLC 8000 advanced console manager uses the default RADIUS port (1812).
Server #2 Secret	Text that serves as a shared secret between a RADIUS client and the server (SLC unit). The shared secret is used to encrypt a password sent between the client and the server. May have up to 128 characters.
Timeout	The number of seconds (1-30) after which the connection attempt times out. The default is 30 seconds.
Use VSA	Select the check box to obtain remote user attributes (group/permissions and port access) from the RADIUS server via the Vendor-Specific Attribute (VSA). For details on the format of the VSA, see <i>User Attributes & Permissions from LDAP Schema or RADIUS VSA on page 231</i> .
Custom Menu	If custom menus have been created, you can assign a default custom menu to RADIUS users.
Escape Sequence	A single character or a two-character sequence that causes the SLC unit to leave direct (interactive) mode. (To leave listen mode, press any key.)
	A suggested value is Esc+A (escape key, then uppercase "A" performed quickly but not simultaneously). You would specify this value as $x1bA$, which is hexadecimal (x) character 27 (1B) followed by an A .
	This setting allows the user to terminate the connect direct command on the command line interface when the endpoint of the command is deviceport, tcp, or udp.
	See <i>Key Sequences on page 179</i> for notes on key sequence precedence and behavior.
Break Sequence	A series of 1-10 characters users can enter on the command line interface to send a break signal to the external device. A suggested value is Esc+B (escape key, then uppercase "B" performed quickly but not simultaneously). You would specify this value as \x1bB , which is hexadecimal (\x) character 27 (1B) followed by a B .

Enable for Dial-back	Select to grant a user dial-back access. Users with dial-back access can dial into the SLC 8000 advanced console manager and enter their login and password. Once the SLC device authenticates them, the modem hangs up and dials them back. Disabled by default.
Dial-back Number	The phone number the modem dials back on depends on this setting for the device port. The user is either dialed back on a fixed number, or on a number that is associated with the user's login (specified here).
Data Ports	The ports users are able to monitor and interact with using the connect direct command. U1 and U2 denote the USB upper and lower ports on the front of the SLC unit.
Listen Port	The ports users are able to monitor using the connect listen command.
Clear Port Buffers	The ports whose port buffer users may clear using the set locallog clear command.

Note: Older RADIUS servers may use **1645** as the default port. Check your RADIUS server configuration.

3. In the **User Rights** section, select the user group to which RADIUS users will belong.

Group	Select the group to which the RADIUS users will belong:
	 Default Users: This group has only the most basic rights. You can specify additional rights for the individual user.
	 Power Users: This group has the same rights as Default Users plus Web Access, Networking, Date/Time, Reboot & Shutdown, and Diagnostics & Reports. Administrators: This group has all possible rights.

4. Select or clear the checkboxes for the following rights:

Full Administrative	Right to add, update, and delete all editable fields.
Networking	Right to enter Network settings.
Services	Right to enable and disable system logging, SSH and Telnet logins, SNMP, and SMTP.
Secure Lantronix Network	Right to view and manage Secure Lantronix units (e.g., Spider, or SLC units) on the local subnet.
Date/Time	Right to set the date and time.
Reboot & Shutdown	Right to shut down and reboot the SLC unit.
Local Users	Right to add or delete local users on the system.
Remote Authentication	Right to assign a remote user to a user group and assign a set of rights to the user.
SSH Keys	Right to set SSH keys for authenticating users.
User Menus	Right to create a custom user menu for the CLI.
Web Access	Right to access Web-Manager.
Diagnostics & Reports	Right to obtain diagnostic information and reports about the unit.
Firmware & Configuration	Right to upgrade the firmware on the unit and save or restore a configuration (all settings). Selecting this option automatically selects Reboot & Shutdown .
Internal Modem	Right to update internal modem settings.

Device Port Operations	Right to control device ports.
Device Port Configuration	Right to enter device port settings.
USB	Right to enter modem settings for USB devices and control USB storage devices.
SD Card	Right to enter settings for SD card.
RPM	Right to manage and control remote power managers.

5. Click the **Apply** button.

RADIUS Commands

Go to *RADIUS Commands* to view CLI commands which correspond to the web page entries described above.

User Attributes & Permissions from LDAP Schema or RADIUS VSA

Remote user attributes (group/permissions and port access) can be obtained from an Active Directory server's schema via the user attribute 'secureLinxSLCPerms', or from a RADIUS server's Vendor-Specific Attribute (see below). This attribute is a set of parameter-value pairs. Each parameter and value is separated by a space, and a space separates each parameter-value pair. Whitespace is not supported in the value strings. The parameters that are supported are:

- rights User rights. The value string is a comma-separated list of two letter user permissions. Example: "nt,wb,ra".
- data Data port access. The value string specifies the list of ports the user has 'direct' access to. Example: "2,4-18,U1,U2".
- listen Listen port access. The value string specifies the list of ports the user has 'listen' access to.
- clear Clear port access. The value string specifies the list of port buffers the user has the right to clear.
- **group** User group. Valid values for the value string are "default", "power", and "admin", and any SLC custom group name. If a custom group name is specified and it matches a current SLC custom group name, any rights attribute will be ignored, and the custom group's rights (permissions) will be used instead. A group name with spaces cannot be specified.
- escseq Escape sequence. The value string specifies the user's escape sequence. Use "\x" to specify non-printable characters. For example, "\x1bA" specifies the sequence "ESC-A".
- brkseq Break sequence. The value string specifies the user's break sequence.
- **menu** Custom user menu. The value string specifies the user's custom user menu.
- display Display custom user menu when a user logs into the CLI. Valid values for the value string are "yes" and "no".
- dbnumber Dial-back number. The value string specifies the user's dial-back number for modem dial-back connections.
- allowdb Allow a user to have dial-back access. Valid values for the value string are "yes" and "no".

RADIUS servers will need to be configured to support the Lantronix Vendor-Specific Attribute. For example, on a FreeRADIUS server, the dictionary will need be updated with the Lantronix definition by including the contents below in a file named *dictionary.lantronix*, and including it in the

RADIUS server dictionary definitions by adding the appropriate \$INCLUDE directive to the main dictionary file.

```
# dictionary.lantronix
#
# Lantronix SLC Console Manager
# Provides SLC-specific user attributes
#
VENDOR Lantronix 244
BEGIN-VENDOR Lantronix
ATTRIBUTE Lantronix-User-Attributes 1 string
END-VENDOR Lantronix
```

Once this is complete, the users file can be updated to include the Lantronix VSA for any user:

```
myuser Auth-Type := Local, User-Password == "myuser_pwd"
Reply-Message = "Hello, %u",
Lantronix-User-Attributes = "data 1-4 listen 1-6 clear 1-4
group power"
```

Kerberos

Kerberos is a network authentication protocol that provides strong authentication for client/server applications by using secret-key cryptography.

The system administrator can configure the SLC 8000 advanced console manager to use Kerberos to authenticate users attempting to log in using the Web, Telnet, SSH, or the console port.

Users who are authenticated through Kerberos are granted device port access through the port permissions on this page.

All Kerberos users are members of a group that has predefined user rights associated with it. You can add additional user rights that are not defined by the group.

To configure the SLC 8000 advanced console manager to use Kerberos to authenticate users:

1. Click the **User Authentication** tab and select the **Kerberos** option. The following page displays.

	Figure 12-	8 User Authen	tication > Ke	erberos	
LANTRONIX	[®] SLC 8048	LCD <mark>SD</mark> U1 <mark>E1</mark> 1 3 U2 <mark>E2</mark> 2 4	5 7 9 11 13 15 6 8 10 12 14 16	17 19 21 23 25 27 29 31 <mark>33</mark> 18 20 22 24 26 28 30 32 <mark>34</mark>	35 37 39 41 43 45 47 🔺 36 38 40 42 44 46 48 🖪
Logout Host: slo User: sy	c4331 /sadmin	Select port for	Configuration	WebSSH (DP only) OConne	cted Device (DP only)
Network Services User	Authentication Devi	ces Maintenance	Quick Setup		合? 🗗 🗉
Auth Methods Local/Remo	te Users NIS LDAP	RADIUS Kerberos	TACACS+ G	roups SSH Keys Cus	tom Menus
		Kerbero	\$		Help?
Enable Kerberos:			The SI C can be c	onfigured to use Kerberos	to authenticate users who
Realm:			login to the	e SLC via SSH, Telnet, the	Web or the Console Port.
KDC:				access through th	e port permissions below.
KDC IP Address:					
KDC Port: 8	8	Custom Menu:	<none> •</none>	Data Ports:	1-48,U1,U2
Use LDAP:		Escape Sequence:	\x1bA	Listen Ports:	1-48,U1,U2
Note: If L	DAP is used for user lookup,	Break Sequence:	\x1bB	Clear Port Buffers:	1-48,U1,U2
please con	ligure the <u>LDAP settings</u> 7.	Enable for Dial-back:			
		Dial-back Number:			
		User Right	5		nomboro of a group which
Group: (Default Users			has predefined use	r rights associated with it.
(Administrators			Addi defined by	tional rights which are not / the group can be added.
Full Administrative:	3	Local Users:		Firmware & Configuration:	
Networking:		Remote Authentication:		Internal Modem:	
Services:		SSH Keys:		Device Port Operations:	
Secure Lantronix Network:		User Menus:		Device Port Configuration:	
Date/Time:		Web Access:		USB:	
Reboot & Shutdown:		Diagnostics & Reports:		SD Card:	
RPMs: [
		Apply			
2. Enter the followin	ıg:				
Enable Kerberos	Displays selecte	d if you enabled	this method	on the User Auther	tication page. If
	you want to set u the checkbox.	up this authentic	ation method	but not enable it in	nmediately, clear
	Note: You can	enable Kerberos	here or on th	ne first User Auther	ntication page. If
	you enable Kerb precedence on t	he User Authent	ication page.	plays at the end of	the order of
Realm	Enter the name	of the logical net	work served	by a single Kerbero	s database and a
	differentiate the NT domain.	realm from the Ir	Jsually, realm nternet doma	n names are all upp in. Realm is similar	in concept to an
KDC	A key distribution	n center (KDC) is	a server that	t issues Kerberos ti	ckets. A ticket is a
	particular service	eiectronic crede	intials that ve	rify the identity of a	client for a

Enter the KDC in the fully qualified domain format (FQDN). An example is

KDC Port	Port on the KDC listening for requests. Enter an integer with a maximum value of 65535. The default is 88 .			
Use LDAP	Indicate whether Kerberos should rely on LDAP to look up user IDs and Group IDs. This setting is disabled by default.			
	Note: Make sure to configure LDAP if you select this option.			
Custom Menu	If custom menus have been created, you can assign a default custom menu to RADIUS users.			
Escape Sequence	A single character or a two-character sequence that causes the SLC 8000 advanced console manager to leave direct (interactive) mode. (To leave listen mode, press any key.)			
	A suggested value is Esc+A (escape key, then uppercase "A" performed quickly but not simultaneously). You would specify this value as \ x1bA , which is hexadecimal (\ x) character 27 (1B) followed by an A .			
	This setting allows the user to terminate the connect direct command on the command line interface when the endpoint of the command is deviceport, tcp, or udp.			
	See <i>Key Sequences on page 179</i> for notes on key sequence precedence and behavior.			
Break Sequence	A series of 1-10 characters users can enter on the command line interface to send a break signal to the external device. A suggested value is Esc+B (escape key, then uppercase "B" performed quickly but not simultaneously). You would specify this value as $x1bB$, which is hexadecimal (x) character 27 (1B) followed by a B .			
Enable for Dial-back	Select to grant a user dial-back access. Users with dial-back access can dial into the SLC 8000 advanced console manager and enter their login and password. Once the SLC unit authenticates them, the modem hangs up and dials them back. Disabled by default.			
Dial-back Number	The phone number the modem dials back on depends on this setting for the device port. The user is either dialed back on a fixed number, or on a number that is associated with the user's login (specified here).			
Data Ports	The ports users are able to monitor and interact with using the connect direct command. U1 and U2 denote the USB upper and lower ports on the front of the SLC unit.			
Listen Port	The ports users are able to monitor using the connect listen command.			
Clear Port Buffers	The ports whose port buffer users may clear using the set locallog clear command.			
3. In the User Right	ts section, select the user group to which Kerberos users will belong.			
Group	 Select the group to which the Kerberos users will belong: Default Users: This group has only the most basic rights. You can specify additional rights for the individual user 			

- Power Users: This group has the same rights as Default Users plus Web Access, Networking, Date/Time, Reboot & Shutdown, and Diagnostics & Reports.
 Administrators: This group has all possible rights.

4. Select or clear the checkboxes for the following rights:

Full Administrative	Right to add, update, and delete all editable fields.		
Networking	Right to enter Network settings.		
Services	Right to enable and disable system logging, SSH and Telnet logins, SNMP, and SMTP.		

Secure Lantronix Network	Right to view and manage secure Lantronix units (e.g.,Spider, or SLC units) on the local subnet.
Date/Time	Right to set the date and time.
Reboot & Shutdown	Right to shut down and reboot the SLC unit.
Local Users	Right to add or delete local users on the system.
Remote Authentication	Right to assign a remote user to a user group and assign a set of rights to the user.
SSH Keys	Right to set SSH keys for authenticating users.
User Menus	Right to create a custom user menu for the CLI.
Web Access	Right to access Web-Manager.
Diagnostics & Reports	Right to obtain diagnostic information and reports about the unit.
Firmware & Configuration	Right to upgrade the firmware on the unit and save or restore a configuration (all settings). Selecting this option automatically selects Reboot & Shutdown .
Internal Modem	Right to update internal modem settings.
Device Port Operations	Right to control device ports.
Device Port Configuration	Right to enter device port settings.
USB	Right to enter modem settings for USB devices and control USB storage devices.
SD Card	Right to enter settings for SD card.
RPM	Right to manage and control remote power managers.

5. Click the **Apply** button.

Note: You must reboot the unit before your changes will take effect.

Kerberos Commands

Go to *Kerberos Commands* to view CLI commands which correspond to the web page entries described above.

TACACS+

Similar to RADIUS, the main function of TACACS+ is to perform authentication for remote access. The SLC 8000 advanced console manager supports the TACACS+ protocol (not the older TACACS or XTACACS protocols).

The system administrator can configure the SLC unit to use TACACS+ to authenticate users attempting to log in using the Web, Telnet, SSH, or the console port.

Users who are authenticated through TACACS+ are granted device port access through the port permissions on this page.

All TACACS+ users are members of a group with associated predefined user rights. You may add additional user rights that are not defined by the group.

TACACS+ Groups

This section describes how a priv_lvl assigned to a TACACS+ user can be mapped to a SLC custom *Groups*, which will set the permissions and port rights for a TACACS+ user when they login to the SLC.

TACACS+ users are typically configured to have a privilege level 0-15, with each level representing a privilege level that is a superset of the next lower value. The privilege level can be assigned to individual users, or to groups that the user is a member of. When the SLC authenticates a TACACS+ user, it will first send an authentication request to the TACACS+ server, and wait for an authentication reply. If the user is successfully authenticated, the SLC will next send an authorization request to the TACACS+ server with the **Service** and optional **Protocol**. The SLC will wait for an authorization response that will indicate if the user was successfully authorized for the requested service and protocol, and also contains a set of attribute-value pairs which define the attributes associated with the TACACS+ user.

The **priv_lvl** or **priv-lvl** is the only attribute sent from the TACACS+ server that the SLC will recognize and utilize. The privilege level number will be used to map to a SLC custom user group by finding a group with a name that ends in the same number as the priv_lvl. For example, a SLC group called "admin15" will map to any TACACS+ users with priv_lvl equal to 15; a SLC group called "manager8" will map to any TACACS+ users with priv_lvl equal to 8, and a SLC group called "readonly0" will map to any TACACS+ users with priv_lvl equal to 0. If two SLC groups ending with the same number exist, the SLC will select the first matching group it finds while searching the group list; for consistency it is recommended that only one SLC group exist for each priv_lvl.

When a TACACS+ user authenticates to the SLC, the Authentication Log will record any priv_lvl attribute-value pair returned by the TACACS+ server:

Sep 21 15:44:38 2017 slc431d SLC-SLB/x15login[2839]:
pam_sm_authenticate: server returned attribute `PRIV_LVL=14'

Any priv_lvl obtained for a TACACS+ user can also be viewed at the CLI with the show user command.

To configure the SLC unit to use TACACS+ to authenticate users:

1. Click the **TACACS+** tab and select **TACACS+**. The following page displays.

	Figure 1	2-9 User Authentica	tion > TACA	CS+
LANTRON	X° SLC 80	48 LCD SD U1 MD E1 1 3	5 7 9 11 13 15 <mark>17</mark>	19 21 23 25 27 29 31 33 35 37 39 41 43 45 47 A
Logout	ost: slc4331	Select port for	6 8 10 12 14 16 16 Configuration WebS	20 22 24 26 28 30 32 34 36 38 40 42 44 46 48 B SSH (DP only) Connected Device (DP only)
Naturalk Samiana		Daviasa Maintananaa	Quick Setur	☆ ? 国
Auth Methods	Remote Lisers NIS	DAP RADIUS Kerberos	TACACS+ Grou	ns SSH Kevs Custom Menus
Addit Methods - Loodi			Nonoo. orou	
		TACACS+		Help?
Enable TACACS+		The S	LC can be configure	ed to use TACACS+ to authenticate users who
TACACS+ Server #1:			login to the SEC	TACACS+ users are granted Device Port
TACACS+ Server #2:				access through the port permissions below.
TACACS+ Server #3:				
Secret:		Custom Menu:	<none> •</none>	Data Ports: 1-48,U1,U2
Retype Secret:		Escape Sequence:	\x1bA	Listen Ports: 1-48,U1,U2
Encrypt Messages:		Break Sequence:	\x1bB	Clear Port Ruffors: 1-48,U1,U2
	ASCII Login	Enable for Dial-		
Authentication Service:		back:		7
Convine		Dial-back Number.		
Service.	Shell			
Protocol:				
limeout:	5 seconds			
	Default Harris	User Rights	All TA	ACACS+ users are members of a group which
Gro	Up: Operation Default Users			has predefined user rights associated with it.
	Administrators			defined by the group can be added.
Full Administrat	ive:	Local Users:	Firmw	are & Configuration:
Networki	ing:	Remote Authentication:		Internal Modem:
Servio	ces:	SSH Keys:	Dev	ice Port Operations:
Secure Lantronix Netwo	ork: 🔲	User Menus:	Device	e Port Configuration:
Date/Tir	me:	Web Access:		USB:
Reboot & Shutdo	wn:	Diagnostics & Reports:		SD Card:
RP	Ms: 🛄			
		Apply		

2. Enter the following:

Enable TACACS+	Displays selected if you enabled this method on the User Authentication page. If you want to set up this authentication method but not enable it immediately, clear the checkbox.
	You can enable TACACS+ here or on the first User Authentication page. If you enable TACACS+ here, it automatically displays at the end of the order of precedence on the User Authentication page.
TACACS+ Servers 1-3	IPv4 or IPv6 address or host name of up to three TACACS+ servers.
Secret/Retype Secret	Shared secret for message encryption between the SLC 8000 advanced console manager and the TACACS+ server. Enter an alphanumeric secret of up to 127 characters.
Encrypt Messages	Select the checkbox to encrypt messages between the SLC unit and the TACACS+ server. Selected by default.

Authentication Service	The type of service used to pass the authentication tokens (e.g., login and password) between the SLC and the TACACS+ server. Options are: ASCII Login (login and password are transmitted in clear, unencrypted text), PPP/PAP (login and password are transmitted in clear, unencrypted text via a PAP protocol packet), and PPP/CHAP (the TACACS+ server sends a challenge that consists of a session ID and an arbitrary challenge string, and the user name and password are encrypted before they are sent back to the server). PPP/PAP is the default.
Service	server to obtain an authenticated user's priv_lvl. The priv_lvl is used to assign a SLC custom group to the authenticated user for permissions and port rights (see TACACS+ Groups). Suggested values are "slip", "ppp", "arap", "shell", "tty-daemon", "connection", "system" and "firewall". The default is "shell".
Protocol	The optional protocol associated with the Service, which is included in the TACACS+ authorization message sent to the server to obtain an authenticated user's priv_lvl. The priv_lvl is used to assign a SLC custom group to the authenticated user for permissions and port rights (see TACACS+ Groups). Suggested values are "lcp", "ip", "ipx", "atalk", "vines", "lat", "xremote", "tn3270", "telnet", "rlogin", "pad", "vpdn", "ftp", "http", "deccp", "osicp" and "unknown".
Timeout	The timeout in seconds when attempting to connect to a TACACS+ server. Timeout range is 1 to 10 seconds. 5 seconds is the default.
Custom Menu	If custom menus have been created (see <i>Custom User Menu Commands</i>), you can assign a default custom menu to TACACS+ users.
Escape Sequence	A single character or a two-character sequence that causes the SLC 8000 advanced console manager to leave direct (interactive) mode. (To leave listen mode, press any key.)
	A suggested value is Esc+A (escape key, then uppercase "A" performed quickly but not simultaneously). You would specify this value as \ x1bA , which is hexadecimal (\ x) character 27 (1B) followed by an A .
	This setting allows the user to terminate the connect direct command on the command line interface when the endpoint of the command is deviceport, tcp, or udp.
Break Sequence	A series of 1-10 characters users can enter on the command line interface to send a break signal to the external device. A suggested value is Esc+B (escape key, then uppercase "B" performed quickly but not simultaneously). You would specify this value as $x1bB$, which is hexadecimal (x) character 27 (1B) followed by a B.
	See Key Sequences for notes on key sequence precedence and behavior.
Enable for Dial-back	Select to grant a user <i>Dial-back</i> access. Users with dial-back access can dial into the SLC unit and enter their login and password. Once the SLC 8000 advanced console manager authenticates them, the modem hangs up and dials them back. Disabled by default.
Dial-back Number	The phone number the modem dials back on depends on this setting for the device port. The user is either <i>Dial-back</i> on a fixed number, or on a number that is associated with the user's login (specified here).
Data Ports	The ports users are able to monitor and interact with using the connect direct command. U1 and U2 denote the USB upper and lower ports on the front of the SLC unit.
Listen Ports	The ports users are able to monitor using the connect listen command.
Clear Port Buffers	The ports whose port buffer users may clear using the set locallog clear command.

3. In the **User Rights** section, select the user group to which TACACS+ users will belong.

Group	Select the group to which the TACACS+ users will belong:
	 Default Users: This group has only the most basic rights. You can specify additional rights for the individual user. Power Users: This group has the same rights as Default Users plus Web Access, Networking, Date/Time, Reboot & Shutdown, and Diagnostics & Reports. Administrators: This group has all possible rights.

4. Select or clear the checkboxes for the following rights:

Full Administrative	Right to add, update, and delete all editable fields.
Networking	Right to enter Network settings.
Services	Right to enable and disable system logging, SSH and Telnet logins, SNMP, and SMTP.
Secure Lantronix Network	Right to view and manage secure Lantronix units (e.g., Spider, or SLC units) on the local subnet.
Date/Time	Right to set the date and time.
Reboot & Shutdown	Right to shut down and reboot the SLC unit.
Local Users	Right to add or delete local users on the system.
Remote Authentication	Right to assign a remote user to a user group and assign a set of rights to the user.
SSH Keys	Right to set SSH keys for authenticating users.
User Menus	Right to create a custom user menu for the CLI.
Web Access	Right to access Web-Manager.
Diagnostics & Reports	Right to obtain diagnostic information and reports about the unit.
Firmware & Configuration	Right to upgrade the firmware on the unit and save or restore a configuration (all settings). Selecting this option automatically selects Reboot & Shutdown .
Internal Modem	Right to update internal modem settings.
Device Port Operations	Right to control device ports.
Device Port Configuration	Right to enter device port settings.
USB	Right to enter modem settings for USB devices and control USB storage devices.
SD Card	Right to enter settings for SD card.
RPM	Right to manage and control remote power managers.

5. Click the **Apply** button.

Note: You must reboot the unit before your changes will take effect.

TACACS+ Commands

Go to *TACACS*+ *Commands* to view CLI commands which correspond to the web page entries described above.

Groups

The SLC 8000 advanced console manager has 3 pre-defined groups: Administrators, Power Users, and Default Users. Custom groups can also be created; each custom group is a set of user attributes and permissions. Local Users and Remote Users defined on the SLC unit can be assigned to one of the pre-defined groups or a custom group. When a user authenticates, if they belong to custom group, they will be granted the custom group attributes and permissions, rather than their individual attributes and permissions. The SLC 8000 advanced console manager supports querying a LDAP server for groups that a LDAP user is a member of; if any of the LDAP group names match a (Custom Group Name), the LDAP user will be granted the rights of the custom group.

A custom group cannot be given the name of one of the pre-defined groups: "Admin", "Power" or "Default" (or any version of these names where the case of the letters is different) since these names are used for the SLC pre-defined groups. Any LDAP group that matches one of these pre-defined group names will be ignored and not used to assign rights to a user.

To configure Groups in the SLC unit:

1. From the main menu, select User Authentication - Groups. The following page displays.

Note: If the fields in the lower part of the page have been populated by viewing another group, the fields can be cleared by selecting the Reset Group button.

									• •.			
	NTRON gout	lost: si Iser: s	SLC 80 Ic4331 ysadmin	48	LCD S	U1 U2 Select	E1 1 3 5 E2 2 4 6	7 9 1 8 10 1 onfigura	11 13 15 17 12 14 16 18 ation We	19 21 23 25 27 20 22 24 26 28 ebSSH (DP only)	29 31 33 35 37 3 30 32 34 36 38 4 Connected Devic	9 41 43 45 47 A 0 42 44 46 48 B e (DP only)
Network	Services	Use	r Authentication	Dev	ices	Maint	enance	Quick	Setup		6	路 ? 🗗 🗉
Auth N	lethods Local	l/Rem	ote Users NIS	LDAP	RAD	IUS K	Cerberos	TACA	CS+ Gro	oups SSH Key	s Custom Me	enus
						Gi	roups					Help?
										Vie	w Group	elete Group
						Gi	roups					
ld	Name	Perm	issions		Esc Seq	Brk Seq	Custom Menu	DB	Listen	Data	Clear	
						<u> </u>						
	Group	p Id: 0)				[Rese	et Group	Add Group	Edit Group]
	Group Na	ame:					,				L	-
	Listen Po	orts:	1-48,U1,U2		E	nable fo	or Dial-back				Custom Menu	: <none> ▼</none>
	Data Po	orts: 1	1-48,U1,U2			Dial-ba	ack Number:			Displa	y Menu at Login	:
	Clear Port Buff	fers:	1-48,U1,U2			Escape	e Sequence:	\x1b	A			
						Break	k Sequence:	\x1b	В			
	Full Ashusiaistas										0.0	
	Full Administra	ative:			_	L	Local Users:			Firmware	& Configuration	: .
	Network	king:			Rem	note Aut				_ .	Internal Modem	: .
	Servi	ices:					SSH Keys:			Device	Port Operations	:
Secur	e Lantronix Netw	vork:				L	Jser Menus:			Device Po	ort Configuration	
	Date/T	ime:				N	Veb Access:				USB	:
	Reboot & Shutdo	own:			Diag	gnostics	s & Reports:				SD Card	
	RF	PMs:										

Figure 12-10 User Authentication > Groups

2. Enter the following:

Group Name	Enter a name for the group.
Listen Ports	The ports users are able to monitor using the connect listen command.
Data Ports	The ports users are able to monitor and interact with using the connect direct command. U1 and U2 denote the USB upper and lower ports on the front of the SLC unit.
Clear Port Buffers	The ports whose port buffer users may clear using the set locallog clear command.
Enable for Dial-back	Select to grant a user. Users with dial-back access can dial into the SLC unit and enter their login and password. Once the SLC 8000 advanced console manager authenticates them, the modem hangs up and dials them back. Disabled by default.
Dial-back Number	The phone number the modem dials back on depends on this setting for the device port. The user is either on a fixed number, or on a number that is associated with the user's login (specified here).

Escape Sequence	A single character or a two-character sequence that causes the SLC 8000 advanced console manager to leave direct (interactive) mode. (To leave listen mode, press any key.)
	A suggested value is Esc+A (escape key, then uppercase "A" performed quickly but not simultaneously). You would specify this value as \x1bA , which is hexadecimal (\x) character 27 (1B) followed by an A .
	This setting allows the user to terminate the connect direct command on the command line interface when the endpoint of the command is deviceport, tcp, or udp.
Break Sequence	A series of one to ten characters users can enter on the command line interface to send a break signal to the external device. A suggested value is Esc+B (escape key, then uppercase "B" performed quickly but not simultaneously). You would specify this value as \x1bB , which is hexadecimal (\x) character 27 (1B) followed by a B .
Custom Menu	If custom menus have been created you can assign a default custom menu to the group. See <i>Custom Menus</i> for more information.
Display Menu at Login	Check the checkbox to display the menu at login.

3. Select or clear the checkboxes for the following rights:

Full Administrative	Right to add, update, and delete all editable fields.
Networking	Right to enter Network settings.
Services	Right to enable and disable system logging, SSH and Telnet logins, SNMP, and SMTP.
Secure Lantronix Network	Right to view and manage Secure Lantronix units (e.g., Spider, or SLC units) on the local subnet.
Date/Time	Right to set the date and time.
Reboot & Shutdown	Right to shut down and reboot the SLC unit.
Local Users	Right to add or delete local users on the system.
Remote Authentication	Right to assign a remote user to a user group and assign a set of rights to the user.
SSH Keys	Right to set SSH keys for authenticating users.
User Menus	Right to create a custom user menu for the CLI.
Web Access	Right to access Web-Manager.
Diagnostics & Reports	Right to obtain diagnostic information and reports about the unit.
Firmware & Configuration	Right to upgrade the firmware on the unit and save or restore a configuration (all settings). Selecting this option automatically selects Reboot & Shutdown .
Internal Modem	Right to update internal modem settings.
Device Port Operations	Right to control device ports.
Device Port Configuration	Right to enter device port settings.
USB	Right to enter modem settings for USB devices and control USB storage devices.
SD Card	Right to enter settings for SD card.
RPM	Right to manage and control remote power managers.

4. Click the **Add Group** button.

To view or update a group:

- 1. In the **Groups** table, select the group and click the **View Group** button. The group attributes and permissions will be displayed in the lower section of the page.
- 2. Modify the group attributes and permissions and click the Edit Group button.

To delete a group:

- 1. Select the group in the **Groups** table.
- 2. Click the **Delete Group** button.

Group Commands

Go to *Group Commands* to view CLI commands which correspond to the web page entries described above.

SSH Keys

The SLC 8000 advanced console manager can import and export SSH keys to facilitate shared key authentication for all incoming and outgoing SSH connections. By using a public/private key pair, a user can access multiple hosts with a single passphrase, or, if a passphrase is not used, a user can access multiple hosts without entering a password. In either case, the authentication is protected against security attacks because both the public key and the private key are required to authenticate. For both imported and exported SSH keys, the SLC unit supports both RSA and DSA keys, and can import and export keys in OpenSSH and SECSH formats. Imported and exported keys are saved with the SLC console manager configuration, and the administrator has the option of retaining the SSH keys during a reset to factory defaults.

The SLC unit can also update the SSH RSA1, RSA and DSA host keys that the SSH server uses with site-specific host keys or reset them to the default values.

Imported Keys

Imported SSH keys must be associated with an SLC 8000 advanced console manager local user. The key can be generated on host "MyHost" for user "MyUser," and when the key is imported into the SLC unit, it must be associated with either "MyUser" (if "MyUser" is an existing SLC console manager local user) or an alternate SLC local user. The public key file can be imported via SCP, SFTP, or FTP; once imported, you can view or delete the public key. Any SSH connection into the SLC unit from the designated host/user combination uses the SSH key for authentication.

Exported Keys

The SLC can generate SSH keys for SSH connections out of the SLC advanced console manager for any SLC user. The SLC 8000 advanced console manager retains both the private and public key on the SLC unit, and makes the public key available for export via SCP, SFTP, FTP, or copy and paste. The name of the key is used to generate the name of the public key file that is exported (for example, <keyname>.pub), and the exported keys are organized by user and key name. Once a key is generated and exported, you can delete the key or view the public portion. Any SSH connection out of the SLC console manager for the designated host/user combination uses the SSH key for authentication.

To configure the SLC unit to use SSH keys to authenticate users:

1. From the main menu, select **User Authentication - SSH Keys**. The following page displays.

	Figure	e 12-11 User	Autnent	cation >	SSH Ke	ys		
	X SLC 804		<mark>E1</mark> 1 3 5	7 9 11 13 1	1 <mark>5</mark> 17 19 21	23 25 27 29 3	<mark>1</mark> 33 35 37 39 41 4	3 45 47 🔼
			E2 2 4 6	8 10 12 14 1	<mark>16</mark> 18 20 22	24 <mark>26</mark> 28 30 3	<mark>2</mark> 34 36 38 40 42 4	4 46 48 B
	ser: sysadmin	Sel	lect port for 🔘	Configuration (WebSSH (DP only) OC	onnected Device (DP c	only)
Network Services	User Authentication	Devices Ma	intenance	Quick Setu	р		岱 ?	₽ ∎
Auth Methods Local/	Remote Users NIS	LDAP RADIUS	Kerberos	TACACS+	Groups	SSH Keys	Custom Menus	
		s	SH Kevs					Help?
			••••••				SSH Server/H	ost Kevs >
Imported Keys (SSH In)								
(not required if host and SLC Loc	' <u>IIN Key</u> cal User login are declared		Imported	SSH Keys			Viev	V Delete
in imported key file; ignored if file	contains multiple keys)		User		Host		Туре	
Host								
User:								
Import via:	Copy/Paste V	oad File >						
Public Kev:								
Host:								
Path:								
Login:								
Password:								
Retype Password:								
Exported Keys (SSH Out	t)							
Export:	New Key for User All Proviously Creater	tod Kovs	Exported	SSH Keys			View Download	d Delete
Liser:		led Reys	User		Key Na	me	Туре	
Key Name:								
Key Type:	RSA DSA							
Number of Bits:	2048 •							
Passphrase:								
Retype Passphrase:								
SECSH Format:								
Public Key Filename:								
Host & Login for Export								
Export via:	Copy/Paste ▼							
Host:								
Path:								
Login:								
Password:								
Retype Password:								
			Apply					
			, thhi					

Figure 12-11 User Authentication > SSH Keys

2. Enter the following:

Imported Keys (SSH In)

Host & User Associated with Key

These entries are required in the following cases:

- The imported key file does not contain the host that the user will be making an SSH connection from, or
- The SLC local user login for the connection is different from the user name the key was generated from or is not included in the imported key file, or
- The imported key file contains multiple keys; in this case, each key must include the user name and host at the end of the line in the standard <key> <user name>@<host> format.

If either of these conditions is true, or the imported file is in SECSH format, you must specify the user and host. The following is an example of a public key file that includes the user and host:

ssh-rsa AAAAB3NzaC1yc2EAAAABIwAAAEEApUHCX9EWsHt+jmUGXa1YC3us
ABYxIXUhSU1N+NU9HNaUADUFfd8LYz8/gUnUSH4Ksm8GRT7/8/Sn9jCVfGPh
UQ== asallaway@winserver

Host	The host name or IP address which will be associated with the SSH Key, typically the host that the key was generated on. Once imported, the key can be used to access the SLC from any host, not just the host associated with the key.
User	The User ID of the user being given secure access to the SLC unit.

Host & Login for Import

Import via	Select SCP , SFTP , FTP , HTTPS , or Copy/Paste as the method for importing the SSH keys. SCP is the default. If SCP, SFTP or FTP are selected, the Filename, Host, Path, Login, and Password fields are filled in. If HTTPS is selected, the Upload File link will become active to upload a file containing a public key to the SLC. If Copy/Paste is selected, the public key will be entered into the Filename/ Public Key field.
Filename Public Key	The name of the file that was uploaded via HTTPS, or to be copied via SCP, SFTP or FTP (may contain multiple keys); or the public key (optionally including "user@host" at the end) if Copy/Paste is used.
Host	IP address of the remote server from which to SCP, SFTP or FTP the public key file.
Path	Optional pathname to the public key file.
Login	User ID to use to SCP, SFTP or FTP the file.
Password / Retype Password	Password to use to SCP, SFTP or FTP the file.

Exported Keys (SSH Out)

Export	Enables you to export created public keys. Select one of the following:
	 New Key for User: Enables you to create a new key for a user and export the public key in a file. All Previously Created Keys: Does not create any keys, but exports all previously created public keys in one file.
User	User ID of the person given secure access to the remote server.

Key Name	Name of the key. This will generate the public key filename (e.g., <keyname>.pub).</keyname>
Кеу Туре	Select either the RSA or the DSA encryption standard. RSA is the default.
Number of Bits	Select the number of bits in the key (1024, 2048, 3072, or 4096). The default is 2048.
Passphrase / Retype Passphrase	Optionally, enter a passphrase associated with the key. The passphrase may have up to 50 characters. The passphrase is an optional password that can be associated with an SSH key. It is unique to each user and to each key. See <i>Key Sequences</i> for notes on key sequence precedence and behavior.
SECSH Format	Indicate whether the keys will be exported in SECSH format (by default the key is exported in OpenSSH format).
Public Key Filename	Filename of the public host key.

Host and Login for Export

Export via	Select the method (SCP, SFTP, FTP, HTTPS, or Copy/Paste) of exporting the key to the remote server. Copy/Paste, the default, requires no other parameters for export.
Host	IP address of the remote server to which the SLC 8000 advanced console manager will SCP, SFTP or FTP the public key file.
Path	Optional path of the file on the host to SCP, SFTP or FTP the public key too.
Login	User ID to use to SCP, SFTP or FTP the public key file.
Password / Retype Password	Password to use to SCP, SFTP or FTP the public key file.

To view or delete a key:

- 1. Select the key from the appropriate table. The **View** and **Delete** buttons become active.
- 2. To view the key, click the **View** button. A pop-up page displays the key.

```
Imported key for sysadmin@DaveSLM:
ssh-rsa AAAAB3NzaC1yc2EAAAABIwAAAIEAxGxPGY9HsG9VqroDo98B89Cf
haqB6jG//0tTMKkb3zrpPu0HHAXaiVXHAvv7lAte31VTpoXdLAXN0uCvuJLf
aL/LvvGmoEWBuBSu505lQHfL70ijxZWOEVTJGFqUQTSq8Ls3/v3lkUJEX5ln
2AlQx0F40I5wNEC0+m3d5QE+FKc= sysadmin@DaveSLM
```

3. To delete the key, click the **Delete** button.

To view, reset, or import SSH RSA1, RSA, And DSA host keys:

1. On the **User Authentication - SSH Keys** page, click the **SSH Server/Host Keys** link at the top right. The following page displays the current host keys. In the example below, the current keys are the defaults.

	Fi	gure 12-12	Current Ho	ost Keys			
	SLC 8048 slc4331 sysadmin	LCD SD U1 U2 Select	E1 1 3 5 7 9 E2 2 4 6 8 10 port for Config	11 13 15 17 19 2 12 14 16 18 20 2 uration WebSSH	1 23 25 27 29 2 <mark>24 26 28 30</mark> I (DP only) OC	31 33 35 37 39 41 32 34 36 38 40 42 Connected Device (DP	43 45 47 A 44 46 48 B only)
Network Services Us	er Authentication	evices Mainte	enance Qui	ck Setup		ය ?	• 🗗 🗉
Auth Methods Local/Ren	note Users NIS LD/	AP RADIUS K	erberos TAC	ACS+ Groups	SSH Keys	Custom Menus	
		SSH Serv	er/Host Key	/s			Help?
Current Host RSA1 Public	: Key (Default Key)						
Fingerprint: 2048 be:2b:0b:f9:18:0	ð3:12:e8:2a:5c:1c:	b1:14:9f:cd:d9	9 root@(non	e) (RSA1)			
Current Host RSA Public	Key (Default Key)						
ssh-rsa AAAAB3NzaCly 4roEBOmHCM4zvJ+GM913j sqS67AGTYWH4LZIM6Vty+ T2WRH9SojQUrPTOfNxw61 ZNVy7YdKb199sOQw35+Fo Fingerprint: 2048 23:45:f4:96:50:1	:2EAAAADAQABAAABAQ y9ihFHH1vGtL7HG7wh fKVssWL/6SOWgTwMWh 58f33F9uoHtVZhIzxW c+nHPMw46BT9huvFrM bd:c5:0d:c8:25:96:	CyXZodmEzPP/Fi ØPf6eC+CQt7ia UlomMGj+/pHcn\ j8/bhBo8Vr9g84 hDUycR7L00xKdv 8c:d2:e8:1d:40	rovhxvfrv81B D2Rhx686s312 /SeAY0ZirpXZ HTGyo3Y9TWZW /mjDM11ZP ro 0 root@slc4	nIvXlSRaQx0FJ 3v3++KIGTrX/M 1824UA9SfAnTB 9qpuovweqm8hp ot@slc4331 331 (RSA)	ISTJe InxLU IY6d/ Izn/F		
Current Host DSA Public	Key (Default Key)						
<pre>ssh-dss AAAAB3NzaC1kc3MAAACBAK3PpSoIhkg96hcQF0U5t4my9SSBPXHZ6qpzLIJnLuPupQunBGxm j/Coa7QkzgszJTFKTwSoHzQBkLmqdNnflC5CrFFftQizzPxB0c00beerhkzaWtLkxdGZsOpXaLirABE6 pEGGhX5nzXD2Bp0/80vcJru6Qmgj4FH9m52m3rqTAAAAFQCu3jEm6dm9u2xMm0ALN0/XJPSQ6wAAAIA3 byUhqKsrKFn7IzBNjb2uWskS0f01zmPYQ4vywpKFRISLQxuaMPQ/wSfbp48vLv5xW4BiKiqSR9Lmt/zQ WIaYSGIWMQ5DnNB/dbcN9sm5dTBage9I6tmyG/pw9zh0tTqM0CcDaybHMhdyN9rG6YrrYj1fRv9/GnsQ Mp4AwzOUuAAAAIBL0cAdGu64dD4AELgpmRA11jxd4pBsbM3hGUYzcVxp213i/WEVJogen6CehWA3bNL0 k1sA4zgKKUW0mefXQ/GyCt+UF6F5x2H2AR7ktGwvNPoyUHqITddD6/Ly43bU62Jqy9kMjIdXWe7Afj/q McjexvnyWk1gmEqhecPHnONyTQ== root@(none) Fingerprint: 1024 37:99:6a:02:7c:10:1b:55:a2:93:e5:41:51:23:b2:e2 root@(none) (DSA)</pre>							
Reset to Default Host Key:	All Keys	DSA			Note: chan reboot fo	iging a host key re r the update to take	quires a e effect.
Import Host Key:				Host:			
Туре:	RSA1 V			Path:			
Import via:	SFTP V			Login:			
Public Key Filename:				Password:			
Private Key Filename:			Re	type Password:			
Sack to SSH Keys		A	Apply				

2. View or enter the following:

Reset to Default Host Key	Select the All Keys checkbox to reset all default key(s), or select one or more checkboxes to reset defaults for RSA1 , RSA , or DSA keys. All checkboxes are unselected by default.
Import Host Key	To import a site-specific host key, select the checkbox. Unselected by default.
Туре	From the drop-down list, select the type of host key to import.

Import via	From the drop-down list, select the method of importing the host key (SCP or SFTP). The default is SFTP .
Public Key Filename	Filename of the public host key.
Private Key Filename	Filename of the private host key.
Host	Host name or IPaddress of the host from which to import the key.
Path	Path of the directory where the host key will be stored.
Login	User ID to use to SCP or SFTP the file.
Password / Retype Password	Password to use to SCP or SFTP the file.

- 3. Click the Apply button.
- 4. Repeat steps 2-3 for each key you want to import.
- 5. To return to the SSH Keys page, click the **Back to SSH Keys** link.

SSH Commands

Go to SSH Key Commands to view CLI commands which correspond to the web page entries described above.

Custom Menus

Users can have custom user menus as their command line interface, rather than the standard CLI command set. Each custom user menu can contain up to 50 commands ('logout' is always the last command). Instead of typing each command, the user enters the number associated with the command. Each command can also have a nickname associated with it, which can be displayed in the menu instead of the command. The commands showmenu <Menu Name> and returnmenu can be entered to display another menu from a menu, or to return to the prior menu. The command returncli can be used to break out of a menu and return to the regular CLI.

To add a custom menu:

1. Click the **User Authentication** tab and select the **Custom Menus** option. The Custom Menus page displays:

		Figure 1	2-13 (User Al	itnentica	tion > Cu	stom IVI	enus		
LVNLS	ONI <mark>X</mark> °	SLC 804	48	LCD SD U1	E1 1 3 5 E2 2 4 6	5 7 9 11 13 1 5 8 10 12 14 1	17 19 21 16 18 20 22	23 25 27 29 24 26 28 30	9 <mark>31</mark> 33 35 37 39 41 9 <mark>32</mark> 34 36 38 40 42	43 45 47 🔺 44 46 48 B
Logout	Host: sic4 User: sysa	331 admin		Se	lect port for 🔘	Configuration (WebSSH	(DP only) 🔘	Connected Device (DF	^o only)
Network Ser	vices User A	uthentication	Devid	ces Ma	intenance	Quick Setu	D		☆	? 🔂 🗉
Auth Methods	Local/Remote	Users NIS	LDAP	RADIUS	Kerberos	TACACS+	Groups	SSH Kevs	Custom Menus	5
				Cus	tom Men	us				Help?
[Custor	m Menus								
	Name									
	glenn1		\bigcirc							
	glenn2		\bigcirc							
	glenn3									
	glenn4									
	glenntacac1		\bigcirc							
	glenntacac2		\odot		View C	ustom Menu				
	glenntacac3				Delete	Custom Menu				
	glennkrb1		\bigcirc		Delete					
	glennkrb2				Сору С	ustom Menu	New Me	enu Name:		
	glennkrb3									
	bart1		\bigcirc							
	bart2									
	bart3		\bigcirc							
	glennnis1		\bigcirc							
	glennnis2									
	glennnis3		\bigcirc							
Menu Neme					Niekas	-		Clear	Custom Menu	
Menu Name.					NICKHA	mes. 💌				
Title:					Redisplay N	1enu: 🔲		Add C	Custom Menu	
								Edit C	ustom Menu	
					t(logout)	mes <u>List</u>				A
Command:				logot	it(logout)					
NICKName:										
QuickEdit Mode:										
De	lete Command	& Nickname								
Cle	ear Command	& Nickname								
Uns	elect Command	d & Nickname	•							

Figure 12-13 User Authentication > Custom Menus

2. In the lower section of the page, enter the following:

Note: To clear fields in the lower part of the page, click the **Clear Custom Menu** button.

Menu Name	Enter a name for the custom menu.
Title	Enter an optional title which will be displayed about the menu at the CLI.

Nicknames	Select to enable nicknames to be displayed in the menu instead of the commands. If the custom menu will have nicknames, this should also be selected prior to entering the commands in the web page, as this will facilitate entry of the nicknames.
Redisplay Menu	Select to redisplay the custom menu each time before the CLI prompt is displayed.

- 3. You have the following options:
 - To save the custom menu without any more commands than the default **logout** command, click the **Add Custom Menu** button.
 - To add menu commands, select the QuickEdit Mode box. This will move the cursor from Command to Nickname and back to Command (if Nicknames is selected), or keep the cursor on Command (if Nicknames is not selected). Commands (and the optional nicknames) are added to the Menu Commands/Nicknames list when carriage return is entered at the Command field (if Nicknames is not selected) or the Nickname field (if Nicknames is selected). Most browsers have a "Select All" keystroke (such as Control-A) which allow you to select all of the text in a field; this can be used in conjunction with the Delete key to clear the contents of a field before entering a new command or nickname. The Clear Command & Nickname button can also be used to delete the contents of the Command and Nickname fields.

Commands can also be added to the list when **QuickEdit Mode** is not selected. Enter the command and the optional nickname and click the **right arrow**. The command will be added before the logout command (if a command/nickname is not selected in the list) or will replace the currently selected command/nickname in the list. The **Unselect Command & Nickname** button can be used to unselect the currently selected command/ nickname in the list.

- 4. To add more commands to the custom menu, repeat step 3.
- 5. You also have the following options:
 - To edit a command/nickname in the custom menu, select the command in the **Commands/Nicknames List** box and select the **left arrow** button. Change the command and/or the nickname, and with the same command still selected in the list, select the **right arrow** button.
 - To remove a command/nickname from the custom menu, select the command in the **Commands/Nicknames List** box and select the **Delete Command & Nickname** button.
 - To move a command higher up in the menu (the commands are shown in the order they will be presented in the custom menu, with command #1 listed first), select the command in the **Commands/Nicknames List** box and click the **up arrow**.
 - To move a command further down in the menu, select the menu in the Commands/ Nicknames List and click the down sarrow.
- 6. Click the Add Custom Menu button.

To view or update a custom menu:

- 1. In the **Custom Menus** table, select the custom menu and click the **View Custom Menu** button. The custom menu attributes appear in the lower part of the page.
- 2. Update the menu attributes following the instructions for adding a menu above.
- 3. Click the Edit Custom Menu button.

To delete a custom menu:

- 1. Select the custom menu in the **Custom Menus** table.
- 2. Click the **Delete Custom Menu** button.

To create a new custom menu from an existing custom menu:

- 1. Select the custom menu in the **Custom Menus** table.
- 2. Enter a name for the new menu in the **New Menu Name** field.
- 3. Click the Copy Custom Menu button.

Custom User Menu Commands

From the current menu, a user can display another menu, thus allowing menus to be nested. The special command showmenu <Menu Name> displays a specified menu. The special command returnmenu redisplays the parent menu if the current menu was displayed from a showmenu command.

The user with appropriate rights creates and manages custom user menus from the command line interface, but can assign a custom user menu to a user from either the command line or the web interface.

When creating a custom user menu, note the following limitations:

- Maximum of 20 custom user menus
- Maximum of 50 commands per custom user menu (logout is always the last command)
- Maximum of 15 characters for menu names
- Maximum of five nested menus can be called.
- No syntax checking (Enter each command correctly.)

Go to *Custom User Menu Commands* to view CLI commands which correspond to the web page entries described above.

13: Maintenance

The system administrator performs maintenance activities and operates the SLC advanced console manager using the options for the Maintenance tab and additional commands on the command line interface.

Firmware & Configurations

The Firmware & Configuration page allows the system administrator to:

- Configure the FTP, SFTP, or TFTP server that will be used to provide firmware updates and save/restore configurations. (TFTP is only used for firmware updates and configurations restored via DHCP/TFTP Zero Touch Provisioning Configuration Restore.)
- Set up the location or method that will be used to save or restore configurations (Local Disk, FTP, SFTP, NFS, CIFS, USB, HTTPS or SD card). Update the version of the firmware running on the SLC unit.
- Save a snapshot of all settings on the SLC device (save a configuration).
- Restore the configuration, either to a previously saved configuration, or to the factory defaults.
- Configurations can also be pushed to the SLC via the HTTPS Push Configuration Restore feature.

Zero Touch Provisioning Configuration Restore

The Zero Touch Provisioning feature allows a factory defaulted SLC to acquire a default configuration from a DHCP server and TFTP server when it is booted. At boot-time, before the normal startup process, a unit will attempt to acquire network parameters and a configuration file, first over Eth1, and then over Eth2:

- The unit will broadcast on the Eth1 network port for a DHCP server on the local subnet, requesting DHCP options "TFTP Server" (DHCP option #66) and "Boot Filename" (DHCP option #67).
- If it receives both options from the DHCP server, and the Boot Filename is a valid SLC configuration filename ending in "-slccfg.tgz", it will attempt to download the Boot Filename from the TFTP Server.
- If it is able to download the Boot Filename from the TFTP Server, it will restore the configuration onto the SLC, and begin the normal startup process.
- If any of these steps fail for the Eth1 network port, it will repeat the process of trying to acquire a configuration over the Eth2 network port.
- After attempting to acquire a configuration over the Eth2 network port, the unit will begin the normal startup process.

Any results of attempting to acquire and restore a configuration file will be output to the console port and the system log. Configurations for firmware versions that are newer than the firmware version running on the unit will not be restored. Spaces are not supported in either the directory or filename portion of the Boot Filename path.
HTTPS Push Configuration Restore

The HTTPS Push Configuration feature allows a saved configuration to be pushed to a SLC via a command line tool such as "curl" that includes the configuration to upload:

```
% curl --insecure --request POST --form "file=@/home/users/admin/
current-slccfg.tgz" `https://myslc.company.com/
cfgupdate.htm?login=sysadmin&password=PASS&config=all&comment=FirmwareUp
date'
```

The arguments that are passed with the URL are:

- login Login token to use for authentication. This must be a local user with firmware/config and reboot/shutdown rights.
- **password** Clear text password for the login token.
- config Indicates the portion of the configuration to restore, either all, or any combination of the following separated by commas: network, datetime, services, localusers, devports, usb, rpms, remoteauth, connections, events, ipfilter, groups, hostlist, nfscifs, maintenance, sites, scripts, slcnetwork, consoleport, menus, sshkeys, or sslcerts.
- comment optional comment to include in the system log and audit log. If spaces are included in the comment they should be URL encoded as shown in this bash script:

#!/bin/bash

```
url="https://myslc.company.com/
cfgupdate.htm?login=sysadmin&password=PASS&config=all&comment=Update
myslc.company.com with default configuration"
```

```
curl --insecure --request POST --form "file=@/home/users/admin/current-
slccfg.tgz" "$( echo $url | sed 's/ /%20/g' )"
```

If an HTTPS Push Config command is accepted and initiated by the SLC, the SLC will respond with "Configuration restore initiated; SLC will reboot.", the restore will be performed, a message will be logged to the audit log and the system log, and the SLC will reboot. Any errors in the process will result in an error message being displayed.

To configure settings:

1. Click the **Maintenance** tab. The *Maintenance* > *Firmware* & *Configurations* page displays.

Logout Host: slc4331 User: sysadmin LCD SD U1 U2 MD E1 1 3 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 35 37 39 41 43 45 Logout Host: slc4331 User: sysadmin Select port for © Configuration WebSSH (DP only) Connected Device (DP only) Network Services User Authentication Devices Maintenance Quick Setup Connected Device (DP only)	47 A 48 B
Logout Host: slc4331 User: sysadmin Select port for Configuration WebSSH (DP only) Connected Device (DP only) Network Services User Authentication Devices Maintenance Quick Setup	
Network Services User Authentication Devices Maintenance Quick Setup	
Firmware/Config System Log Audit Log Email Log Diagnostics Status/Reports Events LCD/Keypad Banners	
Firmware & Configurations	elp?
General	
Reboot: Shutdown:	
Internal Temperature Site Information	
Current: 50 °C / 122 °F Data Center Rack	
Cluster:	
High: 65 °C / 149 °F Data Center Rack: 1	
Calibrate Offset: 0 °C / 0 °F Site Tag:	
Note: Temperatures can be entered in either Celsius or Fahrenheit; to indicate a temperature is Fahrenheit, append the degrees with an 'F', eg "75F".	
Current Version: 7.5.0.0R22 HTTPS: Upload File	
Clear FW Update Log: Firmware Update Log NFS Mounted Dir: select one v	
Update Firmware: USB Port: O Port U1 O Port U2	
Firmware Filename: FTP/SFTP/TFTP Server:	
Kev: Path:	
Login:	
Note: Firmware files stored on NFS, SD Card and USB Password	
can be managed by clicking the Manage link below.	
Retype rassword.	
Boot Banks and Bootloader Settings	
Bank 1: 7.5.0.0R21 Copy configuration from Bank 2 to Bank 2: 7.5.0.0R22 (current) Bank 1 during firmware update:	
Next Boot Count: 0	
Switch to Bank 2: Boot Limit: 3	
Watchdog Timer: 900 seconds Boot Delay: 3 seconds	
Configuration Management	
No Save/Restore Configuration Name to Save To or Restore From:	
Save Configuration Tarball Format (HTTPS only) Location for Save, Restore or Manage	
Restore Factory Defaults Incal Disk Saved Configurations: select one	
Restore Saved Configuration FTP Server Use: FTP Server Use:	
Save with Config or Preserve with Restore: NFS Mounted Directory: select one • 	
SSH Keys SSL Certificate CIFS Share Saved Configurations: select one v	
Scripts USB Use: Port U1 Port U2	
Preserve Configuration after Restore: Saved Configurations: select one v	
Networking Local Users O HTTPS Upload File for Restore File will be uploaded to Local Disk.	
Date/Time Device Ports OSD Card Saved Configurations: select one •	
Services USB	
Remote Auth	
Apply	

Figure 13-1 Maintenance > Firmware & Configurations

2. Enter the following:

Reboot	Select this option to reboot the SLC 8000 advanced console manager immediately. The default is No .
	Note: The front panel LCD displays the "Rebooting the SLC" message, and the normal boot sequence occurs.
Shutdown	Select this option to shut down the SLC unit. The default is No.

Internal Temperature

Current	Displays current temperature.
Low	Sets the acceptable minimum for the internal temperature of the SLC 8000 advanced console manager. If the temperature of the SLC device changes to be outside of this range, the SLC console manager will issue an SNMP trap.
High	Sets the acceptable maximum for the internal temperature of the SLC unit. If the temperature of the SLC 8000 advanced console manager changes to be outside of this range, the SLC unit will issue an SNMP trap.
Calibrate Offset	An offset for calibrating the internal temperature of the SLC console manager. The offset will be applied one hour after setting the calibration value. Zeroing the offset will take effect immediately and will cancel any current and/or pending calibration.

Site Information

Data Center Rack Row	Set these fields to define the rack row the SLC unit is located within a large data center. The default for these fields is 1.
Data Center Rack Cluster	Set these fields to define the rack cluster the SLC 8000 advanced console manager is located within a large data center. The default for these fields is 1.
Data Center Rack	Set these fields to define the rack the SLC unit is located within a large data center. The default for these fields is 1.
Site Tag	Tag or description used to identify the location or some other attribute of the SLC.

SLC Firmware

Note: The non-active boot bank is updated during the firmware update, without requiring a reboot. The configuration on the current boot bank may optionally be copied to the non-active boot bank during the firmware update.

Current Version	Displays the current firmware version.
Clear FW Update Log (checkbox)	Clears the contents of the Firmware Update log file.
Firmware Update Log (link)	To view a log of all prior firmware updates, click the Firmware Update Log link.
Update Firmware	 To update the SLC firmware, select the checkbox. If you select this option, the SLC unit reboots after you apply the update. The first time boot for each bank may take up to 5 minutes. Subsequent boot times will be approximately 2 minutes. To view a log of all prior firmware updates, click the Firmware Update Log link.
Firmware Filename	The name of the firmware update file downloaded from the Lantronix web site.

Кеу	A key for validating the firmware file. The key is provided with the firmware file (32 hex characters).
Load Firmware Via	 From the drop-down list, select the method of loading the firmware. Options are FTP, TFTP, HTTPS, NFS, USB, and SD Card. FTP is the default. If you select HTTPS, the Upload File link becomes active. Select the link to open a popup window that allows you to browse to a firmware update file to upload. If you select NFS, the mount directory must be specified. The SD Card option must be selected if an SD card is to be used.
	Note: Connections available depend on the model of the SLC unit.

Boot Banks and Bootloader Settings

Bank 1	Displays the version of SLC firmware in bank 1.
	<i>Note:</i> The word "current" displays next to the bank from which the SLC booted.
Bank 2	Displays the version of SLC firmware in bank 2.
Next Boot Bank	Displays the current setting for bank to boot from at next reboot.
Switch to Bank 2	If desired, select the alternate bank to boot from at next reboot.
Copy configuration from Bank 1 to Bank 2 during firmware update	If checked, will copy the configuration from the current bank to the bank being updated. The two numbers are automatically generated so that the first number is the current bank.
Boot Count, Boot Delay, Boot Limit	 Parameters that control how the SLC boots and when it switches to the alternate boot bank. Boot Delay - how many seconds the bootloader pauses before booting the SLC. Default is 3 seconds, range is 3 - 1800 seconds. Boot Limit - how many times the SLC will fail to boot before switching to the alternate boot bank. After the SLC fails to boot 2 times Boot limit (so it has attempted to boot Boot Limit times on each bank), the SLC will go into advanced recovery mode, which may require support from Technical Support to resolve so that the SLC can be booted again. Default is 3 boots, range is 3 - 20. Boot Count - how many times the SLC has failed to boot. If this value reaches Boot Limit, the SLC will switch to the alternate boot bank. The SLC will switch to the alternate boot bank 1, it will automatically switch to bank 2; if it fails to boot Boot Limit times on bank 2, it will enter advanced recovery mode. If Boot Count has reached Boot Limit, setting this value to 0 will enable the SLC to boot again. Default is 0, range is 0 - 1.
High Resolution Timers	Enables or disables timers with a high degree of accuracy. High resolution timers are required for <i>Performance Monitoring</i> , but may affect SLC performance if they are enabled. Off by default. Changing this value requires a reboot for the change to take effect.
Watchdog Timer	Timer that will reboot the SLC if the boot fails to properly complete. If the timer expires without a successful boot of the SLC, the timer will automatically reboot the SLC. The default is 300 seconds. A value of zero will disable the watchdog timer.

Load Firmware Via Options

Note: Prior to firmware update, the current configuration is saved to the Local Disk location with the name "before_MMDDYY_HHMM".

HTTPS	Click Upload File to update the SLC firmware.
NFS Mounted Dir	Select the NFS mounted directory from the drop-down menu.
USB Port	Click to select USB port.
FTP/SFTP/TFTP Server	The IP address or host name of the server used for obtaining updates and saving or restoring configurations. May have up to 64 alphanumeric characters; may include hyphens and underscores.
Path	The default path on the server for obtaining firmware update files and getting and putting configuration save files.
Login	The userid for accessing the FTP server. May be blank.
Password / Retype Password	The FTP user password.

Configuration Management

Configuration	From the option list, select one of the following:
Management	 No Save/Restore: Does not save or restore a configuration. Save Configuration: Saves all settings to file, which can be backed up to a location that is not on the SLC 8000 advanced console manager. If Tarball Format is checked, the configuration will be saved in the old (insecure) compressed tar file format, instead of the password protected zip file format. Restore Factory Defaults: Restores factory defaults. If you select this option, the SLC unit reboots after you apply the update. Restore Saved Configuration: Returns the SLC settings to a previously saved configuration. If you select this option, the SLC console manager reboots after you apply the update.
Save with Config or Preserve with Restore	 Select the SSH Keys checkbox to save any imported or exported SSH keys. Select the SSL Certificate checkbox to save an imported certificate. Select the Scripts checkbox to save any interface or batch scripts. Disabled by default.
Preserve Configuration after Restore	Allows the user to keep a subset of the current configuration after restoring a configuration or resetting to factory defaults.
	Select the checkbox for each part of the current configuration you want to keep, for example, Networking, Services, or Device Ports.
Configuration Name to Save to or Restore From	If you selected to save or restore a configuration, enter a name for the configuration file (up to 12 characters).

Location for Save, Restore, or Manage	If you selected to save or restore a configuration, select one of the following options:
	 Manage: This link allows you to view and delete all configurations saved to the selected location. This feature is available for the Local Disk, NFS Mounts, CIFS Share, USB, and SD Card locations. See Manage Files on page 259.
	 Local Disk – Saved Configurations: If restoring, select a saved configuration from the drop-down list.
	• FTP Server: The FTP server specified in the FTP/SFTP/TFTP section. If you select this option, select FTP or SFTP to transfer the configuration file.
	 NFS Mounted Directory: Local directory of the NFS server for mounting files.
	 CIFS Share – Saved Configurations: If restoring, select a saved configuration from the drop-down list.
	 USB: If a USB device is loaded into one of the USB ports of the SLC 8000 advanced console manager, and properly mounted, the configuration can be saved to or restored from this location. If you select this option, select the port in which the USB thumb drive is mounted; then click a saved configuration from the drop-down list.
	 HTTPS: For saving, the browser will prompt the user to save the configuration. For restoring, the configuration will be uploaded to the Local Disk location.
	• SD Card: If an SD card is loaded into a card slots of the SLC and properly mounted, the configuration can be saved to or restored from this location.

3. To view a log of all prior firmware updates, click the **Firmware Update Log** (blue link near the center of the web page).

4. Click Apply.

Note: If you selected an option that forces a reboot (restore configuration, update firmware, or reset factory defaults), the SLC unit automatically reboots at the end of the process.

	SLC 8048	D DI E1 1 3 5 7 9 11 13 15 E2 E2 2 4 6 8 10 12 14 16 Select port for © Configuration	17 19 21 23 25 27 29 31 33 18 20 22 24 26 28 30 32 34 WebSSH (DP only) O connect Connect Connect	35 37 39 41 43 45 47 A 36 38 40 42 44 46 48 B ted Device (DP only)
Network Services	User Authentication Devices	Maintenance Quick Setup		🖓 ? 🗗 🗉
Firmware/Config Syst	tem Log Audit Log Email Lo	g Diagnostics Status/Reports	Events LCD/Keypad	Banners

Figure 13-2 Network > Firmware/Config > Manage

Firmware & Configurations - Manage Files

1				-	è
	н	ê	I٥	1.1	

Configurations - Local Disk											
Name	Date/Time Saved	SSH Keys	SSL Certificate	Scripts							
slc4873R7_250120all- slccfg.tgz	05/18/16 23:29:30	Y	Y	Y							
before_051216_2222- slccfg.tgz	05/12/16 22:22:54	Y	Y	Y							
syscon-slccfg.tgz	05/20/16 16:07:18	Y	Υ	Y							
slc73dhcp-slccfg.tgz	05/20/16 19:52:19	Y	Y	Y							
before_051216_2245- slccfg.tgz	05/12/16 22:45:05	Y	Y	Y							

Manage Files

The **Manage Files** web page allows you to view the firmware and configuration files saved to the selected location and rename, download or delete any of the files. This feature is available for the Local Disk, NFS Mounts, CIFS Share, USB, and SD card locations.

To manage files:

- On the Maintenance > Firmware & Configurations page, click the Manage link. The Network > Firmware/Config > Manage (on page 259) page appears and displays the name and the time and date the file was saved.
- 2. To rename a file, select a file, enter the **New File Name**, and click the **Rename File** button.
- 3. To download a file, select a file and click the **Download File** button.
- To delete files, select one, multiple files, or all files, and click the Delete File button. A verification message showing files deleted will appear. Click Back to Manage Files to return to the Network > Firmware/Config > Manage page.

Note: When deleting multiple files with a single command, the list of files that have been deleted will only be shown if 10 or fewer files are deleted.

Administrative Commands

Go to *Administrative Commands* to view CLI commands which correspond to the web page entries described above.

System Logs

The *Maintenance > System Logs* page allows you to view various system logs. (See *Chapter 7: Services on page 97* for more information about system logs.) You can also clear logs on this page.

To view system logs:

1. Click the Maintenance tab and select the System Logs option. The following page displays:

			i ig	ule 10-5	Mannenai	ice > Oystern	LUgs			
		Host: slc433 User: sysadi	SLC 804 1 min	8 _{LCD}	U1 E1 1 3 U2 E2 2 4 Select port for 1	5 7 9 11 13 15 6 8 10 12 14 16 Image: Configuration Im	17 19 21 2 18 20 22 2 WebSSH (D	23 25 27 29 31 3 24 26 28 30 32 34 P only) Connec	3 35 37 39 4 4 36 38 40 4 cted Device (D	1 43 45 47 A 2 44 46 48 B P only)
Network Servi	ices	User Aut	hentication	Devices	Maintenance	Quick Setup			岱	? 🔂 🗉
Firmware/Config	g (System Log	Audit Log	Email Log	Diagnostics	Status/Reports	Events	LCD/Keypad	Banners	
					System Lo	ogs				Help?
Log:	۲	All			Starting	at: 💿 Beginnin	g of Log			
		Network				Date:				
		Services				May	• 24 •	2016 🔻		
		Authenticatio	on			08 ▼ · 01	▼ · 22	v am v		
		Device Ports	6							
		Diagnostics			Ending	at: 💿 End of L	og			
		General				Date:				
		Software				May	▼ 24 ▼	2016 🔻		
	<u> </u>					08 🔻 : 01	• : 22	?▼ am ▼		
Level:	۲	Error								
	\bigcirc	Warning								
	\bigcirc	Info								
	\bigcirc	Debug								
				View Log		Clear Log]			

Figure 13-3 Maintenance > System Logs

2. Enter the following to define the parameters of the log you would like to view:

Log	Select the type(s) of log you want to view:							
	♦ All							
	 Network 							
	♦ Services							
	 Authentication 							
	 Device Ports 							
	 Diagnostics 							
	 ♦ General 							
	♦ Software							
Level	Select the alert level you want to view for the selected log:							
	◆ Error							
	♦ Warning							
	♦ Info							
	♦ Debug							
Starting at	Select the starting point of the range you want to view:							
	• Beginning of Log: to view the log from the earliest available beginning time and							
	Udie.							
	• Date. to view the log starting norm aspectic starting date and time.							

Ending at	Select the endpoint of the range you want to view:
	• End of Log: to view the log from the latest available ending time and date.
	 Date: to view the log up to the last available log ending date and time.

3. Click the **View Log** button. Your specified system log displays. For example, if you select the type **All** and the level **Error**, the SLC unit displays a log similar to this:

	Log	ITRC	N Ho Us	IX° st: slc43 er: sysad	SLC 804 31 dmin	48 L	SD SD L	J1 E1 1 3 J2 E2 2 4 Select port for	3 5 7 9 11 4 6 8 10 12 Onfigurat	13 15 17 2 14 16 18 ion OW	7 19 21 23 23 8 20 22 24 26 ebSSH (DP on	5 27 29 31 33 3 5 28 30 32 34 3 y) Connecte	35 37 39 4 36 38 40 4 d Device (I	1 43 12 44 DP or	45 47 A 46 48 B
Netw	ork	Servic	es	User Au	thentication	Devices	M	aintenance	Quick	Setup			w	1	
Firr	nwai	re/Config	Syst	tem Log	Audit Log	Email Lo	g Dia	agnostics	Status/Re	ports I	Events LC	D/Keypad	Banners		
							S	ystem Lo	ogs						Help?
Log:	All	- Error Le	evel			Email	Dutput	t	Commen	nt:					
	S	Stop Refre	esh						ti	o:					
May May May May May May May May Nay	20 20 20 20 20 20 20 20 20 20 20 20 20	21:58:29 21:58:27 19:53:39 19:53:06 19:53:03 19:52:56 19:52:56 4 19:52:56 4 19:52:56	2016 2016 2016 2016 2016 2016 2016 2016	slc433 slc433 slc433 slc433 (none) (none) (none) (none) (none)	1 SLC-SLB: 1 SLC-SLB/XI 1 SLC-SLB/KI SLC-SLB/KI SLC-SLB/KI SLC-SLB/KI SLC-SLB/KI SLC-SLB/KI	last messa wsd: sw/en ernel: Car ernel: etØ ernel: IPV0 ernel: xhc: ernel: xhc: ernel: xhc:	age re r-rec not f Link :_hcd i_hcd i_hcd i_hcd	peated 2 vfrom err r Supply ind map f Up: 100FD RCONF(NET 0001:01:0 0001:01:0 0001:01:0	times or: Interr A failed ile. DEV_CHANGE 0.0: xHCI 0.0: xHCI 0.0: new U 0.0: new U	rupted s E): ethe Host Cc Host Cc JSB bus	ystem cal): link bed ntroller ntroller registered registered	l comes ready d, assigned 1. assigned	bus		
May numl May May May 6 May 5 May	20 20 20 20 20 20 20 20 20	19:52:56 19:52:56 19:52:56 19:52:56 19:52:56 19:52:56 19:52:56	2016 2016 2016 2016 2016 2016 2016 2016	(none) (none) (none) (none) (none) (none)	SLC-SLB/kei SLC-SLB/kei SLC-SLB/kei SLC-SLB/kei SLC-SLB/kei SLC-SLB/kei	<pre>mel: xhc: mel: xhc: mel: xhc: mel: xhc: mel: xhc: mel: xhc:</pre>	i_hcd i-hcd i-hcd i-hcd i-hcd i-hcd i-hcd	0001:01:0 xhci-hcd: xhci-hcd: xhci-hcd: xhci-hcd: xhci-hcd:	0.0: irq 1 xHCI Host xHCI Host new USB b new USB b irq 112,	169, io Contro Contro US regi DUS regi io mem	mem 0x4000 oller oller stered, as stered, as 0x18023000	90000 ssigned bus ssigned bus	number number	-	

Figure 13-4 System Logs

From a queried system log (e.g., *Figure 13-4*), you may email this information to a specific individual or to Lantronix Technical Support. See *Emailing Logs and Reports (on page 269)*.

To clear system logs:

- 1. From the *Maintenance* > *System Logs* page, select **Maintenance System Logs**.
- 2. Click the Clear Log button to clear all log information.

System Log Commands

Go to *System Log Commands* to view CLI commands which correspond to the web page entries described above.

Audit Log

The *Maintenance* > *Audit Log* page displays a log of all actions that have changed the configuration of the SLC 8000 advanced console manager. The audit log is disabled by default. Use the *Services* > *SSH/Telnet/Logging* page (*Chapter 7: Services*) to enable the audit log and to configure its maximum size.

Each entry in the log file contains a date/time stamp, user login, and the action performed by the user. The user may clear the log file and sort the log by date/time, user, and command. The audit log is saved through SLC reboots.

1. Click the Maintenance tab and select the Audit Log option. The following page displays:

	Host: slc4331 User: sysadmin	8048 U1 E1 1 3 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 35 37 39 4 U2 E 2 4 6 8 10 12 14 16 18 20 22 24 26 28 30 32 34 36 38 40 4 4 4 4 4 4 4 4 4 4 4	1 43 45 47 A 2 44 46 48 B IP only)
Network Service	us User Authentica	ation Devices Maintenance Quick Setup	? 🗗 🗉
Firmware/Config	System Log Audit	t Log Email Log Diagnostics Status/Reports Events LCD/Keypad Banners	
	-,		
		Audit Log	Help?
Sorted by: Date/Tin Sort by: User (Clear Log Sto	ne Command p Refresh	Email Log Comment:	
May 24 06:45:02 May 24 06:24:14 May 24 05:33:07 May 24 02:08:52 May 24 00:29:54	2016 sysadmin 2016 sysadmin 2016 sysadmin 2016 sysadmin 2016 sysadmin 2016	Host List 'abc' updated Web Authentication Success for user sysadmin Web Authentication Success for user sysadmin Web Authentication Success for user sysadmin User sysadmin logged off of SSH session	
May 24 00:24:18 May 24 00:24:06 May 24 00:24:05 May 24 00:23:52 May 24 00:23:30 May 24 00:23:30	2016 sysadmin 2016 sysadmin 2016 sysadmin 2016 2016 sysadmin 2016 sysadmin	Web Authentication Success for user sysadmin Local user settings updated Auth order: Local Users=1 NIS=0 LDAP=0 RADIUS=0 Kerberos=0 TACACS=0 SSH Authentication Success for user sysadmin Web Authentication Failure for user sysadmin Web Authentication Success for user sysadmin	
May 23 23:00:32 May 23 21:02:35 May 23 20:40:42 May 21 06:21:45	2016 sysadmin 2016 sysadmin 2016 sysadmin 2016 sysadmin 2016 sysadmin	Web Authentication Success for user sysadmin Web Authentication Failure for user sysadmin Web Authentication Success for user sysadmin Web Authentication Success for user sysadmin Web Authentication Success for user sysadmin	
May 21 04:14:48 May 21 00:44:34 May 20 21:09:38 May 20 20:32:34 May 20 19:54:39	2016 sysadmin 2016 sysadmin 2016 sysadmin 2016 sysadmin 2016 sysadmin	Web Authentication Success for user sysadmin Web Authentication Success for user sysadmin Web Authentication Success for user sysadmin Local user 'sysadmin' attributes updated	

Figure 13-5 Maintenance > Audit Log

- 2. To select a sort option, click the appropriate button:
 - To sort by date and time, click the sort by **Date/Time** button (this is the default.)
 - To sort by user, click the sort by **User** button.
 - To sort by command/action, click the sort by **Command** button.
- 3. To email this log, follow the instructions in *Emailing Logs and Reports (on page 269)*.
- 4. To clear the log, click the **Clear Log** button.
- 5. To freeze or stop automatic refreshing of the log, click the **Stop Refresh** button.

Audit Log Commands

Go to *Audit Log Commands* to view CLI commands which correspond to the web page entries described above.

Email Log

The *Maintenance > Email Log* page displays a log of all attempted emails. The log file can be cleared from here. The email log is saved through SLC reboots.

1. Click the Maintenance tab and select the Email Log option. The following page displays:

Logout Host: slc4331 User: sysadmin Network Services User Authentication D	U1 E1 1 3 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 35 37 39 LCD SD U2 E2 2 4 6 8 10 12 14 16 18 20 22 24 26 28 30 32 34 36 38 40 Select port for © Configuration © WebSSH (DP only) © Connected Device (evices Maintenance Quick Setup @ Connected Device (41 43 45 47 A 42 44 46 48 B DP only) ?
Firmware/Config System Log Audit Log Em	ail Log Diagnostics Status/Reports Events LCD/Keypad Banners	
	Email Log	Help?
Clear Log Email Log	Comment:	
Stop Refresh	to:	
Send Failures: 1 Emails Sent: 16 Bytes Sent: 2954		
05/18/16 19:21 gefountain@lantronix.com	Message Sent (SLC Internal Temperature out of Range)	
05/18/16 19:20 getountain@lantronix.com	Message Sent (SLC Internal Temperature out of Range)	
05/18/16 19:18 gefountain@lantronix.com	Message Sent (SLC Internal Temperature out of Range)	
05/18/16 19:17 gefountain@lantronix.com	Message Sent (SLC Internal Temperature out of Range)	
05/18/16 19:16 gefountain@lantronix.com	Message Sent (SLC Internal Temperature out of Range)	
05/18/16 19:15 gefountain@lantronix.com	Message Sent (SLC Internal Temperature out of Range)	
05/18/16 19:14 gefountain@lantronix.com	Message Sent (SLC Internal Temperature out of Range)	
05/18/16 19:13 gefountain@lantronix.com	Message Sent (SLC Internal Temperature out of Range)	
05/18/16 19:12 gefountain@lantronix.com	Message Sent (SLC Internal Temperature out of Range)	
05/18/16 19:11 getountain@lantronix.com	Message Sent (SLC Internal Temperature out of Range)	
05/18/16 19:10 getountain@lantron1x.com	Message Sent (SLC Internal Temperature out of Range)	
05/18/16 19:09 gerountain@lantronix.com	message sent (SLC internal remperature out of Range)	
not known	cannot iocate nost zpatt.iantionix.com. Name of service	
05/18/16 18:35 gefountain@lantronix.com	Message Sent (SLC Internal Temperature out of Range)	

Figure 13-6 Maintenance > Email Log

- 2. To email this log, follow the instructions in *Emailing Logs and Reports (on page 269)*.
- 3. To clear the log, click the **Clear Log** button.

Logging Commands

Go to *Logging Commands*, *USB Device Commands*, *USB Storage Commands*, and *USB Modem Commands* to view CLI commands which correspond to the web page entries described above.

Diagnostics

The *Maintenance > Diagnostics* page provides methods for diagnosing problems such as network connectivity and device port input/output problems. You can use equivalent commands on the command line interface.

1. Click the Maintenance tab and select the Diagnostics option. The following page displays:

	Host: slc433	SLC 80	48 LCD	U1 E1 1 3 U2 E2 2 4 Select port for 5 5 5	5 7 9 11 6 8 10 12	13 15 17 19 21 14 16 18 20 22 ion WebSSH	1 23 25 27 29 3 2 24 26 28 30 3 1 (DP only) Ca	1 33 35 37 39 41 2 34 36 38 40 42 onnected Device (D	1 43 45 47 A 2 44 46 48 B
Network Service	es <u>User Aut</u>	hentication	Devices	Maintenance	Quick Se	etup		础	? 🛱 🗉
Firmware/Config	System Log	Audit Log	Email Log	Diagnostics	Status/Repo	orts Events	LCD/Keypa	d Banners	
				Diagnost	ics				Help?
	Select Diag	nostics: 🗌	All						
			Arp Table						
			Netstat		Protocol:	All TC	P UDP		
			Host Looku	p	Hostname:				
			Ping		Hostname:				
				Et	hernet Port: IPv6 [.]	Both E	Eth1 🔵 Eth2		
			Send Pack	>t	Protocol:		IDP		
			Condition		Hostname:				
					Port:				
					String:	1			
				-	Count:				
			Loopback	L) evice Port: Test:	Internal	External		
		_							
			SLC Interna	ls					
			USB Devic	es Tr	ree Display:	4			
				N	/lap Device:				
				Run Diagnos	stics				

Figure 13-7 Maintenance > Diagnostics

2. Select **Diagnostics** from checklist (one or more diagnostic methods you want to run, or select **All** to run them all):

IPv4 ARP Table	The IPv4 Address Resolution Protocol (ARP) table used to view the IP address-to- hardware address mapping.
IPv6 Neighbor Table	The IPv6 Neighbor table is used to view a list of neighbor's IPv6 addresses on the same network, and their corresponding MAC addresses.
Netstat	Displays network connections. If you select the checkbox, select the TCP or UDP protocol, or select All for both protocols to control the output of the Netstat report.

Host Lookup	Select to verify that the SLC 8000 advanced console manager can resolve the host name into an IP address (if DNS is enabled). If selected, also enter a host name in the corresponding Hostname field,
Ping	Select to verify that the host is up and running. If selected, also do the following:
	 Enter a host name in the corresponding Hostname field Specify Ethernet Port (Both, Eth1 or Eth2) Check if the IPv6 version of ping should be used.
Send Packet	This option sends an Ethernet packet out one of the Ethernet ports, mainly as a network connectivity test. For UDP, the number of times the string is sent is equal to the number of packets sent. For TCP, the number of times the string is sent may (or may not) be equal to the number of packets sent, because TCP controls how data is packetized and sent out. Enter the following:
	 Protocol: Select the type of packet to send (TCP or UDP). Hostname: Specify a host name or IPaddress of the host to send the packet to. Port: Specify a TCP or UDP port number of the host to send the packet to. String: Enter a set of up to 64 characters. The string is encapsulated in the packet (so you could use a network sniffer to track the packet and, by looking at its contents, verify that it was sent). Count: The count is the number of times the string is sent.
Loopback	Specify loopback information:
	 Device Port Select either an Internal or External test
	Note: The External test is currently not supported for USB device ports
SLC Internals	Select to display information on the internal memory, storage and processes of the SLC 8000 advanced console manager.
USB Devices	Select to display information about USB buses and the devices connected to them, including a mapping between a USB device and the SLC ports.

3. Click the **Run Diagnostics** button. The *Maintenance > Diagnostics* page displays.

Logout		8048 LCD	SD U1 MD E1 1 U2 E2 2 Select port for	3 5 7 9 4 6 8 10 Configurat	11 13 15 17 19 21 23 25 27 29 31 33 35 37 3 0 12 14 16 18 20 22 24 26 28 30 32 34 36 38 4 tion WebSSH (DP only) Connected Devic	9 41 43 45 47 A 10 42 44 46 48 B e (DP only)
Network Services User Auth	entic	ation Devices	Maintenance	Quick Se	etup	ያ 🕆 🗈 🖻
Firmware/Config System Log	Audi	t Log Email Log	Diagnostics	Status/Rep	orts Events LCD/Keypad Banners	
			Diagnost	ics		Help?
Select Diagnostics:		All				
		IPv4 Arp Table				
		IPv6 Neighbor Tabl	e			
		Netstat		Protocol:	• All OTCP UDP	
		Host Lookup		Hostname:		
		Ping		Hostname:		
			Et	hernet Port:	Both Eth1 Eth2	
				IPv6:		
		Send Packet		Protocol:	TCP UDP	
				Hostname:		
				Port:		
				String:		
				Count:	1	
		Loopback	[)evice Port:		
				Test:	Internal External	
		SI C Internals				
		USB Devices	Т	ee Display:		
			N	lap Device:		

Figure 13-8 Maintenance > Diagnostics

- 4. To view a report, click the link for that report.
- 5. To email this report, follow the instructions in *Emailing Logs and Reports (on page 269)*.

Diagnostic Commands

Go to *Diagnostic Commands* to view CLI commands which correspond to the web page entries described above.

Status/Reports

On this page, you can view the status of the SLC ports and power supplies and generate a selection of reports.

Note: Status and statistics shown on the web interface represent a snapshot in time. To see the most recent data, you must reload the web page.

1. Click the **Maintenance** tab and select the **Status/Reports** option. The following page displays:

Logout Host: slc4331 User: sysadmin	LCD SD U S	1 E1 1 3 5 2 E2 2 4 6 elect port for • C	7 9 11 13 15 1 8 10 12 14 16 1 onfiguration OW	7 19 21 23 25 27 8 20 22 24 26 28 ebSSH (DP only) (29 31 33 35 37 30 32 34 36 38 Connected Devi	39 41 43 45 47 A 40 42 44 46 48 B ce (DP only)
Network Services User Authentication	Devices M	aintenance	Quick Setup			☆?☆≧
Firmware/Config System Log Audit Log En	nail Log Dia	ignostics Sta	tus/Reports	Events LCD/K	eypad Banne	ers
	Sta	tus/Report	s			Help?
			Devi	ce Ports		
Eth1: Up @ Eth2: Down @ Power Supply A: Failed @ Power Supply B: Ok @ Console Port: Not Connected @ Internal Modem: Not Installed @ Internal Temperature: 52 °C (125 °F) @	1: Ok @ 2: Ok @ 3: Ok @ 4: Ok @ 5: Ok @ 6: Ok @ 7: Ok @ 8: Ok @	9: OK @ 10: OK @ 11: OK @ 12: OK @ 13: OK @ 14: OK @ 15: OK @	17: OK 18: OK 19: OK 20: OK 21: OK 22: OK 23: OK 24:	25: OK @ 26: OK @ 27: OK @ 28: OK @ 30: OK @ 31: OK @ 32: OK @	33: Ok 34: Ok 35: Ok 36: Ok 37: Ok 38: Ok 39: Ok 40: Ok	41: OK 2 42: OK 2 43: OK 2 44: OK 2 45: OK 2 46: OK 2 47: OK 2 48: OK 2
View Report: All Port Status Port Count IP Routes Connection	ers Is Ge	enerate Report	System Confi System Confi System Confi System Confi	guration - Comp guration - Basic guration - Authei guration - Device	lete ntication es	

Figure 13-9 Maintenance > Status/Reports

The top half of the page displays the status of each port, power supply, and the internal modem:

- Green indicates that the port connection or power supply is active and functioning correctly.
- Red indicates an error or failure or that the device is off.
- 2. Select the desired reports to view under View Report:

View Report

All	Displays all reports.
Port Status	Displays the status of each device port: mode, user, any related connections, and serial port settings.
Port Counters	Displays statistics related to the flow of data through each device port.
IP Routes	Displays the routing table.
Connections	Displays all active connections for the SLC unit: Telnet, SSH, TCP, UDP, device port, and modem.

System Configuration – Complete	Displays a complete snapshot of the SLC settings.
System Configuration – Basic	Displays a snapshot of the SLC unit's basic settings (for example, network, date/time, routing, services, console port).
System Configuration – Authentication	Displays a snapshot of authentication settings only (including a list of all localusers).
System Configuration - Devices	Displays a snapshot of settings for each device port, USB Port, Modem, and Host Lists.

3. Click the **Generate Report** button. In the upper left of the *Generated Status/Reports* page displays a list of reports generated.

Logout	Host: slc4331 User: sysadmin		U2 E2 Select p	2 4 6 8	10 12 14 1 figuration	6 18 20 22 WebSSH	24 26 2 (DP only)	8 30 32	34 36 38 40 nected Device	42 44 46 4 (DP only)
work Service	us User Authent	ication Devic	es Mainten	ance Qui	ck Setup				础	? 🕀
rmware/Config	System Log Aud	lit Log Email L	og Diagnost	ics Status/	/Reports	Events	LCD/	Keypad	Banners	
			Status/	Reports						He
Report(s):			Email Output			Com	ment:			
							to:			
<u>P Routes</u> Connections										
P Routes										
ernel IP routi	ing table									
estination	Gateway	Genmask	Flags M	1SS Window	irtt If	ace				
.0.0.0	172.19.0.1	0.0.0.0	UG	0 0	0 e	th0				
/2.19.0.0	172.19.100.148	255.255.0.0	U	00	0 E	thø				
ernel IPv6 rou	ting table									
estination	Next	Нор	Flags Met	ric Ref	Use I	face				
:1/128		:	:				U	0	2	1 lo
001:db80:ac13:	d91e:280:a3ff:fe	96:4331/128 :	:				U	0	0	1 lo
001:db80:ac13:	d91e::/64	:	:				UA	256	0	0 eth0
e80::280:a3ff:	fe96:4331/128	:					U	0	0	1 lo
e80::/64			:				U	256	0	0 eth0
102::1/128		1	102::1				UC	0	5	0 eth0
·/0		:		f.f.o.0.h-2	5		UGDA	250	0	0 eth0
:/0		1	e80::6600:f1	ff:feb6:58	16e		UGDA	1024	0	0 eth0
							JUDA	1024	-	0 0010
onnections										
Id Port/Servic	e	Flw Port/Servi	ice	User	Upt	ime				
2 Console Por	·=====================================	<-> Command Li				22.31				

Figure 13-10 Generated Status/Reports

4. To email these report(s), follow the instructions in *Emailing Logs and Reports (on page 269)*.

Status Commands

Go to *Status Commands* to view CLI commands which correspond to the web page entries described above.

Emailing Logs and Reports

The following logs and reports can be directly emailed to a specific individual or to Lantronix Technical Support directly from the log page:

- System Log (*Figure 13-4*)
- Audit Log (*Figure 13-5*)
- Email Log (*Figure 13-6*)
- Diagnostic Reports (*Figure 13-8*)
- Status/Reports (*Figure 13-10*)

To email a log to an individual:

- 1. In the **Comment** field of a particular log or report page, enter a comment (if desired).
- 2. Select the **to** field beside the empty field where you then enter the person's email address.
- 3. Press the **Email Output** button. An email is immediately sent out and a confirmation appears on the screen.

M	5 🍲 🔶 ╤	SLC8048 Report (slc4331)	- Message (Pla	ain Text)	_ 🗆 🗙		
File	Vlessage Adobe A	PDF			۵ (3)		
🗟 🗙 Delete	Reply 🙀 Reply All	Image: Provide the second	Move	Mark Unread Categorize * Follow Up *	g Zoom		
Delete	Respond	Quick Steps 5	Move	Tags 1	Zoom		
From: To: Cc:	From: donotreply@slc4331 Sent: Tue 5/24/2016 1:18 AM To: Judy Chen Cc: Cc:						
Subject:	SLC8048 Report (slc4	1331)					
SLC8048 Report (slc4331) Generated 05/24/2016 08:18:09 GMT							
Kernel IP routing table Destination Gateway Genmask Flags MSS Window irtt Iface 0.0.0.0 172.19.0.1 0.0.0.0 UG 0.0 0 eth0 172.19.0.0 172.19.100.148 255.255.0.0 U 0.0 0 eth0							
A dor	notreply@slc4331				22 -		

Figure 13-11 Emailed Log or Report

To view information about the SLC unit and contact information for Lantronix:

1. Click the ? button on the upper right portion of any web page to access the **About SLC** page (see *Figure 13-12*).

	Figure 13-12 About SLC								
LAN	TROM	↓ X ° SLC 804		SD <mark>U1</mark> MD U2 ^{MD} E22	3 5 7 9 11 13 1 4 6 8 10 12 14 1	15 17 19 21 23 25 16 18 20 22 24 26	27 29 31 33 35 37 39 28 30 32 34 36 38 40	41 43 42 44	45 47 A 46 48 B
Logout Host: slc4331 User: sysadmin				Select port for <	Configuration	WebSSH (DP only)	Connected Device	(DP onl	y)
Network	Services	User Authentication	Devices	Maintenance	Quick Setup		命	? {	₽∎

About SLC 8048

Model: SLC 8048 Number of USB Ports: 2 Internal Modem: Installed Power Supply: AC, 2 power supplies S/N: 0080A3964331

Memory: 512 MB Flash Size: 512 MB Eth1 HW Address: 00:80:a3:96:43:31 Eth2 HW Address: 00:80:a3:96:43:32 NIC Board Type: N/A

Uptime: 0 days, 6 hours, 28 minutes

Firmware Version: **7.5.0.0R22** OS Version: Bootloader Version: **2.0.0.0R8** Main Board Revision: **unknown** I/O Module Type(s): **RJ45-16**, **USB-16**, **RJ45-16** I/O Module Revision(s): **16SPB**, **16UBA**, **16SPB**

Software Revisions: Kernel: 3.6.5 SSH/SSL: OpenSSH_6.7p1, OpenSSL 1.0.2n 7 Dec 2017 Telnet: netkit-telnet-0.17 NTP: ntpd 4.2.6p5 SMB/CIFS: Version 3.6.14 RIP: zebra version 0.99.22.1 Web Server: mini_httpd/1.24 PAM/NIS: 1.1.4 LDAP: 153 RADIUS: 1.4.0 Kerberos: 2.4.8 TACACS+: 1.4.1 ShellinABox: 2.19

 © 2003-2018, Lantronix, All rights reserved.

Lantronix Corporate Headquarters 7535 Irvine Center Drive, Suite 100 Irvine, CA 92618 USA Tel: +1 (949) 453-3990 Fax: +1 (949) 453-3995

Technical Support Hours: 6:00a - 5:00p PST Monday - Friday (excluding holidays) Tel: (800) 422-7044 (US only) Tel: (949) 453-7198 Fax: (949) 453-7226 FTP: ftp.lantronix.com

Events

On this *Maintenance > Events* page, you can define what action you want to take for events that may occur in the SLC unit.

1. Click the **Maintenance** tab and select the **Events** option. The following page displays:

L/ Netv	Logout vork Se mware/Cor	Host: slc43: User: sysac Invices User Au Infig System Log	SLC 804 31 Imin thentication Audit Log	8 LCD Devices Email Log	U1 E1 1 3 SD U2 E2 2 4 Select port for Maintenance Diagnostics	3 5 7 9 11 6 8 10 12 © Configurat Quick 5 Status/Re	13 15 17 19 21 14 16 18 20 22 ion WebSSH (I Setup ports Events	23 25 27 29 31 3 24 26 28 30 32 3 DP only) Conne LCD/Keypad	3 35 37 39 41 4 36 38 40 42 cted Device (DF CM Banners	43 45 47 A 2 44 46 48 B [⊃] only) ? { 1 / 2 / 2 / 2 / 2 / 2 / 2 / 2 / 2 / 2 /
					Events	;				Help?
	Trigger:	Receive Trap		•	Acti	on: Syslog				¥
Ho	st to Ping:				Etherr	net: 💿 Ethr	Eth2			
	RPM:	Select one 🔻				۲	USB Port l	J1		
	Outlet:	(optional))	N	1odem Connecti	on:	USB Port l	J2		
г	hreshold:	Amps o	r Load %		ND 40 / La -	Dev	ice Port:			
	L				forward trap	to:				
				:	SNMP Commun	ity:				
					SNMP Trap O	ID:				
					Email Addre	ss:				
		A	dd Event E	dit Event	Delete Event]		1	To edit or dele select the in the right co	ete an event, radio button blumn below.
					Events					
ld	Trigger	Options			Act	ion	Options			
					Apply					

Figure 13-13 Maintenance > Events

2. Enter the following:

Event Trigger	 From the drop-down list, select the type of incident that triggers an event. Currently, the options are: Receive Trap Temperature Over/Under Limit (for Sensorsoft devices) Humidity Over/Under Limit (for Sensorsoft devices) Device Port Data Drop No Internal Modem Dial Tone Ping Host Fails RPM Load Over Threshold
Host to Ping	When the trigger is set to Ping Host Fails , enter the hostname, IPv4 address or IPv6 address of the host to ping. The host will be pinged every 2 minutes.
RPM	When the trigger is set to RPM Load over Threshold , select the RPM that will be monitored for a current that exceeds a defined threshold. The RPM needs to support providing a current level as part of its status information. The RPM current will be checked every 2 minutes.

Outlet	When the trigger is set to RPM Load over Threshold , select the outlet that will be monitored for a current that exceeds a defined threshold. The RPM needs to support providing a current level for the selected outlet as part of its status information. If an outlet is not specified, the current level for the entire device will be monitored. The RPM current will be checked every 2 minutes.
Threshold	When the trigger is set to RPM Load over Threshold , specify the maximum allowable threshold for the current; any current readings over this threshold will trigger the selected action. The threshold can be specified in Amps (e.g. 8.5) or as a percentage (e.g. 90%).
Action	 From the drop-down list, select the action taken because of the trigger. For example, the action can be writing an entry into the syslog with details of the event or sending the trap(s) to the Ethernet or modem connection. Syslog Forward All Traps to Ethernet Forward Selected Trap to Ethernet Forward all Traps to a Modem Connection Forward Selected Trap to a Modem Connection Email Alert SNMP Trap
Ethernet	For actions that require an Ethernet connection (for example, Forward All Traps to Ethernet), select the Ethernet port to use.
Modem Connection on	For actions that require a modem connection (for example, Forward All Traps to a Modem Connection , select which modem connection to use (Device Port, USB Port U1, USB Port U2 , or the Internal Modem). Connections available depend on the model of the SLC unit.
NMS/Host to forward trap to	For actions that forward a trap, enter the IP address of the computer to forward the trap to. The computer does not have to be an SNMP NMS; it just has to be capable of receiving SNMP traps.
SNMP Community	Forwarded traps are sent with this SNMP community value There is no default.
SNMP Trap OID	Enter a unique identifier for an SNMP object. (An SNMP object is anything that can hold a value and can be read using an SNMP "get" action.) The OID consists of a string of numbers separated by periods (for example, 1.1.3.2.1). Each number is part of a group represented by the number on its left.
Email Addresses	Enter an email address to receive email alerts.

- 3. You have the following options:
 - To add the defined event, click the **Add Event** button. The event displays in the Events table at the bottom of the page.
 - To edit an event, select the event from the Events table and click the Edit Event button.
 The Maintenance > Events page displays the event.
 - To delete an event, select the event from the Events table and click the **Delete Event** button. A message asks for confirmation. Click **OK**.
- 4. To save, click **Apply**.

Events Commands

Go to *Events Commands* to view CLI commands which correspond to the web page entries described above.

LCD/Keypad

The LCD has a series of screens, consisting of 2 lines of 24 characters each. Specific screens and the display order can be configured. The keypad associated with the LCD can also be configured. The types of screens include: current time, network settings, console settings, date and time, release version, location, and custom user strings.

Enabling the **Auto-Scroll LCD Screens** option enables scrolling through the screens and pausing the number of seconds specified by the **Scroll Delay** between each screen. After any input to the keypad, the LCD waits until the keypad has been idle for the number of seconds specified by the **Idle Delay** before scrolling of the screens continues.

To configure the LCD and Keypad:

1. Click the **Maintenance** tab and select the **LCD/Keypad** option.

			i igu		mannena		sypau			
	RONI	X°S t:slc4331 r:sysadn	LC 804	8	U1 E1 1 3 U2 E2 2 4 Select port for	5 7 9 11 13 15 6 8 10 12 14 16 • Configuration	17 19 21 2 18 20 22 2 WebSSH (D	3 25 27 29 31 33 4 26 28 30 32 34 P only) Connec	35 37 39 41 4 36 38 40 42 4 ted Device (DP o	3 45 47 A 4 46 48 B nly)
Network	Services	Jser Auth	entication	Devices	Maintenance	Quick Setup	L		· ·	
Firmware/C	Config Syste	m Log	Audit Log	Email Log	Diagnostics	Status/Reports	Events	LCD/Keypad	Banners	
					LCD/Keyp	ad				Help?
LCD Set	<u>tings</u>					Keypad	d Settings			
	Enabled scree	ns or):			isabled screens:			Keypad Locl	ked: 🔲	
	Current Time	er). 9 ^			Device Ports	Restore Factory Defaults Passwork	re Factory Defaults Password	ord: •••••		
	Network			L	Location		ord: •••••			
Console Date/Time Release		+		nternal Temp	v					
	User Str	rings - Lin	e 1:							
		Lin	e 2:							
	Auto-Scroll L	CD Scree	ens: 📃							
		Scroll De	elay: 5	seconds						
		Idle De	elay: 10	seconds						
				-	Apply					

Figure 13-14 Maintenance > LCD/Keypad

To configure the LCD:

The screens that are currently enabled are displayed in order in the left Enabled screens list.

- 1. Select a screen to be removed from the **Enabled Screens** and click the button. The screen moves to the **Disabled Screens** list to the right.
- 2. Select a screen to be added from the **Disabled Screens** list and click the **button**. The screen is added to the **Enabled Screens** to the left.

3. Select a screen in the **Enabled Screens** list and click the representation of the screens.

Note: The User Strings screen displays the 2 lines defined by the User Strings - Line 1 and Line 2 fields. By default, these user strings are blank.

4. Click Apply to save.

To configure the Keypad:

1. Enter the following fields.

Keypad Locked	Select this to lock out any input to the keypad. The default is for the keypad to be unlocked.
Restore Factory Defaults Password / Retype Password	Enter the 6 digit key sequence entered at the keypad to restore the SLC unit to factory defaults. The default is 999999 .

2. Click **Apply** to save.

Administrative LCD/Keypad Commands

Go to *Administrative Commands* to view CLI commands which correspond to the web page entries described above.

Banners

The *Maintenance > Banners* page allows the system administrator to customize text messages that display to users.

Figure 13-15 Maintenance > Banners

To configure banner settings:

1. Click the **Maintenance** tab and select **Banners** option.

	Host: slc4331 User: sysadmin	48 LCD	Select port for	3 5 7 9 11 13 15 4 6 8 10 12 14 16 Configuration	17 19 21 2 18 20 22 2 WebSSH (D	23 25 27 29 31 3 24 26 28 30 32 3 0P only) Conne	3 35 37 39 4 4 36 38 40 4 cted Device (D	1 43 45 47 A 2 44 46 48 B OP only)
Network Services	User Authentication	Devices	Maintenance	Quick Setup	1		岱	? 🛱 🗉
Firmware/Config S	ystem Log Audit Log	Email Log	Diagnostics	Status/Reports	Events	LCD/Keypad	Banners	
			Banner	s				Help?
Welcome Banner: Login Banner: Logout Banner: SSH Banner:	Welcome to the SLC							
Note:	Line feeds can be include The web banner can be c	d in the bann onfigured <u>her</u>	ers with the '\n' <u>e</u> ≯.	character sequence	Ð.			

2. Enter the following fields.

Welcome Banner	The text to display on the command line interface before the user logs in. May contain up to 1024 characters. Single quote and double quote characters are not supported. Welcome to the SLC is the default.
	Note: To create more lines use the \n character sequence.
Login Banner	The text to display on the command line interface after the user logs in. May contain up to 1024 characters. Single quote and double quote characters are not supported. Default is blank.
	<i>Note:</i> To create more lines, use the \ n character sequence.
Logout Banner	The text to display on the command line interface after the user logs out. May contain up to 1024 characters. Single quote and double quote characters are not supported. Default is blank.
	Note: To create more lines use, the \n character sequence.
SSH Banner	The text to display when a user logs into the SLC via SSH, prior to authentication. May contain up to 1024 characters. Single quote and double quote characters are not supported. Blank by default.
	<i>Note:</i> To create more lines use the \n character sequence.

3. Click **Apply** to save.

Apply

Administrative Banner Commands

Go to *Administrative Commands* to view CLI commands which correspond to the web page entries described above.

14: Application Examples

Each SLC advanced console manager has multiple serial ports and two network ports. Each serial port can be connected to the console port of an IT device. Using a network port (in-band) or a modem (out-of-band) for dial-up connection, an administrator can remotely access any of the connected IT devices using Telnet or SSH.





This chapter includes three typical scenarios for using the SLC unit. The scenarios assume that the SLC 8000 advanced console manager is connected to the network and has already been assigned an IP address. In the examples, we use the command line interface. You can do the same things using the web page interface except for directly interacting with the SLC unit (direct command).

Telnet/SSH to a Remote Device

The following figure shows a Sun server connected to port 2 of the SLC 8000 advanced console manager.





In this example, the sysadmin would:

1. Display the current settings for device port 2:

```
[SLC] > show deviceport port 2
 Current Device Port
Settings
Number: 2 Name: Port-2
Modem Settings------Data Settings-----IP Settings-----
Modem State: disabled Baud Rate: 9600
                                              Telnet: disabled
Telnet Port: 2002
Modem Mode: text Data Bits: 8
Timeout Logins: disabled Stop Bits: 1
                                                 SSH: disabled
Local IP: negotiateParity: noneSSH Port: 3Remote IP: negotiateFlow Control: xon/xoffIP: <none>
                                                 SSH Port: 3002
Authentication: PAP
                         Logins: disabled
CHAP Host: <none>
                         Break Sequence: \x1bB
CHAP Secret: <none>
                         Check DSR: disabled
NAT: disabled
                         Close DSR: disabled
Dial-out Login: <none>
Dial-out Password: <none>
Dial-out Number: <none>
Dial-back Number: usernumber
Initialization Script: <none>
Logging Settings------
Local Logging: disabled USB Logging: disabled
Email Logging: disabled Log to: upper slot
Byte Threshold: 100 Max number of files: 10
Email Delay: 60 seconds Max size of files: 2048
Restart Delay: 60 seconds
Email To: <none>
Email Subject: Port %d Logging
Email String: <none>
NFS File Logging: disabled
Directory to log to: <none>
Max number of files: 10
Max size of files: 2048
2. Change the baud to 57600 and disable flow control:
[SLC]> set deviceport port 2 baud 57600 flowcontrol none
Device Port settings successfully updated.
3. Connect to the device port:
[SLC] > connect direct deviceport 2
4. View messages from the SUN server console:
Mar 15 09:09:44 tssf280r sendmail[292]: [ID 702911 mail.info] starting
daemon (8.12.2+Sun): SMTP+queueing@00:15:00
Mar 15 09:09:44 tssf280r sendmail[293]: [ID 702911 mail.info] starting
daemon (8.12.2+Sun): queueing@00:15:00
Mar 15 14:44:40 tssf280r sendmail[275]: [ID 702911 mail.info] starting
daemon (8.12.2+Sun): SMTP+queueing@00:15:00
Mar 15 14:44:40 tssf280r sendmail[276]: [ID 702911 mail.info] starting
daemon (8.12.2+Sun): queueing@00:15:00
5. Reboot the SUN server:
```

Reboot

<shutdown messages from SUN>

6. Use the escape sequence to escape from direct mode back to the command line interface.

Dial-in (Text Mode) to a Remote Device

This example shows a phone line connection to the internal modem of the SLC, and a Sun server connected to a device port. You can configure the modem for text mode dial-in, so a remote user can dial into the modem using a terminal emulation program and access the Sun server.



Figure 14-3 Dial-in (Text Mode) to a Remote Device

In this example, the sysadmin would:

1. Configure the device port that the modem is connected to for dial-in:

```
[SLC]> set deviceport port 1 modemmode text
Device Port settings successfully updated.
[SLC]> set deviceport port 1 initscript "AT&F&K3&C1&D2%C0A"
Device Port settings successfully updated.
[SLC]> set deviceport port 1 auth pap
Device Port settings successfully updated.
[SLC]> set deviceport port 1 localsecret "password"
Device Port settings successfully updated.
[SLC]> set deviceport port 1 modemstate dialin
Device Port settings successfully updated.
[SLC]> set deviceport port 1 modemstate dialin
Device Port settings successfully updated.
[SLC]>
```

2. Configure the device port that is connected to the console port of the Sun UNIX server:

[SLC]> set deviceport port 2 baud 57600 flowcontrol none Device Port settings successfully updated.

- 3. Dial into the SLC 8000 advanced console manager via the modem using a terminal emulation program on a remote PC. A command line prompt displays.
- 4. Log into the SLC unit.

```
CONNECT 57600
Welcome to the SLC
login: sysadmin
Password:
Welcome to the SLC Console Manager
Model Number: SLC 8048
For a list of commands, type 'help'.
[SLC]>
```

5. Connect to the SUN Unix server using the direct command.

```
[SLC]> connect direct deviceport 2
SunOS 5.7
login: frank
Password:
Last login: Wed Jul 14 16:07:49 from computer
Sun Microsystems Inc.SunOS 5.7Generic October 1998
SunOS computer 5.7 Generic_123485-05 sun4m sparc SUNW,SPARCstation-20
$
```

6. Use the escape sequence to escape from direct mode back to the command line interface.

Local Serial Connection to Network Device via Telnet

This example shows a terminal device connected to an SLC device port, and a Sun server connected over the network to the SLC device. When a connection is established between the device port and an outbound Telnet session, users can access the Sun server as though they were directly connected to it. (See *Chapter 11: Connections on page 204*).





In this example, the sysadmin would:

1. Display the current settings for device port 2:

```
[SLC] > show deviceport port 2
  Current Device Port
Settings
Number: 2 Name: Port-2
Modem Settings------Data Settings-----IP Settings-----
Modem State: disabled Baud Rate: 9600
                                              Telnet: disabled
Modem Mode: text
                       Data Bits: 8
                                              Telnet Port: 2002
Timeout Logins: disabled Stop Bits: 1
                                             SSH: disabled
Local IP: negotiate Parity: none
                                              SSH Port: 3002
Remote IP: negotiate
                       Flow Control: xon/xoff IP: <none>
Authentication: PAP
                       Logins: disabled
                       Break Sequence: \x1bB
CHAP Host: <none>
CHAP Secret: <none>
                       Check DSR: disabled
NAT: disabled
                        Close DSR: disabled
Dial-out Login: <none>
Dial-out Password: <none>
Dial-out Number: <none>
Dial-back Number: usernumber
Initialization Script: <none>
```

```
Logging Settings------
Local Logging: disabled USB Logging: disabled
Email Logging: disabled Log to: upper slot
Byte Threshold: 100 Max number of files: 10
Email Delay: 60 seconds Max size of files: 2048
Restart Delay: 60 seconds
Email To: <none>
Email Subject: Port %d Logging
Email String: <none>
NFS File Logging: disabled
Directory to log to: <none>
Max number of files: 10
Max size of files: 2048
```

2. Change the serial settings to match the serial settings for the vt100 terminal - changes baud to 57600 and disables flow control:

[SLC]> set deviceport port 2 baud 57600 flowcontrol none Device Port settings successfully updated.

3. Create a connection between the vt100 terminal connected to device port 2 and an outbound telnet session to the server. (The IP address of the server is 192.168.1.1):

[SLC]> connect bidirection 2 telnet 192.168.1.1 Connection settings successfully updated.

 At the VT100 terminal, hit <return> a couple of times. The Telnet prompt from the server displays:

Trying 192.168.1.1... Connected to 192.168.1.1. Escape character is '^]'.

Sun OS 8.0 login:

At this point, a user can log in and interact with the Sun server at the VT100 terminal as if directly connected to the server.

15: Command Reference

After an introduction to using commands, this chapter lists and describes all of the commands available on the SLC command line interface accessed through Telnet, SSH, or a serial connection. The commands are in alphabetical order by category.

Introduction to Commands

Following is some information about command syntax, command line help, and tips for using commands.

Command

Syntax

Commands have the following format:

<action> <category> <parameter(s)>

where

<action> is set, show, connect, admin, diag, or logout. <category> is a group of related parameters whose settings you want to configure or view. Examples are ntp, deviceport, and network. <parameter(s)> is one or more name-value pairs in one of the following formats:

<parameter name=""> <aa bb></aa bb></parameter>	User must specify one of the values (aa or bb) separated by a vertical line (). The values are in all lowercase and must be entered exactly as shown. Bold indicates a default value.
<parameter name=""> <value></value></parameter>	User must specify an appropriate value, for example, an IP address. The parameter values are in mixed case. Square brackets [] indicate optional parameters.

Table 15-1 Actions and Category Options

Action	Category
set	auth cifs cli command consoleport datetime deviceport groups history hostlist intmodem ipfilter kerberos ldap localusers log menu network nfs nis ntp password perfmon radius remoteusers routing rpm script sdcard security services site slcnetwork sshkey tacacs+ temperature usb vpn
show	<pre>auth auditlog cifs cli connections consoleport datetime deviceport emaillog groups history hostlist intmodem ipfilter kerberos ldap localusers log menu network nfs nis ntp perfmon portcounters portstatus radius remoteusers routing rpm script sdcard security services site slcnetwork sshkey sysconfig syslog sysstatus tacacs+ temperature usb user vpn</pre>

Action	Category	
connect	bidirection direct global listen restart script terminate unidirection	
diag	arp arp6 internals lookup loopback netstat nettrace perfstat ping ping6 sendpacket top traceroute usb	
admin	nin banner chip clear config events feature firmware ftp keypa lcd memory quicksetup reboot shutdown site version web	
logout	Terminates CLI session.	

Command Line Help

For general Help and to display the commands to which you have rights, type:

help

For general command line Help, type:

help command line

For release notes for the current firmware release, type:

help release

For more information about a specific command, type help followed by the command, for example:

help set network or help admin firmware

Tips

 Type enough characters to identify the action, category, or parameter name uniquely. For parameter values, type the entire value. For example, you can shorten:

```
set network port 1 state static ipaddr 122.3.10.1 mask 255.255.0.0 to
```

se net po 1 st static ip 122.3.10.1 ma 255.255.0.0

- Use the Tab key to automatically complete action, category, or parameter names. Type a
 partial name and press **Tab** either to complete the name if only one is possible, or to display
 the possible names if more than one is possible. Following a space after the preceding name,
 Tab displays all possible names.
- Should you make a mistake while typing, backspace by pressing the Backspace key and/or the Delete key, depending on how you accessed the interface. Both keys work if you use VT100 emulation in your terminal access program when connecting to the console port. Use the left and right arrow keys to move within a command.
- To clear an IP address, type 0.0.0.0, or to clear a non-IP address value, type CLEAR.

- When the number of lines displayed by a command exceeds the size of the window (the default is 25), the command output is halted until the user is ready to continue. To display the next line, press Enter, and to display the page, press the space bar. You can override the number of lines (or disable the feature altogether) with the set cli command.
- Keyboard Shortcuts:

Control-a: move to the start of the line Control-e: move to the end of the line

Control-b: move back to the start of the current word

Control-f: move forward to the end of the next word

Control-u: erase from cursor to the beginning of the line

Control-k: erase from cursor to end of the line

Administrative Commands

admin banner login

Syntax

admin banner login <Banner Text>

Description

Configures the banner displayed after the user logs in.

Note: To go to the next line, type \n and press Enter.

admin banner logout0

Syntax

admin banner logout <Banner Text>

Description

Configures the banner displayed after the user logs out.

Note: To go to the next line, type \n and press *Enter*.

admin banner show

Syntax

admin banner show

Description

Displays the welcome, SSH, login, and logout banners.

admin banner ssh

Syntax

admin banner ssh <Banner Text>

Description

Configures the banner that displays prior to SSH authorization.

admin banner welcome

Syntax

admin banner welcome <Banner Text>

Description

Configures the banner displayed before the user logs in.

Note: To go to the next line, type \n and press Enter.

admin config checksum

Syntax

admin config checksum

Description

Displays a checksum for the current configuration. Can be used to determine if the configuration has changed.

admin config copy

Syntax

```
admin config copy <current|Config Name>
    [location <local|nfs|cifs|usb|sdcard>
    [nfsdir <NFS Mounted Directory>] [usbport <U1|U2>] ]
```

Description

Copies the current configuration (or optionally, a configuration from another location) to the other bank (for dual-boot SLCs).

admin config rename|delete

Syntax

admin config delete <Config Name> location <local|nfs|cifs|usb|sdcard>
[usbport <U1|U2>] [nfsdir <NFS Mounted Directory>]
admin config rename <Config Name> location <local|nfs|cifs|usb|sdcard>
[usbport <U1|U2>] [nfsdir <NFS Mounted Directory>]

Description

Deletes or renames a configuration.

admin config factorydefaults

Syntax

admin config factorydefaults [savesshkeys <enable|disable>] [savesslcert <enable|disable>] [preserveconfig <Config Params to Preserve>] [savescripts <enable|disable>]

<Config Params to Preserve> is a comma-separated list of current configuration parameters to retain after the config restore or factorydefaults:

nt	Networking
sv	Services
dt	Date/Time
lu	Local Users
dp	Device Ports
ra	Remote Authentication
ub	USB Port/SD Card

Description

Restores the SLC unit to factory default settings.

admin config restore

Syntax

```
admin config restore <Config Name> location
<local|ftp|sftp|nfs|cifs|usb|sdcard> [nfsdir <NFS Mounted Directory>]
[usbport <U1|U2>] [preserveconfig <Config Params to Preserve>]
[savesshkeys <enable|disable>]
[savesslcert <enable|disable>]
[savescripts <enable|disable>]
```

ntNetworkingsvServicesdtDate/TimeluLocal UsersraRemote AuthenticationdpDevice PortsubUSB Port/SD Card

<Config Params to Preserve> is a comma-separated list of current configuration parameters to retain after the config restore or factory defaults:

Description

Restores a saved configuration to the SLC 8000 advanced console manager.

admin config save

Syntax

```
admin config save <Config Name> location
<local|ftp|sftp|nfs|cifs|usb|sdcard> [nfsdir <NFS Mounted Dir>] [usbport
<U1|U2>]
[savesshkeys <enable|disable>]
[savesslcert <enable|disable>]
[savescripts <enable|disable>]
```

Description

Saves the current SLC configuration to a selected location.

admin config show

Syntax

```
admin config show <local|ftp|sftp|nfs|cifs|usb|sdcard> [nfsdir <NFS Mounted Dir>] [usbport <U1|U2>]
```

Description

Lists the configurations saved to a location.

admin firmware bootbank

Syntax

admin firmware bootbank <1|2>

Description

Sets the boot bank to be used at the next SLC reboot.

admin firmware bootcount

Syntax

admin firmware bootcount <0|1>

Description

Configures bootcount parameterse that control how many times the SLC has failed to boot. If this value reaches Boot Limit, the SLC will switch to the alternate boot bank. The SLC will switch to the alternate boot bank only once. For example, if it fails to boot Boot Limit times on bank 1, it will automatically switch to bank 2; if it fails to boot Boot Limit times on bank 2, it will enter advanced recovery mode. If Boot Count has reached Boot Limit, setting this value to 0 will enable the SLC to boot again. Default is 0, range is 0 - 1.

admin firmware bootlimit

Syntax

admin firmware bootlimit <3-20>

Description

Configures bootlimit parameters that control how many times the SLC will fail to boot before switching to the alternate boot bank. After the SLC fails to boot 2 times Boot limit (so it has attempted to boot Boot Limit times on each bank), the SLC will go into advanced recovery mode, which may require support from Technical Support to resolve so that the SLC can be booted again. Default is 3 boots, range is 3 - 20.

admin firmware bootdelay

Syntax

admin firmware bootdelay <3-1800>

Description

Configures bootcount parameters that control how seconds the bootloader pauses before booting the SLC. The default is 3 seconds and the range is between 3 and 1800 seconds.

admin firmware highrestimers

Syntax

admin firmware highrestimers <enable|disable>

Description

Enables high resolution timers required for Performance Monitoring or disables high resolution timers (the default). Changing this setting requires a reboot in order for the change to take effect.
admin firmware watchdog

Syntax

admin firmware watchdog <disable | 180-1800 seconds>

Description

Configures how long the SLC waits for boot completion before forcing a reboot.

admin firmware show

Syntax

admin firmware show [viewlog <enable|disable>]

Description

Lists the current firmware revision, the boot bank status, and optionally displays the log containing details about firmware updates.

admin firmware update

Syntax

admin firmware update <**ftp**|tftp|sftp|nfs|usb|sdcard> file <Firmware File> key <Checksum Key> [nfsdir <NFS Mounted Dir>] [usbport <U1|U2>]

Description

Updates SLC firmware to a new revision.

You should be able to access the firmware file using the settings admin ftp show displays if FTP, TFTP or SFTP are used to load the firmware file. The SLC 8000 advanced console manager automatically reboots after successful update.

admin firmware clearlog

Syntax

admin firmware clearlog

Description

Clears the firmware update log.

admin ftp password

Syntax

admin ftp password

Sets the FTP server password and prevent it from being echoed.

admin ftp server

Syntax

admin ftp server <IP Address or Hostname> [login <User Login>] [path <Directory>]

Description

Sets the FTP/TFTP/SFTP server used for firmware updates and configuration save/restore.

admin ftp show

Syntax

admin ftp show

Description

Displays FTP settings.

admin keypad

Syntax

admin keypad <lock|unlock>

Description

Locks or unlocks the LCD keypad. If the keypad is locked, you can scroll through settings but not change them.

admin keypad password

Syntax

admin keypad password

Must be 6 digits.

Description

Changes the Restore Factory Defaults password used at the LCD to return the SLC advanced console server to the factory settings.

admin keypad show

Syntax

admin keypad show

Description

Displays keypad settings.

admin lcd reset

Syntax

admin lcd reset

Description

Restarts the program that controls the LCD.

admin lcd default

Syntax

admin lcd default

Description

Restores the LCD screens to their factory default settings.

admin lcd screens

Syntax

```
admin lcd screens <zero or more parameters>
```

Parameters

```
currtime <1-9>
network <1-9>
console <1-9>
datetime <1-9>
release <1-9>
devports <1-9>
location <1-9>
temp <1-9>
userstrings <1-9>
```

Description

Sets which screens will be displayed on the LCD, and their order.

admin lcd line1

Syntax

admin lcd line1 <1-24 Chars> line2 <1-24 Chars>

Description

Sets the strings displayed on the LCD user string screen.

admin lcd scrolling

Syntax

```
admin lcd scrolling <enable|disable>
    [scrolldelay <Delay in Seconds>] [idledelay <Delay in Seconds>]
```

Description

Configures auto-scroll of the LCD screens, including the number of seconds after keypad input before auto-scrolling restarts.

admin memory show

Syntax

admin memory show

Description

Displays information about SLC memory usage.

admin memory swap add

Syntax

admin memory swap add <Size of Swap in MB> usbport <U1|U2>

Description

Creates a swap space from an external storage device.

admin memory swap delete

Syntax

admin memory swap delete

Description

Deletes the swap space from an external storage device.

admin quicksetup

Syntax

admin quicksetup

Description

Runs the quick setup script.

admin reboot

Syntax

admin reboot

Description

Immediately terminates all connections and reboots the SLC 8000 advanced console manager.

The front panel LCD displays the "Rebooting the SLC" message, and the normal boot sequence occurs.

admin shutdown

Syntax

admin shutdown

Description

Prepares the SLC 8000 advanced console manager to be powered off.

When you use this command to shut down the SLC console manager, the LCD front panel displays the "Shutting down the SLC" message, followed by a pause, and then "Shutdown complete." When "Shutdown complete" displays, it is safe to power off the SLC 8000 advanced console manager.

admin site

Syntax

```
admin site row <Data Center Rack Row Number>
admin site cluster <Data Center Rack Group Number>
admin site rack <Data Center Rack Number>
admin site tag <Site Description>
admin site show
```

Description

Configures information about the site where the SLC 8000 advanced console manager is located.

admin version

Syntax

admin version

Description

Displays current hardware and firmware information.

admin web certificate import

Syntax

admin web certificate import via <sftp|scp> certfile <Certificate File> privfile <Private Key File> host <IP Address or Name> login <User Login> [path <Path to Files>]

Description

Imports an SSL certificate.

admin web certificate reset

Syntax

admin web certificate reset

Description

Resets the web server to the default SSL certificate.

admin web certificate custom

Syntax

admin web certificate custom

Description

Generates a custom self-signed SSL certificate. The SHA256 hashing algorithm will be used to generate the certificate.

admin web certificate show

Syntax

admin web certificate show

Description

Displays the web server SSL certificate.

admin web gadget

Syntax

admin web gadget <enable|disable>

Description

Enables or disables iGoogle Gadget web content.

admin web group

Syntax

admin web group <Local or Remote Group Name>

Description

Configures the group that can access the web.

admin web server

Syntax

admin web server <enable|disable>

Description

Enables or disables running the web server (TCP ports 80 and 443). admin web server <enable|disable>

admin web sha2

Syntax

admin web sha2 <enable|disable>

Description

Enables using only SHA2 and higher ciphers.

admin web timeout

Syntax

admin web timeout <disable |5-120>

Description

Configures the timeout for web sessions.

admin web terminate

Syntax

admin web terminate <Session ID>

Description

Terminates a web session.

admin web show

Syntax

admin web show [viewcipherlist <enable|disable>]

Description

Displays the current sessions, with optional extra sessions or current ciphers.

admin web banner

Syntax

admin web banner

Description

Configures the banner displayed on the web home page.

admin web iface

Syntax

admin web iface <none,eth1,eth2,ppp>

Description

Defines a list of network interfaces the web is available on.

admin web cipher

Syntax

admin web cipher <high|himed|fips>

Description

Configures the strength of the cipher used by the web server (high is 256, 168 and some 128 bit, medium is 128 bit)

admin web sha2

Syntax

admin web sha2 <enable|disable>

Description

Enable using only SHA2 and higher ciphers.

admin web tlsv10

Syntax

admin web tlsv10 <enable|disable>

Description

Enables or disables TLS v1.0.

admin web tlsv11

Syntax

admin web tlsv11 <enable|disable>

Description

Enables or disables TLS v1.1.

admin web restart

Syntax

admin web restart

Description

Restarts the web server.

Warning: The following admin chip commands should only be used under the direction of Lantronix Technical Support.

admin chip resetmodem

Description

Resets the internal modem chip in key system chips.

```
admin chip resetmodem admin chip reseti2cmux
```

Resets the I2C Mux chip in key system chips.

Syntax

admin chip reseti2cmux
admin chip resetsfp ethport <1|2>

Description

Resets the SFP chip in key system chips.

Syntax

admin chip resetsfp ethport <1|2>

Audit Log Commands

show auditlog

Syntax

show auditlog [command|user|clear]

Description

Displays audit log. By default, shows the audit log sorted by date/time. You can sort it by user or command, or clear the audit log.

Authentication Commands

set auth

Syntax

set auth <one or more parameters>

Parameters

```
authusenextmethod <enable|disable>
kerberos <1-6>
ldap <1-6>
localusers <1-6>
nis <1-6>
radius <1-6>
tacacs+ <1-6>
```

Sets ordering of authentication methods.

Local Users authentication is always the first method used. Any methods omitted from the command are disabled.

show auth

Syntax

show auth

Description

Displays authentication methods and their order of precedence.

show user

Syntax

show user

Description

Displays attributes of the currently logged in user.

Kerberos Commands

set kerberos

Syntax

set kerberos <one or more parameters>

Parameters

```
allowdialback <enable|disable>
clearports <Port List>
custommenu <Menu Name>
dataports <Port List>
dialbacknumber <Phone Number>
breakseq <1-10 Chars>
escapeseq <1-10 Chars>
group <default|power|admin>
ipaddr <Key Distribution Center IP Address>
kdc <Key Distribution Center>
listenports <Port List>
permissions <Permission List>
```

Note: See User Permissions Commands (on page 309) for information on groups and user rights.

port <Key Distribution Center TCP Port>
realm <Kerberos Realm>
state <enable|disable>
useldapforlookup <enable|disable>

Description

Configures the SLC 8000 advanced console manager to use Kerberos to authenticate users who log in via the Web, SSH, Telnet, or the console port.

show kerberos

Syntax

show kerberos

Description

Displays Kerberos settings.

LDAP Commands

set ldap

Syntax

set ldap <one or more parameters>

Parameters

```
state <enable|disable>
server1 <IP Address or Name>
server2 <IP Address or Name>
port <TCP Port>
base <LDAP Base>
bindname <Bind Name>
bindwithlogin <enable|disable>
useldapschema <enable|disable>
adsupport <enable|disable>
filteruser <User Login Attribute>
filtergroup <Group Objectclass>
grmemberattr <Group Membership Attribute>
grmembervalue <dn|name>
encrypt <starttls|ssl|disable>
dataports <Port List>
listenports <Port List>
clearports <Port List>
escapeseq <1-10 Chars>
breakseq <1-10 Chars>
custommenu <Menu Name>
allowdialback <enable|disable>
```

dialbacknumber <Phone Number>
group <default|power|admin>
permissions <Permission List>

Note: See User Permissions Commands (on page 309) for information on groups and user rights.

Description

Configures the SLC 8000 advanced console manager to use LDAP to authenticate users who log in via the Web, SSH, Telnet, or the console port.

set ldap bindpassword

Description

Set the LDAP bind password.

Syntax

```
set ldap bindpassword
```

set ldap certificate import

Description

To upload X.509/PEM certificate for Start TLS encrypted connections:

Syntax

```
set ldap certificate import via <sftp|scp> rootfile <Cert Auth File>
    certfile <Certificate File> keyfile <Key File>
    host <IP Address or Name> login <User Login> [path <Path to Files>]
```

set ldap certificate delete

Description

To delete an LDAP certificate.

Syntax

set ldap certificate delete

show ldap

Syntax

show ldap

Description

Displays LDAP settings.

Local Users Commands

set localusers add|edit

Syntax

set localusers add/edit <User Login> <one or more parameters>

Parameters

```
allowdialback <enable|disable>
breakseq <1-10 Chars>
changenextlogin <enable|disable>
changepassword <enable|disable>
clearports <Port List>
dataports <Port List>
dialbacknumber <Phone Number>
displaymenu <enable|disable>
escapeseq <1-10 Chars>
listenports <Port List>
custommenu <Menu Name>
uid <User Identifier>
group <default|power|admin|Custom Group Name>
passwordexpires <enable|disable>
permissions <Permission List>
```

Note: See User Permissions Commands (on page 309) for information on groups and user rights. Remove Escape & Break Sequences for users making raw binary connections to Device Ports.

Description

Configures local accounts (including sysadmin) who log in to the SLC 8000 advanced console manager by means of the Web, SSH, Telnet, or the console port.

set localusers allowreuse

Syntax

set localusers allowreuse <enable|disable>

Description

Sets whether a login password can be reused.

set local users complexpasswords

```
set localusers complexpasswords <enable | disable>
```

Sets whether a complex login password is required. Complex passwords require at least one uppercase character, one lowercase character, one digit, and one non-alphanumeric character.

set localusers state

Syntax

set localusers state <enable|disable>

Description

Enables or disables authentication of local users.

set localusers delete

Syntax

set localusers delete <User Login>

Description

Deletes a local user.

set localusers lifetime

Syntax

set localusers lifetime <Number of Days>

Description

Sets the number of days the login password may be used. The default is 90 days.

set localusers maxloginattempts

Syntax

set localusers maxloginattempts <Number of Logins>

Description

Sets the maximum number of login attempts before the account is locked. Disabled by default.

set localusers password

```
set localusers password <User Login>
```

Sets a login password for the local user.

set localusers periodlockout

Syntax

set localusers periodlockout <Number of Minutes>

Description

Sets the number of minutes after a lockout before the user can try to log in again. Disabled by default.

set localusers periodwarning

Syntax

set localusers periodwarning <Number of Days>

Description

Sets the number of days the system warns the user that the password will be expiring. The default is 7 days.

set localusers reusehistory

Syntax

set localusers reusehistory <Number of Passwords>

Description

Sets the number of passwords the user must use before reusing an old password. The default is 4.

set localusers multipleadminlogins

Syntax

set localusers multipleadminlogins <enable|disable>

Description

Allows multiple admin logins among local users to the web server.

set localusers consoleonlyadmin

```
set localusers consoleonlyadmin <enable|disable>
```

Sets local users. to console only admin setting. If enabled, the admin user can only log into the SLC via the console, and will be prevented from logging in via the web, SSH or Telnet.

show localusers

Syntax

show localusers [display <brief|extended>] [user <User Login>]

Description

Displays local users.

set localusers lock

Syntax

set localusers lock <User Login>

Description

Blocks (locks) a user's ability to login.

set localusers unlock

Syntax

set localusers unlock <User Login>

Description

Allows (unlocks) a user's ability to login.

set localusers permissions

Syntax

set localusers add/edit <user> permissions <Permission List>

where

<Permission List> is one or more of nt, sv, dt, lu, ra, sk, um, dp, do, ub, rp, rs, rc, dr, wb, sn, ad, md, sd

To remove a permission, type a minus sign before the two-letter abbreviation for a user permission.

Description

Sets a local user's permissions (not defined by the user group).

NIS Commands

set nis

Syntax

set nis <one or more parameters>

Parameters

allowdialback <enable|disable>
broadcast <enable|disable>
clearports <Port List>
custommenu <Menu Name>
dialbacknumber <Phone Number>
dataports <Port List>
domain <NIS Domain Name>
breakseq <1-10 Chars>
escapeseq <1-10 Chars>
group <default|power|admin>
listenports <Port List>
master <IP Address or Hostname>
permissions <Permission List>

Note: See User Permissions Commands on page 309 for information on groups and user rights.

slave1 <IP Address or Hostname>
slave2 <IP Address or Hostname>
slave3 <IP Address or Hostname>
slave4 <IP Address or Hostname>
slave5 <IP Address or Hostname>
state <enable|disable>

Description

Configures the SLC 8000 advanced console manager to use NIS to authenticate users who log in via the Web, SSH, Telnet, or the console port.

show nis

Syntax

show nis

Description

Displays NIS settings.

RADIUS Commands

set radius

Syntax

set radius <one or more parameters>

Parameters

```
state <enable|disable>
allowdialback <enable|disable>
clearports <Port List>
custommenu <Menu Name>
dataports <Port List>
dialbacknumber <Phone Number>
breakseq <1-10 Chars>
escapeseq <1-10 Chars>
group <default|power|admin>
listenports <Port List>
permissions <Permission List>
```

Note: See User Permissions Commands on page 309 for information on groups and user rights.

timeout <enable |1-30>

Note: Sets the number of seconds after which the connection attempt times out. It may be 1-30 seconds.

Description

Configures the SLC 8000 advanced console manager to use RADIUS to authenticate users who log in via the Web, SSH, Telnet, or the console port.

set radius server

Syntax

set radius server <1|2> host <IP Address or Hostname> secret <Secret>
[port <TCP Port>]

Description

Identifies the RADIUS server(s), the text secret, and the number of the TCP port on the RADIUS server.

Note: The default port is 1812.

show radius

Syntax

show radius

Description

Displays RADIUS settings.

TACACS+ Commands

set tacacs+

Syntax

set tacacs+ <one or more parameters>

Parameters

state <enable|disable> server1 <IP Address or Name> server2 <IP Address or Name> server3 <IP Address or Name> encrypt <enable|disable> authservice <login|pap|chap> service <Service to Authorize> protocol <Protocol for Service> timeout <1-10 seconds> dataports <Port List> listenports <Port List> clearports <Port List> escapeseq <1-10 Chars> breakseq <1-10 Chars> custommenu <Menu Name> allowdialback <enable|disable> dialbacknumber < Phone Number> group <default|power|admin> permissions <Permission List>

Note: See User Permissions Commands (on page 309) for information on groups and user rights.

Set the TACACS+ secret (any extra parameters will be ignored):

set tacacs+ secret

Description

Configures the SLC 8000 advanced console manager to use TACACS+ to authenticate users who log in via the Web, SSH, Telnet, or the console port.

show tacacs+

Syntax

show tacacs+

Description

Displays TACACS+ settings.

User Permissions Commands

set localusers group

Syntax

set localusers add|edit <user> group <default|power|admin|custom group
name>

Description

Adds a local user to a user group or changes the group the user belongs to.

set localusers lock

Syntax

set localusers lock <User Login>

Description

Blocks (locks) a user's ability to login.

set localusers unlock

Syntax

set local users unlock <User Login>

Description

Allows (unlocks) a user's ability to login.

set localusers permissions

```
set localusers add|edit <user> permissions <Permission List>
where
```

<Permission List> is one or more of nt, sv, dt, lu, ra, sk, um, dp, do, ub, rp, rs, rc, dr, wb, sn, ad, md, sd

To remove a permission, type a minus sign before the two-letter abbreviation for a user permission.

Description

Sets a local user's permissions (not defined by the user group).

set <nis|ldap|radius|kerberos|tacacs+> permissions

Syntax

set <nis|ldap|radius|kerberos|tacacs> permissions <Permission List>

where

<Permission List> is one or more of nt, sv, dt, lu, ra, sk, um, dp, do, ub, rp, rs, rc, dr, wb, sn, ad, md, sd

Description

Sets permissions not already defined by the assigned permissions group.

show user

Syntax

show user

Description

Displays the rights of the currently logged-in user.

Remote User Commands

set remoteusers add|edit

Syntax

set remoteusers add|edit <User Login> [<parameters>]

Parameters

```
dataports <Port List>
breakseq <1-10 Chars>
escapeseq <1-10 Chars>
listenports <Port List>
clearports <Port List>
custommenu <Menu Name>
displaymenu <enable|disable>
allowdialback <enable|disable>
```

```
dialbacknumber <Phone Number>
group <default|power|admin|Custom Group Name>
permissions <Permissions List>
```

where

```
<Permission List> is one or more of nt, sv, dt, lu, ra, sk, um, dp, do, ub, rp, rs, rc, dr, wb, sn, ad, md, sd
```

To remove a permission, type a minus sign before the two-letter abbreviation for a user right.

Description

Sets attributes for users who log in by a remote authentication method.

set remoteusers listonlyauth

Syntax

```
set remoteusers listonlyauth <enable | disable >
```

Description

Sets whether remote users who are not part of the remote user list will be authenticated.

set remoteusers lock|unlock

Syntax

```
set remoteusers lock|unlock <User Login>
```

Description

Allow (unlock) or block (lock) a user's ability to login.

set remoteusers delete

Syntax

set remoteusers delete <User Login>

Description

Removes a remote user.

show remoteusers

Syntax

show remoteusers

Description

Displays settings for all remote users

set <nis|ldap|radius|kerberos|tacacs+> group

Syntax

set <nis|ldap|radius|kerberos|tacacs> group <default|power|admin>

Description

Sets a permission group for remotely authorized users.

CLI Commands

set cli

Syntax

set cli scscommands <enable|disable>

Parameters

```
set cli scscommands <enable|disable>
set cli terminallines <disable|Number of Lines>
set cli menu <start|Menu Name>
show cli
```

Description

Allows you to use SCS-compatible commands as shortcuts for executing commands. It is disabled by default.

Note: Settings are retained between CLI sessions for local users and users listed in the remote users list.

set cli menu

Description

If a menu is associated with the current user and the menu was not displayed at login, 'start' will run the menu. Users with full administrative or menu user rights can also specify the name of any menu to run.

```
set cli menu <start|Menu Name>
set cli terminallines
set cli terminallines <disable|Number of lines>
```

Sets the number of lines in the terminal emulation (screen) for paging through text one screenful at a time, if the SLC 8000 advanced console manager cannot detect the size of the terminal automatically.

Note: Settings are retained between CLI sessions for local users and users listed in the remote users list.

show cli

Syntax

show cli

Description

Displays current CLI settings.

show user

Syntax

show user

Description

Displays attributes of the currently logged in user.

set history

Syntax

set history clear

Description

Clears the commands that have been entered during the command line interface session.

show history

Syntax

show history

Description

Displays the last 100 commands entered during the session.

Connection Commands

connect bidirection

Syntax

connect bidirection <Port # or Name> <endpoint> <one or more Parameters>

Parameters

```
Endpoint is one of:
charcount <# of Chars>
charseq <Char Sequence>
charxfer <toendpoint|fromendpoint>
date <MMDDYYhhmm[ss]>
deviceport <Device Port # or Name>
exclusive <enable|disable>
ssh <IP Address or Name> [port <TCP Port>][<SSH flags>]
```

where <SSH flags> is one or more of: user <Login Name> version <1|2> command <Command to Execute>

```
tcp <IP Address> [port <TCP Port>]
telnet <IP Address or Name> [port <TCP Port>]
trigger <now|datetime|chars>
```

If the trigger is datetime (establish connection at a specified date/time), enter the date parameter. If the trigger is chars (establish connection on receipt of a specified number or characters or a character sequence), enter the charxfer parameter and either the charcount or the charseq parameter.

```
udp <IP Address> [port <UDP Port>]
```

Description

Connects a device port to another device port or an outbound network connection (data flows in both directions).

connect direct

Syntax

connect direct <endpoint>

Parameters

```
Endpoint is one of:
deviceport <Device Port # or Name>
ssh <IP Address or Name> [port <TCP Port>][<SSH flags>]
where <SSH flags> is one or more of:
  user <Login Name>
  version <1|2>
  command <Command to Execute>
```

tcp <IP Address> [port <TCP Port>]
telnet <IP Address or Name> [port <TCP Port>]
udp <IP Address> [port <UDP Port>

Description

Connects to a device port to monitor and/or interact with it, or establishes an outbound network connection.

connect global outgoingtimeout

Syntax

connect global outgoingtimeout <disable|1-9999 seconds>

Description

Sets the amount of time the SLC 8000 advanced console manager will wait for a response (sign of life) from an SSH/Telnet server that it is trying to connect to.

Note: This is not a TCP timeout.

connect listen deviceport

Syntax

connect listen deviceport <Device Port # or Name>

Description

Monitors a device port.

connect terminate

Syntax

connect terminate <Connection ID>

Description

Terminates a connection.

connect unidirection

Syntax

connect unidirection <Device Port # or Name> dataflow
<toendpoint fromendpoint> <endpoint>

Parameters

Endpoint is one of: charcount <# of Chars>

```
charseq <Char Sequence>
datetime <MMDDYYhhmm[ss]>
deviceport <Port # or Name>
exclusive <enable|disable>
ssh <IP Address or Name> [port <TCP Port][<SSH flags>]
    where <SSH flags> is one or more of:
    user <Login Name>
    version <1|2>
    command <Command to Execute>
tcp <IP Address> [port <TCP Port>]
telnet <IP Address or Name> [port <TCP Port]</pre>
```

```
trigger <now|datetime|chars>
```

If the trigger is datetime (establish connection at a specified date/time), enter the date parameter. If the trigger is chars (establish connection on receipt of a specified number or characters or a character sequence), enter either the charcount or the charseq parameter.

```
udp <IP Address> [port <UDP Port>]
```

Description

Connects a device port to another device port or an outbound network connection (data flows in one direction).

show connections

Syntax

```
show connections [email <Email Address>]
```

Description

Displays connections and their IDs. You can optionally email the displayed information.

The connection IDs are in the left column of the resulting table. The connection ID associated with a particular connection may change if the connection times out and is restarted.

show connections connid

Syntax

show connections connid <Connection ID> [email <Email Address>]

Description

Displays details for a single connection. You can optionally email the displayed information.

Console Port Commands

set consoleport

Syntax

set consoleport <one or more parameters>

Parameters

```
baud <300-230400>
databits <7|8>
flowcontrol <none|xon/xoff|rts/cts>
group <Local or Remote Group Name>
parity <none|odd|even>
showlines <disable|1-50 lines>
stopbits <1|2>
timeout <disable|1-30>
```

Description

Configures console port settings.

show consoleport

Syntax

show consoleport

Description

Displays console port settings.

Custom User Menu Commands

When creating a custom user menu, note the following limitations:

- Maximum of 20 custom user menus.
- Maximum of 50 commands per custom user menu (logout is always the last command).
- Maximum of 15 characters for menu names.
- Maximum of five nested menus can be called.
- No syntax checking. (Enter each command correctly.)

set localusers

```
set localusers add|edit <User Login> custom menu <Menu Name>
```

Assigns a custom user menu to a local user.

set menu add

Syntax

set menu add <Menu Name> [command <Command Number>]

Description

Creates a new custom user menu or adds a command to an existing custom user menu.

set menu edit

Syntax

set menu edit <Menu Name> <parameter>

Parameters

```
command <Command Number>
nickname <Command Number>
redisplaymenu <enable|disable>
shownicknames <enable|disable>
title <Menu Title>
```

Description

Changes a command within an existing custom user menu. Changes a nickname within an existing custom user menu. Enables or disables the redisplay of the menu before each prompt. Enables or disables the display of command nicknames instead of commands. Sets the optional title for a menu.

set menu delete

Syntax

set menu delete <Menu Name> [command <Command Number>]

Description

Deletes a custom user menu or one command within a custom user menu.

set <nis|ldap|radius|kerberos|tacacs+> custommenu

Syntax

set <nis|ldap|radius|kerberos|tacacs> custommenu <Menu Name>

Assigns a custom menu to users who authenticate via NIS, LDAP, Radius, Kerberos, or TACACS+.

set remoteusers add|edit

Syntax

set remoteusers add|edit <User Login> custommenu <Menu Name>

Description

Sets a default custom menu for remotely authorized users.

show menu

Syntax

show menu <all|Menu Name>

Description

Displays a list of all menu names or all commands for a specific menu.

Date and Time Commands

set datetime

Syntax

set datetime <one parameter>

Parameters

date <MMDDYYhhmm[ss]>
timezone <Time Zone>

Note: If you do not know a valid <Time Zone>, enter 'timezone <invalid time zone>' and you will be guided through selecting one from the available time zones.

Description

Sets the local date, time, and local time zone (one parameter at a time).

show datetime

Syntax

show datetime

Displays the local date, time, and time zone.

set ntp

Syntax

set ntp <one or more ntp parameters>

Parameters

```
localserver1 <IP Address or Hostname>
localserver2 <IP Address or Hostname>
localserver3 <IP Address or Hostname>
poll <local|public>
publicserver <IP Address or Hostname>
state <enable|disable>
sync <broadcast|poll>
```

Description

Synchronizes the SLC 8000 advanced console manager with a remote time server using NTP.

show ntp

Syntax

show ntp

Description

Displays NTP settings.

Device Commands

set command

Syntax

set command <Device Port # or Name or List> <one or more parameters>

Parameters

sensorsoft lowtemp <Low Temperature>
Sets the lowest temperature permitted for the port.
sensorsoft hightemp <High Temperature>
Sets the hightest temperature permitted for the port.
sensorsoft lowhumidity <Low Humidity %>

Sets the lowest humidity pemitted for the port.

sensorsoft highhumidity <High Humidity %>

Sets the lowest humidity permitted for the port.

sensorsoft degrees <celsius|fahrenheit>

Enables or disables temperature settings as celcius or fahrenheit.

sensorsoft traps <enable|disable>

Enables or disables traps when specified conditions are met.

sensorsoft status

Displays the status of the port.

sensorsoft showall

Displays the status for all connected Sensorsoft devices and ignores the device port/nlist.

Note: The Sensorsoft lowtemp and hightemp settings are given in the scale specified by the degrees setting.

Description

Sends commands to (or control) a device connected to an SLC device port over the serial port.

Note: Currently the only devices supported for this type of interaction are Sensorsoft devices.

Device Port Commands

set deviceport port

Description

Sets the dialout password.

Syntax

set deviceport port <Device Port # or List or Name> <one or more device
port parameters>

Example: set deviceport port 2-5,6,12,15-16 baud 2400

Parameters

```
actiondelay <Action Delay>
actionrestart <Restart Delay>
assertdtr <enable|disable>
auth <pap|chap>
banner <Banner Text>
baud <300-230400>
breakseq <1-10 Chars>
bytethreshold <# of Characters>
```

calleridcmd <Modem Command String> calleridlogging <enable | disable > cbcptype <admin|user> cbcpnocallback <enable|disable> chapauth <chaphost | localusers> chaphost <CHAP Host or User Name> checkdsr <enable|disable> closedsr <enable|disable> connectedmsg <enable|disable> databits <7 | 8> device <none|sensorsoft|rpm> detectname <enable|disable> detecttokens <Name Detection Tokens> dialbackdelay <PPP Dial-back Delay> dialbacknumber <usernumber|Phone Number> dialbackretries <1-10> dialinlist <Host List for Dial-in> dialoutlogin <Remote User Login> dialoutnumber <Phone Number> dodauth <pap|chap> dodchaphost <CHAP Host or User Name> emailsubj <Email Subject> emailto <Email Address> flowcontrol <none|xon/xoff|rts/cts> group <Local or Remote Group Name> idletimeoutmsg <enable|disable> initscript <Modem Initialization Script> ipaddr <IP Address[/Mask Bits]> locallogging <enable|disable> maxdirect <1-15>

Note: We recommend preceding the initscript with **AT** and include **E1 V1 x4 Q0** so that the SLC 8000 advanced console manager may properly control the modem.

```
localipaddr <negotiate|IP Address>
logins <enable|disable>
minimizelatency <enable|disable>
modemmode <text|ppp>
modemstate <disable|dialin|dialout|dialback|dialinhostlist|dialondemand|</pre>
   dialin+ondemand|dialback+ondemand|cbcpclient|cbcpserver>
modemtimeout <disable|1-9999 seconds>
name <Device Port Name>
nat <enable/disable>
nfsdir <Logging Directory>
nfslogging <enable|disable>
nfsmaxfiles <Max # of Files>
nfsmaxsize <Size in Bytes>
numsessionsmsg <enable|disable>
parity <none|odd|even>
portlogseq <1-10 Chars>
poweraction <on|off|cycle>
powermgmtseq <1-10 Chars>
powersupply <Managed Power Supply Name>
remoteipaddr <negotiate|IP Address>
```

restartdelay <PPP Restart Delay> reversepinout<enable|disable> sendstring <String to Send|QUOTEDSTRING> sendtermstr <enable|disable> showlines <disable |1-50 lines> slmlogging <enable|disable> slmnms <NMS IP Address> slmthreshold <Threshold> slmtime <Time Frame> sshauth <enable|disable> sshdatadir <netin|netout|both> sshin <enable|disable> sshport <TCP Port> sshtimeout <disable|1-1800 seconds> stopbits <1|2> sysloglogging <enable|disable> tcpauth <enable|disable> tcpdatadir <netin|netout|both> tcpin <enable|disable> tcpport <TCP Port> tcptimeout <disable |1-1800> telnetauth <enable|disable> telnetdatadir <netin|netout|both> telnetin <enable|disable> telnetport <TCP Port> telnetsoftiac <enable|disable> telnettimeout <disable |1-1800 sec> termstr <Termination String> timeoutlogins <disable or 1-30 minutes> toggledtr <enable|disable> tokenaction <List of none,log,trap,email,string,power> tokendatadetect <enable|disable> tokenstring <Regex String> tokentrigger <bytecnt|charstr> usblogging <enable|disable> usbmaxfiles <Max # of Files> usbmaxsize <Size in Bytes> usbport <U1|U2|SD> usbvbus <enable|disable> usesites <enable|disable> viewportlog <enable|disable>

Description

Configures a single port or a group of ports.

Set the modem password and CHAP secrets (any extra parameters will be ignored):

set deviceport port <Device Port # or List or Name> dialoutpassword
set deviceport port <Device Port # or List or Name> chapsecret
set deviceport port <Device Port # or List or Name> dodchapsecret

Reset a device port, terminating and restarting all relevant connections:

set deviceport port <Device Port # or List or Name> reset

Configure up to 4 managed power supplies for device connected to a device port:

set deviceport port <Device Port # or Name> managepower

Reset a device port, terminating and restarting all relevant connections:

set deviceport port <Device Port # or List or Name> reset

Note: A group of device ports can be configured by specifying a comma-separated list of ports (i.e., '1-4,8,10-12') or 'ALL'. Remove breakseq for Device Ports connected to raw binary connections. The logging level for the Device Ports log must be set to 'Info' to view Syslog entries for Device Port logging. It is recommended that the 'initscript' be prepended with 'AT' and include 'E1 V1 x4 Q0' so that the SLC may properly control the modem.

set deviceport global

Syntax

set deviceport global <one or more parameters>

Parameters

sshport <TCP Port>
telnetport <TCP Port>
tcpport <TCP Port>

Description

Configures settings for all or a group of device ports.

show deviceport global

Syntax

show deviceport global

Description

Displays global settings for device ports.

show deviceport names

Syntax

show deviceport names

Description

Displays a list of all device port names.
show deviceport port

Syntax

```
show deviceport port <Device Port List or Name>
    [display <ip|data|modem|logging|device>]
```

Description

Displays the settings for one or more device ports.

show deviceport types

Syntax

show deviceport types

Description

Displays the list of port types (RJ45 or USB) for all device ports.

show portcounters

Syntax

show portcounters [deviceport <Device Port List or Name>] [email <Email
Address>]

Description

Displays device port statistics and errors for one or more ports. You can optionally email the displayed information.

show portcounters zerocounters

Syntax

show portcounters zerocounters <Device Port List or Name>

Description

Zeros the port counters for one or more device ports.

show portstatus

Syntax

show portstatus [deviceport <Device Port List or Name>] [email <Email
Address>]

Displays the modes and states of one or more device port(s). You can optionally email the displayed information.

Diagnostic Commands

diag arp

Syntax

diag arp|arp6 [email <Email Address>]

Description

Displays the Address Resolution Protocol table (for IPv4) or the Neighbor table (for IPv6) for mapping IP Addresses to hardware addresses.

diag internals

Syntax

diag internals [email <Email Address>]

Enable debug printing on the next SLC reboot:

```
diag internals [printapplication <enable|disable>
    printconnection <enable|disable>
    printmanagement <enable|disable>
```

Description

Displays information on the internal memory, storage and processes of the SLC 8000 advanced console manager. You can optionally email the displayed information.

diag lookup

Syntax

diag lookup <Name> [email <Email Address>]

Description

Resolves a host name into an IP address. You can optionally email the displayed information.

diag loopback

Syntax

diag loopback <Device Port Number or Name>[<parameters>]

Parameters

```
test <internal|external>
xferdatasize <Size In Kbytes to Transfer>
Defaults: test=external, xferdatasize=1K
```

Description

Tests a device port by transmitting data out the port and verifying that it is received correctly.

A special loopback cable comes with the SLC 8000 advanced console manager. To test a device port, plug the cable into the device port and run this command. The command sends the specified Kbytes to the device port and reports success or failure. The test is performed at 9600 baud. Only an external test requires a loopback cable. The External test is currently not supported for USB device ports.

diag netstat

Syntax

```
diag netstat [protocol <all|tcp|udp>] [email <Email Address>]
Defaults: protocol=all
```

Description

To display a report of network connections. You can optionally email the displayed information.

diag nettrace

Syntax

diag nettrace <one or more parameters>

Parameters

```
ethport <1|2>
protocol <tcp|udp|icmp|esp>
host <IP Address or Name>
numpackets <Number of Packets>
verbose <low|medium|high|disable>
```

Description

Displays all network traffic, applying optional filters. This command is available in the CLI but not the web.

diag perfstat

Description

Display performance statistics for an Ethernet Port or Device Port, averaged over the last 5 seconds. Must specify an Ethernet Port or Device Port.

Syntax

diag perfstat [ethport <1|2>] [deviceport <Device Port # or Name>]

diag ping|ping6

Description

Verifies if the SLC can reach a host over the network.

diag ping|ping6 <IP Address or Name> [<parameters>]

Parameters

```
count <Number Of Times To Ping>
packetsize <Size In Bytes>
ethport <1|2>
Defaults: count=5, packetsize=64
```

diag sendpacket host

Description

Generate and send Ethernet packets.

Syntax

```
diag sendpacket host <IP Address or Name> port <TCP or UDP Port Number>
    [string <Packet String>] [protocol <tcp|udp>]
    [count <Number of Packets>]
```

diag top

Syntax

diag top [parameters]

Description

Displays CPU usage, memory usage and tasks.

Parameters

```
continuous <enable|disable>
count <Number of Iterations to Display>
delay <Delay in Seconds>
numlines <Number of Lines to Display>
```

Defaults:

count=1, delay = 5 seconds

diag traceroute

Syntax

diag traceroute <IP Address or Hostname>

Description

Displays the route that packets take to get to a network host.

diag usb

Syntax

diag usb [<parameters>]

Description

To display information about USB buses and the devices connected to them, including the mapping between a USB device and the SLC port. For "mapdevice enable", the port numbers will displayed at the end of the line in square brackets.

Parameters

```
treedisplay <enable|disable>
mapdevice <enable|disable>
email <Email Address>
Defaults: treedisplay=enable
```

Events Commands

admin events add

Syntax

admin events add <trigger> <response>

<trigger> is one of:

```
dpdatadrop, humidlimit, pingfails, receivetrap, rpmload, nomodemdialor templimit.
```

<response> is one of:

```
action syslog
```

action emailalert emailaddress <destination email address>

action snmptrap nms <SNMP NMS> community <SNMP Community>

action <fwdalltrapseth | fwdseltrapeth > ethport <1 | 2 > nms <SNMP NMS >

community <SNMP Community> [oid <SNMP OID>]

action <fwdalltrapsmodem | fwdseltrapmodem> deviceport <Device Port # or Name> nms <SNMP NMS> community <SNMP Community> [oid <SNMP Trap

```
OID>]
```

action <fwdalltrapsmodem | fwdseltrapmodem> usbport <U1 | U2>

nms <SNMP NMS> community <SNMP Community> [oid <SNMP Trap OID>]

action <fwdalltrapsmodem | fwdseltrapmodem> internal modem

nms <SNMP NMS> community <SNMP Community> [oid <SNMP Trap OID>]

Description

Defines events.

admin events delete

Syntax

admin events delete <Event ID>

Description

Deletes an event definition.

admin events edit

Syntax

admin events edit <Event ID> <parameters>

Parameters

community <SNMP Community>
deviceport <Device Port # or Name>
ethport <1|2>
nms <SNMP NMS>
host <IP Address or Name>
oid <SNMP Trap OID>
outlet <Outlet #>
rpm <RPM Id or Name>
threshold <Load Percentage|Current in Amps>usbport <u1|u2>
internal modem
emailaddress <destination email address>

Description

Edits event definitions.

admin events show

Syntax

admin events show

Displays event definitions.

Group Commands

set groups add|edit <Group Name> [<parameters>]

Syntax

set groups add|edit <Group Name> [<parameters>]

Parameters

```
dataports <Port List>
listenports <Port List>
clearports <Port List>
escapeseq <1-10 Chars>
breakseq <1-10 Chars>
custommenu <Menu Name>
displaymenu <enable|disable>
allowdialback <enable|disable>
dialbacknumber <Phone Number>
permissions <Permission List>
```

Note: See 'help user permissions' for information on user rights.

Rename a group:

set groups rename <Group Name> newname <New Group Name>

Delete a group:

set groups delete <Group Name>

Show one or more groups:

show groups [name <Group Name>] members <enable|disable>

Host List Commands

set hostlist add|edit <Host List Name>

Syntax

set hostlist add|edit <Host List Name> [<parameters>]

Parameters

```
name <Host List Name> (edit only)
retrycount <1-10>
```

Default: retrycount=3, auth=enable.

auth <**enable**|disable>

Description

Configures a prioritized list of hosts to be used for modem dial-in connections.

set hostlist add|edit <Host List Name> entry

Syntax

```
set hostlist add|edit <Host List Name> entry <Host Number>
[<parameters>]
```

Parameters

host <IP Address or Name>
protocol <ssh|telnet|tcp>
port <TCP Port>
escapeseq <1-10 Chars>

Description

Adds a new host entry to a list or edit an existing entry.

set hostlist edit <Host List Name> move

Syntax

```
set hostlist edit <Host List Name> move <Host Number> position <Host
Number>
```

Description

Moves a host entry to a new position in the host list.

set hostlist delete

Syntax

set hostlist delete <Host List> [entry <Host Number>]

Description

Deletes a host list, or a single host entry from a host list.

show hostlist

Syntax

```
show hostlist <all|names|Host List Name>
```

Displays the members of a host list.

Internal Modem Commands

Configure the internal modem:

set intmodem <parameters>

Parameters

auth <pap|chap> calleridcmd <Modem Command String> calleridlogging <enable|disable> modemstate <disable|dialin|dialout|dialback> usesites <enable|disable> modemmode <text|ppp> group <Local or Remote Group Name> timeoutlogins <disable | 1-30 minutes> modemtimeout <disable|1-9999 sec> localipaddr <negotiate|IP Address> restartdelay <PPP Restart Delay> remoteipaddr <negotiate | IP Address> chaphost <CHAP Host or User Name> initscript <Modem Init Script> nat <enable|disable> chapauth <chaphost|localusers> checkdialtone <disable|5-600 min> dialbacknumber <usernumber|Phone Number> dialoutnumber < Phone Number> dialbackdelay <PPP Dialback Delay> dialoutlogin <Remote User Login> dialbackretries <1-10>

Set the modem password and CHAP secret (any extra parameters will be ignored):

set intmodem dialoutpassword set intmodem chapsecret

Note: It is recommended that the initscript be prepended with 'AT' and include 'E1 V1 x4 Q0' so that the SLC may properly control the modem.

Display settings for the internal modem:

show intmodem

IP Filter Commands

set ipfilter state

Syntax

set ipfilter state <enable|disable> [testtimer <disable|1-120 minutes>]

Description

Enables or disables IP filtering for incoming network traffic.

set ipfilter mapping

Syntax

set ipfilter mapping <parameters>

Parameters

ethernet <1|2|bond0> state <disable> ethernet <1|2|bond0> state <enable> ruleset <Ruleset Name> deviceport <1..48> state <disable> deviceport <1..48> state <enable> ruleset <Ruleset Name> usbport <U1|U2> state <disable> usbport <U1|U2> state <enable> ruleset <Ruleset Name> internal modem state <disable> internal modem state <enable> ruleset <Ruleset Name>

Description

Maps an IP filter to an interface.

set ip filter rules

Syntax

set ipfilter rules <parameters>

Parameters

add <Ruleset Name> delete <Ruleset Name> edit <Ruleset Name> <Edit Parameters>

Edit Parameters

append insert <Rule Number> replace <Rule Number> delete <Rule Number>

Sets IP filter rules.

Logging Commands

set deviceport port

Syntax

set deviceport port <Device Port List or Name> <one or more deviceport
parameters>

Parameters

```
actiondelay <Action Delay>
actionrestart <Restart Delay>
bytethreshold <# of Characters>
emailsubj <Email Subject>
emailto <Email Address>
locallogging <enable|disable>
nfsdir <Logging Directory>
nfslogging <enable|disable>
nfsmaxfiles <Max # of Files>
nfsmaxsize <Size in Bytes>
poweraction <on|off|cycle>
powersupply <Managed Power Supply Name>
sendstring <String to Send|QUOTEDSTRING>
tokenaction <List of none,log,trap,email,string,power>
tokendatadetect <enable|disable>
tokenstring <Regex String>
tokentrigger <bytecnt|charstr>
usblogging <enable | disable >
usbmaxfiles <Max # of Files>
usbmaxsize <Size in Bytes>
usbport <u1|u2|sd>
sysloglogging <enable | disable>
```

Description

Configures logging settings for one or more device ports.

Local logging must be enabled for a device port for the locallog commands to be executed. To use the set locallog clear command, the user must have permission to clear port buffers (see *Chapter 12: User Authentication*.)

Example

```
set deviceport port 2-5,6,12,15-16 locallogging enable
```

show locallog

Syntax

```
show locallog <Device Port # or Name> [bytes <Bytes To Display>]
   [startbyte <Byte Index>]
```

Description

Displays a specific number of bytes of data for a device port. 1K is the default.

set locallog clear

Syntax

set locallog clear <Device Port # or Name>

Description

Clears the local log for a device port.

The locallog commands can only be executed for a device port if local logging is enabled for the port. The set locallog clear command can only be executed if the user has permission to clear port buffers (see *Chapter 12: User Authentication*).

set log clear modem

Syntax

set log clear modem

Description

Clear the modem log (the modem log is automatically pruned when it reaches 50K):

set log modem ppplog

Syntax

set log modem ppplog <enable|disable>

Description

Enables PPP activity messages in the modem log.

set log modem ppplog <enable|disable>

Syntax

set log modem pppdebug

Enables PPP debugging messages in the modem log:

set log modem pppdebug <enable|disable>

Syntax

show log modem

Description

View the modem activity log for external modems and USB modems:

```
show log modem [display <head|tail>][numlines <Number of Lines>]
```

show log local

Syntax

show log local

Description

View the log for local, NFS, or USB logging (NFS and USB use the current logging settings for the Device Port). Default is to show the log tail:

show log local|nfs|usb|sdcard <Device Port # or Name> [<parameters>]

Parameters

display <head|tail>
numlines <Number of Lines>
bytes <Bytes to Display>
startbyte <Byte Index>
logfile <NFS, USB or SD card Log File>
Defaults: bytes=1000, startbyte=1, numlines=40

Lists the NFS, USB, or SD card log files, either for a specific device port, or all log files in a USB, NFS, or SD card location:

show log files nfs|usb|sdcard [localdir <NFS Mount Local Directory>]
[usbport <U1|U2>]
[deviceport <Device Port # or name>]

Network Commands

set network

Syntax

set network <parameters>

Parameters

```
interval <1-99999 Seconds>
ipforwarding <enable|disable>
probes <Number of Probes>
startprobes <1-99999 Seconds>
```

Description

Sets TCP Keepalive and IP Forwarding network parameters.

set network bonding

Syntax

set network bonding <disabled|active-backup|802.3ad|load-balancing>

Description

Configure Ethernet Bonding.

set network dns

Syntax

set network dns <1|2|3> ipaddr <IP Address>

Description

Configures up to three DNS servers.

set network dnsipv4prec

Syntax

set network dnsipv4prec <enable|disable>

Description

Configures IPv4/IPv6 lookup precedence.

set network gateway

Syntax

set network gateway <parameters>

Parameters

default <IP Address>
ipv6default <IPv6 Address>
precedence <dhcp|default>
failover <IP Address>

pingip <IP Address>
ethport <1|2>
pingdelay <1-250 seconds>
failedpings <1-250>
faildevice <none|hspa>
faildevapn <Fail-over Device: APN of Mobile Carrier>
faildevlockpin <enable|disable>
faildevlogin <Fail-over Device: Admin Login>

Set the fail-over device PIN # for SIM Card, SIM Personal Unblocking Key or Admin Password (any extra parameters will be ignored):

set network gateway faildevpin set network gateway faildevpuk set network gateway faildevpassword

Description

Set default & fail-over gateways (the fail-over gateway is used if an IP address usually accessible through the default gateway fails to return 1 or more pings), and configure settings for supported fail-over devices.

set network host

Syntax

set network host <Hostname> [domain <Domain Name>]

Description

Sets the SLC host name and domain name.

set network port

Syntax

set network port <1|2> <parameters>

Parameters

Description

Displays DNS settings.

show network dns

Syntax

show network dns

Description

Displays DNS settings.

show network gateway

Syntax

show network gateway

Description

Displays gateway settings.

show network host

Syntax

show network host

Description

Displays the network host name of the SLC 8000 advanced console manager.

show network port

Syntax

```
show network port <1 2>
```

Description

Displays Ethernet port settings and counters.

show network ipv6

Syntax

show network ipv6

Description

Displays all ipv6 settings. show network sfp

Syntax

show network sfp

Description

Displays network port 1 and port 2 SFP diagnostics.

show network all

Syntax

show network all

Description

Displays all network settings.

NFS and SMB/CIFS Commands

set nfs mount

Syntax

set nfs mount <one or more parameters>

Parameters

```
locdir <Directory>
mount <enable|disable>
remdir <Remote NFS Directory>
rw <enable|disable>
Enables or disables read/write access to remote directory.
```

Description

Mounts a remote NFS share.

The remdir and locdir parameters are required, but if they have been specified previously, you do not need to provide them again.

set nfs unmount

Syntax

set nfs unmount <1|2|3>

Description

Unmounts a remote NFS share.

set cifs

Syntax

set cifs <one or more parameters>

Parameters

```
eth1 <enable|disable>
eth2 <enable|disable>
state <enable|disable>
workgroup <Windows workgroup>
```

Description

Configures the SMB/CIFS share, which contains the system and device port logs.

The admin config command saves SLC configurations on the SMB/CIFS share.

set cifs password

Syntax

set cifs password

Description

Changes the password for the SMB/CIFS share login (default is cifsuser).

show cifs

Syntax

show cifs

Description

Displays SMB/CIFS settings.

show nfs

Syntax

show nfs

Description

Displays NFS share settings.

Performance Monitoring Commands

show perfmon

Syntax

show perfmon

Parameters

show perfmon [probe <all|Probe Id or Name>]

Description

Display global settings and all probes, or a selected probe.

show perfmon status

Syntax

show perfmon status

Parameters

show perfmon status [probe <Probe Id or Name>]

Description

Display the running status of all probes or a selected probe.

show perfmon operations

Syntax

show perfmon operations

Parameters

show perfmon operations <Probe Id or Name>

Description

Display list of completed operation sets for a probe.

set perfmon results

Syntax

set perfmon results

Parameters

show perfmon results <Probe Id or Name> [set <Operation Set Number>]

```
[display <head|tail>] [numlines <Number of Lines>]
[email <Email Address>]
```

Display round trip times (RTT) for last completed operation set or selected set, and optionally email the complete results.

show perfmon accumulated

Syntax

```
show perfmon accumulated
```

Parameters

show perfmon accumulated <Probe Id or Name> [set <Operation Set Number>]
 [email <Email Address>]

Description

Display accumulated statistics for last completed operation set or selected set, and optionally email the statistics.

set perfmon repo

Syntax

```
set perfmon repo <local|usb|sdcard> [usbport <U1|U2>]
```

Description

Set repository where probe operations are stored.

set perfmon keep

Syntax

set perfmon keep <Number of Operations to Keep>

Description

Set number of operations stored for each probe.

set perfmon udpjitterresp

Syntax

set perfmon udpjitterresp <enable|disable>

Description

Enable responders for UDP jitter.

set perfmon udpechoresp

Syntax

set perfmon udpechoresp <UDP Port Number | disable>

Description

Enable responders for UDP echo.

set perfmon tcpconnectresp

Syntax

set perfmon tcpconnectresp <TCP Port Number | disable>

Description

Enable responders for TCP connect.

set perfmon add

Syntax

set perfmon add <Probe Name>
type <dns|http|icmp|tcpconnect|udpecho|udpjitter|udpjittervoip>

Parameters

```
name <Probe Name>
            starttime <now|HH:MM[:SS][MMDD]|afterHH:MM:SS>
            operations <Number of Operations to Perform>
            frequency <Seconds between Operations>
            packets <Number of Packets to Send>
            interval <Milliseconds between Packets>
            timeout <Milliseconds to Wait for Response>
            host <Destination IP Address or Name>
            port <Destination Port>
            precision <milli|micro>
            datasize <Payload Data Size in Bytes>
            verifydata <enable|disable>
            codec <g729a|g711alaw|g711mulaw>
            tos <none|Type of Service>
            interface <none|eth1|eth2>
            nameserver <IPv4 Address>
```

Description

Add a new probe.

set perfmon edit

Syntax

set perfmon edit <Probe Id or Name> [<parameters>]

Parameters

```
name <Probe Name>
            starttime <now|HH:MM[:SS][MMDD]|afterHH:MM:SS>
            operations <Number of Operations to Perform>
            frequency <Seconds between Operations>
            packets <Number of Packets to Send>
            interval <Milliseconds between Packets>
            timeout <Milliseconds to Wait for Response>
            host <Destination IP Address or Name>
            port <Destination Port>
            precision <milli|micro>
            datasize <Payload Data Size in Bytes>
            verifydata <enable|disable>
            codec <g729a|g711alaw|g711mulaw>
            tos <none|Type of Service>
            interface <none|eth1|eth2>
            nameserver <IPv4 Address>
```

Description

Edit an existing probe.

set perfmon delete

Syntax

set perfmon delete <Probe Id or Name> [data <all|# of Sets to Keep>]

Description

Delete a probe, or delete all operation data for a probe, or delete all but the most recent operation sets for a probe.

set perfmon state

Syntax

set perfmon state <all | Probe Id or Name> action <restart>

Description

Set the running state of all probes or a single a probe.

Routing Commands

set routing

Syntax

set routing [parameters]

Parameters

```
rip <enable|disable>
route <1-64> ipaddr <IP Address> mask <Netmask> gateway <IP Address>
static <enable|disable>
version <1|2|both>
```

Description

Configures static or dynamic routing.

To delete a static route, set the IP address, mask, and gateway parameters to **0.0.0.0**.

show routing

Syntax

show routing [resolveip <enable|disable>] [email <Email Address>]

Description

Sets the routing table to display IP addresses (disable) or the corresponding host names (enable). You can optionally email the displayed information.

RPM Commands

set rpm add

Syntax

set rpm add <RPM Name>

Description

Adds an RPM to be managed (prompts will guide selection of RPM vendor and model).

set RPM command

Syntax

```
set rpm command <RPM Id or Name>
    outlet <all|Outlet # or List> state <on|off|cyclepower>
```

Sends a command to control one or more outlets on an RPM.

Syntax

set rpm command <RPM Id or Name> device <reboot|shutdown>

Description

Sends a command to control an RPM device.

Syntax

set rpm command <RPM Id or Name> beeper <mute|enable|disable>

Description

Sends a command to control an RPM beeper.

set rpm delete

Syntax

set rpm delete <RPM Id or Name>

Description

Deletes an RPM.

set rpm driver

Syntax

Description

Control and debug the RPM driver if the driver is not properly communicating with the PDU or UPS: restart the driver; restart the driver with debug output to a file; show the running driver; view and email the driver debug output.

Note: Drivers running in debug mode will generate copious output and for disk space reasons should not be left running in debug mode for long periods of time.

set rpm edit

Syntax

set rpm edit <RPM Id or Name> <one or more parameters>

Parameters

```
name <New RPM Name>
outlets <# of Outlets>
ipaddr <IP Address>
port <TCP or Device Port>
login <RPM Admin Login>
rocommunity <SNMP Read-Only Community>
rwcommunity <SNMP Read-Write Community>
logstatus <disable|1-60 minutes>
snmptraps <enable|disable>
emailaddress <Email Address>
upslowbattery <shutdown|shutdownall|shutdownboth|allowfailure>
sdorder <disable|1-49>
powertoslc <enable|disable>
driveropts <Driver Options Override>
```

Description

Configure and control Remote Power Managers (RPMs), including PDUs and UPSes.

set rpm password

Syntax

set rpm password <RPM Id or Name>

Description

Set RPM administrative password.

show RPM

Syntax

```
show rpm [type <ups|pdu>]
    [config <sdorder|notify>]
    [device <RPM Name or Id> [data <raw|logs|envmon>]]
```

Note: The show rpm envmon command for RPM-configured ServerTech Serial/Network Mode is not supported by NUT/Powerman.

Description

Display a list of all RPMs, RPMs of a specific type, UPS shutdown and notification configuration, or details and outlets for a single RPM device.

SD Card Commands

Enables or disables access to SD Card devices:

set sdcard access <enable|disable>

Mounts a SD Card for use as a storage device. The SD Card can be used for saving configurations, firmware updates and device logging.

set sdcard mount

Unmounts a SD Card:

set sdcard unmount

Formats a SD Card:

set sdcard format [filesystem <ext2|fat16|fat32>]

Defaults: filesystem=ext2

Runs a filesystem check on a SD Card (recommended if it does not mount):

set sdcard fsck

Displays a directory listing of a SD Card:

set sdcard dir

Renames a file on a SD Card:

set sdcard rename <Filename> newfile <New Filename>

Copies a file on a SD Card:

set sdcard copy <Filename> newfile <New Filename>

Removes a file on a SD Card:

set sdcard delete <Current Filename>

Displays information about the SD Card device:

show sdcard

Security Commands

set security

Description

Configures SLC security and FIPS settings.

Parameters

set security <parameters>

fipsmode

Parameters

fipsmode <enable|disable>

show security

Description

Displays security settings and current status.

Parameters

show security

Services Commands

set services

Syntax

set services <one or more services parameters>

Parameters

```
netlog <off|error|warning|info|debug>
authlog <off|error|warning|info|debug>
diaglog <off|error|warning|info|debug>
servlog <off|error|warning|info|debug>
genlog <off|error|warning|info|debug>
syslogserver1 <IP Address or Name>
syslogserver2 <IP Address or Name>
rpmlogsize <5-40 Kbytes>
otherlogsize <5-400 Kbytes>
telnet <enable|disable>
timeouttelnet <disable|1-30 minutes>
telnetdatadir <netin|netout|both>
webtelnet <enable|disable>
escapeseqtelnet <1-10 Chars>
```

outgoingtelnet <enable|disable>

```
ssh <enable|disable>
portssh <TCP Port>
vlssh <enable|disable>
timeoutssh <disable|1-30 minutes>
sshdatadir <netin|netout|both>
```

dsakeys <enable|disable>

auditlog <enable|disable> auditsize <1-500 Kbytes> clicommands <enable|disable> includesyslog <enable|disable> snmp <enable|disable> v1 <enable|disable> v2c <enable|disable> traps <enable|disable> trapversion <1|2|3> nms1 <IP Address or Name> nms2 <IP Address or Name>; alarmdelay <1-6000 Seconds> location <Physical Location> contact <Admin Contact Info> rocommunity <Read-Only Community> rwcommunity <Read-Write Community> trapcommunity < Trap Community> v3user <v3 RO User> v3rwuser <v3 RW User> v3trapuser <v3 Trap User> v3security <noauth|auth|authencrypt> v3auth <md5|sha>

```
sha2 <enable|disable>
webssh <enable|disable>
smtpserver <IP Address or Name>
smtpsender <Email Address>
```

v3encrypt <des|aes>
phonehome <enable|disable>
phoneip <IP Address>
termbufsize <Number of Lines>

Description

Configures services (system logging, SSH and Telnet access, SSH and Telnet timeout, SNMP agent, email [SMTP] server, and audit log.)

set services v3password

Description

Set SNMP v3 read-only, read-write and trap password/passphrase.

Syntax

```
set services v3password|v3phrase|v3rwpassword|v3rwphrase|v3trappassword
|v3trapphrase
```

show services

Syntax

show services

Description

Displays current service settings.

Site Commands

Configure a set of site-oriented modem parameters that can be activated by various modemrelated events (authentication, outbound network traffic for DOD connections, etc.). The site parameters will override any parameters configured for the modem. To use sites with a modem, enable 'usesites'. Sites can be used with the following modem states: dialin, dialback, cbcpserver, dialondemand, dialin+ondemand, and dialback+ondemand.

Create or edit a site:

set site add|edit <Site Name> [<parameters>]

Parameters

localipaddr <negotiate|IP Address> dialbackretries <1-10>
remoteipaddr <negotiate|IP Address> timeoutlogins <disable|1-30
minutes>
routeipaddr <IP Address> modemtimeout <disable|1-9999
secs>
routemask <Mask> restartdelay <PPP Restart
Delay>
routegateway <Gateway> cbcpnocallback
<enable|disable>

```
nat <enable|disable>
```

Set the site password and CHAP secret (any extra parameters will be ignored):

set site dialoutpassword <Site Name>
set site chapsecret <Site Name>

Deletes a site:

set site delete <Site Name>
show site <all|names|Site Name>

SLC Network Commands

set slcnetwork

Syntax

set slcnetwork <one or more parameters>

Parameters

add <IP Address>
delete <IP Address>
search <localsubnet|ipaddrlist|both>

Description

Detects and displays all SLC 8000 advanced console manager or user-defined IP addresses on the local network.

show slcnetwork

Syntax

show slcnetwork [ipaddrlist <all|Address Mask>]

Description

Detects and displays all SLC 8000 advanced console managers on the local network.

Without the ipaddrlist parameter, the command searches the SLC network. With the ipaddrlist parameter, the command displays a sorted list of all IP addresses or displays the IP addresses that match the mask (for example, 172.19.255.255 would display all IP addresses that start with 172.19).

SSH Key Commands

set sshkey all export

Syntax

```
set sshkey allexport <ftp|sftp|scp|copypaste> [pubfile <Public Key
File>][host <IP Address or Name>] [login <User Login>][path <Path to Copy
Keys>]
```

Description

Exports the public keys all of the previously created SSH keys.

set sshkey delete

Syntax

set sshkey delete <one or more parameters>

Parameters

keyhost <SSH Key Host> keyname <SSH Key Name> keyuser <SSH Key User>

Description

Deletes an ssh key.

Specify the keyuser and keyhost to delete an imported key; specify the keyuser and keyname to delete exported key.

set sshkey export

Syntax

set sshkey export <ftp|sftp|scp|copypaste> <one or more parameters>

Parameters

```
[format <openssh|secsh>]
[host <IP Address or Name>]
[login <User Login>]
[path <Path to Copy Key>]
[bits <1024|2048|3072|4096>]
keyname <SSH Key Name>
keyuser <SSH Key User>
type <rsa|dsa>
```

Description

Exports an sshkey.

set sshkey import

Syntax

set sshkey import

Description

set sshkey import <ftp|sftp|scp|copypaste> <one or more parameters>

Parameters

[keyhost <SSH Key IP Address or Name>]
[keyuser <SSH Key User>]
[path <Path to Public Key File>]
file <Public Key File>
host <IP Address or Name>
login <User Login>

Description

Imports an SSH key.

set sshkey server import type

Syntax

set sshkey server import type <rsal|rsa|dsa> via <sftp|scp>
pubfile <Public Key File> privfile <Private Key File>
host <IP Address or Name> login <User Login> [path <Path to Key File>]

Description

Imports an SLC host key.

set sshkey server reset

Syntax

set sshkey server reset [type <all|rsa1|rsa|dsa>]

Description

Resets defaults for all or selected host keys.

show sshkey export

Syntax

show sshkey export <one or more parameters>

Parameters

```
[keyhost <SSH Key IP Address or Name>]
[keyname <SSH Key Name>]
[keyuser <SSH Key User>]
[viewkey <enable|disable>]
```

Description

Displays all exported keys or keys for a specific user, IP address, or name.

show sshkey import

Syntax

show sshkey import <one or more parameters>]

Parameters

```
[keyhost <SSH Key IP Address or Name>]
[keyuser <SSH Key User>]
[viewkey <enable|disable>]
```

Description

Displays all keys that have been imported or keys for a specific user, IP address, or name.

show sshkey server

Syntax

show sshkey server [type <all|rsa1|rsa|dsa>]

Description

Displays host keys (public key only).

Status Commands

show connections

Syntax

show connections [email <Email Address>]

Description

Displays a list of current connections. Optionally emails the displayed information. The connection IDs are in the left column of the resulting table. The connection ID associated with a particular connection may change if the connection times out and is restarted.

show connections connid

Syntax

show connections connid <Connection ID> [email <Email Address>]

Description

Provides details, for example, endpoint parameters and trigger, for a specific connection. Optionally emails the displayed information.

Note: Use the basic show connections command to obtain the Connection ID.

show portcounters

Syntax

```
show portcounters [deviceport <Device Port List or Name>]
    [email <Email Address>]
```

Description

Generates a device port statistics report for one or more ports. Optionally emails the displayed information.

show portstatus

Syntax

```
show portstatus [deviceport <Device Port List or Name>] [email <Email
Address>]
```

Description

Displays device port modes and states for one or more ports. Optionally emails the displayed information.

show sysconfig

Syntax

```
show sysconfig [display <basic|auth|devices>] [email <Email Address>]
```

Description

Displays a snapshot of all configurable parameters. Optionally emails the displayed information.

show sysstatus

Syntax

```
show sysstatus [email <Email Address>]
```

To display the overall status of all SLC units. Optionally emails the displayed information.

System Log Commands

show syslog

Syntax

show syslog [<parameters>]

Parameters

```
[email <Email Address>]
level <error|warning|info|debug>
log <all|netlog|servlog|authlog|devlog|diaglog|genlog>
display <head|tail> [numlines <Number of Lines>]
starttime <MMDDYYhhmm[ss]>
endtime <MMDDYYhhmm[ss]>
```

Description

Displays the system logs containing information and error messages.

Note: The level, display, and time parameters cannot be used simultaneously.

show syslog clear

Syntax

show syslog clear <all|netlog|servlog|authlog|devlog|diaglog|genlog>

Description

Clears one or all of the system logs.

USB Access Commands

set usb access

Syntax

set usb access <enable|disable>

Description

Enables or disables access to USB devices.

USB Device Commands

show usb devices

Syntax

show usb devices

Description

Displays all usb devices with the port each device is connected to.

diag usb

Syntax

diag usb [<parameters>]

Parameters

treedisplay <enable|disable>
mapdevice <enable|disable>
email <Email Address>

Defaults: treedisplay=enable

Description

Displays information about USB buses and the devices connected to them, including the mapping between a USB device and the SLC port.

Note: For "mapdevice enable", the port names will displayed at the end of the line in square brackets. To see a list of USB devices with vendor id and product id, use 'treedisplay disable'.

USB Storage Commands

set usb storage dir

Syntax

set usb storage dir <U1|U2>

Description

Views a directory listing of a USB flash drive.

set usb storage fsck

Syntax

set usb storage fsck <U1|U2>

Description

Runs a file system check on a thumb drive (recommended if it does not mount).

set usb storage format

Syntax

set usb storage format <U1|U2> [filesystem <ext2|fat16|fat32>]

Description

Formats a USB flash drive.

set usb storage mount

Syntax

set usb storage mount <U1|U2>

Description

Mounts a USB flash drive in the SLC 8000 advanced console manager for use as a storage device.

The USB flash drive must be formatted with an ext2 or FAT file system before you mount it.

set usb storage unmount

Syntax

set usb storage unmount <U1|U2>

Description

Unmounts a USB flash drive. Enter this command before removing the USB device.

set usb storage rename

Description

Renames a file on a thumb drive.

Syntax

set usb storage rename <U1|U2> file <Filename> newfile <New Filename>
set usb storage copy

Description

Copies a file on a thumb drive.

Syntax

set usb storage copy <U1|U2> file <Filename> newfile <New Filename>

set usb storage delete

Description

Removes a file on a thumb drive.

Syntax

set usb storage delete <U1|U2> file <Current Filename>

show usb storage

Description

Display product information and settings for any USB thumb drive.

Syntax

show usb storage

show usb

Description

Display currently attached USB devices with product information and settings.

Syntax

show usb modem

Description

Display product information and settings for any USB modem:

Syntax

show usb modem

USB Modem Commands

set usb modem

Syntax

set usb modem <u1|u2> <parameters>

Parameters

auth <**pap**|chap> baud <300-115200>

9600 is the default.

```
calleridcmd <Modem Command String>
calleridlogging <enable|disable>
cbcpnocallback <enable|disable>
cbcptype <admin|user>
chapauth <chaphost|localusers>
chaphost <CHAP Host or User Name>
checkdialtone <disable | 5-600 minutes>
databits <7|8>
dialbackdelay <PPP Dialback Delay>
dialbacknumber <usernumber|Phone Number>
dialbackretries <1-10>
dialinlist <Host List for Dial-in>
dialoutlogin <Remote User Login>
dialoutnumber < Phone Number>
dodauth <pap|chap>
dodchaphost <CHAP Host or User Name>
flowcontrol <none|xon/xoff|rts/cts>
group <Local or Remote Group Name>
initscript <Modem Init Script>
localipaddr <negotiate|IP Address>
modemmode <text|ppp>
modemstate
<disable|dialin|dialout|dialback|cbcpserver|cbcpclient|dialondemand|</pre>
      dialin+ondemand|dialback+ondemand|dialinhostlist>
modemtimeout <disable|1-9999 sec>
nat <enable|disable>
parity <none|odd|even>
remoteipaddr <negotiate | IP Address>
restartdelay <PPP Restart Delay>
service <none|telnet|ssh|tcp>
sshauth <enable|disable>
sshport <TCP Port>
stopbits <1|2>
tcpauth <enable|disable>
tcpport <TCP Port>
telnetauth <enable|disable>
telnetport <TCP Port>
timeoutlogins <disable | 1-30 minutes>
usesites <enable|disable>
```

Description

Configures a currently loaded USB Modem.

Note: It is recommended that the initscript be prepended with 'AT' and include 'E1 V1 x4 Q0' so that the SLC may properly control the modem.

Set the dialout password and CHAP secrets:

set usb modem <U1|U2> dialoutpassword
set usb modem <U1|U2> chapsecret
set usb modem <U1|U2> dodchapsecret

show usb modem

Description

Display product information and settings for any USB modem:

Syntax

show usb modem

VPN Commands

set vpn

Syntax

set vpn

Description

Configures setting for an IPsec VPN tunnel.

Parameters

```
set vpn <parameters>
name <VPN Tunnel Name>
ethport <1|2|defaultroute>
auth <rsa|psk>
auth <rsa|psk|x509>
remotehost <Remote Host IP Address or Name>
remoteid <Authentication Name>
remotehop <IP Address>
remotesubnet <one or more subnets in CIDR notation>
localid <Authentication name>
localhop <IP Address>
localsubnet <one or more subnets in CIDR notation>
ikenegotation <main|aggressive>
ikeenc <any|3des|aes>
ikeauth <any|sha1|md5|sha2 256|sha2 512>
```

```
ikedhgroup <any|dh2|dh5|dh14|dh15>
espec <any|3des|aes>
espauth <any|sha1|md5|sha2_256|sha2_512>
espdhgroup <any|dh2|dh5|dh14|dh15>
pfs <enable|disable>
lifetime <SA Lifetime in Seconds>
modeconfig <enable|disable>
xauthclient <enable|disable>
xauthlogin <User Login>
remotepeertype <ietf|cisco>
forceencaps <enable|disable>
deadpeerdelay <disable|1-300 seconds>
deadpeertimeout <5-1200 seconds>
deadpeeraction <restart|hold|clear>
```

Enter RSA public key or Pre-Shared Key of remote host:

```
set vpn key
```

Configure X.509 certificate for remote peer or local peer.

certfile <Certificate File> host <IP Address or Name> login <User Login> [path <Path to Files>]

Delete X.509 certificate for local and/or remote peer.

set vpn certificate delete

Enter XAUTH password:

set vpn xauthpassword

show vpn

Syntax

show vpn

Description

Shows the settings for the IPsec VPN tunnel.

Parameters

Display all VPN settings and current status:

```
show vpn [email <Email Address>]
Display detailed VPN status:
show vpn status [email <Email Address>]
Display VPN logs:
show vpn viewlog [numlines <Number of Lines] [email <Email Address>]
```

Display RSA public key of the SLC:

show vpn rsakey

set temperature

Syntax

set temperature

Description

Sets the acceptable range for the internal temperature sensor (an SNMP trap is sent if the temperature is outside of this range). Temperatures can be entered in either Celsius or Fahrenheit; to indicate a temperature is Fahrenheit, append the degrees with an 'F', i.e., "75F".

Parameter

```
set temperature <one or more parameters>
Parameters: low <Low Temperature in C. or F.>
high <High Temperature in C. or F.>
calibrate <Temperature Calibration in C. or F.|cancel>
```

Note: The calibration offset will be applied one hour after setting the value.

Description

Displays the acceptable range and the current reading from the internal temperature sensor.

show temperature

Syntax

show temperature

Description

Shows the temperature.

Appendix A: Security Considerations

The SLC advanced console manager provides data path security by means of SSH or Web/SSL. Even with the use of SSH/SSL, however, do not assume you have complete security. Securing the data path is only one measure needed to ensure security. This appendix briefly discusses some important security considerations.

Security Practice

Develop and document a Security Practice. The Security Practice should state:

- The dos and don'ts of maintaining security. For example, the power of SSH and SSL is compromised if users leave sessions open or advertise their password.
- The assumptions that users can make about the facility and network infrastructure, for example, how vulnerable the CAT 5 wiring is to tapping.

Factors Affecting Security

External factors affect the security provided by the SLC unit, for example:

- Telnet sends the login exchange as clear text across Ethernet. A person snooping on a subnet may read your password.
- A terminal to the SLC may be secure, but the path from the SLC 8000 advanced console manager to the end device may not be secure.
- With the right tools, a person with physical access to open the SLC unit may be able to read the encryption keys.
- There is no true test for a denial-of-service attack. There is always a legitimate scenario for a request storm. A denial-of-service filter locks out some high-performance automated/scripted requests. The SLC 8000 advanced console manager will attempt to service all requests and will not filter out potential denial-of-service attacks.

Appendix B: Safety Information

Safety Precautions

Please follow the safety precautions described below when installing and operating the SLC advanced console manager.

Caution: EQUIPMENT IS FOR INDOOR USE ONLY!

Fuse Caution Statement

For protection against fire, replace the power-input-module fuse with the same type and rating.

Pour préserver la protection contre l'incendie, remplacez toujours le fusible du module d'alimentation électrique par un modèle du même type et de la même capacité.

Ersetzen Sie die Netzteilsicherung nur durch eine Sicherung desselben Typs und derselben Nennstromstärke um die Gefahr eines Brandes zu vermeiden.

Para proteger la unidad contra el fuego, sustituya el fusible del módulo de entrada de alimentación por otro del mismo tipo y capacidad.

주의 – 전원 입력 모듈 퓨즈를 교환할 때는 화재 예방을 위해 형식과 정격 전압 전류가 동일 한 퓨즈를 사용하십시오 .

Предупреждение : Для защиты от пожара заменяйте предохранитель блока питания на предохранитель такого же типа и с такой же характеристикой.

Cover

- Do not remove the cover of the chassis. There are no user-serviceable parts inside. Opening
 or removing the cover may expose you to dangerous voltage that could cause fire or electric
 shock. The exception is access to the internal modem and RTC battery. For these you don't
 have to remove the chassis cover, but just the battery/modem door.
- Refer all servicing to Lantronix.

Power Plug

- When disconnecting the power cable from the socket, pull on the plug, not the cord.
- Always connect the power cord to a properly wired and grounded power source. Do not use adapter plugs or remove the grounding prong from the cord.
- Only use a power cord with a voltage and current rating greater than the voltage and current rating marked on the SLC unit.
- The SLC 8000 unit must be connected to a branch circuit provided with 15A or 20A, single pole circuit breaker.
- Install the SLC 8000 advanced console manager near an AC outlet that is easily accessible.
- Always connect any equipment used with the product to properly wired and grounded power sources.
- To help protect the product from sudden, transient increases and decreases in electrical power, use a surge suppressor, line conditioner, or uninterruptible power supply (UPS).

• Do not connect or disconnect this product during an electrical storm.

Input Supply

Caution: Disconnect all power supply sources before servicing to avoid electric shock.

 Check nameplate ratings to assure there is no overloading of supply circuits that could affect over current protection and supply wiring.

Grounding

- 1. Maintain reliable grounding of this product.
- 2. Pay particular attention to supply connections when connecting to power strips, rather than directly to the branch circuit.

Rack

If rack mounted SLC 8000 advanced console managers are installed in a closed or multi-unit rack assembly, they may require further evaluation by Certification Agencies. The following items must be considered:

- Do not install the SLC unit in a rack in such a way that a hazardous stability condition results because of uneven loading. A drop or fall could cause injury.
- The ambient temperature (Tma) inside the rack may be greater than the room ambient temperature. Make sure to install the SLC 8000 advanced console manager in an environment with an ambient temperature less than the maximum operating temperature of the SLC unit. See *Technical Specifications (on page 34)*.
- Install the equipment in a rack in such a way that the amount of airflow required for safe operation of the equipment is not compromised.
- Mount the equipment in the rack so that a hazardous condition is not achieved due to uneven mechanical loading.
- Maintain reliable earthing of rack-mounted equipment. Give particular attention to supply connections other than direct connections to the branch circuit (e.g. use of power strips).
- Before operating the SLC 8000 advanced console manager, make sure the SLC unit is secured to the rack.

Port Connections

- Only connect the network port to an Ethernet network that supports 10/100/1000 Base-T.
- Only connect device ports to equipment with serial ports that support EIA-232 (formerly RS-232C).
- Only connect the console port to equipment with serial ports that support EIA-232 (formerly RS-232C).
- Only connect a telephone line to the MODEM port.

Caution: To reduce the risk of fire, use only number 26 AWG or larger (e.g., 24 AWG) UL-listed or CSA-certified telecommunication line cord.

Appendix C: Adapters and Pinouts

The serial device ports of the SLC products match the RJ45 pinouts of the console ports of many popular devices found in a network environment. The SLC advanced console manager uses conventional straight-through Category 5 fully pinned network cables for all connections when used with Lantronix adapters. The cables are available in various lengths.

In most cases, you will need an adapter for your serial devices. Lantronix offers a variety of RJ45to-serial connector adapters for many devices. These adapters convert the RJ45 connection on the SLC unit to a 9-pin or 25-pin serial connector found on other manufacturers' serial devices or re-route the serial signals for connections to other devices that use RJ45 serial connectors.

The console port is wired the same way as the device ports and has the same signal options.

Note: You can view or change the console port settings using the LCDs and keypads on the front panel, the Devices > Console Port page, or the command line interface show console port and set consoleport commands.

The adapters illustrated below are compatible with the Lantronix SLC models.





Use PN 200.2066A adapter with a dumb terminal or with many SUN applications.



Figure C-2 RJ45 Receptacle to DB25F DCE Adapter for the SLC unit (PN 200.2067A)







Figure C-4 RJ45 Receptacle to DB9F DCE Adapter for the SLC unit (PN 200.2070A)

Use PN 200.2070A adapter with a PC's serial port.





Appendix D: Protocol Glossary

BOOTP (Bootstrap Protocol)

Similar to DHCP, but for smaller networks. Automatically assigns the IP address for a specific duration of time.

CHAP (Challenge Handshake Authentication Protocol)

A secure protocol for connecting to a system; it is more secure than the PAP.

DHCP (Dynamic Host Configuration Protocol)

Internet protocol for automating the configuration of computers that use TCP/IP.

DNS (Domain Name Servers)

A system that allows a network nameserver to translate text host names into numeric IP addresses.

IPsec

A protocol suite for securing Internet Protocol (IP) communications by authenticating and encrypting each IP packet of a communication session.

Kerberos

A network authentication protocol that provides strong authentication for client/server applications by using secret-key cryptography.

LDAP (Lightweight Directory Access Protocol)

A protocol for accessing directory information.

NAT (Network Address Translation)

An Internet standard that enables a LAN to use one set of IP addresses for internal traffic and a second set of addresses for external traffic. This enables a company to shield internal addresses from the public Internet.

NFS (Network File System)

A protocol that allows file sharing across a network. Users can view, store, and update files on a remote computer. You can use NFS to mount all or a portion of a file system. Users can access the portion mounted with the same privileges as the user's access to each file.

NIS (Network Information System)

System developed by Sun Microsystems for distributing system data such as user and host names among computers on a network.

NMS (Network Management System)

NMS acts as a central server, requesting and receiving SNMP-type information from any computer using SNMP.

NTP (Network Time Protocol)

A protocol used to synchronize time on networked computers and equipment.

PAP (Password Authentication Protocol)

A method of user authentication in which the username and password are transmitted over a network and compared to a table of name-password pairs.

PPP (Point-to-Point Protocol)

A protocol for creating and running IP and other network protocols over a serial link.

RADIUS (Remote Authentication Dial-In User Service)

An authentication and accounting protocol. Enables remote access servers to communicate with a central server to authenticate dial-in users and their access permissions. A company stores user profiles in a central database that all remote servers can share.

SMB/CIFS

(Server Message Block/Common Internet File System): Microsoft's protocol for allowing all applications as well as Web browsers to share files across the Internet. CIFS runs on TCP/IP and uses the SMB protocol in Microsoft Windows for accessing files. With CIFS, users with different platforms and computers can share files without having to install new software.

SNMP (Simple Network Management Protocol)

A protocol that system administrators use to monitor networks and connected devices and to respond to queries from other network hosts.

SMTP (Simple Mail Transfer Protocol)

TCP/IP protocol for sending email between servers.

SSL (Secure Sockets Layer)

A protocol that provides authentication and encryption services between a web server and a web browser.

SSH (Secure Shell)

A secure transport protocol based on public-key cryptography.

TACACS+ (Terminal Access Controller Access Control System)

A method of authentication used in UNIX networks. It allows a remote access server to communicate with an authentication server to determine whether the user has access to the network.

Telnet

A terminal protocol that provides an easy-to-use method of creating terminal connections to a network host.

Appendix E: Compliance Information

Manufacturer's Name & Address

Lantronix Inc., 7535 Irvine Center Drive, Suite100, Irvine, CA 92618 USA

Declares that the following product:

Product Name(s): SLC™ 8000 Advanced Console Manager

Conforms to the following standards or other normative documents:

Safety

- IEC 60950-1:2005 (2nd Edition); Am 1:2009 + A2:2013
- EN 60950-1:2006 + A11:2009 + A1:2010 + + A12:2011 + A2:2013
- UL 60950-1, 2nd Edition, 2014-10-14 (Information Technology Equipment Safety Part 1: General Requirements)
- CAN/CSA C22.2 No. 60950-1-07, 2nd Edition, 2014-10 (Information Technology Equipment -Safety - Part 1: General Requirements)
- GB4943.1: 2011 China Product Safety Compliance for ITE

Electromagnetic Emissions

- FCC Part 15, Subpart B, Class A EN 55022: 2011 (IEC/CISPR 22: 2009), class A
- EN 55032: 2012 + AC: 2013 (IEC/CISPR 32: 2015), class A
- KN 22: 2008 and KN 32: 2015 Korea Radio Disturbance Characteristics Compliance for ITE
- GB9254: 2008 China Radio Disturbance Characteristics Compliance for ITE

Electromagnetic Immunity

- EN 55024: 2010 Information Technology Equipment-Immunity Characteristics
- EN 61000-4-2: 2008, KN 61000-4-2 Electro-Static Discharge Test
- EN 61000-4-3: 2010, KN 61000-4-3 Radiated Immunity Field Test
- EN 61000-4-4: 2012, KN 61000-4-4 Electrical Fast Transient Test
- EN 61000-4-5: 2014, KN 61000-4-5 Power Supply Surge Test
- EN 61000-4-6: 2013, KN 61000-4-6 Conducted Immunity Test
- EN 61000-4-8: 2009, KN 61000-4-8 Magnetic Field Test
- EN 61000-4-11: 2004, KN 61000-4-11 Voltage Dips & Interrupts
- KN 24:2008 and KN 35: 2015 Korea Immunity Characteristics Compliance for ITE

Supplementary Information

This Class A digital apparatus complies with Canadian ICES-003 (CSA) and has been verified as being compliant within the Class A limits of the FCC Radio Frequency Device Rules (FCC Title 47, Part 15, Subpart B CLASS A), measured to CISPR 22: 2008 limits and methods of measurement of Radio Disturbance Characteristics of Information Technology Equipment. The product complies with the requirements of the Low Voltage Directive 72/23/EEC and the EMC Directive 89/336/ EEC.

Additional Agency Approvals and Certifications

- VCCI
- UL/CUL
- RCM
- CB Scheme
- NIST-certified implementation of AES as specified by FIPS 197
- CCC*
- KC*

Note: *Not available in some hardware configurations.

This product carries the CE mark since it has been tested and found compliant with the following standards:

- Safety: EN 60950-1
- Emissions: EN 55022, EN 55032 Class A
- Immunity: EN 55024

RoHS, REACH and WEEE Compliance Statement

Please visit <u>http://www.lantronix.com/legal/rohs/</u> for Lantronix's statement about RoHS, REACH and WEEE compliance.